



## Introduction

This document describes the ARM®-based 32-bit MCU STM32F101xx and STM32F103xx firmware library.

This library is a firmware package which contains a collection of routines, data structures and macros covering the features of all peripherals. It includes a description of the device drivers plus a set of examples for each peripheral. The firmware library allows any device to be used in the user application without the need for in-depth study of each peripheral specifications. As a result, using the firmware library saves significant time that would otherwise be spent in coding, while reducing the application development and integration cost.

Each device driver consists of a set of functions covering all peripheral functionalities. The development of each driver is driven by a common API (application programming interface) which standardizes the driver structure, the functions and the names of parameters.

The driver source code is developed in 'Strict ANSI-C' (relaxed ANSI-C for projects and examples files). It is fully documented and is MISRA-C 2004 compliant (the compliancy matrix is available upon request). Writing the whole library in 'Strict ANSI-C' makes it independent from the software toolchain. Only the start-up files depend on the toolchain.

The firmware library implements run-time failure detection by checking the input values for all library functions. This dynamic checking contributes to enhance the robustness of the software. Run-time detection is suitable for user application development and debugging. It adds an overhead and can be removed from the final application code to minimize code size and execution speed. For more details refer to [Section 2.5: Run-time checking on page 48](#).

Since the firmware library is generic and covers all peripherals functionalities, the size and/or execution speed of the application code may not be optimized. For many applications, the library may be used as is. However, for applications having tough constraints in terms of code size and/or execution speed, the library drivers should be used as a reference on how to configure the peripheral and tailor them to specific application requirements.

The firmware library user manual is structured as follows:

- Definitions, document conventions and firmware library rules
- Overview of the firmware library (package content, library structure), installation guidelines, and example on how to use the library.
- Detailed description the firmware library: configuration structure and software functions for each peripheral.

STM32F101xx and STM32F103xx will be referred to as STM32F10xxx throughout the document.

# Contents

<b>1</b>	<b>Document and library rules</b>	<b>36</b>
1.1	Acronyms	36
1.2	Naming conventions	37
1.3	Coding rules	38
1.3.1	Variables	38
1.3.2	Boolean type	38
1.3.3	FlagStatus type	39
1.3.4	FunctionalState type	39
1.3.5	ErrorStatus type	39
1.3.6	Peripherals	39
<b>2</b>	<b>Firmware library</b>	<b>42</b>
2.1	Package description	42
2.1.1	Examples folder	43
2.1.2	Library folder	43
2.1.3	Project folder	43
2.2	Description of firmware library files	44
2.3	Peripheral initialization and configuration	46
2.4	Bit-Banding	47
2.4.1	Mapping formula	47
2.4.2	Example of implementation	47
2.5	Run-time checking	48
<b>3</b>	<b>Peripheral firmware overview</b>	<b>51</b>
<b>4</b>	<b>Analog/digital converter (ADC)</b>	<b>52</b>
4.1	ADC register structure	52
4.2	ADC library functions	55
4.2.1	ADC_DeInit function	56
4.2.2	ADC_Init function	57
	ADC_InitTypeDef structure	57
4.2.3	ADC_StructInit function	60
4.2.4	ADC_Cmd function	61

4.2.5	ADC_DMACmd function	61
4.2.6	ADC_ITConfig function	62
4.2.7	ADC_ResetCalibration function	63
4.2.8	ADC_GetResetCalibrationStatus function	63
4.2.9	ADC_StartCalibration function	64
4.2.10	ADC_GetCalibrationStatus function	64
4.2.11	ADC_SoftwareStartConvCmd function	65
4.2.12	ADC_GetSoftwareStartConvStatus function	65
4.2.13	ADC_DiscModeChannelCountConfig function	66
4.2.14	ADC_DiscModeCmd function	66
4.2.15	ADC_RegularChannelConfig function	67
4.2.16	ADC_ExternalTrigConvCmd function	69
4.2.17	ADC_GetConversionValue function	69
4.2.18	ADC_GetDualModeConversionValue function	70
4.2.19	ADC_AutoInjectedConvCmd function	70
4.2.20	ADC_InjectedDiscModeCmd function	71
4.2.21	ADC_ExternalTrigInjectedConvConfig function	71
4.2.22	ADC_ExternalTrigInjectedConvCmd function	73
4.2.23	ADC_SoftwareStartInjectedConvCmd function	73
4.2.24	ADC_GetSoftwareStartInjectedConvStatus function	74
4.2.25	ADC_InjectedChannelConfig function	75
4.2.26	ADC_InjectedSequencerLengthConfig function	76
4.2.27	ADC_SetInjectedOffset function	76
4.2.28	ADC_GetInjectedConversionValue function	77
4.2.29	ADC_AnalogWatchdogCmd function	78
4.2.30	ADC_AnalogWatchdogThresholdsConfig function	79
4.2.31	ADC_AnalogWatchdogSingleChannelConfig function	79
4.2.32	ADC_TempSensorVrefintCmd function	80
4.2.33	ADC_GetFlagStatus function	80
4.2.34	ADC_ClearFlag function	81
4.2.35	ADC_GetITStatus function	82
4.2.36	ADC_ClearITPendingBit function	82
<b>5</b>	<b>Backup registers (BKP)</b>	<b>83</b>
5.1	BKP register structure	83
5.2	Firmware library functions	86
5.2.1	BKP_DeInit function	86

5.2.2	BKP_TamperPinLevelConfig function	87
5.2.3	BKP_TamperPinCmd function	87
5.2.4	BKP_ITConfig function	88
5.2.5	BKP_RTCOutputConfig function	88
5.2.6	BKP_SetRTCCalibrationValue function	89
5.2.7	BKP_WriteBackupRegister function	90
5.2.8	BKP_ReadBackupRegister function	90
5.2.9	BKP_GetFlagStatus function	91
5.2.10	BKP_ClearFlag function	92
5.2.11	BKP_GetITStatus function	92
5.2.12	BKP_ClearITPendingBit function	93
<b>6</b>	<b>Controller area network (CAN)</b>	<b>94</b>
6.1	CAN register structure	94
6.2	Firmware library functions	97
6.2.1	CAN_DeInit function	98
6.2.2	CAN_Init function	98
	CAN_InitTypeDef structure	99
6.2.3	CAN_FilterInit function	101
	CAN_FilterInitTypeDef structure	102
6.2.4	CAN_StructInit function	104
6.2.5	CAN_ITConfig function	105
6.2.6	CAN_Transmit function	106
	CanTxMsg	106
6.2.7	CAN_TransmitStatus function	107
6.2.8	CAN_CancelTransmit function	108
6.2.9	CAN_FIFORelease function	109
6.2.10	CAN_MessagePending function	109
6.2.11	CAN_Receive function	110
	CanRxMsg structure	110
6.2.12	CAN_Sleep function	112
6.2.13	CAN_WakeUp function	112
6.2.14	CAN_GetFlagStatus function	113
6.2.15	CAN_ClearFlag function	114
6.2.16	CAN_GetITStatus function	114
6.2.17	CAN_ClearITPendingBit function	116

<b>7</b>	<b>DMA controller (DMA)</b>	<b>117</b>
7.1	DMA register structures	117
7.2	Firmware library functions	122
7.2.1	DMA_DeInit function	123
7.2.2	DMA_Init function	123
	DMA_InitTypeDef structure	124
7.2.3	DMA_StructInit function	127
7.2.4	DMA_Cmd function	128
7.2.5	DMA_ITConfig function	128
7.2.6	DMA_GetCurrDataCounter function	129
7.2.7	DMA_GetFlagStatus function	130
7.2.8	DMA_ClearFlag function	132
7.2.9	DMA_GetITStatus function	133
7.2.10	DMA_ClearITPendingBit function	135
<b>8</b>	<b>External interrupt/event controller (EXTI)</b>	<b>136</b>
8.1	EXTI register structure	136
8.2	Firmware library functions	137
8.2.1	EXTI_DeInit function	138
8.2.2	EXTI_Init function	138
	EXTI_InitTypeDef structure	139
8.2.3	EXTI_Struct function	141
8.2.4	EXTI_GenerateSWInterrupt function	142
8.2.5	EXTI_GetFlagStatus function	142
8.2.6	EXTI_ClearFlag function	143
8.2.7	EXTI_GetITStatus function	143
8.2.8	EXTI_ClearITPendingBit function	144
<b>9</b>	<b>Flash memory (FLASH)</b>	<b>145</b>
9.1	FLASH register structures	145
9.2	Firmware library functions	147
9.2.1	FLASH_SetLatency function	148
9.2.2	FLASH_HalfCycleAccessCmd function	149
9.2.3	FLASH_PrefetchBufferCmd function	150
9.2.4	FLASH_Unlock function	151
9.2.5	FLASH_Lock function	151

9.2.6	FLASH_ErasePage function	152
9.2.7	FLASH_EraseAllPages function	152
9.2.8	FLASH_EraseOptionBytes function	153
9.2.9	FLASH_ProgramWord function	153
9.2.10	FLASH_ProgramHalfWord function	154
9.2.11	FLASH_ProgramOptionByteData function	154
9.2.12	FLASH_EnableWriteProtection function	155
9.2.13	FLASH_ReadOutProtection function	157
9.2.14	FLASH_UserOptionByteConfig function	158
9.2.15	FLASH_GetUserOptionByte function	160
9.2.16	FLASH_GetWriteProtectionOptionByte function	160
9.2.17	FLASH_GetReadOutProtectionStatus function	161
9.2.18	FLASH_GetPrefetchBufferStatus function	161
9.2.19	FLASH_ITConfig function	162
9.2.20	FLASH_GetFlagStatus function	163
9.2.21	FLASH_ClearFlag function	164
9.2.22	FLASH_GetStatus function	165
9.2.23	FLASH_WaitForLastOperation function	165
<b>10</b>	<b>General purpose I/O (GPIO)</b>	<b>166</b>
10.1	GPIO register structure	166
10.2	Firmware library functions	170
10.2.1	GPIO_DeInit function	170
10.2.2	GPIO_AFIODeInit function	171
10.2.3	GPIO_Init function	171
	GPIO_InitTypeDef structure	172
10.2.4	GPIO_StructInit function	174
10.2.5	GPIO_ReadInputDataBit function	175
10.2.6	GPIO_ReadInputData function	175
10.2.7	GPIO_ReadOutputDataBit function	176
10.2.8	GPIO_ReadOutputData function	176
10.2.9	GPIO_SetBits	177
10.2.10	GPIO_ResetBits	177
10.2.11	GPIO_WriteBit function	178
10.2.12	GPIO_Write function	178
10.2.13	GPIO_PinLockConfig function	179
10.2.14	GPIO_EventOutputConfig function	179

10.2.15	GPIO_EventOutputCmd function	180
10.2.16	GPIO_PinRemapConfig function	181
10.2.17	GPIO_EXTILineConfig function	182
<b>11</b>	<b>Inter-integrated circuit (I<sup>2</sup>C)</b>	<b>184</b>
11.1	I <sup>2</sup> C register structure	184
11.2	Firmware library functions	186
11.2.1	I2C_DeInit function	187
11.2.2	I2C_Init function	188
	I2C_InitTypeDef structure	188
11.2.3	I2C_StructInit function	190
11.2.4	I2C_Cmd function	191
11.2.5	I2C_DMACmd function	191
11.2.6	I2C_DMALastTransferCmd function	192
11.2.7	I2C_GenerateSTART function	192
11.2.8	I2C_GenerateSTOP function	193
11.2.9	I2C_AcknowledgeConfig function	193
11.2.10	I2C_OwnAddress2Config function	194
11.2.11	I2C_DualAddressCmd function	194
11.2.12	I2C_GeneralCallCmd function	195
11.2.13	I2C_ITConfig function	196
11.2.14	I2C_SendData function	197
11.2.15	I2C_ReceiveData function	197
11.2.16	I2C_Send7bitAddress function	198
11.2.17	I2C_ReadRegister function	199
11.2.18	I2C_SoftwareResetCmd function	200
11.2.19	I2C_SMBusAlertConfig function	201
11.2.20	I2C_TransmitPEC function	202
11.2.21	I2C_PECPositionConfig function	202
11.2.22	I2C_CalculatePEC function	203
11.2.23	I2C_GetPEC function	204
11.2.24	I2C_ARPCmd function	204
11.2.25	I2C_StretchClockCmd function	205
11.2.26	I2C_FastModeDutyCycleConfig function	205
11.2.27	I2C_GetLastEvent function	206
11.2.28	I2C_CheckEvent function	207
11.2.29	I2C_GetFlagStatus function	208

11.2.30	I2C_ClearFlag function	209
11.2.31	I2C_GetITStatus function	210
11.2.32	I2C_ClearITPendingBit function	211
<b>12</b>	<b>Independent watchdog (IWDG)</b>	<b>213</b>
12.1	IWDG register structure	213
12.2	Firmware library functions	214
12.2.1	IWDG_WriteAccessCmd function	214
12.2.2	IWDG_SetPrescaler function	215
12.2.3	IWDG_SetReload function	216
12.2.4	IWDG_ReloadCounter function	216
12.2.5	IWDG_Enable function	217
12.2.6	IWDG_GetFlagStatus function	217
<b>13</b>	<b>Nested vectored interrupt controller (NVIC)</b>	<b>219</b>
13.1	NVIC register structure	219
13.2	Firmware library functions	221
13.2.1	NVIC_DeInit function	222
13.2.2	NVIC_SCBDeInit function	223
13.2.3	NVIC_PriorityGroupConfig function	223
13.2.4	NVIC_Init function	224
	NVIC_InitTypeDef structure	224
13.2.5	NVIC_StructInit function	228
13.2.6	NVIC_SETPRIMASK function	229
13.2.7	NVIC_RESETPRIMASK function	229
13.2.8	NVIC_SETFAULTMASK function	230
13.2.9	NVIC_RESETFaultMask function	230
13.2.10	NVIC_BASEPRICONFIG function	231
13.2.11	NVIC_GetBASEPRI function	231
13.2.12	NVIC_GetCurrentPendingIRQChannel function	232
13.2.13	NVIC_GetIRQChannelPendingBitStatus function	232
13.2.14	NVIC_SetIRQChannelPendingBit function	233
13.2.15	NVIC_ClearIRQChannelPendingBit function	233
13.2.16	NVIC_GetCurrentActiveHandler function	234
13.2.17	NVIC_GetIRQChannelActiveBitStatus function	234
13.2.18	NVIC_GetCpuID function	235
13.2.19	NVIC_SetVectorTable function	235



13.2.20	NVIC_GenerateSystemReset function	236
13.2.21	NVIC_GenerateCoreReset function	236
13.2.22	NVIC_SystemLPConfig function	237
13.2.23	NVIC_SystemHandlerConfig function	238
13.2.24	NVIC_SystemHandlerPriorityConfig function	244
13.2.25	NVIC_GetSystemHandlerPendingBitStatus function	245
13.2.26	NVIC_SetSystemHandlerPendingBit function	246
13.2.27	NVIC_ClearSystemHandlerPendingBit function	247
13.2.28	NVIC_GetSystemHandlerActiveBitStatus function	248
13.2.29	NVIC_GetFaultHandlerSources function	249
13.2.30	NVIC_GetFaultAddress function	250
<b>14</b>	<b>Power control (PWR)</b>	<b>251</b>
14.1	PWR register structure	251
14.2	Firmware library functions	252
14.2.1	PWR_DeInit function	252
14.2.2	PWR_BackupAccessCmd function	253
14.2.3	PWR_PVDCmd function	253
14.2.4	PWR_PVDLevelConfig function	254
14.2.5	PWR_WakeUpPinCmd function	255
14.2.6	PWR_EnterSTOPMode function	255
14.2.7	PWR_EnterSTANDBYMode function	256
14.2.8	PWR_GetFlagStatus function	257
14.2.9	PWR_ClearFlag function	258
<b>15</b>	<b>Reset and clock control (RCC)</b>	<b>259</b>
15.1	RCC register structure	259
15.2	Firmware library functions	260
15.2.1	RCC_DeInit function	262
15.2.2	RCC_HSEConfig function	262
15.2.3	RCC_WaitForHSEStartUp function	263
15.2.4	RCC_AdjustHSICalibrationValue function	264
15.2.5	RCC_HSICmd function	264
15.2.6	RCC_PLLConfig function	265
15.2.7	RCC_PLLCmd function	266
15.2.8	RCC_SYSCLKConfig function	267
15.2.9	RCC_GetSYSCLKSource function	268

15.2.10	RCC_HCLKConfig function	269
15.2.11	RCC_PCLK1Config function	270
15.2.12	RCC_PCLK2Config function	271
15.2.13	RCC_ITConfig function	272
15.2.14	RCC_USBCLKConfig function	273
15.2.15	RCC_ADCCLKConfig function	274
15.2.16	RCC_LSEConfig function	275
15.2.17	RCC_LSIConfig function	276
15.2.18	RCC_RTCCLKConfig function	276
15.2.19	RCC_RTCCLKCmd function	277
15.2.20	RCC_GetClocksFreq function	278
	RCC_ClocksTypeDef structure	278
15.2.21	RCC_AHBPeriphClockCmd function	279
15.2.22	RCC_APB2PeriphClockCmd function	280
15.2.23	RCC_APB1PeriphClockCmd function	281
15.2.24	RCC_APB2PeriphResetCmd function	282
15.2.25	RCC_APB1PeriphResetCmd function	283
15.2.26	RCC_BackupResetCmd function	283
15.2.27	RCC_ClockSecuritySystemCmd function	284
15.2.28	RCC_MCOConfig function	284
15.2.29	RCC_GetFlagStatus function	285
15.2.30	RCC_ClearFlag function	287
15.2.31	RCC_GetITStatus function	287
15.2.32	RCC_ClearITPendingBit function	288
<b>16</b>	<b>Real-time clock (RTC)</b>	<b>290</b>
16.1	RTC register structure	290
16.2	Firmware library functions	292
16.2.1	RTC_ITConfig function	293
16.2.2	RTC_EnterConfigMode function	294
16.2.3	RTC_ExitConfigMode function	294
16.2.4	RTC_GetCounter function	295
16.2.5	RTC_SetCounter function	295
16.2.6	RTC_SetPrescaler function	296
16.2.7	RTC_SetAlarm function	296
16.2.8	RTC_GetDivider function	297
16.2.9	RTC_WaitForLastTask function	297

	16.2.10	RTC_WaitForSynchro function	298
	16.2.11	RTC_GetFlagStatus function	298
	16.2.12	RTC_ClearFlag function	299
	16.2.13	RTC_GetITStatus function	300
	16.2.14	RTC_ClearITPendingBit function	300
<b>17</b>		<b>Serial peripheral interface (SPI)</b>	<b>301</b>
	17.1	SPI register structure	301
	17.2	Firmware library functions	303
	17.2.1	SPI_I2S_DeInit function	304
	17.2.2	SPI_Init function	304
		SPI_InitTypeDef structure	305
	17.2.3	I2S_Init function	308
	17.2.4	SPI_StructInit function	310
	17.2.5	I2S_StructInit function	311
	17.2.6	SPI_Cmd function	312
	17.2.7	I2S_Cmd	312
	17.2.8	SPI_I2S_ITConfig function	313
	17.2.9	SPI_I2S_DMACmd function	314
	17.2.10	SPI_I2S_SendData function	315
	17.2.11	SPI_I2S_ReceiveData function	315
	17.2.12	SPI_NSSInternalSoftwareConfig function	316
	17.2.13	SPI_SSOutputCmd function	317
	17.2.14	SPI_DataSizeConfig function	317
	17.2.15	SPI_TransmitCRC function	318
	17.2.16	SPI_CalculateCRC function	319
	17.2.17	SPI_GetCRC function	319
	17.2.18	SPI_GetCRCPolynomial function	320
	17.2.19	SPI_BiDirectionalLineConfig function	321
	17.2.20	SPI_I2S_GetFlagStatus function	322
	17.2.21	SPI_I2S_ClearFlag function	323
	17.2.22	SPI_I2S_GetITStatus function	324
	17.2.23	SPI_I2S_ClearITPendingBit function	325
<b>18</b>		<b>Cortex system timer (SysTick)</b>	<b>326</b>
	18.1	SysTick register structure	326
	18.2	Firmware library functions	327

18.2.1	SysTick_CLKSourceConfig function	327
18.2.2	SysTick_SetReload function	328
18.2.3	SysTick_CounterCmd function	329
18.2.4	SysTick_ITConfig function	330
18.2.5	SysTick_GetCounter function	330
18.2.6	SysTick_GetFlagStatus function	331

## 19 **Advanced-control timer, general-purpose timer and basic timer (TIM)** . 332

19.1	TIM register structure	332
19.2	Firmware library functions	336
19.2.1	TIM_DeInit function	339
19.2.2	TIM_TimeBaseInit function	340
	TIM_TimeBaseInitTypeDef structure	340
19.2.3	TIM_OC1Init function	342
	TIM_OCInitTypeDef structure	342
19.2.4	TIM_OC2Init function	345
19.2.5	TIM_OC3Init function	346
19.2.6	TIM_OC4Init function	347
19.2.7	TIM_ICInit function	348
	TIM_ICInitTypeDef structure	348
19.2.8	TIM_PWMConfig function	350
19.2.9	TIM_BDTRConfig function	351
	TIM_BDTRInitStruct structure	351
19.2.10	TIM_TimeBaseStructInit function	353
19.2.11	TIM_OCStructInit function	354
19.2.12	TIM_ICStructInit function	355
19.2.13	TIM_BDTRStructInit function	356
19.2.14	TIM_Cmd function	357
19.2.15	TIM_CtrlPWMOutputs function	357
19.2.16	TIM_ITConfig function	358
19.2.17	TIM_GenerateEvent function	359
19.2.18	TIM_DMAConfig function	360
19.2.19	TIM_DMACmd function	362
19.2.20	TIM_InternalClockConfig function	363
19.2.21	TIM_ITRxExternalClockConfig function	364
19.2.22	TIM_TlxEternalClockConfig function	365

19.2.23	TIM_ETRClockMode1Config function	366
19.2.24	TIM_ETRClockMode2Config function	367
19.2.25	TIM_ETRConfig	368
19.2.26	TIM_PrescalerConfig function	369
19.2.27	TIM_CounterModeConfig function	370
19.2.28	TIM_SelectInputTrigger function	370
19.2.29	TIM_EncoderInterfaceConfig function	371
19.2.30	TIM_ForcedOC1Config function	372
19.2.31	TIM_ForcedOC2Config function	373
19.2.32	TIM_ForcedOC3Config function	373
19.2.33	TIM_ForcedOC4Config function	374
19.2.34	TIM_ARRPreloadConfig function	374
19.2.35	TIM_SelectCOM function	375
19.2.36	TIM_SelectCCDMA function	375
19.2.37	TIM_CCPreloadControl function	376
19.2.38	TIM_OC1PreloadConfig function	376
19.2.39	TIM_OC2PreloadConfig function	377
19.2.40	TIM_OC3PreloadConfig function	378
19.2.41	TIM_OC4PreloadConfig function	378
19.2.42	TIM_OC1FastConfig function	379
19.2.43	TIM_OC2FastConfig function	380
19.2.44	TIM_OC3FastConfig function	380
19.2.45	TIM_OC4FastConfig function	381
19.2.46	TIM_ClearOC1Ref	381
19.2.47	TIM_ClearOC2Ref	382
19.2.48	TIM_ClearOC3Ref	383
19.2.49	TIM_ClearOC4Ref	383
19.2.50	TIM_OC1PolarityConfig function	384
19.2.51	TIM_OC1NPolarityConfig function	385
19.2.52	TIM_OC2PolarityConfig function	385
19.2.53	TIM_OC2NPolarityConfig function	386
19.2.54	TIM_OC3PolarityConfig function	386
19.2.55	TIM_OC3NPolarityConfig function	387
19.2.56	TIM_OC4PolarityConfig function	387
19.2.57	TIM_CCxCmd function	388
19.2.58	TIM_CCxNCmd function	388
19.2.59	TIM_SelectOCxM function	389

19.2.60	TIM_UpdateDisableConfig function	390
19.2.61	TIM_UpdateRequestConfig function	390
19.2.62	TIM_SelectHallSensor function	391
19.2.63	TIM_SelectOnePulseMode function	392
19.2.64	TIM_SelectOutputTrigger function	393
19.2.65	TIM_SelectSlaveMode function	394
19.2.66	TIM_SelectMasterSlaveMode function	395
19.2.67	TIM_SetCounter function	395
19.2.68	TIM_SetAutoreload function	396
19.2.69	TIM_SetCompare1 function	396
19.2.70	TIM_SetCompare2 function	397
19.2.71	TIM_SetCompare3 function	397
19.2.72	TIM_SetCompare4 function	398
19.2.73	TIM_SetIC1Prescaler function	398
19.2.74	TIM_SetIC2Prescaler function	399
19.2.75	TIM_SetIC3Prescaler function	400
19.2.76	TIM_SetIC4Prescaler function	400
19.2.77	TIM_SetClockDivision function	401
19.2.78	TIM_GetCapture1 function	401
19.2.79	TIM_GetCapture2 function	402
19.2.80	TIM_GetCapture3 function	402
19.2.81	TIM_GetCapture4 function	403
19.2.82	TIM_GetCounter function	403
19.2.83	TIM_GetPrescaler function	404
19.2.84	TIM_GetFlagStatus function	404
19.2.85	TIM_ClearFlag function	406
19.2.86	TIM_GetITStatus function	406
19.2.87	TIM_ClearITPendingBit function	407

<b>20</b>	<b>Universal synchronous asynchronous receiver transmitter (USART)</b>	<b>408</b>
20.1	USART register structure	408
20.2	Firmware library functions	411
20.2.1	USART_DeInit function	412
20.2.2	USART_Init function	412
	USART_InitTypeDef structure	413
20.2.3	USART_StructInit function	416

20.2.4	USART_ClockInit function	416
	USART_ClockInitTypeDef structure	417
20.2.5	USART_ClockStructInit function	419
20.2.6	USART_Cmd function	420
20.2.7	USART_ITConfig function	420
20.2.8	USART_DMACmd function	421
20.2.9	USART_SetAddress function	422
20.2.10	USART_WakeUpConfig function	423
20.2.11	USART_ReceiverWakeUpCmd function	424
20.2.12	USART_LINBreakDetectLengthConfig function	424
20.2.13	USART_LINCmd function	425
20.2.14	USART_SendData function	426
20.2.15	USART_ReceiveData function	426
20.2.16	USART_SendBreak function	427
20.2.17	USART_SetGuardTime function	427
20.2.18	USART_SetPrescaler function	428
20.2.19	USART_SmartCardCmd function	428
20.2.20	USART_SmartCardNACKCmd function	429
20.2.21	USART_HalfDuplexCmd function	429
20.2.22	USART_IrDAConfig function	430
20.2.23	USART_IrDACmd function	431
20.2.24	USART_GetFlagStatus function	431
20.2.25	USART_ClearFlag function	432
20.2.26	USART_GetITStatus function	433
20.2.27	USART_ClearITPendingBit function	434
<b>21</b>	<b>Window watchdog (WWDG)</b>	<b>435</b>
21.1	WWDG registers	435
21.2	Firmware library functions	436
21.2.1	WWDG_DeInit function	436
21.2.2	WWDG_SetPrescaler function	437
21.2.3	WWDG_SetWindowValue function	438
21.2.4	WWDG_EnableIT function	438
21.2.5	WWDG_SetCounter function	439
21.2.6	WWDG_Enable function	439
21.2.7	WWDG_GetFlagStatus function	440
21.2.8	WWDG_ClearFlag function	440

<b>22</b>	<b>Digital/analog converter (DAC)</b>	<b>441</b>
22.1	DAC register structure	441
22.2	Firmware library functions	443
22.2.1	DAC_DeInit	443
22.2.2	DAC_Init	444
	DAC_Channel	444
	DAC_InitTypeDef	444
22.2.3	DAC_StructInit	447
22.2.4	DAC_Cmd	448
22.2.5	DAC_DMAMCmd	448
22.2.6	DAC_SoftwareTriggerCmd	449
22.2.7	DAC_DualSoftwareTriggerCmd	449
22.2.8	DAC_WaveGenerationCmd	450
22.2.9	DAC_SetChannel1Data	451
22.2.10	DAC_SetChannel2Data	452
22.2.11	DAC_SetDualChannelData	453
22.2.12	DAC_GetDataOutputValue	454
<b>23</b>	<b>Flexible static memory controller (FSMC)</b>	<b>455</b>
23.1	FSMC register structure	455
23.2	Firmware library functions	458
23.2.1	FSMC_NORSRAMDeInit	459
23.2.2	FSMC_NANDDeInit	460
23.2.3	FSMC_PCCARDeInit	461
23.2.4	FSMC_NORSRAMInit	461
	FSMC_NORSRAMTimingInitTypeDef	462
	FSMC_NORSRAMInitTypeDef	463
23.2.5	FSMC_NANDInit	468
	FSMC_NAND_PCCARDTimingInitTypeDef	468
	FSMC_NANDInitTypeDef	469
23.2.6	FSMC_PCCARDInit	472
	FSMC_NAND_PCCARDTimingInitTypeDef	472
	FSMC_PCCARDInitTypeDef	473
23.2.7	FSMC_NORSRAMStructInit	475
23.2.8	FSMC_NANDStructInit	476
23.2.9	FSMC_PCCARDStructInit	477
23.2.10	FSMC_NORSRAMCmd	479



23.2.11	FSMC_NANDCmd	479
23.2.12	FSMC_PCCARDCmd	480
23.2.13	FSMC_PCCARDCmd	480
23.2.14	FSMC_NANDECCCmd	481
23.2.15	FSMC_ITConfig	481
23.2.16	FSMC_GetFlagStatus	482
23.2.17	FSMC_ClearFlag	483
23.2.18	FSMC_GetITStatus	484
23.2.19	FSMC_ClearITPendingBit	484
<b>24</b>	<b>SDIO interface (SDIO)</b>	<b>485</b>
24.1	SDIO register structure	485
24.2	Firmware library functions	487
24.2.1	SDIO_DeInit	488
24.2.2	SDIO_Init	488
	SDIO_InitTypeDef	489
24.2.3	SDIO_StructInit	491
24.2.4	SDIO_ClockCmd	492
24.2.5	SDIO_SetPowerState	492
24.2.6	SDIO_GetPowerState	493
24.2.7	SDIO_ITConfig	493
24.2.8	SDIO_DMACmd	495
24.2.9	SDIO_SendCommand	495
	SDIO_CmdInitTypeDef	496
24.2.10	SDIO_CmdStructInit	497
24.2.11	SDIO_GetCommandResponse	498
24.2.12	SDIO_GetResponse	498
24.2.13	SDIO_DataConfig	499
	SDIO_DataInitTypeDef	499
24.2.14	SDIO_DataStructInit	501
24.2.15	SDIO_GetDataCounter	502
24.2.16	SDIO_ReadData	503
24.2.17	SDIO_WriteData	503
24.2.18	SDIO_GetFIFOCount	504
24.2.19	SDIO_StartSDIOReadWait	504
24.2.20	SDIO_StopSDIOReadWait	505
24.2.21	SDIO_SetSDIOReadWaitMode	505

	24.2.22	SDIO_SetSDIOOperation	506
	24.2.23	SDIO_SendSDIOSuspendCmd	506
	24.2.24	SDIO_CommandCompletionCmd	507
	24.2.25	SDIO_CEATAITCmd	507
	24.2.26	SDIO_SendCEATACmd	508
	24.2.27	SDIO_GetFlagStatus	508
	24.2.28	SDIO_ClearFlag	510
	24.2.29	SDIO_GetITStatus	511
	24.2.30	SDIO_ClearITPendingBit	511
<b>25</b>		<b>Debug MCU</b>	<b>513</b>
	25.1	DBGMCU register structure	513
	25.2	Firmware library functions	514
	25.2.1	DBGMCU_GetREVID function	514
	25.2.2	DBGMCU_GetDEVID function	515
	25.2.3	DBGMCU_Config function	515
<b>26</b>		<b>CRC calculation unit</b>	<b>517</b>
	26.1	CRC register structure	517
	26.2	Firmware library functions	518
	26.2.1	CRC_ResetDR function	518
	26.2.2	CRC_CalcCRC function	519
	26.3	CRC_CalcBlockCRC function	519
	26.3.1	CRC_GetCRC function	520
	26.3.2	CRC_SetIDRegister function	520
	26.3.3	CRC_GetIDRegister function	521
<b>27</b>		<b>Revision history</b>	<b>522</b>

## List of tables

Table 1.	List of abbreviations . . . . .	36
Table 2.	Firmware library files . . . . .	44
Table 3.	Function description format . . . . .	51
Table 4.	ADC registers . . . . .	52
Table 5.	ADC firmware library functions . . . . .	55
Table 6.	ADC_Delnit function . . . . .	56
Table 7.	ADC_Init function . . . . .	57
Table 8.	ADC_Mode definition . . . . .	58
Table 9.	ADC_ExternalTrigConv definition . . . . .	58
Table 10.	ADC_DataAlign definition . . . . .	59
Table 11.	ADC_StructInit function . . . . .	60
Table 12.	ADC_IniyStruct default values . . . . .	60
Table 13.	ADC_Cmd function . . . . .	61
Table 14.	ADC_DMAMCmd function . . . . .	61
Table 15.	ADC_ITConfig function . . . . .	62
Table 16.	ADC_IT definition . . . . .	62
Table 17.	ADC_ResetCalibration function . . . . .	63
Table 18.	ADC_GetResetCalibration function . . . . .	63
Table 19.	ADC_StartCalibration function . . . . .	64
Table 20.	ADC_GetCalibrationStatus function . . . . .	64
Table 21.	ADC_SoftwareStartConvCmd function . . . . .	65
Table 22.	ADC_GetSoftwareStartConvStatus function . . . . .	65
Table 23.	ADC_DiscModeChannelCountConfig function . . . . .	66
Table 24.	ADC_DiscModeCmd function . . . . .	66
Table 25.	ADC-RegularChannelConfig function . . . . .	67
Table 26.	ADC_Channel values . . . . .	67
Table 27.	ADC_SampleTime values . . . . .	68
Table 28.	ADC_ExternalTrigConvCmd function . . . . .	69
Table 29.	ADC_GetConversionValue function . . . . .	69
Table 30.	ADC_GetDualModeConversionValue function . . . . .	70
Table 31.	ADC_AutoInjectedConvCmd function . . . . .	70
Table 32.	ADC_InjectedDiscModeCmd function . . . . .	71
Table 33.	ADC_ExternalTrigInjectedConvConfig function . . . . .	71
Table 34.	ADC_ExternalTrigInjecConv values . . . . .	72
Table 35.	ADC_ExternalTrigInjectedConvCmd function . . . . .	73
Table 36.	ADC_SoftwareStartInjectedConvCmd function . . . . .	73
Table 37.	ADC_GetSoftwareStartInjectedConvStatus function . . . . .	74
Table 38.	ADC_InjectedChannelConfig function . . . . .	75
Table 39.	ADC_InjectedSequencerLengthConfig function . . . . .	76
Table 40.	ADC_SetInjectedOffset function . . . . .	76
Table 41.	ADC_InjectedChannel values . . . . .	77
Table 42.	ADC_GetInjectedConversionValue function . . . . .	77
Table 43.	ADC_AnalogWatchdogCmd function . . . . .	78
Table 44.	ADC_AnalogWatchdog values . . . . .	78
Table 45.	ADC_AnalogWatchdogThresholdsConfig function . . . . .	79
Table 46.	AnalogWatchdogSingleChannelConfig function . . . . .	79
Table 47.	ADC_TempSensorVrefintCmd function . . . . .	80
Table 48.	ADC_GetFlagStatus function . . . . .	80

Table 49.	ADC_FLAG values	81
Table 50.	ADC_ClearFlag function	81
Table 51.	ADC_GetITStatus function	82
Table 52.	ADC_ClearITPendingBit function	82
Table 53.	BKP registers	85
Table 54.	BKP library functions	86
Table 55.	BKP_DeInit function	86
Table 56.	BKP_TamperPinLevelConfig function	87
Table 57.	BKP_TamperPinLevel values	87
Table 58.	BKP_TamperPinCmd function	87
Table 59.	BKP_ITConfig function	88
Table 60.	BKP_RTCOutputConfig function	88
Table 61.	BKP_RTCOutputSource values	89
Table 62.	BKP_SetRTCCalibrationValue function	89
Table 63.	BKP_WriteBackupRegister function	90
Table 64.	BKP_DR values	90
Table 65.	BKP_ReadBackupRegister function	90
Table 66.	BKP_GetFlagStatus function	91
Table 67.	BKP_ClearFlag function	92
Table 68.	BKP_GetITStatus function	92
Table 69.	BKP_ClearITPendingBit function	93
Table 70.	CAN registers	95
Table 71.	CAN firmware library functions	97
Table 72.	CAN_DeInit function	98
Table 73.	CAN_Init function	98
Table 74.	CAN_Mode values	100
Table 75.	CAN_SJW values	100
Table 76.	CAN_BS1 values	100
Table 77.	CAN_BS2 values	100
Table 78.	CAN_FilterInit function	101
Table 79.	CAN_FilterMode values	102
Table 80.	CAN_FilterScale values	102
Table 81.	CAN_FilterFIFO values	103
Table 82.	CAN_StructInit function	104
Table 83.	CAN_InitStruct default values	104
Table 84.	CAN_ITConfig function	105
Table 85.	CAN_IT values	105
Table 86.	CAN_Transmit function	106
Table 87.	IDE values	106
Table 88.	RTR values	107
Table 89.	CAN_TransmitStatus function	107
Table 90.	CAN_CancelTransmit function	108
Table 91.	CAN_FIFORelease function	109
Table 92.	CAN_MessagePending function	109
Table 93.	CAN_Receive function	110
Table 94.	IDE values	110
Table 95.	RTR values	111
Table 96.	CAN_Sleep function	112
Table 97.	CAN_Wakeup function	112
Table 98.	CAN_GetFlagStatus function	113
Table 99.	CAN_FLAG definition	113
Table 100.	CAN_ClearFlag function	114

Table 101.	CAN_GetITStatus function . . . . .	114
Table 102.	CAN_IT values . . . . .	115
Table 103.	CAN_ClearITPendingBit function . . . . .	116
Table 104.	DMA registers . . . . .	117
Table 105.	DMA firmware library functions . . . . .	122
Table 106.	DMA_DeInit function . . . . .	123
Table 107.	DMA_Init function . . . . .	123
Table 108.	DMA_DIR definition . . . . .	124
Table 109.	DMA_PeripheralInc definition . . . . .	124
Table 110.	DMA_MemoryInc definition . . . . .	125
Table 111.	DMA_PeripheralDataSize definition . . . . .	125
Table 112.	DMA_MemoryDataSize definition . . . . .	125
Table 113.	DMA_Mode definition . . . . .	125
Table 114.	DMA_Priority definition . . . . .	126
Table 115.	DMA_M2M definition . . . . .	126
Table 116.	DMA_StructInit function . . . . .	127
Table 117.	DMA_InitStruct default values . . . . .	127
Table 118.	DMA_Cmd function . . . . .	128
Table 119.	DMA_ITConfig function . . . . .	128
Table 120.	DMA_IT values . . . . .	129
Table 121.	DMA_GetCurrDataCounter function . . . . .	129
Table 122.	DMA_GetFlagStatus function . . . . .	130
Table 123.	DMA_FLAG definition . . . . .	130
Table 124.	DMA_ClearFlag function . . . . .	132
Table 125.	DMA_GetITStatus function . . . . .	133
Table 126.	DMA_IT values . . . . .	133
Table 127.	DMA_ClearITPendingBit function . . . . .	135
Table 128.	EXTI registers . . . . .	136
Table 129.	EXTI Firmware library functions . . . . .	137
Table 130.	EXTI_DeInit function . . . . .	138
Table 131.	EXTI_DeInit function . . . . .	138
Table 132.	EXTI_Line values . . . . .	139
Table 133.	EXTI_Mode values . . . . .	140
Table 134.	EXT_Trigger values . . . . .	140
Table 135.	EXTI_StructInit function . . . . .	141
Table 136.	EXTI_InitStruct default values . . . . .	141
Table 137.	EXTI_GenerateSWInterrupt function . . . . .	142
Table 138.	EXTI_GetFlagStatus function . . . . .	142
Table 139.	EXTI_ClearFlag function . . . . .	143
Table 140.	EXTI_GetITStatus function . . . . .	143
Table 141.	EXTI_ClearITPendingBit function . . . . .	144
Table 142.	FLASH registers . . . . .	145
Table 143.	Option Bytes registers (OB) . . . . .	146
Table 144.	FLASH library function . . . . .	147
Table 145.	FLASH_SetLatency function . . . . .	148
Table 146.	FLASH_Latency values . . . . .	148
Table 147.	FLASH_HalfCycleAccessCmd function . . . . .	149
Table 148.	FLASH_HalfCycleAccess values . . . . .	149
Table 149.	FLASH_PrefetchBufferCmd function . . . . .	150
Table 150.	FLASH_PrefetchBuffer values . . . . .	150
Table 151.	FLASH_Unlock function . . . . .	151
Table 152.	FLASH_Lock function . . . . .	151

Table 153.	FLASH_ErasePage function . . . . .	152
Table 154.	FLASH_EraseAllPages function . . . . .	152
Table 155.	FLASH_EraseOptionBytes function . . . . .	153
Table 156.	FLASH_ProgramWord function . . . . .	153
Table 157.	FLASH_ProgramHalfWord function . . . . .	154
Table 158.	FLASH_ProgramOptionByteData function . . . . .	154
Table 159.	FLASH_EnableWriteProtection function . . . . .	155
Table 160.	FLASH_Pages values for Medium-density devices . . . . .	155
Table 161.	FLASH_Pages values for High-density devices . . . . .	156
Table 162.	FLASH_ReadOutProtection function . . . . .	157
Table 163.	FLASH_UserOptionByteConfig function . . . . .	158
Table 164.	OB_IWDG values . . . . .	159
Table 165.	OB_STOP values . . . . .	159
Table 166.	OB_STDBY values . . . . .	159
Table 167.	FLASH_GetUserOptionByte function . . . . .	160
Table 168.	FLASH_GetWriteProtectionOptionByte function . . . . .	160
Table 169.	FLASH_GetReadOutProtectionStatus function . . . . .	161
Table 170.	FLASH_GetPrefetchBufferStatus function . . . . .	161
Table 171.	FLASH_ITConfig function . . . . .	162
Table 172.	FLASH_IT values . . . . .	162
Table 173.	Flash_GetFlagStatus function . . . . .	163
Table 174.	FLASH_FLAG definition . . . . .	163
Table 175.	FLASH_ClearFlag function . . . . .	164
Table 176.	FLASH_FLAG definition . . . . .	164
Table 177.	FLASH_GetStatus function . . . . .	165
Table 178.	FLASH_WaitForLastOperation function . . . . .	165
Table 179.	GPIO registers . . . . .	166
Table 180.	GPIO firmware library functions . . . . .	170
Table 181.	GPIO_DeInit function . . . . .	170
Table 182.	GPIO_AFIODeInit function . . . . .	171
Table 183.	GPIO_Init function . . . . .	171
Table 184.	GPIO_Pin values . . . . .	172
Table 185.	GPIO_Speed values . . . . .	173
Table 186.	GPIO_Mode values . . . . .	173
Table 187.	GPIO_Mode indexes and codes . . . . .	174
Table 188.	GPIO_StructInit function . . . . .	174
Table 189.	GPIO_InitStruct default values . . . . .	174
Table 190.	GPIO_ReadInputDataBit function . . . . .	175
Table 191.	GPIO_ReadInputData function . . . . .	175
Table 192.	GPIO_ReadOutputDataBit function . . . . .	176
Table 193.	GPIO_ReadOutputData function . . . . .	176
Table 194.	GPIO_SetBits function . . . . .	177
Table 195.	GPIO_ResetBits function . . . . .	177
Table 196.	GPIO_WriteBit function . . . . .	178
Table 197.	GPIO_Write function . . . . .	178
Table 198.	GPIO_PinLockConfig function . . . . .	179
Table 199.	GPIO_EventOutputConfig function . . . . .	179
Table 200.	GPIO_PortSource values . . . . .	180
Table 201.	GPIO_EventOutputCmd function . . . . .	180
Table 202.	GPIO_PinRemapConfig function . . . . .	181
Table 203.	GPIO_Remap values . . . . .	181
Table 204.	GPIO_EXTILineConfig function . . . . .	182

Table 205.	GPIO_PortSource values . . . . .	183
Table 206.	I2C registers . . . . .	185
Table 207.	I2C firmware library functions . . . . .	186
Table 208.	I2C_DelInit function . . . . .	187
Table 209.	I2C_Init function . . . . .	188
Table 210.	I2C_Mode definition . . . . .	188
Table 211.	I2C_DutyCycle definition . . . . .	189
Table 212.	I2C_Ack definition . . . . .	189
Table 213.	I2C_AcknowledgedAddress values . . . . .	189
Table 214.	I2C_StructInit function . . . . .	190
Table 215.	I2C_InitStruct default values . . . . .	190
Table 216.	I2C_Cmd function . . . . .	191
Table 217.	I2C_DMAMCmd function . . . . .	191
Table 218.	I2C_DMALastTransferCmd function . . . . .	192
Table 219.	I2C_GenerateSTART function . . . . .	192
Table 220.	I2C_GenerateSTOP function . . . . .	193
Table 221.	I2C_AcknowledgeConfig function . . . . .	193
Table 222.	I2C_OwnAddress2Config function . . . . .	194
Table 223.	I2C_DualAddressCmd function . . . . .	194
Table 224.	I2C_GeneralCallCmd function . . . . .	195
Table 225.	I2C_ITConfig function . . . . .	196
Table 226.	I2C_IT values . . . . .	196
Table 227.	I2C_SendData function . . . . .	197
Table 228.	I2C_ReceiveData function . . . . .	197
Table 229.	I2C_Send7bitAddress function . . . . .	198
Table 230.	I2C_Direction . . . . .	198
Table 231.	I2C_ReadRegister function . . . . .	199
Table 232.	Readable I2C registers . . . . .	199
Table 233.	I2C_SoftwareResetCmd function . . . . .	200
Table 234.	I2C_SMBusAlertConfig function . . . . .	201
Table 235.	I2C_SMBusAlert values . . . . .	201
Table 236.	I2C_TransmitPEC function . . . . .	202
Table 237.	I2C_PECPositionConfig function . . . . .	202
Table 238.	I2C_PECPosition values . . . . .	203
Table 239.	I2C_CalculatePEC function . . . . .	203
Table 240.	I2C_GetPEC function . . . . .	204
Table 241.	I2C_ARPCmd function . . . . .	204
Table 242.	I2C_StretchClockCmd function . . . . .	205
Table 243.	I2C_FastModeDutyCycleConfig function . . . . .	205
Table 244.	I2C_DutyCycle . . . . .	206
Table 245.	I2C_GetLastEvent function . . . . .	206
Table 246.	I2C_CheckEvent function . . . . .	207
Table 247.	I2C_Event . . . . .	207
Table 248.	I2C_GetFlagStatus function . . . . .	208
Table 249.	I2C_FLAG definition . . . . .	208
Table 250.	I2C_ClearFlag function . . . . .	209
Table 251.	I2C_FLAG definition . . . . .	210
Table 252.	I2C_GetITStatus function . . . . .	210
Table 253.	I2C_IT definition . . . . .	211
Table 254.	I2C_ClearITPendingBit function . . . . .	211
Table 255.	I2C_IT definition . . . . .	212
Table 256.	IWDG registers . . . . .	213

Table 257.	IWDG firmware library functions . . . . .	214
Table 258.	IWDG_WriteAccessCmd function . . . . .	214
Table 259.	IWDG_WriteAccess definition . . . . .	215
Table 260.	IWDG_SetPrescaler function . . . . .	215
Table 261.	IWDG_Prescaler definition . . . . .	215
Table 262.	IWDG_SetReload function . . . . .	216
Table 263.	IWDG_ReloadCounter function . . . . .	216
Table 264.	IWDG_Enable function . . . . .	217
Table 265.	IWDG_GetFlagStatus function . . . . .	217
Table 266.	IWDG_FLAG definition . . . . .	218
Table 267.	NVIC registers . . . . .	220
Table 268.	NVIC firmware library functions . . . . .	221
Table 269.	NVIC_DeInit function . . . . .	222
Table 270.	NVIC_SCBDeInit function . . . . .	223
Table 271.	NVIC_PriorityGroupConfig function . . . . .	223
Table 272.	NVIC_PriorityGroup . . . . .	224
Table 273.	NVIC_Init function . . . . .	224
Table 274.	NVIC_IRQChannels . . . . .	225
Table 275.	Pre-emption priority and subpriority values . . . . .	227
Table 276.	NVIC_StructInit function . . . . .	228
Table 277.	NVIC_InitStruct default values . . . . .	228
Table 278.	NVIC_SETPRIMASK function . . . . .	229
Table 279.	NVIC_RESETPRIMASK function . . . . .	229
Table 280.	NVIC_SETFAULTMASK function . . . . .	230
Table 281.	NVIC_RESETFAULTMASK function . . . . .	230
Table 282.	NVIC_BASEPRICONFIG function . . . . .	231
Table 283.	NVIC_GetBASEPRI function . . . . .	231
Table 284.	NVIC_GetCurrentPendingIRQChannel function . . . . .	232
Table 285.	NVIC_GetIRQChannelPendingBitStatus function . . . . .	232
Table 286.	NVIC_SetIRQChannelPendingBitStatus function . . . . .	233
Table 287.	NVIC_ClearIRQChannelPendingBit function . . . . .	233
Table 288.	NVIC_GetCurrentActiveHandler function . . . . .	234
Table 289.	NVIC_GetIRQChannelActiveBitStatus function . . . . .	234
Table 290.	NVIC_GetCUID function . . . . .	235
Table 291.	NVIC_SetVectorTable function . . . . .	235
Table 292.	NVIC_VectTab values . . . . .	236
Table 293.	NVIC_GenerateSystemReset function . . . . .	236
Table 294.	NVIC_GenerateCoreReset function . . . . .	236
Table 295.	NVIC_SystemLPConfig function . . . . .	237
Table 296.	LowerPowerMode definition . . . . .	237
Table 297.	NVIC_SystemHandlerConfig function . . . . .	238
Table 298.	SystemHandler types . . . . .	238
Table 299.	SystemHandler definition . . . . .	239
Table 300.	SystemHandler_NMI definition . . . . .	239
Table 301.	SystemHandler_HardFault definition . . . . .	240
Table 302.	SystemHandler_MemoryManage definition . . . . .	240
Table 303.	SystemHandler_BusFault definition . . . . .	241
Table 304.	SystemHandler_UsageFault definition . . . . .	241
Table 305.	SystemHandler_SVCall definition . . . . .	242
Table 306.	SystemHandler_DebugMonitor definition . . . . .	242
Table 307.	SystemHandler_PSV definition . . . . .	243
Table 308.	SystemHandler_SysTick definition . . . . .	243



Table 309.	NVIC_SystemHandlerPriorityConfig function . . . . .	244
Table 310.	SystemHandler types . . . . .	244
Table 311.	NVIC_GetSystemHandlerPendingBitStatus function . . . . .	245
Table 312.	systemHandler types . . . . .	245
Table 313.	NVIC_SetSystemHandlerPendingBit function . . . . .	246
Table 314.	systemHandler types . . . . .	246
Table 315.	NVIC_ClearSystemHandlerPendingBit function . . . . .	247
Table 316.	systemHandler types . . . . .	247
Table 317.	NVIC_GetSystemHandlerActiveBitStatus function . . . . .	248
Table 318.	systemHandler types . . . . .	248
Table 319.	NVIC_GetFaultHandlerSources function . . . . .	249
Table 320.	systemHandler types . . . . .	249
Table 321.	NVIC_GetFaultAddress function . . . . .	250
Table 322.	SystemHandler types . . . . .	250
Table 323.	PWR registers . . . . .	251
Table 324.	PWR firmware library functions . . . . .	252
Table 325.	PWR_DeInit function . . . . .	252
Table 326.	PWR_BackupAccessCmd function . . . . .	253
Table 327.	PWR_PVDCmd function . . . . .	253
Table 328.	PWR_PVDLevelConfig function . . . . .	254
Table 329.	PWR_PVDLevel values . . . . .	254
Table 330.	PWR_WakeUpPinCmd function . . . . .	255
Table 331.	PWR_EnterSTOPMode function . . . . .	255
Table 332.	PWR_Regulator definition . . . . .	256
Table 333.	PWR_STOPEntry definition . . . . .	256
Table 334.	PWR_EnterSTANDBYMode function . . . . .	256
Table 335.	PWR_GetFlagStatus function . . . . .	257
Table 336.	PWR_Flag values . . . . .	257
Table 337.	PWR_ClearFlag function . . . . .	258
Table 338.	RCC registers . . . . .	259
Table 339.	RCC firmware library functions . . . . .	260
Table 340.	RCC_DeInit function . . . . .	262
Table 341.	RCC_HSEConfig function . . . . .	262
Table 342.	RCC_HSE definition . . . . .	263
Table 343.	RCC_WaitForHSEStartUp function . . . . .	263
Table 344.	RCC_AdjustHSICalibrationValue function . . . . .	264
Table 345.	RCC_HSICmd function . . . . .	264
Table 346.	RCC_PLLConfig function . . . . .	265
Table 347.	RCC_PLLSource definition . . . . .	265
Table 348.	RCC_PLLMul definition . . . . .	265
Table 349.	RCC_PLLCmd function . . . . .	266
Table 350.	RCC_SYSCLKConfig function . . . . .	267
Table 351.	RCC_SYSCLKSource definition . . . . .	267
Table 352.	RCC_GetSYSCLKSource function . . . . .	268
Table 353.	RCC_HCLKConfig function . . . . .	269
Table 354.	RCC_HCLK values . . . . .	269
Table 355.	RCC_PCLK1Config function . . . . .	270
Table 356.	RCC_PCLK1 values . . . . .	270
Table 357.	RCC_PCLK2Config function . . . . .	271
Table 358.	RCC_PCLK2 values . . . . .	271
Table 359.	RCC_ITConfig function . . . . .	272
Table 360.	RCC_IT values . . . . .	272

Table 361.	RCC_USBCLKConfig function . . . . .	273
Table 362.	RCC_USBCLKSource values . . . . .	273
Table 363.	RCC_ADCCLKConfig function . . . . .	274
Table 364.	RCC_ADCCLK values . . . . .	274
Table 365.	RCC_LSEConfig function . . . . .	275
Table 366.	RCC_LSE values . . . . .	275
Table 367.	RCC_LSICmd function . . . . .	276
Table 368.	RCC_RTCCLKConfig function . . . . .	276
Table 369.	RCC_RTCCLKSource values . . . . .	277
Table 370.	RCC_RTCCLKCmd function . . . . .	277
Table 371.	RCC_GetClocksFreq function . . . . .	278
Table 372.	RCC_AHBPeriphClockCmd function . . . . .	279
Table 373.	RCC_AHBPeriph values . . . . .	279
Table 374.	RCC_APB2PeriphClockCmd function . . . . .	280
Table 375.	RCC_APB2Periph values . . . . .	280
Table 376.	RCC_APB1PeriphClockCmd function . . . . .	281
Table 377.	RCC_APB1Periph values . . . . .	281
Table 378.	RCC_APB2PeriphResetCmd function . . . . .	282
Table 379.	RCC_APB1PeriphResetCmd function . . . . .	283
Table 380.	RCC_BackupResetCmd function . . . . .	283
Table 381.	RCC_ClockSecuritySystemCmd function . . . . .	284
Table 382.	RCC_MCOConfig function . . . . .	284
Table 383.	RCC_MCO values . . . . .	285
Table 384.	RCC_GetFlagStatus function . . . . .	285
Table 385.	RCC_FLAG values . . . . .	286
Table 386.	RCC_ClearFlag function . . . . .	287
Table 387.	RCC_GetITStatus function . . . . .	287
Table 388.	RCC_IT values . . . . .	288
Table 389.	RCC_ClearITPendingBit function . . . . .	288
Table 390.	RCC_IT values . . . . .	289
Table 391.	RTC registers . . . . .	291
Table 392.	RTC firmware library functions . . . . .	292
Table 393.	RTC_ITConfig function . . . . .	293
Table 394.	RTC_IT values . . . . .	293
Table 395.	RTC_EnterConfigMode function . . . . .	294
Table 396.	RTC_ExitConfigMode function . . . . .	294
Table 397.	RTC_GetCounter function . . . . .	295
Table 398.	RTC_SetCounter function . . . . .	295
Table 399.	RTC_SetPrescaler function . . . . .	296
Table 400.	RTC_SetAlarm function . . . . .	296
Table 401.	RTC_GetDivider function . . . . .	297
Table 402.	RTC_WaitForLastTask function . . . . .	297
Table 403.	RTC_WaitForSynchro function . . . . .	298
Table 404.	RTC_GetFlagStatus function . . . . .	298
Table 405.	RTC_FLAG values . . . . .	299
Table 406.	RTC_ClearFlag function . . . . .	299
Table 407.	RTC_GetITStatus function . . . . .	300
Table 408.	RTC_ClearITPendingBit function . . . . .	300
Table 409.	SPI registers . . . . .	301
Table 410.	SPI firmware library functions . . . . .	303
Table 411.	SPI_DelInit function . . . . .	304
Table 412.	SPI_Init function . . . . .	304

Table 413.	SPI_Direction definition	305
Table 414.	SPI_Mode definition	305
Table 415.	SPI_DataSize definition	305
Table 416.	SPI_CPOL definition	306
Table 417.	SPI_CPHA definition	306
Table 418.	SPI_NSS definition	306
Table 419.	SPI_BaudRatePrescaler definition	306
Table 420.	SPI_FirstBit definition	307
Table 421.	I2S_Init function	308
Table 422.	I <sup>2</sup> S peripheral configuration	308
Table 423.	Used standard	309
Table 424.	Used data format	309
Table 425.	I <sup>2</sup> S MCLK output	309
Table 426.	Selecting the I <sup>2</sup> S frequency	309
Table 427.	I <sup>2</sup> S clock idle state	310
Table 428.	SPI_StructInit function	310
Table 429.	SPI_InitStruct default values	311
Table 430.	I2S_StructInit function	311
Table 431.	Default I2S_InitStruct values	311
Table 432.	SPI_Cmd function	312
Table 433.	I2S_Cmd function	312
Table 434.	SPI_I2S_ITConfig function	313
Table 435.	SPI_I2S_IT flags	313
Table 436.	SPI_I2S_DMAMCmd function	314
Table 437.	SPI_I2S_DMAMReq values	314
Table 438.	SPI_I2S_SendData function	315
Table 439.	SPI_I2S_ReceiveData function	315
Table 440.	SPI_NSSInternalSoftwareConfig function	316
Table 441.	SPI_NSSInternalSoft values	316
Table 442.	SPI_SSOutputCmd function	317
Table 443.	SPI_DataSizeConfig function	317
Table 444.	SPI_DataSize values	318
Table 445.	SPI_TransmitCRC function	318
Table 446.	SPI_CalculateCRC function	319
Table 447.	SPI_GetCRC function	319
Table 448.	SPI_CRC values	320
Table 449.	SPI_GetCRCPolynomial function	320
Table 450.	SPI_BiDirectionalLineConfig function	321
Table 451.	SPI_Direction values	321
Table 452.	SPI_I2S_GetFlagStatus function	322
Table 453.	SPI_I2S_FLAG flags	322
Table 454.	SPI_I2S_ClearFlag function	323
Table 455.	SPI_I2S_GetITStatus function	324
Table 456.	SPI_I2S_IT flags	324
Table 457.	SPI_I2S_ClearITPendingBit function	325
Table 458.	SysTick registers	326
Table 459.	SysTick firmware library functions	327
Table 460.	SysTick_CLKSourceConfig function	327
Table 461.	SysTick_CLKSource values	328
Table 462.	SysTick_SetReload function	328
Table 463.	SysTick_CounterCmd function	329
Table 464.	SysTick_Counter values	329

Table 465.	SysTick_ITConfig function . . . . .	330
Table 466.	SysTick_GetCounter function . . . . .	330
Table 467.	SysTick_GetFlagStatus function . . . . .	331
Table 468.	SysTick flags . . . . .	331
Table 469.	TIM registers . . . . .	333
Table 470.	TIM firmware library functions . . . . .	336
Table 471.	TIM_DelInit function . . . . .	339
Table 472.	TIM_TimeBaseInit function . . . . .	340
Table 473.	TIM_ClockDivision definition . . . . .	341
Table 474.	TIM_CounterMode definition . . . . .	341
Table 475.	TIM_OC1Init function . . . . .	342
Table 476.	TIM_OCMode definition . . . . .	342
Table 477.	TIM_OutputState definition . . . . .	343
Table 478.	TIM_OutputNState definition . . . . .	343
Table 479.	TIM_OCPolarity definition . . . . .	343
Table 480.	TIM_OCNPolarity definition . . . . .	344
Table 481.	TIM_OCIdleState definition . . . . .	344
Table 482.	TIM_OCNIIdleState definition . . . . .	344
Table 483.	TIM_OC2Init function . . . . .	345
Table 484.	TIM_OC3Init function . . . . .	346
Table 485.	TIM_OC14Init function . . . . .	347
Table 486.	TIM_ICInit function . . . . .	348
Table 487.	TIM_Channel definition . . . . .	348
Table 488.	TIM_ICPolarity definition . . . . .	349
Table 489.	TIM_ICSelection definition . . . . .	349
Table 490.	TIM_ICPrescaler definition . . . . .	349
Table 491.	TIM_PWMConfig function . . . . .	350
Table 492.	TIM_BDTRConfig function . . . . .	351
Table 493.	TIM_OSSRState definition . . . . .	351
Table 494.	TIM_OSSIState definition . . . . .	352
Table 495.	TIM_LOCKLevel definition . . . . .	352
Table 496.	TIM_Break definition . . . . .	352
Table 497.	TIM_BreakPolarity definition . . . . .	352
Table 498.	TIM_AutomaticOutput definition . . . . .	353
Table 499.	TIM_TimeBaseStructInit function . . . . .	353
Table 500.	TIM_TimeBaseInitStruct default values . . . . .	354
Table 501.	TIM_OCStructInit function . . . . .	354
Table 502.	TIM_OCInitStruct default values . . . . .	354
Table 503.	TIM_ICStructInit function . . . . .	355
Table 504.	TIM_ICInitStruct default values . . . . .	355
Table 505.	TIM_BDTRStructInit function . . . . .	356
Table 506.	TIM_BDTRInitStruct default values . . . . .	356
Table 507.	TIM_Cmd function . . . . .	357
Table 508.	TIM_CtrlPWMOutputs function . . . . .	357
Table 509.	TIM_ITConfig function . . . . .	358
Table 510.	TIM_IT values . . . . .	358
Table 511.	TIM_GenerateEvent function . . . . .	359
Table 512.	TIM_EventSource values . . . . .	359
Table 513.	TIM_DMAConfig function . . . . .	360
Table 514.	TIM_DMABase values . . . . .	360
Table 515.	TIM_DMABurstLength values . . . . .	361
Table 516.	TIM_DMACmd function . . . . .	362

Table 517.	TIM_DMASource values . . . . .	362
Table 518.	TIM DMA requests . . . . .	363
Table 519.	TIM_InternalClockConfig function . . . . .	363
Table 520.	TIM_ITRxExternalClockConfig function . . . . .	364
Table 521.	TIM_InputTriggerSource values . . . . .	364
Table 522.	TIM_TlxEternalClockConfig function . . . . .	365
Table 523.	TIM_TlxEternalCLKSource values . . . . .	365
Table 524.	TIM_ETRClockMode1Config function . . . . .	366
Table 525.	TIM_ExtTRGPrescaler values . . . . .	366
Table 526.	TIM_ExtTRGPolarity values . . . . .	367
Table 527.	TIM_ETRClockMode2Config function . . . . .	367
Table 528.	TIM_ETRConfig function . . . . .	368
Table 529.	TIM_PrescalerConfig function . . . . .	369
Table 530.	TIM_PSCReloadMode values . . . . .	369
Table 531.	TIM_CounterModeConfig function . . . . .	370
Table 532.	TIM_SelectInputTrigger function . . . . .	370
Table 533.	TIM_InputTriggerSource values . . . . .	371
Table 534.	TIM_EncoderInterfaceConfig function . . . . .	371
Table 535.	TIM_EncoderMode definition . . . . .	372
Table 536.	TIM_ForcedOC1Config function . . . . .	372
Table 537.	TIM_ForcedAction values . . . . .	372
Table 538.	TIM_ForcedOC2Config function . . . . .	373
Table 539.	TIM_ForcedOC3Config function . . . . .	373
Table 540.	TIM_ForcedOC4Config function . . . . .	374
Table 541.	TIM_ARRPreloadConfig function . . . . .	374
Table 542.	TIM_SelectCOM function . . . . .	375
Table 543.	TIM_SelectCCDMA function . . . . .	375
Table 544.	TIM_CCPreloadControl function . . . . .	376
Table 545.	TIM_OC1PreloadConfig function . . . . .	376
Table 546.	TIM_OCPreload states . . . . .	377
Table 547.	TIM_OC2PreloadConfig function . . . . .	377
Table 548.	TIM_OC3PreloadConfig function . . . . .	378
Table 549.	TIM_OC4PreloadConfig function . . . . .	378
Table 550.	TIM_OC1FastConfig function . . . . .	379
Table 551.	TIM_OCFast states . . . . .	379
Table 552.	TIM_OC2FastConfig function . . . . .	380
Table 553.	TIM_OC3FastConfig function . . . . .	380
Table 554.	TIM_OC4FastConfig function . . . . .	381
Table 555.	TIM_ClearOC1Ref function . . . . .	381
Table 556.	TIM_OCClear . . . . .	382
Table 557.	TIM_ClearOC2Ref function . . . . .	382
Table 558.	TIM_ClearOC3Ref function . . . . .	383
Table 559.	TIM_ClearOC4Ref function . . . . .	383
Table 560.	TIM_OC1PolarityConfig function . . . . .	384
Table 561.	TIM_OCPolarity values . . . . .	384
Table 562.	TIM_OC1NPolarityConfig function . . . . .	385
Table 563.	TIM_OC2PolarityConfig function . . . . .	385
Table 564.	TIM_OC2NPolarityConfig function . . . . .	386
Table 565.	TIM_OC3PolarityConfig function . . . . .	386
Table 566.	TIM_OC3NPolarityConfig function . . . . .	387
Table 567.	TIM_OC4PolarityConfig function . . . . .	387
Table 568.	TIM_CCxCmd function . . . . .	388

Table 569.	TIM_CCxNCmd function . . . . .	388
Table 570.	TIM_SelectOCxM function . . . . .	389
Table 571.	TIM_OCMode definition . . . . .	389
Table 572.	TIM_UpdateDisableConfig function . . . . .	390
Table 573.	TIM_UpdateRequestConfig function . . . . .	390
Table 574.	TIM_UpdateSource values . . . . .	391
Table 575.	TIM_SelectHallSensor function . . . . .	391
Table 576.	TIM_SelectOnePulseMode function . . . . .	392
Table 577.	TIM_OPMode definition . . . . .	392
Table 578.	TIM_SelectOutputTrigger function . . . . .	393
Table 579.	TIM8TRGOSource values . . . . .	393
Table 580.	TIM_SelectSlaveMode function . . . . .	394
Table 581.	TIM_SlaveMode definition . . . . .	394
Table 582.	TIM_SelectMasterSlaveMode function . . . . .	395
Table 583.	TIM_MasterSlaveMode definition . . . . .	395
Table 584.	TIM_SetCounter function . . . . .	395
Table 585.	TIM_SetAutoreload function . . . . .	396
Table 586.	TIM_SetCompare1 function . . . . .	396
Table 587.	TIM_SetCompare2 function . . . . .	397
Table 588.	TIM_SetCompare3 function . . . . .	397
Table 589.	TIM_SetCompare4 function . . . . .	398
Table 590.	TIM_SetIC1Prescaler function . . . . .	398
Table 591.	TIM_ICPrescaler values . . . . .	399
Table 592.	TIM_SetIC2Prescaler function . . . . .	399
Table 593.	TIM_SetIC3Prescaler function . . . . .	400
Table 594.	TIM_SetIC4Prescaler function . . . . .	400
Table 595.	TIM_SetClockDivision function . . . . .	401
Table 596.	TIM_CKD values . . . . .	401
Table 597.	TIM_GetCapture1 function . . . . .	401
Table 598.	TIM_GetCapture2 function . . . . .	402
Table 599.	TIM_GetCapture3 function . . . . .	402
Table 600.	TIM_GetCapture4 function . . . . .	403
Table 601.	TIM_GetCounter function . . . . .	403
Table 602.	TIM_GetPrescaler function . . . . .	404
Table 603.	TIM_GetFlagStatus function . . . . .	404
Table 604.	TIM_FLAG definition . . . . .	405
Table 605.	TIM_ClearFlag function . . . . .	406
Table 606.	TIM_GetITStatus function . . . . .	406
Table 607.	TIM_ClearITPendingBit function . . . . .	407
Table 608.	USART registers . . . . .	408
Table 609.	USART firmware library functions . . . . .	411
Table 610.	USART_DeInit function . . . . .	412
Table 611.	USART_Init function . . . . .	412
Table 612.	USART_InitTypeDef members versus USART mode . . . . .	413
Table 613.	USART_WordLength definition . . . . .	413
Table 614.	USART_StopBits definition . . . . .	414
Table 615.	USART_Parity definition . . . . .	414
Table 616.	USART_HardwareFlowControl definition . . . . .	414
Table 617.	USART_Mode definition . . . . .	415
Table 618.	USART_StructInit function . . . . .	416
Table 619.	USART_InitStruct default values . . . . .	416
Table 620.	USART_ClockInit function . . . . .	417



Table 621.	USART_Clock definition . . . . .	417
Table 622.	USART_CPOL definition . . . . .	418
Table 623.	USART_CPHA definition . . . . .	418
Table 624.	USART_LastBit definition . . . . .	418
Table 625.	USART_ClockStructInit function . . . . .	419
Table 626.	USART_ClockInitStruct default values . . . . .	419
Table 627.	USART_Cmd function . . . . .	420
Table 628.	USART_ITConfig function . . . . .	420
Table 629.	USART_IT values . . . . .	421
Table 630.	USART_DMAMCmd function . . . . .	421
Table 631.	USART_DMAREq values . . . . .	422
Table 632.	USART_SetAddress function . . . . .	422
Table 633.	USART_WakeUpConfig function . . . . .	423
Table 634.	USART_WakeUp values . . . . .	423
Table 635.	USART_ReceiverWakeUpCmd function . . . . .	424
Table 636.	USART_LINBreakDetectLengthConfig function . . . . .	424
Table 637.	USART_LINBreakDetectionLength values . . . . .	425
Table 638.	USART_LINCmd function . . . . .	425
Table 639.	USART_SendData function . . . . .	426
Table 640.	USART_ReceiveData function . . . . .	426
Table 641.	USART_SendBreak function . . . . .	427
Table 642.	USART_SetGuardTime function . . . . .	427
Table 643.	USART_SetPrescaler function . . . . .	428
Table 644.	USART_SmartCardCmd function . . . . .	428
Table 645.	USART_SmartCardNACKCmd function . . . . .	429
Table 646.	USART_HalfDuplexCmd function . . . . .	429
Table 647.	USART_IrDAConfig function . . . . .	430
Table 648.	USART_IrDAMode values . . . . .	430
Table 649.	USART_IrDACmd function . . . . .	431
Table 650.	USART_GetFlagStatus function . . . . .	431
Table 651.	USART_FLAG definition . . . . .	432
Table 652.	USART_ClearFlag function . . . . .	432
Table 653.	USART_GetITStatus function . . . . .	433
Table 654.	USART_IT definition . . . . .	433
Table 655.	USART_ClearITPendingBit function . . . . .	434
Table 656.	WWDG registers . . . . .	435
Table 657.	WWDG firmware library functions . . . . .	436
Table 658.	WWDG_DeInit function . . . . .	436
Table 659.	WWDG_SetPrescaler function . . . . .	437
Table 660.	WWDG_Prescaler values . . . . .	437
Table 661.	WWDG_SetWindowValue function . . . . .	438
Table 662.	WWDG_EnableIT function . . . . .	438
Table 663.	WWDG_SetCounter function . . . . .	439
Table 664.	WWDG_Enable function . . . . .	439
Table 665.	WWDG_GetFlagStatus function . . . . .	440
Table 666.	WWDG_ClearFlag function . . . . .	440
Table 667.	DAC registers . . . . .	441
Table 668.	DAC firmware library functions . . . . .	443
Table 669.	DAC_DeInit function . . . . .	443
Table 670.	DAC_Init function . . . . .	444
Table 671.	DAC_Channel definition . . . . .	444
Table 672.	DAC_Trigger definition . . . . .	445

Table 673.	DAC_WaveGeneration definition . . . . .	445
Table 674.	DAC_LFSRUNmask_TriangleAmplitude definition . . . . .	445
Table 675.	DAC_OutputBuffer definition . . . . .	446
Table 676.	DAC_StructInit function . . . . .	447
Table 677.	DAC_InitStruct definition. . . . .	447
Table 678.	DAC_Cmd function . . . . .	448
Table 679.	DAC_DMAMCmd function . . . . .	448
Table 680.	DAC_SoftwareTriggerCmd function . . . . .	449
Table 681.	DAC_DualSoftwareTriggerCmd function . . . . .	449
Table 682.	DAC_WaveGenerationCmd function . . . . .	450
Table 683.	Dac_Wave definition. . . . .	450
Table 684.	DAC_SetChannel1Data function . . . . .	451
Table 685.	DAC_Align definition. . . . .	451
Table 686.	DAC_SetChannel2Data function . . . . .	452
Table 687.	DAC_SetDualChannelData function. . . . .	453
Table 688.	DAC_GetDataOutputValue function . . . . .	454
Table 689.	FSMC registers . . . . .	456
Table 690.	FSMC firmware library functions. . . . .	458
Table 691.	FSMC_NORSRAMDeInit function . . . . .	459
Table 692.	FSMC_Bank definition . . . . .	459
Table 693.	FSMC_NANDDeInit function . . . . .	460
Table 694.	FSMC_Bank definition . . . . .	460
Table 695.	FSMC_PCCARDeInit function . . . . .	461
Table 696.	FSMC_NORSRAMInit function. . . . .	461
Table 697.	FSMC_AccessMode definition . . . . .	463
Table 698.	FSMC_Bank definition . . . . .	463
Table 699.	FSMC_DataAddressMux definition. . . . .	464
Table 700.	FSMC_MemoryType definition . . . . .	464
Table 701.	FSMC_MemoryDataWidth definition . . . . .	464
Table 702.	FSMC_BurstAccessMode definition . . . . .	464
Table 703.	FSMC_WaitSignalPolarity definition . . . . .	465
Table 704.	FSMC_WrapMode definition. . . . .	465
Table 705.	FSMC_WaitTiming definition . . . . .	465
Table 706.	FSMC_WriteOperation definition . . . . .	465
Table 707.	FSMC_WaitSignal defintiion . . . . .	466
Table 708.	FSMC_ExtendedMode defintiion . . . . .	466
Table 709.	FSMC_AsyncWait definition . . . . .	466
Table 710.	FSMC_WriteBurst definition . . . . .	466
Table 711.	FSMC_NANDInit function. . . . .	468
Table 712.	FSMC_Bank definition . . . . .	469
Table 713.	FSMC_Waitfeature definition . . . . .	469
Table 714.	FSMC_MemoryDataWidth definition . . . . .	470
Table 715.	FSMC_ECC definition. . . . .	470
Table 716.	FSMC_ECCPageSize definition . . . . .	470
Table 717.	FSMC_AddressLowMapping definition. . . . .	470
Table 718.	FSMC_PCCARDInit function . . . . .	472
Table 719.	FSMC_Waitfeature definition . . . . .	473
Table 720.	FSMC_AddressLowMapping definition. . . . .	473
Table 721.	FSMC_NORSRAMStructInit function . . . . .	475
Table 722.	FSMC_NORSRAMInitStruct member definition . . . . .	475
Table 723.	FSMC_NANDStructInit function . . . . .	476
Table 724.	FSMC_NANDInitStruct member definitions . . . . .	476



Table 725.	FSMC_PCCARDStructInit function . . . . .	477
Table 726.	FSMC_PCCARDInitStruct member definition . . . . .	478
Table 727.	FSMC_NORSRAMCmd function . . . . .	479
Table 728.	FSMC_NANDCmd function . . . . .	479
Table 729.	FSMC_PCCARDCmd function . . . . .	480
Table 730.	FSMC_PCCARDCmd function . . . . .	480
Table 731.	FSMC_NANDECCCmd function . . . . .	481
Table 732.	FSMC_ITConfig function . . . . .	481
Table 733.	FSMC_IT definition . . . . .	482
Table 734.	FSMC_GetFlagStatus function . . . . .	482
Table 735.	FSMC_FLAG definition . . . . .	482
Table 736.	FSMC_ClearFlag function . . . . .	483
Table 737.	FSMC_GetITStatus function . . . . .	484
Table 738.	FSMC_ClearITPendingBit function . . . . .	484
Table 739.	SDIO registers . . . . .	485
Table 740.	SDIO firmware library functions . . . . .	487
Table 741.	SDIO_DeInit function . . . . .	488
Table 742.	SDIO_Init function . . . . .	488
Table 743.	SDIO_ClockEdge definition . . . . .	489
Table 744.	SDIO_MCLKBypass definition . . . . .	489
Table 745.	SDIO_ClockPowerSave definition . . . . .	489
Table 746.	SDIO_BusWide definition . . . . .	490
Table 747.	SDIO_HardwareFlowControl definition . . . . .	490
Table 748.	SDIO_StructInit function . . . . .	491
Table 749.	SDIO_InitStruct member definition . . . . .	491
Table 750.	SDIO_ClockCmd function . . . . .	492
Table 751.	SDIO_SetPowerState function . . . . .	492
Table 752.	SDIO_PowerState definition . . . . .	492
Table 753.	SDIO_GetPowerState function . . . . .	493
Table 754.	SDIO_ITConfig function . . . . .	493
Table 755.	SDIO_IT definition . . . . .	494
Table 756.	SDIO_DMAMCmd function . . . . .	495
Table 757.	SDIO_SendCommand function . . . . .	495
Table 758.	SDIO_Response definition . . . . .	496
Table 759.	SDIO_Wait definition . . . . .	496
Table 760.	SDIO_CPSM definition . . . . .	497
Table 761.	SDIO_CmdStructInit function . . . . .	497
Table 762.	SDIO_CmdInitStruct member definition . . . . .	497
Table 763.	SDIO_GetCommandResponse function . . . . .	498
Table 764.	SDIO_GetResponse function . . . . .	498
Table 765.	SDIO_RESP definition . . . . .	499
Table 766.	SDIO_DataConfig function . . . . .	499
Table 767.	SDIO_DataBlockSize definition . . . . .	500
Table 768.	SDIO_TransferDir definition . . . . .	500
Table 769.	SDIO_TransferMode definition . . . . .	501
Table 770.	SDIO_DPSM definition . . . . .	501
Table 771.	SDIO_DataStructInit function . . . . .	501
Table 772.	SDIO_DataInitStruct member definition . . . . .	502
Table 773.	SDIO_GetDataCounter function . . . . .	502
Table 774.	SDIO_ReadData function . . . . .	503
Table 775.	SDIO_WriteData function . . . . .	503
Table 776.	SDIO_GetFIFOCount function . . . . .	504

Table 777.	SDIO_StartSDIOReadWait function . . . . .	504
Table 778.	SDIO_StopSDIOReadWait function . . . . .	505
Table 779.	SDIO_SetSDIOReadWaitMode function . . . . .	505
Table 780.	SDIO_SetSDIOOperation function . . . . .	506
Table 781.	SDIO_SendSDIOSuspendCmd function . . . . .	506
Table 782.	SDIO_CommandCompletionCmd function . . . . .	507
Table 783.	SDIO_CEATAITCmd function . . . . .	507
Table 784.	SDIO_SendCEATACmd function . . . . .	508
Table 785.	SDIO_GetFlagStatus function . . . . .	508
Table 786.	SDIO_FLAG definition . . . . .	509
Table 787.	SDIO_ClearFlag function . . . . .	510
Table 788.	SDIO_FLAG definition . . . . .	510
Table 789.	SDIO_GetITStatus function . . . . .	511
Table 790.	SDIO_ClearITPendingBit function . . . . .	511
Table 791.	SDIO_IT definitions. . . . .	512
Table 792.	DBGMCU registers . . . . .	513
Table 793.	DBGMCU firmware library functions. . . . .	514
Table 794.	DBGMCU_GetREVID function . . . . .	514
Table 795.	DBGMCU_GetDEVID function . . . . .	515
Table 796.	DBGMCU_Config function . . . . .	515
Table 797.	DBGMCU_Periph definition . . . . .	516
Table 798.	CRC registers . . . . .	517
Table 799.	CRC firmware library functions . . . . .	518
Table 800.	CRC_ResetDR function . . . . .	518
Table 801.	CRC_CalcCRC function . . . . .	519
Table 802.	CRC_CalcBlockCRC function. . . . .	519
Table 803.	CRC_GetCRC function. . . . .	520
Table 804.	CRC_SetIDRegister function . . . . .	520
Table 805.	CRC_GetIDRegister function . . . . .	521
Table 806.	Revision history . . . . .	522

List of figures

Figure 1.   Firmware library folder structure . . . . . 42

Figure 2.   Firmware library file architecture . . . . . 45

# 1 Document and library rules

The user manual and the firmware library use the conventions described in the sections below.

## 1.1 Acronyms

[Table 1](#) describes the acronyms used in this document.

**Table 1. List of abbreviations**

Acronym	Peripheral / Unit
ADC	Analog/digital converter
BKP	Backup registers
CAN	Controller area network
CRC	CRC calculation unit
DAC	Digital to analog converter (DAC)
DBGMCU	Debug MCU
DMA	DMA controller
EXTI	External interrupt/event controller
FSMC	Flexible static memory controller
FLASH	Flash memory
GPIO	General purpose I/O
I <sup>2</sup> C	Inter-integrated circuit
I <sup>2</sup> S	Inter-integrated sound
IWDG	Independent watchdog
NVIC	Nested vectored interrupt controller
PWR	Power control
RCC	Reset and clock controller
RTC	Real-time clock
SDIO	SDIO interface
SPI	Serial peripheral interface
SysTick	System tick timer
TIM	Advanced-control, general-purpose or basic timer
USART	Universal synchronous asynchronous receiver transmitter
WWDG	Window watchdog

## 1.2 Naming conventions

The firmware library uses the following naming conventions:

- **PPP** refers to any peripheral acronym, for example **ADC**. See [Section 1.1: Acronyms](#) for more information.
- System and source/header file names are preceded by 'stm32f10x\_', for example *stm32f10x\_conf.h*.
- Constants used in one file are defined within this file. A constant used in more than one file is defined in a header file. All constants are written in upper case.
- Registers are considered as constants. Their names are in upper case. In most cases, the same acronyms as in the STM32F10x reference manual document are used.
- Names of peripheral functions are preceded by the corresponding peripheral acronym in upper case followed by an underscore. The first letter in each word is in upper case, for example **USART\_SendData**. Only one underscore is allowed in a function name to separate the peripheral acronym from the rest of the function name.
- Functions used to initialize the PPP peripheral according to parameters specified in **PPP\_InitTypeDef** are named **PPP\_Init**, for example **TIM\_Init**.
- Functions used to reset the PPP peripheral registers to their default values are named **PPP\_DeInit**, for example **TIM\_DeInit**.
- Functions used to fill the **PPP\_InitTypeDef** structure with the reset values of each member are named **PPP\_StructInit**, for example **USART\_StructInit**.
- Functions used to enable or disable the specified PPP peripheral are named **PPP\_Cmd**, for example **USART\_Cmd**.
- Functions used to enable or disable an interrupt source of the specified PPP peripheral are named **PPP\_ITConfig**, for example **RCC\_ITConfig**.
- Functions used to enable or disable the DMA interface of the specified PPP peripheral are named **PPP\_DMAConfig**, for example **TIM\_DMAConfig**.
- Functions used to configure a peripheral function always end with the string 'Config', for example **GPIO\_PinRemapConfig**.
- Functions used to check whether the specified PPP flag is set or reset are named **PPP\_GetFlagStatus**, for example **I2C\_GetFlagStatus**.
- Functions used to clear a PPP flag are named **PPP\_ClearFlag**, for example **I2C\_ClearFlag**.
- Functions used to check whether the specified PPP interrupt has occurred or not are named **PPP\_GetITStatus**, for example **I2C\_GetITStatus**.
- Functions used to clear a PPP interrupt pending bit are named **PPP\_ClearITPendingBit**, for example **I2C\_ClearITPendingBit**.

## 1.3 Coding rules

This section describes the coding rules used in the firmware Library.

### 1.3.1 Variables

24 specific variable types are defined. Their type and size are fixed. These types are defined in the file *stm32f10x\_type.h*:

```
typedef signed long   s32;
typedef signed short  s16;
typedef signed char   s8;

typedef signed long   const sc32; /* Read Only */
typedef signed short  const sc16; /* Read Only */
typedef signed char   const sc8;  /* Read Only */

typedef volatile signed long   vs32;
typedef volatile signed short  vs16;
typedef volatile signed char   vs8;

typedef volatile signed long   const vsc32; /* Read Only */
typedef volatile signed short  const vsc16; /* Read Only */
typedef volatile signed char   const vsc8;  /* Read Only */

typedef unsigned long   u32;
typedef unsigned short  u16;
typedef unsigned char   u8;

typedef unsigned long   const uc32; /* Read Only */
typedef unsigned short  const uc16; /* Read Only */
typedef unsigned char   const uc8;  /* Read Only */

typedef volatile unsigned long   vu32;
typedef volatile unsigned short  vu16;
typedef volatile unsigned char   vu8;

typedef volatile unsigned long   const vuc32; /* Read Only */
typedef volatile unsigned short  const vuc16; /* Read Only */
typedef volatile unsigned char   const vuc8;  /* Read Only */
```

### 1.3.2 Boolean type

*bool* type is defined in the *stm32f10x\_type.h* file as:

```
typedef enum
{
    FALSE = 0,
    TRUE  = !FALSE
} bool;
```

### 1.3.3 FlagStatus type

*FlagStatus* type is defined in the file *stm32f10x\_type.h*. Two values can be assigned to this variable: *SET* or *RESET*.

```
typedef enum
{
    RESET = 0,
    SET    = !RESET
} FlagStatus;
```

### 1.3.4 FunctionalState type

*FunctionalState* type is defined in the *stm32f10x\_type.h* file. Two values can be assigned to this variable: *ENABLE* or *DISABLE*.

```
typedef enum
{
    DISABLE = 0,
    ENABLE  = !DISABLE
} FunctionalState;
```

### 1.3.5 ErrorStatus type

*ErrorStatus* type is defined in the *stm32f10x\_type.h* file. Two values can be assigned to this variable: *SUCCESS* or *ERROR*.

```
typedef enum
{
    ERROR    = 0,
    SUCCESS  = !ERROR
} ErrorStatus;
```

### 1.3.6 Peripherals

Pointers to peripherals are used to access the peripheral control registers. They point to data structures that represent the mapping of the peripheral control registers.

#### Peripheral control register structures

*stm32f10x\_map.h* contains the definition of all peripheral structures. The example below illustrates the *SPI* register structure declaration:

```
/*----- Serial Peripheral Interface -----*/
typedef struct
{
    vu16 CR1;
    u16  RESERVED0;
    vu16 CR2;
    u16  RESERVED1;
    vu16 SR;
    u16  RESERVED2;
    vu16 DR;
    u16  RESERVED3;
    vu16 CRCPR;
```

```

    u16  RESERVED4;
    vu16 RXCRCCR;
    u16  RESERVED5;
    vu16 TXCRCCR;
    u16  RESERVED6;
    vu16 I2SCFGR;
    u16  RESERVED7;
    vu16 I2SPR;
    u16  RESERVED8;
} SPI_TypeDef;

```

Register names are the register acronyms written in upper case for each peripheral. RESERVEDi (i being an integer that indexes the reserved field) indicates a reserved field.

### Peripheral declaration

All peripherals are declared in *stm32f10x\_map.h*. The following example shows the declaration of the *SPI* peripheral:

```

#ifndef EXT
#define EXT extern
#endif

...
#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE      PERIPH_BASE
#define APB2PERIPH_BASE      (PERIPH_BASE + 0x10000)
...
/* SPI2 Base Address definition*/
#define SPI2_BASE             (APB1PERIPH_BASE + 0x3800)
...
/* SPI2 peripheral declaration*/
#ifndef DEBUG
...
#ifdef _SPI2
    #define SPI2              ((SPI_TypeDef *) SPI2_BASE)
#endif /*_SPI2 */
...
#else /* DEBUG */
...
#ifdef _SPI2
    EXT SPI_TypeDef           *SPI2;
#endif /*_SPI2 */
...
#endif /* DEBUG */

```

Define the label *\_SPI*, to include the *SPI* peripheral library in your application.

Define the label *\_SPIn*, to access the *SPIn* peripheral registers. For example, the *\_SPI2* label must be defined in *stm32f10x\_conf.h* to be able to access the registers of *SPI2* peripheral. *\_SPI* and *\_SPIn* labels are defined in the *stm32f10x\_conf.h* file as follows:

```

#define _SPI
#define _SPI1
#define _SPI2
#define _SPI3

```



Each peripheral has several dedicated registers which contain different flags. Registers are defined within a dedicated structure for each peripheral. Flags are defined as acronyms written in upper case and preceded by '**PPP\_FLAG\_**'. Flag definition is adapted to each peripheral case and defined in *stm32f10x\_ppp.h*.

To enter DEBUG mode you have to define the label *DEBUG* in the file *stm32f10x\_conf.h*. This creates a pointer to the peripheral structure in SRAM. Debugging consequently becomes easier and all register settings can be obtain by dumping a peripheral variable. In both cases *SPI2* is a pointer to the first address of the *SPI2* peripheral.

The *DEBUG* variable is defined in the *stm32f10x\_conf.h* file as follows:

```
#define DEBUG    1
```

The DEBUG mode is initialized as follows in the *stm32f10x\_lib.c* file:

```
#ifdef DEBUG
void debug(void)
{
    ...
#ifdef _SPI2
    SPI2 = (SPI_TypeDef *) SPI2_BASE;
#endif /*_SPI2 */
    ...
}
#endif /* DEBUG*/
```


- Note:**
- 1 When the DEBUG mode is selected, the ***assert\_param*** macro is expanded and run time checking is enabled in the firmware library code.
  - 2 The DEBUG mode increases the code size and reduces the code performance. For this reason, it is recommended to used it only when debugging the application and to remove it from the final application code.

## 2 Firmware library

### 2.1 Package description

The firmware library is supplied in one single installation file. The execution of the installation file generates one folder, **STM32F10xFWLib**, which contains the following sub-folders:

Figure 1. Firmware library folder structure



### 2.1.1 Examples folder

This **Examples** folder contains, for each peripheral sub-folder, the minimum set of files needed to run a typical example on how to use a peripheral:

- **readme.txt**: - brief text file describing the example and how to make it work,
- **stm32f10x\_conf.h** - header file allowing to configure the peripherals that are used, and containing miscellaneous DEFINE statements,
- **stm32f10x\_it.c** - source file containing the interrupt handlers (the function bodies may be emptied if not used),
- **stm32f10x\_it.h** - header file including all interrupt handler prototypes,
- **main.c** - example of code

*Note:* All the examples are independent from the software toolchain.

### 2.1.2 Library folder

The **Library** folder contains all the subdirectories and files that make up the core of the library:

- **inc** sub-folder contains the firmware library header files. They do not need to be modified by the user:
  - **stm32f10x\_type.h**: common data types and enumeration used in all other files,
  - **stm32f10x\_map.h**: peripherals memory mappings and registers data structures,
  - **stm32f10x\_lib.h**: main header file including all other headers,
  - **stm32f10x\_ppp.h** (one header file per peripheral): Function prototypes, data structures and enumeration.
  - **cortexm3\_macro.h**: header file for cortexm3\_macro.s.
- **src** sub-folder contains the firmware library source files. They do not need to be modified by the user:
  - **stm32f10x\_ppp.c** (one source file per peripheral): function bodies of each peripheral.
  - **stm32f10x\_lib.c**: all peripherals pointers initialization.

*Note:* All library files are coded in Strict ANSI-C and are independent from the software toolchain.

### 2.1.3 Project folder

The **Project** folder contains a standard template project program that compiles all library files plus all the user-modifiable files that are necessary to create a new project:

- **stm32f10x\_conf.h**: configuration header file with all peripherals defined by default.
- **stm32f10x\_it.c**: source file containing the interrupt handlers (the function bodies are empty in this template).
- **stm32f10x\_it.h**: header file including all interrupt handlers prototypes.
- **main.c**: main program body.
- **EWARM, RVMDK, RIDE, HiTOP**: it is used by the toolchain, and refers to the **readme.txt** file located in the same folder.

## 2.2 Description of firmware library files

[Table 2](#) lists and describes the different files used by the firmware library.

The firmware library architecture and file inclusion relationship are shown in [Figure 2](#). Each peripheral has a source code file, *stm32f10x\_ppp.c*, and a header file, *stm32f10x\_ppp.h*. The *stm32f10x\_ppp.c* file contains all the firmware functions required to use the PPP peripheral. A single memory mapping file, *stm32f10x\_map.h*, is supplied for all peripherals. It contains all the register declarations used both in Debug and release modes.


The header file *stm32f10x\_lib.h* includes all the peripheral header files. This is the only file that needs to be included in the user application to interface with the library.

*stm32f10x\_conf.h* is the only file which must be modified by the user. It is used to specify the set of parameters to interface with the library before running any application.

**Table 2. Firmware library files**

File name	Description
<i>stm32f10x_conf.h</i>	Parameter configuration file. It must be modified by the user to define the parameters used to interface with the library before running any application. The user can enable or disable peripherals by using the template and can also change the value of the external Quartz oscillator. This file can also be used to enable the Debug or Release mode before compiling the firmware library.
<i>main.c</i>	Main example program body.
<i>stm32f10x_it.h</i>	Header file including all interrupt handlers prototypes.
<i>stm32f10x_it.c</i>	Peripheral interrupt functions file. The user can modify it by including the code of interrupt functions used in his application. In case of multiple interrupt requests mapped to the same interrupt vector, the function polls the interrupt flags of the peripheral to identify the exact source of the interrupt. The names of these functions are already provided in the firmware library.
<i>stm32f10x_lib.h</i>	Header file including all peripheral header files. It is the only file that has to be included in the user application to interface with the firmware library.
<i>stm32f10x_lib.c</i>	Debug mode initialization file. It includes the definition of variable pointers. Each one points to the first address of a specific peripheral and to the definition of the function which is called when the Debug mode is enabled. This function initializes the defined pointers.
<i>stm32f10x_map.h</i>	This file implements memory mapping and physical registers address definition for both debug and release modes. It is supplied with all peripherals.
<i>stm32f10x_type.h</i>	Common declarations file. It includes common types and constants used by all peripheral drivers.
<i>stm32f10x_ppp.c</i>	Driver source code file of PPP peripheral written in C language.
<i>stm32f10x_ppp.h</i>	Header file of PPP peripheral. It includes the definition of PPP peripheral functions and variables used within these functions.
<i>cortexm3_macro.h</i>	Header file for <i>cortexm3_macro.s</i> .
<i>cortexm3_macro.s</i>	Instruction wrappers for special Cortex-M3 instructions.

Figure 2. Firmware library file architecture



1. Some RCC routines are used:
  - In `PPP_DeInit` function to reset the peripheral
  - To get the clock frequency of the bus to which the communication peripherals are connected.

## 2.3 Peripheral initialization and configuration

This section describes step-by-step how to initialize and configure a peripheral. The peripheral will be referred to as PPP.

1. In the main application file, declare a **PPP\_InitTypeDef** structure, for example:

```
PPP_InitTypeDef  PPP_InitStructure;
```

The `PPP_InitStructure` is a working variable located in data memory area. It allows to initialize one or more PPP instances.

2. Fill the `PPP_InitStructure` variable with the allowed values of the structure member. There are two ways of doing this:

- a) Configuring the whole structure by following the procedure described below:

```
PPP_InitStructure.member1 = val1;
PPP_InitStructure.member2 = val2;
PPP_InitStructure.memberN = valN;
/* where N is the number of the structure members */
```

The previous initialization step can be merged in one single line to optimize the code size:

```
PPP_InitTypeDef  PPP_InitStructure = { val1, val2, ..., valN}
```

- b) Configuring only a few members of the structure: in this case the user should modify the `PPP_InitStructure` variable that has been already filled by a call to the **PPP\_StructInit(..)** function. This ensures that the other members of the `PPP_InitStructure` variable are initialized to the appropriate values (in most cases their default values).

```
PPP_StructInit(&PPP_InitStructure);
PPP_InitStructure.memberX = valX;
PPP_InitStructure.memberY = valY;
/*where X and Y are the members the user wants to configure*/
```

3. Initialize the PPP peripheral by calling the **PPP\_Init(..)** function.

```
PPP_Init(PPP, &PPP_InitStructure);
```

4. At this stage the PPP peripheral is initialized and can be enabled by making a call to **PPP\_Cmd(..)** function.

```
PPP_Cmd(PPP, ENABLE);
```

The PPP peripheral can then be used through a set of dedicated functions. These functions are specific to the peripheral. For more details refer to [Section 3: Peripheral firmware overview](#).

**Note:** 1 Before configuring a peripheral, its clock must be enabled by calling one of the following functions:

```
RCC_AHBPeriphClockCmd(RCC_AHBPeriph_PPPx, ENABLE);
RCC_APB2PeriphClockCmd(RCC_APB2Periph_PPPx, ENABLE);
RCC_APB1PeriphClockCmd(RCC_APB1Periph_PPPx, ENABLE);
```

- 2 **PPP\_DeInit(..)** function can be used to set all PPP peripheral registers to their default values:

```
PPP_DeInit(PPP)
```

- 3 To modify the peripheral settings after configuring the peripheral, the user can proceed as follows:

```
PPP_InitStructure.memberX = valX;
PPP_InitStructure.memberY = valY; /* where X and Y are the only
members that user wants to modify*/
PPP_Init(PPP, &PPP_InitStructure);
```

## 2.4 Bit-Banding

The Cortex-M3 memory map includes two bit-band memory regions. These regions map each word in an alias region of memory to a bit in a bit-band region of memory. Writing to a word in the alias region has the same effect as a read-modify-write operation on the targeted bit in the bit-band region.

All the STM32F10x peripheral registers are mapped in a bit-band region. This feature is consequently intensively used in functions which perform single bit set/reset in order to reduce and optimize code size.

[Section 2.4.1](#) and [Section 2.4.2](#) give a description of how the bit-band access is used in the peripheral firmware library.

### 2.4.1 Mapping formula

The mapping formula shows how to link each word in the alias region to a corresponding target bit in the bit-band region. The mapping formula is given below:

$$\text{bit\_word\_offset} = (\text{byte\_offset} \times 32) + (\text{bit\_number} \times 4)$$

$$\text{bit\_word\_addr} = \text{bit\_band\_base} + \text{bit\_word\_offset}$$

where:

- bit\_word\_offset is the position of the target bit in the bit-band memory region
- bit\_word\_addr is the address of the word in the alias memory region that maps to the targeted bit.
- bit\_band\_base is the starting address of the alias region
- byte\_offset is the number of the byte in the bit-band region that contains the targeted bit
- bit\_number is the bit position (0-7) of the targeted bit.

### 2.4.2 Example of implementation

The following example shows how to map the PLLON[24] bit of RCC\_CR register in the alias region:

```
/* Peripheral base address in the bit-band region */
#define PERIPH_BASE      ((u32)0x40000000)

/* Peripheral address in the alias region */
#define PERIPH_BB_BASE   ((u32)0x42000000)

/* ----- RCC registers bit address in the alias region ----- */
#define RCC_OFFSET       (RCC_BASE - PERIPH_BASE)

/* --- CR Register ---*/
/* Alias word address of PLLON bit */
```

```
#define CR_OFFSET          (RCC_OFFSET + 0x00)
#define PLLON_BitNumber    0x18
#define CR_PLLON_BB        (PERIPH_BB_BASE + (CR_OFFSET * 32
(PLLON_BitNumber * 4))
```

To code a function which enables/disables the PLL, the usual method is the following:

```
...
#define CR_PLLON_Set       ((u32)0x01000000)
#define CR_PLLON_Reset     ((u32)0xFEFFFFFF)
...
void RCC_PLLCmd(FunctionalState NewState)
{
    if (NewState != DISABLE)
    { /* Enable PLL */
        RCC->CR |= CR_PLLON_Set;
    }
    else
    { /* Disable PLL */
        RCC->CR &= CR_PLLON_Reset;
    }
}
```

Using bit-band access this function will be coded as follows:

```
void RCC_PLLCmd(FunctionalState NewState)
{
    *(vu32 *) CR_PLLON_BB = (u32)NewState;
}
```

## 2.5 Run-time checking

The firmware library implements run-time failure detection by checking the input values of all library functions. The run-time checking is achieved by using an ***assert\_param*** macro. This macro is used in all the library functions which have an input parameter. It allows to check that the input value lies within the parameter allowed values.

### Example: *PWR\_ClearFlag* function

*stm32f10x\_pwr.c:*

```
void PWR_ClearFlag(u32 PWR_FLAG)
{
    /* Check the parameters */
    assert_param(IS_PWR_CLEAR_FLAG(PWR_FLAG));
    PWR->CR |= PWR_FLAG << 2;
}
```

*stm32f10x\_pwr.h:*

```
/* PWR Flag */
#define PWR_FLAG_WU          ((u32)0x00000001)
#define PWR_FLAG_SB          ((u32)0x00000002)
#define PWR_FLAG_PVDO        ((u32)0x00000004)
```



```
#define IS_PWR_CLEAR_FLAG(FLAG) (((FLAG) == PWR_FLAG_WU) || ((FLAG) == PWR_FLAG_SB))
```

If the expression passed to the ***assert\_param*** macro is false, the ***assert\_failed*** function is called and returns the name of the source file and the source line number of the call that failed. If the expression is true, no value is returned.

The ***assert\_param*** macro is implemented in ***stm32f10x\_conf.h***:

```
/* Exported macro -----*/
#ifdef  DEBUG
/*****
* Macro Name      : assert_param
* Description      : The assert_param macro is used for function's parameters check.
*                  It is used only if the library is compiled in DEBUG mode.
* Input           : - expr: If expr is false, it calls assert_failed function
*                  which reports the name of the source file and the source
*                  line number of the call that failed.
*                  If expr is true, it returns no value.
* Return          : None
*****/
#define assert_param(expr) ((expr) ? (void)0 : assert_failed((u8 *)__FILE__,
__LINE__))
/* Exported functions ----- */
void assert_failed(u8* file, u32 line);
#else
#define assert_param(expr) ((void)0)
#endif /* DEBUG */
```

The ***assert\_failed*** function is implemented in the ***main.c*** file or in any other user C file:

```
#ifdef  DEBUG
/*****
* Function name    : assert_failed
* Description      : Reports the name of the source file and the source line number
*                  where the assert_param error has occurred.
* Input           : - file: pointer to the source file name
*                  - line: assert_param error line source number
* Output          : None
* Return          : None
*****/
void assert_failed(u8* file, u32 line)
{
    /* User can add his own implementation to report the file name and line number,
```

```
ex: printf("Wrong parameters value: file %s on line %d\r\n", file, line) */

/* Infinite loop */
while (1)
{
}
}
#endif
```

**Note:** ***The run-time checking, that is the `assert_param` macro, should only be used when the library is compiled in `DEBUG` mode.***

It is recommended to use run-time checking during application code development and debugging, and to remove it from the final application to improve code size and speed (because of the overhead it introduces).

However if the user wants to keep this functionality in his final application, he can re-use the **`assert_param`** macro defined within the library to test the parameter values before calling the library functions.

### 3 Peripheral firmware overview

This section describes in detail each peripheral firmware library. The related functions are fully described, an example of how to use them is provided.

The functions are described in the following format:

**Table 3. Function description format**

Function name	The name of the peripheral function
Function prototype	Prototype declaration
Behavior description	Brief explanation of how the function is executed
Input parameter {x}	Description of the input parameters
Output parameter {x}	Description of the output parameters
Return Value	Value returned by the function
Required preconditions	Requirements before calling the function
Called functions	Other library functions called

## 4 Analog/digital converter (ADC)

The analog/digital converter (ADC) consists of an input multiplexing channel selector feeding an approximation converter. The conversion resolution is of 12 bits.

The data structures used in the ADC firmware library are described in [Section 4.1](#), while [Section 4.2](#) presents the firmware library functions.

### 4.1 ADC register structure

The ADC register structure, *ADC\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
  vu32 SR;
  vu32 CR1;
  vu32 CR2;
  vu32 SMPR1;
  vu32 SMPR2;
  vu32 JOFR1;
  vu32 JOFR2;
  vu32 JOFR3;
  vu32 JOFR4;
  vu32 HTR;
  vu32 LTR;
  vu32 SQR1;
  vu32 SQR2;
  vu32 SQR3;
  vu32 JSQR;
  vu32 JDR1;
  vu32 JDR2;
  vu32 JDR3;
  vu32 JDR4;
  vu32 DR;
} ADC_TypeDef;
```

[Table 4](#) gives the lists of ADC registers:

**Table 4. ADC registers**

Register	Description
SR	ADC Status Register
CR1	ADC Configuration Register1
CR2	ADC Configuration Register2
SMPR1	ADC Sample Time Register1
SMPR2	ADC Sample Time Register2
JOFR1	ADC Offset Register1
JOFR2	ADC Offset Register2

**Table 4. ADC registers (continued)**

Register	Description
JOFR3	ADC Offset Register3
JOFR4	ADC Offset Register4
HTR	ADC High Voltage Threshold Register
LTR	ADC Low Voltage Threshold Register
SQR1	ADC Sequence Selector for Regular group Register1
SQR2	ADC Sequence Selector for Regular group Register2
SQR3	ADC Sequence Selector for Regular group Register3
JSQR	ADC Sequence Selector for Injected group Register
JDR1	ADC Data converted Injected group Register1
JDR2	ADC Data converted Injected group Register2
JDR3	ADC Data converted Injected group Register3
JDR4	ADC Data converted Injected group Register4
DR	ADC Regular group data Register

The two ADC peripherals are declared in *stm32f10x\_map*:

```

...
#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE      PERIPH_BASE
#define APB2PERIPH_BASE      (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE       (PERIPH_BASE + 0x20000)
...
#define ADC1_BASE             (APB2PERIPH_BASE + 0x2400)
#define ADC2_BASE             (APB2PERIPH_BASE + 0x2800)
#define ADC3_BASE             (APB2PERIPH_BASE + 0x3C00)
...
#ifndef DEBUG
...
#ifdef _ADC1
    #define ADC1               ((ADC_TypeDef *) ADC1_BASE)
#endif /* _ADC1 */

#ifdef _ADC2
    #define ADC2               ((ADC_TypeDef *) ADC2_BASE)
#endif /* _ADC2 */

#ifdef _ADC3
    #define ADC3               ((ADC_TypeDef *) ADC3_BASE)
#endif /* _ADC3 */
...
#else /* DEBUG */
...
#ifdef _ADC1
    EXT ADC_TypeDef            *ADC1;
#endif /* _ADC1 */

```

```
#ifdef _ADC2
    EXT ADC_TypeDef          *ADC2;
#endif /*_ADC2 */

#ifdef _ADC3
    EXT ADC_TypeDef          *ADC3;
#endif /*_ADC3 */
...
#endif
```

When using the Debug mode, `_ADC1`, `_ADC2` and `_ADC3` pointers are initialized in *stm32f10x\_lib.c* file:

```
...
#ifdef _ADC1
    ADC1 = (ADC_TypeDef *)  ADC1_BASE;
#endif /*_ADC1 */

#ifdef _ADC2
    ADC2 = (ADC_TypeDef *)  ADC2_BASE;
#endif /*_ADC2 */

#ifdef _ADC3
    ADC3 = (ADC_TypeDef *)  ADC3_BASE;
#endif /*_ADC3 */
...
```

To access the ADC registers, `_ADC`, `_ADC1`, `_ADC2` and `_ADC3` must be defined in *stm32f10x\_conf.h*, as follows:

```
...
#define _ADC
#define _ADC1
#define _ADC2
#define _ADC3
...
```

## 4.2 ADC library functions

[Table 5](#) lists the ADC firmware library functions.

**Table 5. ADC firmware library functions**

Function name	Description
ADC_DeInit	Resets the ADCx peripheral registers to their default reset values.
ADC_Init	Initializes the ADCx peripheral according to the parameters specified in the ADC_InitStruct.
ADC_StructInit	Fills each ADC_InitStruct member with its default value.
ADC_Cmd	Enables or disables the specified ADC peripheral.
ADC_DMACmd	Enables or disables the specified ADC DMA request
ADC_ITConfig	Enables or disables the specified ADC interrupts.
ADC_ResetCalibration	Resets the selected ADC calibration registers
ADC_GetResetCalibrationStatus	Gets the selected ADC reset calibration registers status.
ADC_StartCalibration	Starts the selected ADC calibration process.
ADC_GetCalibrationStatus	Gets the selected ADC calibration status.
ADC_SoftwareStartConvCmd	Enables or disables the selected ADC software start conversion.
ADC_GetSoftwareStartConvStatus	Gets the selected ADC Software start conversion Status.
ADC_DiscModeChannelCountConfig	Configures the discontinuous mode for the selected ADC regular group channel.
ADC_DiscModeCmd	Enables or disables the discontinuous mode on regular group channel for the specified ADC.
ADC_RegularChannelConfig	Configures for the selected ADC regular channel the corresponding rank in the sequencer and the sample time.
ADC_ExternalTrigConvCmd	Enables or disables the ADCx conversion through external trigger
ADC_GetConversionValue	Returns the last ADCx conversion result data for regular channel
ADC_GetDualModeConversionValue	Returns the last ADCs conversion result data in dual mode
ADC_AutoInjectedConvCmd	Enables or disables the selected ADC automatic injected group conversion after regular one
ADC_InjectedDiscModeCmd	Enables or disables the discontinuous mode for injected group channel for the specified ADC
ADC_ExternalTrigInjectedConvConfig	Configures the ADCx external trigger for injected channels conversion

**Table 5. ADC firmware library functions (continued)**

Function name	Description
ADC_ExternalTrigInjectedConvCmd	Enables or disables the ADCx injected channels conversion through external trigger
ADC_SoftwareStartInjectedConvCmd	Enables or disables the selected ADC start of the injected channels conversion
ADC_GetSoftwareStartInjectedConvStatus	Gets the selected ADC Software start injected conversion Status.
ADC_InjectedChannelConfig	Configures for the selected ADC injected channel its corresponding rank in the sequencer and its sample time.
ADC_InjectedSequencerLengthConfig	Configures the sequencer length for injected channels
ADC_SetInjectedOffset	Sets the injected channels conversion value offset
ADC_GetInjectedConversionValue	Returns the ADC conversion result data for the selected injected channel
ADC_AnalogWatchdogCmd	Enables or disables the analog watchdog on single/all regular or injected channels
ADC_AnalogWatchdogThresholdsConfig	Configures the high and low thresholds of the analog watchdog
ADC_AnalogWatchdogSingleChannelConfig	Configures the analog watchdog guarded single channel
ADC_TempSensorVrefintCmd	Enables or disables the temperature sensor and Vrefint channel.
ADC_GetFlagStatus	Checks whether the specified ADC flag is set or not.
ADC_ClearFlag	Clears the ADCx pending flags.
ADC_GetITStatus	Checks whether the specified ADC interrupt has occurred or not.
ADC_ClearITPendingBit	Clears the ADCx interrupt pending bits.

#### 4.2.1 ADC\_DelInit function

[Table 6](#) describes the ADC\_DelInit function.

**Table 6. ADC\_DelInit function**

Function name	ADC_DelInit
Function prototype	void ADC_DelInit(ADC_TypeDef* ADCx)
Behavior description	Resets the ADCx peripheral registers to their default reset values.
Input parameter	ADCx: where x can be either 1 or 2 to select ADC peripheral ADC1 or ADC2.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_APB2PeriphClockCmd().



**Example:**

```
/* Resets ADC2 */
ADC_DeInit(ADC2);
```

**4.2.2 ADC\_Init function**

[Table 7](#) describes the ADC\_Init function.

**Table 7. ADC\_Init function**

Function name	ADC_Init
Function prototype	void ADC_Init(ADC_TypeDef* ADCx, ADC_InitTypeDef* ADC_InitStruct)
Behavior description	Initializes the ADCx peripheral according to the parameters specified in the ADC_InitStruct.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_InitStruct: pointer to an ADC_InitTypeDef structure that contains the configuration information for the specified ADC peripheral. Refer to the <a href="#">Section 4.2.3: ADC_StructInit function</a> for a full description of the ADC_InitStruct values.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**ADC\_InitTypeDef structure**

The **ADC\_InitTypeDef** structure is defined in the *stm32f10x\_adc.h* file:

```
typedef struct
{
    u32 ADC_Mode;
    FunctionalState ADC_ScanConvMode;
    FunctionalState ADC_ContinuousConvMode;
    u32 ADC_ExternalTrigConv;
    u32 ADC_DataAlign;
    u8 ADC_NbrOfChannel;
} ADC_InitTypeDef
```

**ADC\_Mode**

ADC\_Mode configures the ADC to operate in independent or dual mode. See [Table 8](#) for the values taken by this member.

**Table 8. ADC\_Mode definition**

ADC_Mode	Description
ADC_Mode_Independent	ADC1 and ADC2 operate in independent mode
ADC_Mode_RegInjecSimult	ADC1 and ADC2 operate in simultaneous sample/hold 1 and 2 mode
ADC_Mode_RegSimult_AlterTrig	ADC1 and ADC2 operate in simultaneous sample/hold 2 and Alternate trigger mode
ADC_Mode_InjecSimult_FastInterl	ADC1 and ADC2 operate in simultaneous sample/hold 1 and Interleaved 1 mode
ADC_Mode_InjecSimult_SlowInterl	ADC1 and ADC2 operate in simultaneous sample/hold 1 and Interleaved 2 mode
ADC_Mode_InjecSimult	ADC1 and ADC2 operate in simultaneous sample/hold 1 mode
ADC_Mode_RegSimult	ADC1 and ADC2 operate in simultaneous sample/hold 2 mode
ADC_Mode_FastInterl	ADC1 and ADC2 operate in interleaved 1 mode
ADC_Mode_SlowInterl	ADC1 and ADC2 operate in interleaved 2 mode
ADC_Mode_AlterTrig	ADC1 and ADC2 operate in alternate trigger mode

**ADC\_ScanConvMode**

ADC\_ScanConvMode specifies whether the conversion is performed in Scan (multi-channels) or Single (one channel) mode. This member can be set to ENABLE or DISABLE.

**ADC\_ContinuousConvMode**

ADC\_ContinuousConvMode specifies whether the conversion is performed in Continuous or Single mode. This member can be set to ENABLE or DISABLE.

**ADC\_ExternalTrigConv**

ADC\_ExternalTrigConv defines the external trigger used to start the analog to digital conversion of regular channels. The values taken by this member are given in [Table 9](#).

**Table 9. ADC\_ExternalTrigConv definition**

ADC_ExternalTrigConv	Description
ADC_ExternalTrigConv_T1_CC3	Timer1 Capture Compare3 selected as external trigger conversion (ADC1, ADC2 and ADC3)
ADC_ExternalTrigConv_None	Conversion started by software and not by external trigger (ADC1, ADC2 and ADC3)
ADC_ExternalTrigConv_T1_CC1	Timer1 Capture Compare1 selected as external trigger conversion (ADC1 and ADC2)
ADC_ExternalTrigConv_T1_CC2	Timer1 Capture Compare2 selected as external trigger conversion (ADC1 and ADC2)
ADC_ExternalTrigConv_T2_CC2	Timer2 Capture Compare2 selected as external trigger conversion (ADC1 and ADC2)

**Table 9. ADC\_ExternalTrigConv definition (continued)**

ADC_ExternalTrigConv	Description
ADC_ExternalTrigConv_T3_TRGO	Timer3 TRGO selected as external trigger conversion (ADC1 and ADC2)
ADC_ExternalTrigConv_T4_CC4	Timer4 Capture Compare4 selected as external trigger conversion (ADC1 and ADC2)
ADC_ExternalTrigConv_Ext_IT11_TIM8_TRGO	External interrupt 11 event/Timer8 TRGO selected as external trigger conversion (ADC1 and ADC2)
ADC_ExternalTrigConv_T3_CC1	Timer3 Capture Compare1 selected as external trigger conversion (ADC3 only)
ADC_ExternalTrigConv_T2_CC3	Timer2 Capture Compare3 selected as external trigger conversion (ADC3 only)
ADC_ExternalTrigConv_T8_CC1	Timer8 Capture Compare1 selected as external trigger conversion (ADC3 only)
ADC_ExternalTrigConv_T8_TRGO	Timer8 TRGO selected as external trigger conversion (ADC3 only)
ADC_ExternalTrigConv_T5_CC1	Timer5 Capture Compare1 selected as external trigger conversion (ADC3 only)
ADC_ExternalTrigConv_T5_CC3	Timer5 Capture Compare3 selected as external trigger conversion (ADC3 only)

**Note:** The *TIM8\_TRGO* event exists only in High-density devices. The *EXTI* line11 or *TIM8\_TRGO* external trigger event for regular channels is selected through *AFIO* configuration bits *ADC1\_ETRGREG\_REMAP* and *ADC2\_ETRGREG\_REMAP* for *ADC1* and *ADC2*, respectively.

### ADC\_DataAlign

*ADC\_DataAlign* specifies whether the ADC data alignment is left or right. The values taken by this member are given in [Table 10](#).

**Table 10. ADC\_DataAlign definition**

ADC_DataAlign	Description
ADC_DataAlign_Right	ADC data right aligned
ADC_DataAlign_Left	ADC data left aligned

### ADC\_NbrOfChannel

*ADC\_NbrOfChannel* specifies the number of ADC channels that will be converted using the sequencer for regular channel group. This number must range from 1 to 16.

#### Example:

```
/* Initialize the ADC1 according to the ADC_InitStructure members */
ADC_InitTypeDef  ADC_InitStructure;
ADC_InitStructure.ADC_Mode = ADC_Mode_Independent;
ADC_InitStructure.ADC_ScanConvMode = ENABLE;
ADC_InitStructure.ADC_ContinuousConvMode = DISABLE;
ADC_InitStructure.ADC_ExternalTrigConv =
ADC_ExternalTrigConv_T1_CC3;
```

```
ADC_InitStructure.ADC_DataAlign = ADC_DataAlign_Right;
ADC_InitStructure.ADC_NbrOfChannel = 16;
ADC_Init(ADC1, &ADC_InitStructure);
```

**Note:** To correctly configure the ADC channels conversion, the user must call the `ADC_ChannelConfig()` function after `ADC_Init()` to configure the sequencer rank and sample time for each used channel.

### 4.2.3 ADC\_StructInit function

[Table 11](#) describes the `ADC_StructInit` function.

**Table 11. ADC\_StructInit function**

Function name	ADC_StructInit
Function prototype	void ADC_StructInit(ADC_InitTypeDef* ADC_InitStruct)
Behavior description	Fills each ADC_InitStruct member with its default value.
Input parameter	ADC_InitStruct: pointer to the ADC_InitTypeDef structure to initialize.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The ADC\_InitStruct members have the following default values:

**Table 12. ADC\_IniyStruct default values**

Member	Default value
ADC_Mode	ADC_Mode_Independent
ADC_ScanConvMode	DISABLE
ADC_ContinuousConvMode	DISABLE
ADC_ExternalTrigConv	ADC_ExternalTrigConv_T1_CC1
ADC_DataAlign	ADC_DataAlign_Right
ADC_NbrOfChannel	1

**Example:**

```
/* Initialize a ADC_InitTypeDef structure. */
ADC_InitTypeDef ADC_InitStructure;
ADC_StructInit(&ADC_InitStructure);
```

#### 4.2.4 ADC\_Cmd function

[Table 13](#) describes the ADC\_Cmd function.

**Table 13. ADC\_Cmd function**

Function name	Description
Function name	ADC_Cmd
Function prototype	void ADC_Cmd(ADC_TypeDef* ADCx, FunctionalState NewState)
Behavior description	Enables or disables the specified ADC peripheral.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	NewState: new state of the ADCx peripheral. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable ADC1 */
ADC_Cmd(ADC1, ENABLE);
```

*Note:* The ADC\_Cmd function must be called after all other ADC configuration functions.

#### 4.2.5 ADC\_DMACmd function

[Table 14](#) describes the ADC\_DMACmd function.

**Table 14. ADC\_DMACmd function**

Function name	ADC_DMACmd
Function prototype	ADC_DMACmd(ADC_TypeDef* ADCx, FunctionalState NewState)
Behavior description	Enables or disables the specified ADC DMA request.
Input parameter1	ADCx: where x can be 1 or 3 to select ADC1 or ADC3 peripheral.
Input parameter2	NewState: new state of the ADC DMA transfer. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable ADC1 DMA transfer */
ADC_DMACmd(ADC1, ENABLE);
```

## 4.2.6 ADC\_ITConfig function

[Table 15](#) describes the ADC\_ITConfig function.

**Table 15. ADC\_ITConfig function**

Function name	ADC_ITConfig
Function prototype	void ADC_ITConfig(ADC_TypeDef* ADCx, u16 ADC_IT, FunctionalState NewState)
Behavior description	Enables or disables the specified ADC interrupts.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_IT: specifies the ADC interrupt sources to be enabled or disabled. Refer to <a href="#">ADC_IT</a> for details on the allowed values for this parameter.
Input parameter3	NewState: new state of the specified ADC interrupts. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### ADC\_IT

ADC\_IT is used to enable or disable ADC interrupts. One or a combination of the following values can be used:

**Table 16. ADC\_IT definition**

ADC_IT	Description
ADC_IT_EOC	EOC interrupt mask
ADC_IT_AWD	AWDOG interrupt mask
ADC_IT_JEOC	JEOC interrupt mask

#### Example:

```
/* Enable ADC2 EOC and AWDog interrupts */
ADC_ITConfig(ADC2, ADC_IT_EOC | ADC_IT_AWD, ENABLE);
```

#### 4.2.7 ADC\_ResetCalibration function

[Table 17](#) describes the ADC\_ResetCalibration function.

**Table 17. ADC\_ResetCalibration function**

Function name	ADC_ResetCalibration
Function prototype	void ADC_ResetCalibration(ADC_TypeDef* ADCx)
Behavior description	Resets the selected ADC calibration registers.
Input parameter	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Reset the ADC1 Calibration registers */
ADC_ResetCalibration(ADC1);
```

#### 4.2.8 ADC\_GetResetCalibrationStatus function

[Table 18](#) describes the ADC\_GetResetCalibration function.

**Table 18. ADC\_GetResetCalibration function**

Function name	ADC_GetResetCalibrationStatus
Function prototype	FlagStatus ADC_GetResetCalibrationStatus(ADC_TypeDef* ADCx)
Behavior description	Gets the selected ADC reset calibration registers status.
Input parameter	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Output parameter	None
Return parameter	The new state of ADC Reset Calibration registers (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the ADC2 reset calibration registers status */
FlagStatus Status;
Status = ADC_GetResetCalibrationStatus(ADC2);
```

### 4.2.9 ADC\_StartCalibration function

*Table 19* describes the ADC\_StartCalibration function.

**Table 19. ADC\_StartCalibration function**

Function name	ADC_StartCalibration
Function prototype	void ADC_StartCalibration(ADC_TypeDef* ADCx)
Behavior description	Starts the selected ADC calibration process.
Input parameter	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Start the ADC2 Calibration */
ADC_StartCalibration(ADC2);
```

### 4.2.10 ADC\_GetCalibrationStatus function

*Table 20* describes the ADC\_GetCalibrationStatus function.

**Table 20. ADC\_GetCalibrationStatus function**

Function name	ADC_GetCalibrationStatus
Function prototype	FlagStatus ADC_GetCalibrationStatus(ADC_TypeDef* ADCx)
Behavior description	Gets the selected ADC calibration status.
Input parameter	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Output parameter	None
Return parameter	The new state of ADC Calibration (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the ADC2 calibration status */
FlagStatus Status;
Status = ADC_GetCalibrationStatus(ADC2);
```



#### 4.2.11 ADC\_SoftwareStartConvCmd function

[Table 21](#) describes the ADC\_SoftwareStartConvCmd function.

**Table 21. ADC\_SoftwareStartConvCmd function**

Function name	ADC_SoftwareStartConvCmd
Function prototype	void ADC_SoftwareStartConvCmd(ADC_TypeDef* ADCx, FunctionalState NewState)
Behavior description	Enables or disables the selected ADC software start conversion.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	NewState: new state of the selected ADC software start conversion. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Start by software the ADC1 Conversion */
ADC_SoftwareStartConvCmd(ADC1, ENABLE);
```

#### 4.2.12 ADC\_GetSoftwareStartConvStatus function

[Table 22](#) describes the ADC\_GetSoftwareStartConvStatus function.

**Table 22. ADC\_GetSoftwareStartConvStatus function**

Function name	ADC_GetSoftwareStartConvStatus
Function prototype	FlagStatus ADC_GetSoftwareStartConvStatus(ADC_TypeDef* ADCx)
Behavior description	Gets the selected ADC Software start conversion Status.
Input parameter	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Output parameter	None
Return parameter	The new state of ADC software start conversion (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the ADC1 conversion start bit */
FlagStatus Status;
Status = ADC_GetSoftwareStartConvStatus(ADC1);
```

### 4.2.13 ADC\_DiscModeChannelCountConfig function

[Table 23](#) describes the ADC\_DiscModeChannelCountConfig function.

**Table 23. ADC\_DiscModeChannelCountConfig function**

Function name	ADC_DiscModeChannelCountConfig
Function prototype	void ADC_DiscModeChannelCountConfig(ADC_TypeDef* ADCx, u8 Number)
Behavior description	Configures the discontinuous mode for the selected ADC regular group channel.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	Number: the discontinuous mode regular channel count value. This number ranges from 1 to 8.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set the discontinuous mode channel count to 2 for ADC1 */
ADC_DiscModeChannelCountConfig(ADC1, 2);
```

### 4.2.14 ADC\_DiscModeCmd function

[Table 24](#) describes the ADC\_DiscModeCmd function.

**Table 24. ADC\_DiscModeCmd function**

Function name	ADC_DiscModeCmd
Function prototype	void ADC_DiscModeCmd(ADC_TypeDef* ADCx, FunctionalState NewState)
Behavior description	Enables or disables the discontinuous mode on regular group channel for the specified ADC
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	NewState: new state of the ADC discontinuous mode on regular group channel. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the discontinuous mode for ADC1 regular group channel */
ADC_DiscModeCmd(ADC1, ENABLE);
```

### 4.2.15 ADC\_RegularChannelConfig function

[Table 25](#) describes the ADC\_RegularChannelConfig function.

**Table 25. ADC\_RegularChannelConfig function**

Function name	ADC_RegularChannelConfig
Function prototype	void ADC_RegularChannelConfig(ADC_TypeDef* ADCx, u8 ADC_Channel, u8 Rank, u8 ADC_SampleTime)
Behavior description	Configures for the selected ADC regular channel its corresponding rank in the sequencer and its sample time.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_Channel: the ADC channel to be configured. Refer to <a href="#">ADC_Channel</a> for details on the allowed values for this parameter.
Input parameter3	Rank: The rank in the regular group sequencer. This parameter ranges from 1 to 16.
Input parameter4	ADC_SampleTime: The sample time value to be set for the selected channel. Refer to section <a href="#">ADC_SampleTime</a> for details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### ADC\_Channel

The ADC\_Channel parameter specifies the ADC channel that will be configured by issuing a ADC\_RegularChannelConfig function. [Table 26](#) shows the values taken by ADC\_Channel:

**Table 26. ADC\_Channel values**

ADC_Channel	Description
ADC_Channel_0	ADC Channel0 selected
ADC_Channel_1	ADC Channel1 selected
ADC_Channel_2	ADC Channel2 selected
ADC_Channel_3	ADC Channel3 selected
ADC_Channel_4	ADC Channel4 selected
ADC_Channel_5	ADC Channel5 selected
ADC_Channel_6	ADC Channel6 selected
ADC_Channel_7	ADC Channel7 selected
ADC_Channel_8	ADC Channel8 selected
ADC_Channel_9	ADC Channel9 selected

**Table 26. ADC\_Channel values (continued)**

ADC_Channel	Description
ADC_Channel_10	ADC Channel10 selected
ADC_Channel_11	ADC Channel11 selected
ADC_Channel_12	ADC Channel12 selected
ADC_Channel_13	ADC Channel13 selected
ADC_Channel_14	ADC Channel14 selected
ADC_Channel_15	ADC Channel15 selected
ADC_Channel_16	ADC Channel16 selected
ADC_Channel_17	ADC Channel17 selected

**ADC\_SampleTime**

This parameter specifies the ADC samples time for the selected channel. [Table 27](#) gives the values taken by ADC\_SampleTime.

**Table 27. ADC\_SampleTime values**

ADC_SampleTime	Description
ADC_SampleTime_1Cycles5	Sample time equal to 1.5 cycles
ADC_SampleTime_7Cycles5	Sample time equal to 7.5 cycles
ADC_SampleTime_13Cycles5	Sample time equal to 13.5 cycles
ADC_SampleTime_28Cycles5	Sample time equal to 28.5 cycles
ADC_SampleTime_41Cycles5	Sample time equal to 41.5 cycles
ADC_SampleTime_55Cycles5	Sample time equal to 55.5 cycles
ADC_SampleTime_71Cycles5	Sample time equal to 71.5 cycles
ADC_SampleTime_239Cycles5	Sample time equal to 239.5 cycles

**Example:**

```
/* Configures ADC1 Channel2 as: first converted channel with an 7.5
cycles sample time */
ADC-RegularChannelConfig(ADC1, ADC_Channel_2, 1,
ADC_SampleTime_7Cycles5);

/* Configures ADC1 Channel8 as: second converted channel with an 1.5
cycles sample time */
ADC-RegularChannelConfig(ADC1, ADC_Channel_8, 2,
ADC_SampleTime_1Cycles5);
```

#### 4.2.16 ADC\_ExternalTrigConvCmd function

*Table 28* describes the ADC\_ExternalTrigConvCmd function.

**Table 28. ADC\_ExternalTrigConvCmd function**

Function name	ADC_ExternalTrigConvCmd
Function prototype	void ADC_ExternalTrigConvCmd(ADC_TypeDef* ADCx, FunctionalState NewState)
Behavior description	Enables or disables the ADCx conversion through external Trigger.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	NewState: new state of the selected ADC external trigger starting the conversion. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/*Enable the start of conversion for ADC1 through external trigger */
ADC_ExternalTrigConvCmd(ADC1, ENABLE);
```

#### 4.2.17 ADC\_GetConversionValue function

*Table 29* describes the ADC\_GetConversionValue function.

**Table 29. ADC\_GetConversionValue function**

Function name	ADC_GetConversionValue
Function prototype	u16 ADC_GetConversionValue(ADC_TypeDef* ADCx)
Behavior description	Returns the last ADCx conversion result data for regular channel.
Input parameter	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Output parameter	None
Return parameter	The Data conversion value.
Required preconditions	None
Called functions	None

**Example:**

```
/*Returns the ADC1 Master data value of the last converted channel*/
u16 DataValue;
DataValue = ADC_GetConversionValue(ADC1);
```

#### 4.2.18 ADC\_GetDualModeConversionValue function

*Table 30* describes the ADC\_GetDualModeConversionValue function.

**Table 30. ADC\_GetDualModeConversionValue function**

Function name	ADC_GetDualModeConversionValue
Function prototype	u32 ADC_GetDualModeConversionValue()
Behavior description	Returns the last ADC converted data in dual mode
Output parameter	None
Return parameter	The Data conversion value.
Required preconditions	None
Called functions	None

**Example:**

```
/* Returns the ADC1 and ADC2 last converted values*/
u32 DataValue;
DataValue = ADC_GetDualModeConversionValue();
```

#### 4.2.19 ADC\_AutoInjectedConvCmd function

*Table 31* describes the ADC\_AutoInjectedConvCmd function.

**Table 31. ADC\_AutoInjectedConvCmd function**

Function name	ADC_AutoInjectedConvCmd
Function prototype	void ADC_AutoInjectedConvCmd(ADC_TypeDef* ADCx, FunctionalState NewState)
Behavior description	Enables or disables the selected ADC automatic injected group conversion after regular group.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	NewState: new state of the selected ADC auto injected conversion. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the auto injected conversion for ADC2 */
ADC_AutoInjectedConvCmd(ADC2, ENABLE);
```

#### 4.2.20 ADC\_InjectedDiscModeCmd function

[Table 32](#) describes the ADC\_InjectedDiscModeCmd function.

**Table 32. ADC\_InjectedDiscModeCmd function**

Function name	ADC_InjectedDiscModeCmd
Function prototype	void ADC_InjectedDiscModeCmd(ADC_TypeDef* ADCx, FunctionalState NewState)
Behavior description	Enables or disables the discontinuous mode for injected group channel for the specified ADC
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	NewState: new state of the selected ADC discontinuous mode on injected group channel. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the injected discontinuous mode for ADC2 */
ADC_InjectedDiscModeCmd(ADC2, ENABLE);
```

#### 4.2.21 ADC\_ExternalTrigInjectedConvConfig function

[Table 33](#) describes the ADC\_ExternalTrigInjectedConvConfig function.

**Table 33. ADC\_ExternalTrigInjectedConvConfig function**

Function name	ADC_ExternalTrigInjectedConvConfig
Function prototype	void ADC_ExternalTrigInjectedConvConfig(ADC_TypeDef* ADCx, u32 ADC_ExternalTrigInjecConv)
Behavior description	Configures the ADCx external trigger for injected channels conversion.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_ExternalTrigInjecConv: the ADC trigger to start injected conversion. Refer to <a href="#">ADC_ExternalTrigInjecConv</a> for details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**ADC\_ExternalTrigInjecConv**

This parameter specifies the ADC trigger that is used to start injected conversion. [Table 34](#) gives the values taken by ADC\_ExternalTrigInjecConv.

**Table 34. ADC\_ExternalTrigInjecConv values**

ADC_ExternalTrigInjecConv	Description
ADC_ExternalTrigInjecConv_T1_TRGO	Timer1 TRGO event selected as external trigger for injected conversion (ADC1, ADC2 and ADC3)
ADC_ExternalTrigInjecConv_T1_CC4	Timer1 capture compare4 selected as external trigger for injected conversion (ADC1, ADC2 and ADC3)
ADC_ExternalTrigInjecConv_None	Injected conversion started by software and not by external trigger (ADC1, ADC2 and ADC3)
ADC_ExternalTrigInjecConv_T2_TRGO	Timer2 TRGO selected as external trigger for injected conversion (ADC1 and ADC2)
ADC_ExternalTrigInjecConv_T2_CC1	Timer2 capture compare1 selected as external trigger for injected conversion (ADC1 and ADC2)
ADC_ExternalTrigInjecConv_T3_CC4	Timer3 capture compare4 selected as external trigger for injected conversion (ADC1 and ADC2)
ADC_ExternalTrigInjecConv_T4_TRGO	Timer4 TRGO selected as external trigger for injected conversion (ADC1 and ADC2)
ADC_ExternalTrigInjecConv_Ext_IT15_TIM8_CC4	External interrupt 15 event/Timer8 capture compare4 selected as external trigger for injected conversion (ADC1 and ADC2)
ADC_ExternalTrigInjecConv_T4_CC3	Timer4 capture compare3 selected as external trigger for injected conversion (ADC3 only)
ADC_ExternalTrigInjecConv_T8_CC2	Timer8 capture compare2 selected as external trigger for injected conversion (ADC3 only)
ADC_ExternalTrigInjecConv_T8_CC4	Timer8 capture compare4 selected as external trigger for injected conversion (ADC3 only)
ADC_ExternalTrigInjecConv_T5_TRGO	Timer5 TRGO selected as external trigger for injected conversion (ADC3 only)
ADC_ExternalTrigInjecConv_T5_CC4	Timer5 capture compare4 selected as external trigger for injected conversion (ADC3 only)

**Note:** The TIM8\_CC4 event exists only in High-density devices. The EXTI line15 or TIM8\_CC4 external trigger event for injected channels is selected through AFIO configuration bits ADC1\_ETRGINJ\_REMAP and ADC2\_ETRGINJ\_REMAP for ADC1 and ADC2, respectively.

**Example:**

```
/* Set ADC1 injected external trigger conversion start to Timer1
capture compare4 */
ADC_ExternalTrigInjectedConvConfig(ADC1,
ADC_ExternalTrigConv_T1_CC4);
```



#### 4.2.22 ADC\_ExternalTrigInjectedConvCmd function

[Table 35](#) describes the ADC\_ExternalTrigInjectedConvCmd function.

**Table 35. ADC\_ExternalTrigInjectedConvCmd function**

Function name	ADC_ExternalTrigInjectedConvCmd
Function prototype	void ADC_ExternalTrigInjectedConvCmd(ADC_TypeDef* ADCx, FunctionalState NewState)
Behavior description	Enables or disables the ADCx injected channels conversion through external trigger
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	NewState: new state of the selected ADC external trigger used to start injected conversion. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the start of injected conversion for ADC1 through external
trigger */
ADC_ExternalTrigInjectedConvCmd(ADC1, ENABLE);
```

#### 4.2.23 ADC\_SoftwareStartInjectedConvCmd function

[Table 36](#) describes the ADC\_SoftwareStartInjectedConvCmd function.

**Table 36. ADC\_SoftwareStartInjectedConvCmd function**

Function name	ADC_SoftwareStartInjectedConvCmd
Function prototype	void ADC_SoftwareStartInjectedConvCmd(ADC_TypeDef* ADCx, FunctionalState NewState)
Behavior description	Enables or disables the start of the injected channels conversion.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	NewState: new state of the selected ADC software used to start injected conversion. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Start by software the ADC2 Conversion */
ADC_SoftwareStartInjectedConvCmd(ADC2, ENABLE);
```

#### 4.2.24 ADC\_GetSoftwareStartInjectedConvStatus function

[Table 37](#) describes the ADC\_GetSoftwareStartInjectedConvStatus function.

**Table 37. ADC\_GetSoftwareStartInjectedConvStatus function**

Function name	ADC_GetSoftwareStartInjectedConvStatus
Function prototype	FlagStatus ADC_GetSoftwareStartInjectedConvStatus(ADC_TypeDef* ADCx)
Behavior description	Gets the selected ADC Software start injected conversion Status.
Input parameter	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Output parameter	None
Return parameter	The new state of ADC software start injected conversion (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the ADC1 injected conversion start bit */  
FlagStatus Status;  
Status = ADC_GetSoftwareStartInjectedConvStatus(ADC1);
```

## 4.2.25 ADC\_InjectedChannelConfig function

[Table 38](#) describes the ADC\_InjectedChannelConfig function.

**Table 38. ADC\_InjectedChannelConfig function**

Function name	ADC_InjectedChannelConfig
Function prototype	void ADC_InjectedChannelConfig(ADC_TypeDef* ADCx, u8 ADC_Channel, u8 Rank, u8 ADC_SampleTime)
Behavior description	Configures for the selected ADC injected channel the corresponding rank in the sequencer and the sample time.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_Channel: ADC channel to be configured. Refer to <a href="#">ADC_Channel</a> for more details on the allowed values for this parameter.
Input parameter3	Rank: The rank in the injected group sequencer. This parameter ranges from 1 to 4.
Input parameter4	ADC_SampleTime: sample time value to be set for the selected channel. Refer to <a href="#">ADC_SampleTime</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	ADC_InjectedSequencerLengthConfig must be called before to specify the total injected channel number. This is necessary specially when this number is less than 4 to properly configure the rank of each injected channel
Called functions	None

### ADC\_Channel

ADC\_Channel specifies the ADC channel to be configured. Refer to [Table 26](#) for the values taken by this parameter.

### ADC\_SampleTime

ADC\_SampleTime specifies the ADC Sample Time for the selected channel. Refer to [Table 27](#) for the values taken by this parameter.

#### Example:

```
/* Configures ADC1 Channel12 as: second converted channel with a
28.5 cycle sample time */
ADC_InjectedChannelConfig(ADC1, ADC_Channel_12, 2,
ADC_SampleTime_28Cycles5);

/* Configures ADC2 Channel4 as: fourth converted channel with a 71.5
cycle sample time */
ADC_InjectedChannelConfig(ADC2, ADC_Channel_4, 4,
ADC_SampleTime_71Cycles5);
```

#### 4.2.26 ADC\_InjectedSequencerLengthConfig function

[Table 39](#) describes the ADC\_InjectedSequencerLengthConfig function.

**Table 39. ADC\_InjectedSequencerLengthConfig function**

Function name	ADC_InjectedSequencerLengthConfig
Function prototype	void ADC_InjectedSequencerLengthConfig(ADC_TypeDef* ADCx, u8 Length)
Behavior description	Configures the sequencer length for injected channels
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	Length: sequencer length. This parameter ranges from 1 to 4.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set the ADC1 Sequencer length to 4 channels */
ADC_InjectedSequencerLengthConfig(ADC1, 4);
```

#### 4.2.27 ADC\_SetInjectedOffset function

[Table 40](#) describes the ADC\_SetInjectedOffset function.

**Table 40. ADC\_SetInjectedOffset function**

Function name	ADC_SetInjectedOffset
Function prototype	void ADC_SetInjectedOffset(ADC_TypeDef* ADCx, u8 ADC_InjectedChannel, u16 Offset)
Behavior description	Set the injected channels conversion offset value
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_InjectedChannel: ADC injected channel for which the offset must be set Refer to <a href="#">ADC_InjectedChannel</a> for more details on the allowed values for this parameter.
Input parameter3	Offset: offset value for the selected ADC injected channel This parameter is a 12-bit value.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### ADC\_InjectedChannel

ADC\_InjectedChannel specifies the ADC injected channel for which the offset must be set. [Table 41](#) gives the values of this parameter.

**Table 41. ADC\_InjectedChannel values**

ADC_InjectedChannel	Description
ADC_InjectedChannel_1	Injected Channel1 selected
ADC_InjectedChannel_2	Injected Channel2 selected
ADC_InjectedChannel_3	Injected Channel3 selected
ADC_InjectedChannel_4	Injected Channel4 selected

**Example:**

```
/* Set the offset 0x100 for the 3rd injected Channel of ADC1 */
ADC_SetInjectedOffset(ADC1, ADC_InjectedChannel_3, 0x100);
```

## 4.2.28 ADC\_GetInjectedConversionValue function

[Table 42](#) describes the ADC\_GetInjectedConversionValue function.

**Table 42. ADC\_GetInjectedConversionValue function**

Function name	ADC_GetInjectedConversionValue
Function prototype	u16 ADC_GetInjectedConversionValue(ADC_TypeDef* ADCx, u8 ADC_InjectedChannel)
Behavior description	Returns the selected ADC injected channel conversion result
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_InjectedChannel: converted ADC injected channel. Refer to <a href="#">ADC_InjectedChannel</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	Data conversion value.
Required preconditions	None
Called functions	None

**Example:**

```
/* Return the ADC1 injected channel1 converted data value */
u16 InjectedDataValue;
InjectedDataValue = ADC_GetInjectedConversionValue(ADC1,
ADC_InjectedChannel_1);
```

## 4.2.29 ADC\_AnalogWatchdogCmd function

[Table 43](#) describes the ADC\_AnalogWatchdogCmd function.

**Table 43. ADC\_AnalogWatchdogCmd function**

Function name	ADC_AnalogWatchdogCmd
Function prototype	void ADC_AnalogWatchdogCmd(ADC_TypeDef* ADCx, u32 ADC_AnalogWatchdog)
Behavior description	Enables or disables the analog watchdog on one or all regular or injected channels
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_AnalogWatchdog: ADC analog watchdog configuration. Refer to <a href="#">ADC_AnalogWatchdog</a> for more details on the values taken by this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### ADC\_AnalogWatchdog

ADC\_AnalogWatchdog specifies the ADC analog watchdog configuration. [Table 44](#) gives the value taken by this parameter.

**Table 44. ADC\_AnalogWatchdog values**

ADC_AnalogWatchdog	Description
ADC_AnalogWatchdog_SingleRegEnable	Analog watchdog on a single regular channel
ADC_AnalogWatchdog_SingleInjecEnable	Analog watchdog on a single injected channel
ADC_AnalogWatchdog_SingleRegorInjecEnable	Analog watchdog on a single regular or injected channel
ADC_AnalogWatchdog_AllRegEnable	Analog watchdog on all regular channels
ADC_AnalogWatchdog_AllInjecEnable	Analog watchdog on all injected channels
ADC_AnalogWatchdog_AllRegAllInjecEnable	Analog watchdog on all regular and injected channels
ADC_AnalogWatchdog_None	No channel guarded by the analog watchdog

#### Example:

```
/* Configure the Analog watchdog on all regular and injected channels
of ADC2 */
ADC_AnalogWatchdogCmd(ADC2,
ADC_AnalogWatchdog_AllRegAllInjecEnable);
```

### 4.2.30 ADC\_AnalogWatchdogThresholdsConfig function

*Table 45* describes the ADC\_AnalogWatchdogThresholdsConfig function.

**Table 45. ADC\_AnalogWatchdogThresholdsConfig function**

Function name	ADC_AnalogWatchdogThresholdsConfig
Function prototype	void ADC_AnalogWatchdogThresholdsConfig(ADC_TypeDef* ADCx, u16 HighThreshold, u16 LowThreshold)
Behavior description	Configures the high and low thresholds of the analog watchdog
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	HighThreshold: ADC analog watchdog High threshold value. This parameter must be a 12-bit value.
Input parameter3	LowThreshold: ADC analog watchdog Low threshold value. This parameter must be a 12-bit value.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Configure the Analog watchdog High and Low thresholds for ADC1 */
ADC_AnalogWatchdogThresholdsConfig(ADC1, 0x400, 0x100);
```

### 4.2.31 ADC\_AnalogWatchdogSingleChannelConfig function

*Table 46* describes the AnalogWatchdogSingleChannelConfig function.

**Table 46. AnalogWatchdogSingleChannelConfig function**

Function name	ADC_AnalogWatchdogSingleChannelConfig
Function prototype	void ADC_AnalogWatchdogSingleChannelConfig(ADC_TypeDef* ADCx, u8 ADC_Channel)
Behavior description	Configures the analog watchdog guarded single channel
Input parameter1	ADCx: where x can be 1, 2 or 3 to select ADC1, ADC2 or ADC3 peripheral
Input parameter2	ADC_Channel: ADC channel for which the analog watchdog will be configured. Refer to <a href="#">ADC_Channel</a> or more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Configure the Analog watchdog on Channel1 of ADC1 */
ADC_AnalogWatchdogSingleChannelConfig(ADC1, ADC_Channel_1);
```

### 4.2.32 ADC\_TempSensorVrefintCmd function

[Table 47](#) describes the ADC\_TempSensorVrefintCmd function.

**Table 47. ADC\_TempSensorVrefintCmd function**

Function name	ADC_TempSensorVrefintCmd
Function prototype	void ADC_TempSensorVrefintCmd(FunctionalState NewState)
Behavior description	Enables or disables the temperature sensor and Vrefint channel.
Input parameter	NewState: new state of the temperature sensor and Vrefint channel This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the temperature sensor and vref internal channel */
ADC_TempSensorVrefintCmd(ENABLE);
```

### 4.2.33 ADC\_GetFlagStatus function

[Table 48](#) describes the ADC\_GetFlagStatus function.

**Table 48. ADC\_GetFlagStatus function**

Function name	ADC_GetFlagStatus
Function prototype	FlagStatus ADC_GetFlagStatus(ADC_TypeDef* ADCx, u8 ADC_FLAG)
Behavior description	Checks whether the specified ADC flag is set or not.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_FLAG: specifies the flag to check. Refer to <a href="#">ADC_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	New state of ADC_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

#### ADC\_FLAG

The values of the ADC\_FLAG are given in [Table 49](#).



**Table 49. ADC\_FLAG values**

ADC_FLAG	Description
ADC_FLAG_AWD	Analog watchdog flag
ADC_FLAG_EOC	End of conversion flag
ADC_FLAG_JEOC	End of injected group conversion flag
ADC_FLAG_JSTRT	Start of injected group conversion flag
ADC_FLAG_STRT	Start of regular group conversion flag

**Example:**

```
/* Test if the ADC1 EOC flag is set or not */
FlagStatus Status;
Status = ADC_GetFlagStatus(ADC1, ADC_FLAG_EOC);
```

**4.2.34 ADC\_ClearFlag function**

[Table 50](#) describes the ADC\_ClearFlag function.

**Table 50. ADC\_ClearFlag function**

Function name	ADC_ClearFlag
Function prototype	void ADC_ClearFlag(ADC_TypeDef* ADCx, u8 ADC_FLAG)
Behavior description	Clears the ADCx's pending flags.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_FLAG: flag to clear. More than one flag can be cleared using the “ ” operator. Refer to <a href="#">ADC_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the ADC2 STRT pending flag */
ADC_ClearFlag(ADC2, ADC_FLAG_STRT);
```

### 4.2.35 ADC\_GetITStatus function

[Table 51](#) describes the ADC\_GetITStatus function.

**Table 51. ADC\_GetITStatus function**

Function name	ADC_GetITStatus
Function prototype	ITStatus ADC_GetITStatus(ADC_TypeDef* ADCx, u16 ADC_IT)
Behavior description	Checks whether the specified ADC interrupt has occurred or not.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_IT: ADC interrupt source to check. Refer to <a href="#">ADC_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of ADC_IT (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Test if the ADC1 AWD interrupt has occurred or not */
ITStatus Status;
Status = ADC_GetITStatus(ADC1, ADC_IT_AWD);
```

### 4.2.36 ADC\_ClearITPendingBit function

[Table 52](#) describes the ADC\_ClearITPendingBit function.

**Table 52. ADC\_ClearITPendingBit function**

Function name	ADC_ClearITPending Bit
Function prototype	void ADC_ClearITPendingBit(ADC_TypeDef* ADCx, u16 ADC_IT)
Behavior description	Clears the ADCx's interrupt pending bits.
Input parameter1	ADCx: where x can be 1, 2 or 3 to select the ADC1, ADC2 or ADC3 peripheral.
Input parameter2	ADC_IT: interrupt pending bit to clear. Refer to <a href="#">ADC_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the ADC2 JEOP interrupt pending bit */
ADC_ClearITPendingBit(ADC2, ADC_IT_JEOP);
```

## 5 Backup registers (BKP)

There are forty-two 16-bit backup registers used to store 84 bytes of user application data. They are implemented in the backup domain that remains powered on by  $V_{BAT}$  when  $V_{DD}$  is switched off.

The BKP registers are also used to manage Tamper detection feature and RTC calibration.

[Section 5.1: BKP register structure](#) describes the data structures used in the BKP firmware library. [Section 5.2: Firmware library functions](#) presents the firmware library functions.

### 5.1 BKP register structure

The BKP register structure, *BKP\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    u32   RESERVED0;
    vu16  DR1;
    u16   RESERVED1;
    vu16  DR2;
    u16   RESERVED2;
    vu16  DR3;
    u16   RESERVED3;
    vu16  DR4;
    u16   RESERVED4;
    vu16  DR5;
    u16   RESERVED5;
    vu16  DR6;
    u16   RESERVED6;
    vu16  DR7;
    u16   RESERVED7;
    vu16  DR8;
    u16   RESERVED8;
    vu16  DR9;
    u16   RESERVED9;
    vu16  DR10;
    u16   RESERVED10;
    vu16  RTCCR;
    u16   RESERVED11;
    vu16  CR;
    u16   RESERVED12;
    vu16  CSR;
    u16   RESERVED13[5];
    vu16  DR11;
    u16   RESERVED14;
    vu16  DR12;
    u16   RESERVED15;
    vu16  DR13;
    u16   RESERVED16;
    vu16  DR14;
    u16   RESERVED17;
```

```
vu16 DR15;  
u16  RESERVED18;  
vu16 DR16;  
u16  RESERVED19;  
vu16 DR17;  
u16  RESERVED20;  
vu16 DR18;  
u16  RESERVED21;  
vu16 DR19;  
u16  RESERVED22;  
vu16 DR20;  
u16  RESERVED23;  
vu16 DR21;  
u16  RESERVED24;  
vu16 DR22;  
u16  RESERVED25;  
vu16 DR23;  
u16  RESERVED26;  
vu16 DR24;  
u16  RESERVED27;  
vu16 DR25;  
u16  RESERVED28;  
vu16 DR26;  
u16  RESERVED29;  
vu16 DR27;  
u16  RESERVED30;  
vu16 DR28;  
u16  RESERVED31;  
vu16 DR29;  
u16  RESERVED32;  
vu16 DR30;  
u16  RESERVED33;  
vu16 DR31;  
u16  RESERVED34;  
vu16 DR32;  
u16  RESERVED35;  
vu16 DR33;  
u16  RESERVED36;  
vu16 DR34;  
u16  RESERVED37;  
vu16 DR35;  
u16  RESERVED38;  
vu16 DR36;  
u16  RESERVED39;  
vu16 DR37;  
u16  RESERVED40;  
vu16 DR38;  
u16  RESERVED41;  
vu16 DR39;  
u16  RESERVED42;  
vu16 DR40;  
u16  RESERVED43;
```

```

vu16 DR41;
u16  RESERVED44;
vu16 DR42;
u16  RESERVED45;
} BKP_TypeDef;

```

[Table 53](#) gives the list of the BKP registers:

**Table 53. BKP registers**

Register	Description
DR 1-10	Data Backup Register 1 to 42
RTCCR	RTC Clock Calibration Register
CR	Backup Control Register
CSR	Backup Control Status Register

The BKP peripheral is also declared in *stm32f10x\_map.h*:

```

#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE     PERIPH_BASE
#define APB2PERIPH_BASE     (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE      (PERIPH_BASE + 0x20000)
#define BKP_BASE             (APB1PERIPH_BASE + 0x6C00)
#ifndef DEBUG
...
#endif
#define _BKP
    #define BKP                ((BKP_TypeDef *) BKP_BASE)
#endif /* _BKP */
...
#else /* DEBUG */
...
#endif
#define _BKP
    EXT BKP_TypeDef             *BKP;
#endif /* _BKP */
...
#endif

```

When using the Debug mode, the BKP pointer is initialized in *stm32f10x\_lib.c*:

```

#ifdef _BKP
    BKP = (BKP_TypeDef *) BKP_BASE;
#endif /* _BKP */

```

To access the backup registers, `_BKP` must be defined in *stm32f10x\_conf.h*, as follows:

```

#define _BKP

```

## 5.2 Firmware library functions

[Table 54](#) lists the BKP library functions.

**Table 54. BKP library functions**

Function name	Description
BKP_DeInit	Resets the BKP peripheral registers to their default reset values.
BKP_TamperPinLevelConfig	Configures the Tamper Pin active level.
BKP_TamperPinCmd	Enables or disables the Tamper Pin activation.
BKP_ITConfig	Enables or disables the Tamper Pin Interrupt.
BKP_RTCOutputConfig	Selects the RTC output source to output on the Tamper pin.
BKP_SetRTCCalibrationValue	Sets RTC Clock Calibration value.
BKP_WriteBackupRegister	Writes user data to the specified Data Backup Register.
BKP_ReadBackupRegister	Reads data from the specified Data Backup Register.
BKP_GetFlagStatus	Checks whether the Tamper Pin Event flag is set or not.
BKP_ClearFlag	Clears Tamper Pin Event pending flag.
BKP_GetITStatus	Checks whether the Tamper Pin Interrupt has occurred or not.
BKP_ClearITPendingBit	Clears Tamper Pin Interrupt pending bit.

### 5.2.1 BKP\_DeInit function

[Table 55](#) describes the BKP\_DeInit function.

**Table 55. BKP\_DeInit function**

Function name	BKP_DeInit
Function prototype	void BKP_DeInit(void)
Behavior description	Resets the BKP registers to their default reset values.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_BackupResetCmd

**Example:**

```
/* Reset the BKP registers */
BKP_DeInit();
```

### 5.2.2 BKP\_TamperPinLevelConfig function

[Table 56](#) describes the BKP\_TamperPinLevelConfig function.

**Table 56. BKP\_TamperPinLevelConfig function**

Function name	BKP_TamperPinLevelConfig
Function prototype	void BKP_TamperPinLevelConfig(u16 BKP_TamperPinLevel)
Behavior description	Configures the Tamper Pin active level.
Input parameter	BKP_TamperPinLevel: Tamper Pin active level. Refer to <a href="#">BKP_TamperPinLevel</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### BKP\_TamperPinLevel

The BKP\_TamperPinLevel input parameter is used to select the Tamper Pin active level. It can take one of the following values:

**Table 57. BKP\_TamperPinLevel values**

BKP_TamperPinLevel	Description
BKP_TamperPinLevel_High	Tamper pin active on high level
BKP_TamperPinLevel_Low	Tamper pin active on low level

#### Example:

```
/* Configure Tamper pin to be active on high level*/
BKP_TamperPinLevelConfig(BKP_TamperPinLevel_High);
```

### 5.2.3 BKP\_TamperPinCmd function

[Table 58](#) describes the BKP\_TamperPinCmd function.

**Table 58. BKP\_TamperPinCmd function**

Function name	BKP_TamperPinCmd
Function prototype	void BKP_TamperPinCmd(FunctionalState NewState)
Behavior description	Enables or disables the Tamper Pin activation.
Input parameter	NewState: new state of the Tamper Pin activation. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable Tamper Pin functionality */
BKP_TamperPinCmd(ENABLE);
```

**5.2.4 BKP\_ITConfig function**

[Table 59](#) describes the BKP\_ITConfig function.

**Table 59. BKP\_ITConfig function**

Function name	BKP_ITConfig
Function prototype	void BKP_ITConfig(FunctionalState NewState)
Behavior description	Enables or disables the Tamper Pin Interrupt.
Input parameter	NewState: new state of the Tamper Pin Interrupt. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable Tamper Pin interrupt */
BKP_ITConfig(ENABLE);
```

**5.2.5 BKP\_RTCTOutputConfig function**

[Table 60](#) describes the BKP\_RTCTOutputConfig function.

**Table 60. BKP\_RTCTOutputConfig function**

Function name	BKP_RTCTOutputConfig
Function prototype	void BKP_RTCTOutputConfig(u16 BKP_RTCTOutputSource)
Behavior description	Selects the RTC output source to output on the Tamper pin.
Input parameter	BKP_RTCTOutputSource: specifies the RTC output source. Refer to <a href="#">BKP_RTCTOutputSource</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	The Tamper Pin functionality must be disabled before using this function.
Called functions	None



## BKP\_RTCOutputSource

The BKP\_RTCOutputSource input parameter is used to select the RTC output source. It can take one of the following values:

**Table 61. BKP\_RTCOutputSource values**

BKP_RTCOutputSource	Description
BKP_RTCOutputSource_None	No RTC output on the Tamper pin.
BKP_RTCOutputSource_CalibClock	Output the RTC clock with frequency divided by 64 on the Tamper pin
BKP_RTCOutputSource_Alarm	Output the RTC Alarm pulse signal on the Tamper pin.
BKP_RTCOutputSource_Second	Output the RTC Second pulse signal on the Tamper pin.

### Example:

```
/* Output the RTC clock source with frequency divided by 64 on the
Tamper pad(if the Tamper Pin functionality is disabled) */
BKP_RTCOutputConfig(BKP_RTCOutputSource_CalibClock);
```

## 5.2.6 BKP\_SetRTCCalibrationValue function

[Table 62](#) describes the BKP\_SetRTCCalibrationValue function.

**Table 62. BKP\_SetRTCCalibrationValue function**

Function name	BKP_SetRTCCalibrationValue
Function prototype	void BKP_SetRTCCalibrationValue(u8 CalibrationValue)
Behavior description	Sets RTC Clock Calibration value.
Input parameter	CalibrationValue: RTC Clock Calibration value. This parameter ranges from 0 to 0x7F.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### Example:

```
/* Set RTC clock calibration value to 0x7F (maximum) */
BKP_SetRTCCalibrationValue(0x7F);
```

### 5.2.7 BKP\_WriteBackupRegister function

[Table 63](#) describes the BKP\_WriteBackupRegister function.

**Table 63. BKP\_WriteBackupRegister function**

Function name	BKP_WriteBackupRegister
Function prototype	void BKP_WriteBackupRegister(u16 BKP_DR, u16 Data)
Behavior description	Writes user data to the specified Data Backup Register.
Input parameter1	BKP_DR: Data Backup Register. Refer to <a href="#">BKP_DR</a> for more details on the allowed values for this parameter.
Input parameter2	Data: data to write.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### BKP\_DR

BKP\_DR is used to select the Data Backup Register. [Table 64](#) shows the values taken by this parameter.

**Table 64. BKP\_DR values**

BKP_DR	Description
BKP_DRx	Data Backup Register x is selected, where x is a value between 1 and 42

#### Example:

```
/* Write 0xA587 to Data Backup Register1 */
BKP_WriteBackupRegister(BKP_DR1, 0xA587);
```

### 5.2.8 BKP\_ReadBackupRegister function

[Table 65](#) describes the BKP\_ReadBackupRegister function.

**Table 65. BKP\_ReadBackupRegister function**

Function name	BKP_ReadBackupRegister
Function prototype	u16 BKP_ReadBackupRegister(u16 BKP_DR)
Behavior description	Reads data from the specified Data Backup Register.
Input parameter	BKP_DR: Data Backup Register. Refer to <a href="#">BKP_DR</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The content of the specified Data Backup Register.
Required preconditions	None
Called functions	None

**Example:**

```
/* Read Data Backup Register1 */
u16 Data;
Data = BKP_ReadBackupRegister(BKP_DR1);
```

**5.2.9 BKP\_GetFlagStatus function**

[Table 66](#) describes the BKP\_GetFlagStatus function.

**Table 66. BKP\_GetFlagStatus function**

Function name	BKP_GetFlagStatus
Function prototype	FlagStatus BKP_GetFlagStatus(void)
Behavior description	Checks whether the Tamper Pin Event flag is set or not.
Input parameter	None
Output parameter	None
Return parameter	The new state of the Tamper Pin Event flag (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Test if the Tamper Pin Event flag is set or not */
FlagStatus Status;
Status = BKP_GetFlagStatus();
if(Status == RESET)
{
    ...
}
else
{
    ...
}
```

### 5.2.10 BKP\_ClearFlag function

[Table 67](#) describes the BKP\_ClearFlag function.

**Table 67. BKP\_ClearFlag function**

Function name	BKP_ClearFlag
Function prototype	void BKP_ClearFlag(void)
Behavior description	Clears Tamper Pin Event pending flag.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear Tamper Pin Event pending flag */
BKP_ClearFlag();
```

### 5.2.11 BKP\_GetITStatus function

[Table 68](#) describes the BKP\_GetITStatus function.

**Table 68. BKP\_GetITStatus function**

Function name	BKP_GetITStatus
Function prototype	ITStatus BKP_GetITStatus(void)
Behavior description	Checks whether the Tamper Pin Interrupt has occurred or not.
Input parameter	None
Output parameter	None
Return parameter	The new state of the Tamper Pin Interrupt (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Test if the Tamper Pin interrupt has occurred or not */
ITStatus Status;
Status = BKP_GetITStatus();
if (Status == RESET)
{
    ...
}
else
{
    ...
}
```

### 5.2.12 BKP\_ClearITPendingBit function

*Table 69* describes the BKP\_ClearITPendingBit function.

**Table 69. BKP\_ClearITPendingBit function**

Function name	BKP_ClearITPendingBit
Function prototype	void BKP_ClearITPendingBit(void)
Behavior description	Clears Tamper Pin Interrupt pending bit.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear Tamper Pin interrupt pending bit */  
BKP_ClearITPendingBit();
```

## 6 Controller area network (CAN)

This peripheral interfaces the CAN network. It supports the CAN protocols version 2.0A and B. It has been designed to manage efficiently a high number of incoming messages with a minimum CPU load. It also meets the priority requirements for transmit messages.

[Section 6.1](#) describes the data structures used in the CAN firmware library. [Section 6.2](#) presents the firmware library functions.

### 6.1 CAN register structure

The CAN register structure, `CAN_TypeDef`, is defined in `stm32f10x_map.h` as follows:

```
typedef struct
{
    vu32 MCR;
    vu32 MSR;
    vu32 TSR;
    vu32 RF0R;
    vu32 RF1R;
    vu32 IER;
    vu32 ESR;
    vu32 BTR;
    u32 RESERVED0[88];
    CAN_TxMailBox_TypeDef sTxMailBox[3];
    CAN_FIFOMailBox_TypeDef sFIFOMailBox[2];
    u32 RESERVED1[12];
    vu32 FMR;
    vu32 FM0R;
    u32 RESERVED2[1];
    vu32 FS0R;
    u32 RESERVED3[1];
    vu32 FFA0R;
    u32 RESERVED4[1];
    vu32 FA0R;
    u32 RESERVED5[8];
    CAN_FilterRegister_TypeDef sFilterRegister[14];
} CAN_TypeDef;

typedef struct
{
    vu32 TIR;
    vu32 TDTR;
    vu32 TDLR;
    vu32 TDHR;
} CAN_TxMailBox_TypeDef;

typedef struct
{
    vu32 RIR;
    vu32 RDTR;
```

```

    vu32 RDLR;
    vu32 RDHR;
} CAN_FIFOMailBox_TypeDef;
typedef struct
{
    vu32 FR0;
    vu32 FR1;
} CAN_FilterRegister_TypeDef;

```

[Table 70](#) shows the list of all CAN registers.

**Table 70. CAN registers**

Register	Description
CAN_MCR	CAN Master Control Register
CAN_MSR	CAN Master Status Register
CAN_TSR	CAN Transmit Status Register
CAN_RF0R	CAN Receive FIFO 0 Register
CAN_RF1R	CAN Receive FIFO 1 Register
CAN_IER	CAN Interrupt Enable Register
CAN_ESR	CAN Error Status Register
CAN_BTR	CAN Bit Timing Register
TIR	Tx Mailbox Identifier Register
TDTR	Mailbox Data Length Control and Time Stamp Register
TDLR	Mailbox Data Low Register
TDHR	Mailbox Data High Register
RIR	Rx FIFO Mailbox Identifier Register
RDTR	Receive FIFO Mailbox Data Length Control and Time Stamp Register
RDLR	Receive FIFO Mailbox Data Low Register
RDHR	Receive FIFO Mailbox Data High Register
CAN_FMR	CAN Filter Master Register
CAN_FM0R	CAN Filter Mode Register
CAN_FSC0R	CAN Filter Scale Register
CAN_FFA0R	CAN Filter FIFO Assignment Register
CAN_FA0R	CAN Filter Activation Register
CAN_FR0	Filter x Register 0
CAN_FR1	Filter x Register 1

The CAN peripheral is also declared in *stm32f10x\_map.h*:

```

#define PERIPH_BASE          ((u32) 0x40000000)
#define APB1PERIPH_BASE     PERIPH_BASE
#define APB2PERIPH_BASE     (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE      (PERIPH_BASE + 0x20000)

```

```
#define CAN_BASE                (APB1PERIPH_BASE + 0x6400)

#ifndef DEBUG
...
#endif
#define _CAN
    #define CAN                ((CAN_TypeDef *) CAN_BASE)
#endif /* _CAN */
...
#else /* DEBUG */
...
#endif
#define _CAN
    EXT CAN_TypeDef            *CAN;
#endif /* _CAN */
...
#endif
```

When using the Debug mode, the CAN pointer is initialized in *stm32f10x\_lib.c*:

```
#ifdef _CAN
    CAN = (CAN_TypeDef *) CAN_BASE;
#endif /* _CAN */
```

To access the CAN registers, `_CAN` must be defined in *stm32f10x\_conf.h*:

```
#define _CAN
```



## 6.2 Firmware library functions

[Table 71](#) gives the list of the CAN library functions.

**Table 71. CAN firmware library functions**

Function name	Description
CAN_DeInit	Resets the CAN peripheral registers to their default reset values.
CAN_Init	Initializes the CAN peripheral according to the parameters specified in the CAN_InitStruct.
CAN_FilterInit	Initializes the CAN peripheral according to the parameters specified in the CAN_FilterInitStruct.
CAN_StructInit	Fills each CAN_InitStruct member with its default value.
CAN_ITConfig	Enables or disables the specified CAN interrupts.
CAN_Transmit	Initiates the transmission of a message
CAN_TransmitStatus	Checks the transmission of a message
CAN_CancelTransmit	Cancels a transmit request
CAN_FIFORelease	Releases a FIFO
CAN_MessagePending	Returns the number of pending messages
CAN_Receive	Receives a message
CAN_Sleep	Enters the low power mode
CAN_WakeUp	Wakes the CAN up
CAN_GetFlagStatus	Checks whether the specified CAN flag is set or not.
CAN_ClearFlag	Clears the CAN pending flags.
CAN_GetITStatus	Checks whether the specified CAN interrupt has occurred or not.
CAN_ClearITPendingBit	Clears the CAN interrupt pending bits.

## 6.2.1 CAN\_DelInit function

[Table 72](#) describes the CAN\_DelInit function.

**Table 72. CAN\_DelInit function**

Function name	CAN_DelInit
Function prototype	void CAN_DelInit(void)
Behavior description	Resets the CAN peripheral registers to their default reset values.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_APB1PeriphResetCmd()

### Example:

```
/* Deinitialize the CAN */
CAN_DeInit();
```

## 6.2.2 CAN\_Init function

[Table 73](#) describes the CAN\_Init function.

**Table 73. CAN\_Init function**

Function name	CAN_Init
Function prototype	u8 CAN_Init(CAN_InitTypeDef* CAN_InitStruct)
Behavior description	Initializes the CAN peripheral according to the parameters specified in the CAN_InitStruct.
Input parameter	CAN_InitStruct: pointer to a CAN_InitTypeDef structure that contains the configuration information for the CAN peripheral. Refer to <a href="#">CAN_InitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	Constant indicating that the CAN initialization has been successful. CANINITFAILED = initialization failed CANINITOK = initialization successful
Required preconditions	None
Called functions	None

## CAN\_InitTypeDef structure

The CAN\_InitTypeDef structure is defined in the *stm32f10x\_can.h* file:

```
typedef struct
{
    FunctionnalState CAN_TTCM;
    FunctionnalState CAN_ABOM;
    FunctionnalState CAN_AWUM;
    FunctionnalState CAN_NART;
    FunctionnalState CAN_RFLM;
    FunctionnalState CAN_TXFP;
    u8 CAN_Mode;
    u8 CAN_SJW;
    u8 CAN_BS1;
    u8 CAN_BS2;
    u16 CAN_Prescaler;
} CAN_InitTypeDef;
```

### CAN\_TTCM

CAN\_TTCM is used to enable or disable the time triggered communication mode. This member can be set either to ENABLE or DISABLE.

### CAN\_ABOM

CAN\_ABOM is used to enable or disable the automatic bus-off management. This member can be set either to ENABLE or DISABLE.

### CAN\_AWUM

CAN\_AWUM is used to enable or disable the automatic wake-up mode. This member can be set either to ENABLE or DISABLE.

### CAN\_NART

CAN\_NART is used to enable or disable the no-automatic retransmission mode. This member can be either set to ENABLE or DISABLE.

### CAN\_RFLM

CAN\_RFLM is used to enable or disable the Receive Fifo Locked mode. This member can be either set to ENABLE or DISABLE.

### CAN\_TXFP

CAN\_TXFP is used to enable or disable the transmit FIFO priority. This member can be set either to ENABLE or DISABLE.

**CAN\_Mode**

CAN\_Mode configures the CAN operating mode. The values taken by this member are given in [Table 74](#).

**Table 74. CAN\_Mode values**

CAN_Mode	Description
CAN_Mode_Normal	CAN hardware operates in normal mode
CAN_Mode_Silent	CAN hardware operates in silent mode
CAN_Mode_LoopBack	CAN hardware operates in loop back mode
CAN_Mode_Silent_LoopBack	CAN hardware operates in loop back combined with silent mode

**CAN\_SJW**

CAN\_SJW configures the maximum number of time quanta the CAN hardware is allowed to lengthen or shorten a bit to perform resynchronization. The values taken by this member are given in [Table 75](#).

**Table 75. CAN\_SJW values**

CAN_SJW	Description
CAN_SJW_1tq	Resynchronization Jump Width=1 time quantum
CAN_SJW_2tq	Resynchronization Jump Width= 2 time quantum
CAN_SJW_3tq	Resynchronization Jump Width= 3 time quantum
CAN_SJW_4tq	Resynchronization Jump Width= 4 time quantum

**CAN\_BS1**

CAN\_BS1 configures the number of time quanta in Bit Segment 1. The values taken by this member are given in [Table 76](#).

**Table 76. CAN\_BS1 values**

CAN_BS1	Description
CAN_BS1_1tq	Bit Segment 1= 1 time quantum
...	...
CAN_BS1_16tq	Bit Segment 1= 16 time quantum

**CAN\_BS2**

CAN\_BS2 configures the number of time quanta in Bit Segment 2. The values taken by this member are given in [Table 77](#).

**Table 77. CAN\_BS2 values**

CAN_BS2	Description
CAN_BS2_1tq	Bit Segment 2= 1 time quantum
...	...
CAN_BS2_8tq	Bit Segment 2= 8 time quantum

### CAN\_Prescaler

CAN\_Prescaler configures the length of a time quantum. It ranges from 1 to 1024.

#### Example:

```
/* Initialize the CAN as 1Mb/s in normal mode, receive FIFO locked:
 */
CAN_InitTypeDef CAN_InitStructure;

CAN_InitStructure.CAN_TTCM = DISABLE;
CAN_InitStructure.CAN_ABOM = DISABLE;
CAN_InitStructure.CAN_AWUM = DISABLE;
CAN_InitStructure.CAN_NART = DISABLE;
CAN_InitStructure.CAN_RFLM = ENABLE;
CAN_InitStructure.CAN_TXFP = DISABLE;
CAN_InitStructure.CAN_Mode = CAN_Mode_Normal;
CAN_InitStructure.CAN_BS1 = CAN_BS1_4tq;
CAN_InitStructure.CAN_BS2 = CAN_BS2_3tq;
CAN_InitStructure.CAN_Prescaler = 0;
CAN_Init(&CAN_InitStructure);
```

### 6.2.3 CAN\_FilterInit function

[Table 78](#) describes the CAN\_FilterInit function.

**Table 78. CAN\_FilterInit function**

Function name	CAN_FilterInit
Function prototype	void CAN_FilterInit(CAN_FilterInitTypeDef* CAN_FilterInitStruct)
Behavior description	Initializes the CAN peripheral according to the specified parameters in the CAN_FilterInitStruct.
Input parameter	CAN_FilterInitStruct: pointer to a CAN_FilterInitTypeDef structure containing the configuration information. Refer to <a href="#">CAN_FilterInitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## CAN\_FilterInitTypeDef structure

The CAN\_FilterInitTypeDef structure is defined in the *stm32f10x\_can.h* file:

```
typedef struct
{
    u8 CAN_FilterNumber;
    u8 CAN_FilterMode;
    u8 CAN_FilterScale;
    u16 CAN_FilterIdHigh;
    u16 CAN_FilterIdLow;
    u16 CAN_FilterMaskIdHigh;
    u16 CAN_FilterMaskIdLow;
    u16 CAN_FilterFIFOAssignment;
    FunctionalState CAN_FilterActivation;
} CAN_FilterInitTypeDef;
```

### CAN\_FilterNumber

CAN\_FilterNumber selects the filter which will be initialized. It ranges from 0 to 13.

### CAN\_FilterMode

CAN\_FilterMode selects the mode to be initialized. The values taken by this member are given in [Table 79](#).

**Table 79. CAN\_FilterMode values**

CAN_FilterMode	Description
CAN_FilterMode_IdMask	id/mask mode
CAN_FilterMode_IdList	identifier list mode

### CAN\_FilterScale

CAN\_FilterScale configures the filter scale. The values taken by this member are given in [Table 80](#).

**Table 80. CAN\_FilterScale values**

CAN_FilterScale	Description
CAN_FilterScale_Two16bit	Two 16-bit filters
CAN_FilterScale_One32bit	One 32-bit filter

### CAN\_FilterIdHigh

CAN\_FilterIdHigh is used to select the filter identification number (MSBs for a 32-bit configuration, first one for a 16-bit configuration). It ranges from 0x0000 to 0xFFFF.

### CAN\_FilterIdLow

CAN\_FilterIdLow is used to select the filter identification number (LSBs for a 32-bit configuration, second one for a 16-bit configuration). It ranges from 0x0000 to 0xFFFF.

**CAN\_FilterMaskIdHigh**

CAN\_FilterMaskIdHigh is used to select the filter mask number or identification number, according to the mode (MSBs for a 32-bit configuration, first one for a 16-bit configuration). It ranges from 0x0000 to 0xFFFF.

**CAN\_FilterMaskIdLow**

CAN\_FilterMaskIdLow is used to select the filter mask number or identification number, according to the mode (LSBs for a 32-bit configuration, second one for a 16-bit configuration). It ranges from 0x0000 to 0xFFFF.

**CAN\_FilterFIFO**

CAN\_FilterFIFO is used to select the FIFO (0 or 1) which will be assigned to the filter. The values taken by this member are given in [Table 81](#).

**Table 81. CAN\_FilterFIFO values**

CAN_FilterFIFO	Description
CAN_FilterFIFO0	Filter FIFO 0 assignment for filter x
CAN_FilterFIFO1	Filter FIFO 1 assignment for filter x

**CAN\_FilterActivation**

CAN\_FilterActivation enables or disables the filter. It can be set either to ENABLE or DISABLE.

**Example:**

```

/* Initialize the CAN filter 2 */
CAN_FilterInitTypeDef CAN_FilterInitStructure;

CAN_FilterInitStructure.CAN_FilterNumber = 2;
CAN_FilterInitStructure.CAN_FilterMode = CAN_FilterMode_IdMask;
CAN_FilterInitStructure.CAN_FilterScale = CAN_FilterScale_One32bit;
CAN_FilterInitStructure.CAN_FilterIdHigh = 0x0F0F;
CAN_FilterInitStructure.CAN_FilterIdLow = 0xF0F0;
CAN_FilterInitStructure.CAN_FilterMaskIdHigh = 0xFF00;
CAN_FilterInitStructure.CAN_FilterMaskIdLow = 0x00FF;
CAN_FilterInitStructure.CAN_FilterFIFO = CAN_FilterFIFO0;
CAN_FilterInitStructure.CAN_FilterActivation = ENABLE;
CAN_FilterInit(&CAN_FilterInitStructure);

```

## 6.2.4 CAN\_StructInit function

[Table 82](#) describes the CAN\_StructInit function.

**Table 82. CAN\_StructInit function**

Function name	CAN_StructInit
Function prototype	void CAN_StructInit(CAN_InitTypeDef* CAN_InitStruct)
Behavior description	Fills each CAN_InitStruct member with its default value.
Input parameter	CAN_InitStruct: pointer to a CAN_InitTypeDef structure which will be initialized. Refer to <a href="#">Table 83</a> for the default values of the CAN_InitStruct members.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Table 83. CAN\_InitStruct default values**

Member	Default value
CAN_TTCM	DISABLE
CAN_ABOM	DISABLE
CAN_AWUM	DISABLE
CAN_NART	DISABLE
CAN_RFLM	DISABLE
CAN_TXFP	DISABLE
CAN_Mode	CAN_Mode_Normal
CAN_SJW	CAN_SJW_1tq
CAN_BS1	CAN_BS1_4tq
CAN_BS2	CAN_BS2_3tq
CAN_Prescaler	1

**Example:**

```
/* Initialize a CAN_InitTypeDef structure. */
CAN_InitTypeDef CAN_InitStructure;
CAN_StructInit(&CAN_InitStructure);
```



## 6.2.5 CAN\_ITConfig function

[Table 84](#) describes the CAN\_ITConfig function.

**Table 84. CAN\_ITConfig function**

Function name	CAN_ITConfig
Function prototype	void CAN_ITConfig(u32 CAN_IT, FunctionalState NewState)
Behavior description	Enables or disables the specified CAN interrupts.
Input parameter1	CAN_IT: CAN interrupt sources to be enabled or disabled. Refer to <a href="#">CAN_IT</a> for details on the allowed values for this parameter.
Input parameter2	NewState: new state of the CAN interrupts. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### CAN\_IT

The CAN\_IT input parameter enables or disables CAN interrupts. One or a combination of the following values can be used:

**Table 85. CAN\_IT values**

CAN_IT	Description
CAN_IT_TME	Transmit Mailbox Empty Mask
CAN_IT_FMP0	FIFO 0 Message Pending Mask
CAN_IT_FF0	FIFO 0 Full Mask
CAN_IT_FOV0	FIFO 0 Overrun Mask
CAN_IT_FMP1	FIFO 1 Message Pending Mask
CAN_IT_FF1	FIFO 1 Full Mask
CAN_IT_FOV1	FIFO 1 Overrun Mask
CAN_IT_EWG	Error Warning Mask
CAN_IT_EPV	Error Passive Mask
CAN_IT_BOF	Bus-Off Mask
CAN_IT_LEC	Last Error Code Mask
CAN_IT_ERR	Error Mask
CAN_IT_WKU	Wake-Up Mask
CAN_IT_SLK	Sleep Flag Mask

### Example:

```
/* Enable CAN FIFO 0 overrun interrupt */
CAN_ITConfig(CAN_IT_FOV0, ENABLE);
```

## 6.2.6 CAN\_Transmit function

[Table 86](#) describes the CAN\_Transmit function.

**Table 86. CAN\_Transmit function**

Function name	CAN_Transmit
Function prototype	u8 CAN_Transmit(CanTxMsg* TxMessage)
Behavior description	Initiates the transmission of a message.
Input parameter	TxMessage: pointer to a structure which contains CAN Id, CAN DLC and CAN data.
Output parameter	None
Return parameter	Number of the mailbox that is used for transmission or CAN_NO_MB if there is no empty mailbox.
Required preconditions	None
Called functions	None

## CanTxMsg

The CanTxMsg structure is defined in the *stm32f10x\_can.h* file:

```
typedef struct
{
    u32 StdId;
    u32 ExtId;
    u8 IDE;
    u8 RTR;
    u8 DLC;
    u8 Data[8];
} CanTxMsg;
```

### StdId

StdId is used to configure the standard identifier. This member ranges from 0 to 0x7FF.

### ExtId

ExtId is used to configure the extended identifier. This member ranges from 0 to 0x1FFF FFFF.

### IDE

IDE is used to configure the type of identifier for the message that will be transmitted. See [Table 87](#) for the values taken by this member.

**Table 87. IDE values**

IDE	Description
CAN_ID_STD	standard ID used
CAN_ID_EXT	extended ID used

## RTR

RTR is used to select the type of frame for the message that will be transmitted. It can be set either to data frame or remote frame.

**Table 88. RTR values**

RTR	Description
CAN_RTR_DATA	Data frame
CAN_RTR_REMOTE	Remote frame

## DLC

DLC is used to configure the length of the frame that will be transmitted. It ranges from 0 to 0x8.

## Data[8]

Data[8] contain the data to be transmitted. It ranges from 0 to 0xFF.

### Example:

```
/* Send a message with the CAN */
CanTxMsg TxMessage;

TxMessage.StdId = 0x1F;
TxMessage.ExtId = 0x00;
TxMessage.IDE = CAN_ID_STD;
TxMessage.RTR = CAN_RTR_DATA;
TxMessage.DLC = 2;
TxMessage.Data[0] = 0xAA;
TxMessage.Data[1] = 0x55;
CAN_Transmit(&TxMessage);
```

## 6.2.7 CAN\_TransmitStatus function

[Table 89](#) describes the CAN\_TransmitStatus function.

**Table 89. CAN\_TransmitStatus function**

Function name	CAN_Transmit
Function prototype	u8 CAN_TransmitStatus(u8 TransmitMailbox)
Behavior description	Checks message transmission status
Input parameter	TransmitMailbox: the number of the mailbox that is used for the transmission.
Output parameter	None
Return parameter	CANTXOK if the CAN driver is transmitting the message CANTXPENDING if the message is pending CANTXFAILED otherwise
Required preconditions	Transmission ongoing
Called functions	None

**Example:**

```
/* Check the status of a transmission with the CAN */
CanTxMsg TxMessage;
...
switch(CAN_TransmitStatus(CAN_Transmit(&TxMessage))
{
case CANTXOK: ...;break;
...
}
```

## 6.2.8 CAN\_CancelTransmit function

[Table 90](#) describes the CAN\_CancelTransmit function.

**Table 90. CAN\_CancelTransmit function**

Function name	CAN_CancelTransmit
Function prototype	void CAN_CancelTransmit(u8 Mailbox)
Behavior description	Cancels a transmission request
Input parameter	Mailbox number
Output parameter	None
Return parameter	None
Required preconditions	Transmission pending in a mailbox
Called functions	None

**Example:**

```
/* Cancel a CAN transmit initiated by CANTransmit */
u8 MBNumber;
CanTxMsg TxMessage;
MBNumber = CAN_Transmit(&TxMessage);
if (CAN_TransmitStatus(MBNumber) == CANTXPENDING)
{
    CAN_CancelTransmit(MBNumber);
}
```

## 6.2.9 CAN\_FIFORelease function

[Table 91](#) describes the CAN\_FIFORelease function.

**Table 91. CAN\_FIFORelease function**

Function name	CAN_FIFORelease
Function prototype	void CAN_FIFORelease(u8 FIFONumber)
Behavior description	Releases a FIFO
Input parameter	FIFO number: FIFO to release, CANFIFO0 or CANFIFO1.
Output parameter	None
Return parameter	None
Required preconditions	none
Called functions	None

**Example:**

```
/* Release FIFO 0*/
CAN_FIFORelease(CANFIFO0);
```

## 6.2.10 CAN\_MessagePending function

[Table 92](#) describes the CAN\_MessagePending function.

**Table 92. CAN\_MessagePending function**

Function name	CAN_MessagePending
Function prototype	u8 CAN_MessagePending(u8 FIFONumber)
Behavior description	Return the number of pending messages.
Input parameter	FIFONumber: receive FIFO number, CANFIFO0 or CANFIFO1.
Output parameter	None
Return parameter	NbMessage which is the number of pending messages
Required preconditions	none
Called functions	None

**Example:**

```
/* Check the number of pending messages for FIFO 0*/
u8 MessagePending = 0;
MessagePending = CAN_MessagePending(CANFIFO0);
```

### 6.2.11 CAN\_Receive function

[Table 93](#) describes the CAN\_Receive function.

**Table 93. CAN\_Receive function**

Function name	CAN_Receive
Function prototype	void CAN_Receive(u8 FIFONumber, CanRxMsg* RxMessage)
Behavior description	Receives a message.
Input parameter	FIFONumber: receive FIFO number, CANFIFO0 or CANFIFO1.
Output parameter	RxMessage: pointer to a structure which contains CAN Id, CAN DLC and CAN data.
Return parameter	None
Required preconditions	None
Called functions	None

### CanRxMsg structure

The CanRxMsg structure is defined in the *stm32f10x\_can.h* file:

```
typedef struct
{
    u32 StdId;
    u32 ExtId;
    u8 IDE;
    u8 RTR;
    u8 DLC;
    u8 Data[8];
    u8 FMI;
} CanRxMsg;
```

#### StdId

StdId is used to configure the standard identifier. This member ranges from 0 to 0x7FF.

#### ExtId

ExtId is used to configure the extended identifier. This member ranges from 0 to 0x1FFF FFFF.

#### IDE

IDE is used to configure the type of identifier for the message that will be received. See [Table 87](#) for the values taken by this member.

**Table 94. IDE values**

IDE	Description
CAN_ID_STD	standard ID used
CAN_ID_EXT	extended ID used

## RTR

RTR is used to select the type of frame for the received message. It can be set either to data frame or remote frame.

**Table 95. RTR values**

RTR	Description
CAN_RTR_DATA	Data frame
CAN_RTR_REMOTE	Remote frame

## DLC

DLC is used to configure the length of the frame that will be transmitted. It ranges from 0 to 0x8.

## Data[8]

Data[8] contains the data to be received. It ranges from 0 to 0xFF.

## FMI

FMI configures the index of the filter the message stored in the mailbox passes through. FMI ranges from 0 to 0xFF.

### Example:

```
/* Receive a message with the CAN */  
CanRxMsg RxMessage;  
CAN_Receive(&RxMessage);
```

### 6.2.12 CAN\_Sleep function

[Table 96](#) describes the CAN\_Sleep function.

**Table 96. CAN\_Sleep function**

Function name	CAN_Sleep
Function prototype	u8 CAN_Sleep(void)
Behavior description	Put the CAN in low power mode.
Input parameter	None
Output parameter	None
Return parameter	CANSLEEPOK if sleep entered, CANSLEEPFAILED otherwise data.
Required preconditions	None
Called functions	None

**Example:**

```
/* Enter the CAN sleep mode*/  
CAN_Sleep();
```

### 6.2.13 CAN\_WakeUp function

[Table 97](#) describes the CAN\_Wakeup function.

**Table 97. CAN\_Wakeup function**

Function name	CAN_WakeUp
Function prototype	u8 CAN_WakeUp(void)
Behavior description	Wakes up the CAN.
Input parameter	None
Output parameter	None
Return parameter	CANWAKEUPOK if sleep mode left, CANWAKEUPFAILED otherwise.
Required preconditions	None
Called functions	None

**Example:**

```
/* CAN waking up */  
CAN_WakeUp();
```



## 6.2.14 CAN\_GetFlagStatus function

[Table 98](#) describes the CAN\_GetFlagStatus function.

**Table 98. CAN\_GetFlagStatus function**

Function name	CAN_GetFlagStatus
Function prototype	FlagStatus CAN_GetFlagStatus(u32 CAN_FLAG)
Behavior description	Checks whether the specified CAN flag is set or not.
Input parameter	CAN_FLAG: it specifies the flag to be checked. Refer to <a href="#">CAN_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of CAN_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

### CAN\_FLAG

The CAN\_FLAG is used to define the type of flag that will be checked. See [Table 99](#) for a description of CAN\_FLAG values.

**Table 99. CAN\_FLAG definition**

CAN_FLAG	Description
CAN_FLAG_EWG	Error Warning Flag
CAN_FLAG_EPV	Error Passive Flag
CAN_FLAG_BOF	Bus-Off Flag

#### Example:

```
/* Test if the CAN warning limit has been reached */
FlagStatus Status;
Status = CAN_GetFlagStatus(CAN_FLAG_EWG);
```

## 6.2.15 CAN\_ClearFlag function

[Table 100](#) describes the CAN\_ClearFlag function.

**Table 100. CAN\_ClearFlag function**

Function name	CAN_ClearFlag
Function prototype	void CAN_ClearFlag(u32 CAN_Flag)
Behavior description	Clears the CAN's pending flags.
Input parameter	CAN_FLAG specifies the flag to clear. Refer to <a href="#">CAN_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the CAN bus-off state flag */  
CAN_ClearFlag(CAN_FLAG_BOF);
```

## 6.2.16 CAN\_GetITStatus function

[Table 101](#) describes the CAN\_GetITStatus function.

**Table 101. CAN\_GetITStatus function**

Function name	CAN_GetITStatus
Function prototype	ITStatus CAN_GetITStatus(u32 CAN_IT)
Behavior description	Checks whether the specified CAN interrupt has occurred or not.
Input parameter	CAN_IT: CAN interrupt source to check. Refer to <a href="#">CAN_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of CAN_IT (SET or RESET).
Required preconditions	None
Called functions	None

## CAN\_IT

The CAN\_IT input parameter selects the interrupt that will be checked. See [Table 102](#) for a description of CAN\_IT values.

**Table 102. CAN\_IT values**

CAN_IT	Description
CAN_IT_RQCP0	Request completed mailbox 0
CAN_IT_RQCP1	Request completed mailbox 1
CAN_IT_RQCP2	Request completed mailbox 2
CAN_IT_FMP0	FIFO 0 Message Pending
CAN_IT_FULL0	FIFO 0 three messages stored
CAN_IT_FOVR0	FIFO 0 Overrun
CAN_IT_FMP1	FIFO 1 Message Pending
CAN_IT_FULL1	FIFO 1 three messages stored
CAN_IT_FOVR1	FIFO 1 Overrun
CAN_IT_EWGF	Warning limit reached
CAN_IT_EPVF	Error passive limit reached
CAN_IT_BOFF	Bus-of state entered
CAN_IT_WKUI	SOF detected whilst in sleep mode

**Example:**

```
/* Test if the CAN FIFO 0 overrun interrupt has occurred or not */  
ITStatus Status;  
Status = CAN_GetITStatus(CAN_IT_FOVR0);
```

### 6.2.17 CAN\_ClearITPendingBit function

*Table 103* describes the CAN\_ClearITPendingBit function.

**Table 103. CAN\_ClearITPendingBit function**

Function name	CAN_ClearITPendingBit
Function prototype	void CAN_ClearITPendingBit(u32 CAN_IT)
Behavior description	Clears the CAN pending interrupt bits.
Input parameter	CAN_IT: pending interrupt bit to clear. Refer to <a href="#">CAN_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the CAN error passive overflow interrupt pending bit */  
CAN_ClearITPendingBit(CAN_IT_EPVF);
```

## 7 DMA controller (DMA)

The DMA controller provides access to twelve data channels. Since peripherals are memory mapped, data transfers from/to peripherals are managed like memory/memory data transfers.

[Section 7.1: DMA register structures](#) describes the data structures used in the DMA Firmware Library. [Section 7.2: Firmware library functions](#) presents the Firmware Library functions.

### 7.1 DMA register structures

The DMA register structures, *DMA\_Channel\_TypeDef* and *DMA\_TypeDef*, are defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32 CCR;
    vu32 CNDTR;
    vu32 CPAR;
    vu32 CMAR;
} DMA_Channel_TypeDef;

typedef struct
{
    vu32 ISR;
    vu32 IFCR;
} DMA_TypeDef;
```

[Table 104](#) shows the list of all DMA registers.

**Table 104. DMA registers**

Register	Description
ISR	DMA Interrupt Status register
IFCR	DMA Interrupt Flag Clear Register
CCR <sub>x</sub>	DMA Channel <sub>x</sub> Configuration register
CNDTR <sub>x</sub>	DMA Channel <sub>x</sub> Number of Data to Transfer register
CPAR <sub>x</sub>	DMA Channel <sub>x</sub> Peripheral Address Register
CMAR <sub>x</sub>	DMA Channel <sub>x</sub> Memory0 Address Register

The DMA and its seven channels are also declared in *stm32f10x\_map*:

```
...
#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE     PERIPH_BASE
#define APB2PERIPH_BASE     (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE      (PERIPH_BASE + 0x20000)
...
#define DMA1_BASE            (AHBPERIPH_BASE + 0x0000)
```

```

#define DMA2_BASE                (AHBPERIPH_BASE + 0x0400)

#define DMA1_Channel1_BASE      (AHBPERIPH_BASE + 0x0008)
#define DMA1_Channel2_BASE      (AHBPERIPH_BASE + 0x001C)
#define DMA1_Channel3_BASE      (AHBPERIPH_BASE + 0x0030)
#define DMA1_Channel4_BASE      (AHBPERIPH_BASE + 0x0044)
#define DMA1_Channel5_BASE      (AHBPERIPH_BASE + 0x0058)
#define DMA1_Channel6_BASE      (AHBPERIPH_BASE + 0x006C)
#define DMA1_Channel7_BASE      (AHBPERIPH_BASE + 0x0080)
#define DMA2_Channel1_BASE      (AHBPERIPH_BASE + 0x0408)
#define DMA2_Channel2_BASE      (AHBPERIPH_BASE + 0x041C)
#define DMA2_Channel3_BASE      (AHBPERIPH_BASE + 0x0430)
#define DMA2_Channel4_BASE      (AHBPERIPH_BASE + 0x0444)
#define DMA2_Channel5_BASE      (AHBPERIPH_BASE + 0x0458)
....
#ifndef DEBUG
...
#ifdef _DMA
    #define DMA1                ((DMA_TypeDef *) DMA1_BASE)
    #define DMA2                ((DMA_TypeDef *) DMA2_BASE)
#endif /* _DMA */

#ifdef _DMA1_Channel1
    #define DMA1_Channel1        ((DMA_Channel_TypeDef *)
DMA1_Channel1_BASE)
#endif /* _DMA1_Channel1 */

#ifdef _DMA1_Channel2
    #define DMA1_Channel2        ((DMA_Channel_TypeDef *)
DMA1_Channel2_BASE)
#endif /* _DMA1_Channel2 */

#ifdef _DMA1_Channel3
    #define DMA1_Channel3        ((DMA_Channel_TypeDef *)
DMA1_Channel3_BASE)
#endif /* _DMA1_Channel3 */

#ifdef _DMA1_Channel4
    #define DMA1_Channel4        ((DMA_Channel_TypeDef *)
DMA1_Channel4_BASE)
#endif /* _DMA1_Channel4 */

#ifdef _DMA1_Channel5
    #define DMA1_Channel5        ((DMA_Channel_TypeDef *)
DMA1_Channel5_BASE)
#endif /* _DMA1_Channel5 */

#ifdef _DMA1_Channel6
    #define DMA1_Channel6        ((DMA_Channel_TypeDef *)
DMA1_Channel6_BASE)
#endif /* _DMA1_Channel6 */

```

```

#ifdef _DMA1_Channel7
    #define DMA1_Channel7          ((DMA_Channel_TypeDef *)
DMA1_Channel7_BASE)
#endif /*_DMA1_Channel7 */

#ifdef _DMA2_Channel1
    #define DMA2_Channel1          ((DMA_Channel_TypeDef *)
DMA2_Channel1_BASE)
#endif /*_DMA2_Channel1 */

#ifdef _DMA2_Channel2
    #define DMA2_Channel2          ((DMA_Channel_TypeDef *)
DMA12_Channel2_BASE)
#endif /*_DMA2_Channel2 */

#ifdef _DMA2_Channel3
    #define DMA2_Channel3          ((DMA_Channel_TypeDef *)
DMA2_Channel3_BASE)
#endif /*_DMA2_Channel3 */

#ifdef _DMA2_Channel4
    #define DMA2_Channel4          ((DMA_Channel_TypeDef *)
DMA2_Channel4_BASE)
#endif /*_DMA2_Channel4 */

#ifdef _DMA2_Channel5
    #define DMA2_Channel5          ((DMA_Channel_TypeDef *)
DMA2_Channel5_BASE)
#endif /*_DMA2_Channel5 */

...
#else /* DEBUG */
...
#ifdef _DMA
    EXT DMA_TypeDef              *DMA1;
    EXT DMA_TypeDef              *DMA2;
#endif /*_DMA */

#ifdef _DMA1_Channel1
    EXT DMA1_Channel_TypeDef      *DMA1_Channel1;
#endif /*_DMA1_Channel1 */

#ifdef _DMA1_Channel2
    EXT DMA1_Channel_TypeDef      *DMA1_Channel2;
#endif /*_DMA1_Channel2 */

#ifdef _DMA1_Channel3
    EXT DMA1_Channel_TypeDef      *DMA1_Channel3;
#endif /*_DMA1_Channel3 */

#ifdef _DMA1_Channel4
    EXT DMA1_Channel_TypeDef      *DMA1_Channel4;

```

```

#endif /*_DMA1_Channel4 */

#ifdef _DMA1_Channel5
    EXT DMA1_Channel_TypeDef    *DMA1_Channel5;
#endif /*_DMA1_Channel5 */

#ifdef _DMA1_Channel6
    EXT DMA1_Channel_TypeDef    *DMA1_Channel6;
#endif /*_DMA1_Channel6 */

#ifdef _DMA1_Channel7
    EXT DMA1_Channel_TypeDef    *DMA1_Channel7;
#endif /*_DMA1_Channel7 */

#ifdef _DMA2_Channel1
    EXT DMA2_Channel_TypeDef    *DMA2_Channel1;
#endif /*_DMA2_Channel1 */

#ifdef _DMA2_Channel2
    EXT DMA2_Channel_TypeDef    *DMA2_Channel2;
#endif /*_DMA2_Channel2 */

#ifdef _DMA2_Channel3
    EXT DMA2_Channel_TypeDef    *DMA2_Channel3;
#endif /*_DMA2_Channel3 */

#ifdef _DMA2_Channel4
    EXT DMA2_Channel_TypeDef    *DMA2_Channel4;
#endif /*_DMA2_Channel4 */

#ifdef _DMA2_Channel5
    EXT DMA2_Channel_TypeDef    *DMA2_Channel5;
#endif /*_DMA2_Channel5 */
...
#endif

```

When using the Debug mode, `_DMA`, `_DMA1_Channel1`, `_DMA1_Channel2`, ..., `_DMA1_Channel7`, `_DMA2_Channel1`, `_DMA2_Channel2`, ..., `_DMA2_Channel5` pointers are initialized in `stm32f10x_lib.c` file:

```

...
#ifdef _DMA
    DMA1 = (DMA_TypeDef *)    DMA1_BASE;
    DMA2 = (DMA_TypeDef *)    DMA2_BASE;
#endif /*_DMA */

#ifdef _DMA1_Channel1
    DMA1_Channel1 = (DMA_Channel_TypeDef *)    DMA1_Channel1_BASE;
#endif /*_DMA1_Channel1 */

#ifdef _DMA1_Channel2
    DMA1_Channel2 = (DMA_Channel_TypeDef *)    DMA1_Channel2_BASE;
#endif /*_DMA1_Channel2 */

```



```

#ifdef _DMA1_Channel3
    DMA1_Channel3 = (DMA_Channel_TypeDef *) DMA1_Channel3_BASE;
#endif /*_DMA1_Channel3 */

#ifdef _DMA1_Channel4
    DMA1_Channel4 = (DMA_Channel_TypeDef *) DMA1_Channel4_BASE;
#endif /*_DMA1_Channel4 */

#ifdef _DMA1_Channel5
    DMA1_Channel5 = (DMA_Channel_TypeDef *) DMA1_Channel5_BASE;
#endif /*_DMA1_Channel5 */

#ifdef _DMA1_Channel6
    DMA1_Channel6 = (DMA_Channel_TypeDef *) DMA1_Channel6_BASE;
#endif /*_DMA1_Channel6 */

#ifdef _DMA1_Channel7
    DMA1_Channel7 = (DMA_Channel_TypeDef *) DMA1_Channel7_BASE;
#endif /*_DMA1_Channel7 */

#ifdef _DMA2_Channel1
    DMA2_Channel1 = (DMA_Channel_TypeDef *) DMA2_Channel1_BASE;
#endif /*_DMA2_Channel1 */

#ifdef _DMA2_Channel2
    DMA2_Channel2 = (DMA_Channel_TypeDef *) DMA2_Channel2_BASE;
#endif /*_DMA2_Channel2 */

#ifdef _DMA2_Channel3
    DMA2_Channel3 = (DMA_Channel_TypeDef *) DMA2_Channel3_BASE;
#endif /*_DMA2_Channel3 */

#ifdef _DMA2_Channel4
    DMA2_Channel4 = (DMA_Channel_TypeDef *) DMA2_Channel4_BASE;
#endif /*_DMA2_Channel4 */

#ifdef _DMA2_Channel5
    DMA2_Channel5 = (DMA_Channel_TypeDef *) DMA2_Channel5_BASE;
#endif /*_DMA2_Channel5 */

...
To access the DMA registers, _DMA, _DMA1_Channel1 to _DMA1_Channel7
and _DMA2_Channel1 to _DMA2_Channel5 must be defined in
stm32f10x_conf.h as follows:
...
#define _DMA
#define _DMA1_Channel1
#define _DMA1_Channel2
#define _DMA1_Channel3
#define _DMA1_Channel4
#define _DMA1_Channel5

```

```
#define _DMA1_Channel6
#define _DMA1_Channel7
#define _DMA2_Channel1
#define _DMA2_Channel2
#define _DMA2_Channel3
#define _DMA2_Channel4
#define _DMA2_Channel5

...
```

## 7.2 Firmware library functions

[Table 105](#) lists the various functions of the DMA firmware library.

**Table 105. DMA firmware library functions**

Function name	Description
DMA_DeInit	Resets the DMAy Channelx registers to their default reset values.
DMA_Init	Initializes the DMAy Channelx according to the specified parameters in the DMA_InitStruct.
DMA_StructInit	Fills each DMA_InitStruct member with its default value.
DMA_Cmd	Enables or disables the specified DMAy Channelx.
DMA_ITConfig	Enables or disables the specified DMAy Channelx interrupts.
DMA_GetCurrDataCounter	Returns the number of remaining data units in the current DMAy Channelx transfer.
DMA_GetFlagStatus	Checks whether the specified DMAy Channelx flag is set or not.
DMA_ClearFlag	Clears the DMAy Channelx pending flags.
DMA_GetITStatus	Checks whether the specified DMAy Channelx interrupt has occurred or not.
DMA_ClearITPendingBit	Clears the DMAy Channelx interrupt pending bits.

## 7.2.1 DMA\_DeInit function

[Table 106](#) describes the DMA\_DeInit function.

**Table 106. DMA\_DeInit function**

Function name	DMA_DeInit
Function prototype	void DMA_DeInit(DMA_Channel_TypeDef* DMAy_Channelx)
Behavior description	Resets the DMAy Channelx registers to their default reset values.
Input parameter	DMAy_Channelx: where y selects the DMA (y = 1 for DMA1, y = 2 for DMA2) and x selects the DMA Channel (x = 1 to 7 for DMA1 or x = 1 to 5 for DMA2).
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_AHBPeriphClockCmd().

**Example:**

```
/* Deinitialize the DMA1 Channel2 */
DMA_DeInit(DMA1_Channel2);
```

## 7.2.2 DMA\_Init function

[Table 107](#) describes the DMA\_Init function.

**Table 107. DMA\_Init function**

Function name	DMA_Init
Function prototype	void DMA_Init(DMA_Channel_TypeDef* DMAy_Channelx, DMA_InitTypeDef* DMA_InitStruct)
Behavior description	Initializes the DMAy Channelx according to the parameters specified in the DMA_InitStruct.
Input parameter1	DMAy_Channelx: where y selects the DMA (y = 1 for DMA1, y = 2 for DMA2) and x selects the DMA Channel (x = 1 to 7 for DMA1 or x = 1 to 5 for DMA2).
Input parameter2	DMA_InitStruct: pointer to a DMA_InitTypeDef structure that contains the configuration information for the specified DMAy Channelx. Refer to <a href="#">DMA_InitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## DMA\_InitTypeDef structure

The DMA\_InitTypeDef structure is defined in the *stm32f10x\_dma.h* file:

```
typedef struct
{
    u32 DMA_PeripheralBaseAddr;
    u32 DMA_MemoryBaseAddr;
    u32 DMA_DIR;
    u32 DMA_BufferSize;
    u32 DMA_PeripheralInc;
    u32 DMA_MemoryInc;
    u32 DMA_PeripheralDataSize;
    u32 DMA_MemoryDataSize;
    u32 DMA_Mode;
    u32 DMA_Priority;
    u32 DMA_M2M;
} DMA_InitTypeDef;
```

### DMA\_PeripheralBaseAddr

This member is used to define the peripheral base address for DMAy Channelx.

### DMA\_MemoryBaseAddr

This member is used to define the memory base address for DMAy Channelx.

### DMA\_DIR

DMA\_DIR specifies if the peripheral is the source or destination. The values taken by this member are given in [Table 108](#).

**Table 108. DMA\_DIR definition**

DMA_DIR	Description
DMA_DIR_PeripheralDST	Peripheral is the destination
DMA_DIR_PeripheralSRC	Peripheral is the source

### DMA\_BufferSize

DMA\_BufferSize is used to define the buffer size, in data unit, of the specified Channel. The data unit is equal to the configuration set in DMA\_PeripheralDataSize or DMA\_MemoryDataSize members depending in the transfer direction.

### DMA\_PeripheralInc

DMA\_PeripheralInc specifies whether the Peripheral address register is incremented or not. The values taken by this member are given in [Table 109](#).

**Table 109. DMA\_PeripheralInc definition**

DMA_PeripheralInc	Description
DMA_PeripheralInc_Enable	Current peripheral register incremented
DMA_PeripheralInc_Disable	Current peripheral register unchanged

**DMA\_MemoryInc**

DMA\_MemoryInc specifies whether the memory address register is incremented or not. The values taken by this member are given in [Table 110](#).

**Table 110. DMA\_MemoryInc definition**

DMA_MemoryInc	Description
DMA_MemoryInc_Enable	Current memory register incremented
DMA_MemoryInc_Disable	Current memory register unchanged

**DMA\_PeripheralDataSize**

DMA\_PeripheralDataSize configures the Peripheral data width. The values taken by this member are given in [Table 111](#).

**Table 111. DMA\_PeripheralDataSize definition**

DMA_PeripheralDataSize	Description
DMA_PeripheralDataSize_Byte	Data width = 8 bits
DMA_PeripheralDataSize_HalfWord	Data width = 16 bits
DMA_PeripheralDataSize_Word	Data width = 32 bits

**DMA\_MemoryDataSize**

DMA\_MemoryDataSize defines the Memory data width. The values taken by this member are given in [Table 112](#).

**Table 112. DMA\_MemoryDataSize definition**

DMA_MemoryDataSize	Description
DMA_MemoryDataSize_Byte	Data width = 8 bits
DMA_MemoryDataSize_HalfWord	Data width = 16 bits
DMA_MemoryDataSize_Word	Data width = 32 bits

**DMA\_Mode**

DMA\_Mode configures the operation mode of the DMAy Channelx. The values taken by this member are given in [Table 113](#).

**Table 113. DMA\_Mode definition**

DMA_Mode	Description
DMA_Mode_Circular	Circular buffer mode is used
DMA_Mode_Normal	Normal buffer mode is used

*Note:* The circular buffer mode cannot be used if the memory-to-memory data transfer is configured on the selected Channel (see [DMA\\_M2M](#)).

**DMA\_Priority**

DMA\_Priority configures the software priority for the DMAy Channelx. The values taken by this member are given in [Table 114](#).

**Table 114. DMA\_Priority definition**

DMA_Priority	Description
DMA_Priority_VeryHigh	DMAy Channelx has a very high priority
DMA_Priority_High	DMAy Channelx has a high priority
DMA_Priority_Medium	DMAy Channelx has a medium priority
DMA_Priority_Low	DMAy Channelx has a low priority

**DMA\_M2M**

DMA\_M2M enables the DMAy Channelx memory- to-memory transfer. The values taken by this member are given in [Table 115](#).

**Table 115. DMA\_M2M definition**

DMA_M2M	Description
DMA_M2M_Enable	DMAy Channelx configured for memory-to-memory transfer
DMA_M2M_Disable	DMAy Channelx not configured for memory-to-memory transfer

**Example:**

```
/* Initialize the DMA1 Channel1 according to the DMA_InitStructure
members */
DMA_InitTypeDef DMA_InitStructure;

DMA_InitStructure.DMA_PeripheralBaseAddr = 0x40005400;
DMA_InitStructure.DMA_MemoryBaseAddr = 0x20000100;
DMA_InitStructure.DMA_DIR = DMA_DIR_PeripheralSRC;
DMA_InitStructure.DMA_BufferSize = 256;
DMA_InitStructure.DMA_PeripheralInc = DMA_PeripheralInc_Disable;
DMA_InitStructure.DMA_MemoryInc = DMA_MemoryInc_Enable;
DMA_InitStructure.DMA_PeripheralDataSize =
DMA_PeripheralDataSize_HalfWord;
DMA_InitStructure.DMA_MemoryDataSize =
DMA_MemoryDataSize_HalfWord;
DMA_InitStructure.DMA_Mode = DMA_Mode_Normal;
DMA_InitStructure.DMA_Priority = DMA_Priority_Medium;
DMA_InitStructure.DMA_M2M = DMA_M2M_Disable;
DMA_Init(DMA1_Channel1, &DMA_InitStructure);
```

### 7.2.3 DMA\_StructInit function

*Table 116* describes the DMA\_Init function.

**Table 116. DMA\_StructInit function**

Function name	DMA_StructInit
Function prototype	void DMA_StructInit(DMA_InitTypeDef* DMA_InitStruct)
Behavior description	Fills each DMA_InitStruct member with its default value.
Input parameter	DMA_InitStruct: pointer to the DMA_InitTypeDef structure to be initialized
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The DMA\_InitStruct members have the following default values:

**Table 117. DMA\_InitStruct default values**

Member	Default value
DMA_PeripheralBaseAddr	0
DMA_MemoryBaseAddr	0
DMA_DIR	DMA_DIR_PeripheralSRC
DMA_BufferSize	0
DMA_PeripheralInc	DMA_PeripheralInc_Disable
DMA_MemoryInc	DMA_MemoryInc_Disable
DMA_PeripheralDataSize	DMA_PeripheralDataSize_Byte
DMA_MemoryDataSize	DMA_MemoryDataSize_Byte
DMA_Mode	DMA_Mode_Normal
DMA_Priority	DMA_Priority_Low
DMA_M2M	DMA_M2M_Disable

**Example:**

```
/* Initialize a DMA_InitTypeDef structure */
DMA_InitTypeDef DMA_InitStructure;
DMA_StructInit(&DMA_InitStructure);
```

## 7.2.4 DMA\_Cmd function

[Table 118](#) describes DMA\_Cmd function.

**Table 118. DMA\_Cmd function**

Function name	DMA_Cmd
Function prototype	void DMA_Cmd(DMA_Channel_TypeDef* DMAy_Channelx, FunctionalState NewState)
Behavior description	Enables or disables the specified DMAy Channelx.
Input parameter1	DMAy_Channelx: where y selects the DMA (y = 1 for DMA1, y = 2 for DMA2) and x selects the DMA Channel (x = 1 to 7 for DMA1 or x = 1 to 5 for DMA2).
Input parameter2	NewState: new state of the DMAy Channelx. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable DMA1 Channel7 */
DMA_Cmd(DMA1_Channel7, ENABLE);
```

## 7.2.5 DMA\_ITConfig function

[Table 119](#) describes DMA\_ITConfig function.

**Table 119. DMA\_ITConfig function**

Function name	DMA_ITConfig
Function prototype	void DMA_ITConfig(DMA_Channel_TypeDef* DMAy_Channelx, u32 DMA_IT, FunctionalState NewState)
Behavior description	Enables or disables the specified DMAy Channelx interrupts.
Input parameter1	DMAy_Channelx: where y selects the DMA (y = 1 for DMA1, y = 2 for DMA2) and x selects the DMA Channel (x = 1 to 7 for DMA1 or x = 1 to 5 for DMA2).
Input parameter2	DMA_IT: specifies the DMAy Channelx interrupt sources to be enabled or disabled. More than one interrupt can be selected using the “ ” operator. Refer to <a href="#">DMA_IT</a> for more details on the allowed values for this parameter.
Input parameter3	NewState: new state of the specified DMAy Channelx interrupts. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None



**DMA\_IT**

The DMA\_IT input parameter enables or disables DMAy Channelx interrupts. One or a combination of the following values can be used.

**Table 120. DMA\_IT values**

DMA_IT	Description
DMA_IT_TC	Transfer complete interrupt mask
DMA_IT_HT	Half transfer interrupt mask
DMA_IT_TE	Transfer error interrupt mask

**Example:**

```
/* Enable DMA1 Channel5 complete transfer interrupt */
DMA_ITConfig(DMA1_Channel5, DMA_IT_TC, ENABLE);
```

**7.2.6 DMA\_GetCurrDataCounter function**

[Table 121](#) describes DMA\_GetCurrDataCounter function.

**Table 121. DMA\_GetCurrDataCounter function**

Function name	DMA_GetCurrDataCounter
Function prototype	u16 DMA_GetCurrDataCounter(DMA_Channel_TypeDef* DMAy_Channelx)
Behavior description	Returns the number of remaining data units in the current DMAy Channelx transfer.
Input parameter	DMAy_Channelx: where y selects the DMA (y = 1 for DMA1, y = 2 for DMA2) and x selects the DMA Channel (x = 1 to 7 for DMA1 or x = 1 to 5 for DMA2).
Output parameter	None
Return parameter	The number of remaining data units in the current DMAy Channelx transfer.
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the number of remaining data units in the current DMA1
Channel2 transfer */
u16 CurrDataCount;
CurrDataCount = DMA_GetCurrDataCounter(DMA1_Channel2);
```

### 7.2.7 DMA\_GetFlagStatus function

[Table 122](#) describes DMA\_GetFlagStatus function.

**Table 122. DMA\_GetFlagStatus function**

Function name	DMA_GetFlagStatus
Function prototype	FlagStatus DMA_GetFlagStatus(u32 DMA_FLAG)
Behavior description	Checks whether the specified DMAy Channelx flag is set or not.
Input parameter	DMA_FLAG: specifies the flag to check. Refer to <a href="#">DMA_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	New state of DMA_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

#### DMA\_FLAG

The DMA\_FLAG is used to define the type of flag that will be checked. See [Table 123](#) for a description of this input parameter.

**Table 123. DMA\_FLAG definition**

DMA_FLAG	Description
DMA1_FLAG_GL1	DMA1 Channel1 global flag
DMA1_FLAG_TC1	DMA1 Channel1 transfer complete flag
DMA1_FLAG_HT1	DMA1 Channel1 half transfer flag
DMA1_FLAG_TE1	DMA1 Channel1 transfer error flag
DMA1_FLAG_GL2	DMA1 Channel2 global flag
DMA1_FLAG_TC2	DMA1 Channel2 transfer complete flag
DMA1_FLAG_HT2	DMA1 Channel2 half transfer flag
DMA1_FLAG_TE2	DMA1 Channel2 transfer error flag
DMA1_FLAG_GL3	DMA1 Channel3 global flag
DMA1_FLAG_TC3	DMA1 Channel3 transfer complete flag
DMA1_FLAG_HT3	DMA1 Channel3 half transfer flag
DMA1_FLAG_TE3	DMA1 Channel3 transfer error flag
DMA1_FLAG_GL4	DMA1 Channel4 global flag
DMA1_FLAG_TC4	DMA1 Channel4 transfer complete flag
DMA1_FLAG_HT4	DMA1 Channel4 half transfer flag
DMA1_FLAG_TE4	DMA1 Channel4 transfer error flag
DMA1_FLAG_GL5	DMA1 Channel5 global flag
DMA1_FLAG_TC5	DMA1 Channel5 transfer complete flag

**Table 123. DMA\_FLAG definition (continued)**

DMA_FLAG	Description
DMA1_FLAG_HT5	DMA1 Channel5 half transfer flag
DMA1_FLAG_TE5	DMA1 Channel5 transfer error flag
DMA1_FLAG_GL6	DMA1 Channel6 global flag
DMA1_FLAG_TC6	DMA1 Channel6 transfer complete flag
DMA1_FLAG_HT6	DMA1 Channel6 half transfer flag
DMA1_FLAG_TE6	DMA1 Channel6 transfer error flag
DMA1_FLAG_GL7	DMA1 Channel7 global flag
DMA1_FLAG_TC7	DMA1 Channel7 transfer complete flag
DMA1_FLAG_HT7	DMA1 Channel7 half transfer flag
DMA1_FLAG_TE7	DMA1 Channel7 transfer error flag
DMA2_FLAG_GL1	DMA2 Channel1 global flag
DMA2_FLAG_TC1	DMA2 Channel1 transfer complete flag
DMA2_FLAG_HT1	DMA2 Channel1 half transfer flag
DMA2_FLAG_TE1	DMA2 Channel1 transfer error flag
DMA2_FLAG_GL2	DMA2 Channel2 global flag
DMA2_FLAG_TC2	DMA2 Channel2 transfer complete flag
DMA2_FLAG_HT2	DMA2 Channel2 half transfer flag
DMA2_FLAG_TE2	DMA2 Channel2 transfer error flag
DMA2_FLAG_GL3	DMA2 Channel3 global flag
DMA2_FLAG_TC3	DMA2 Channel3 transfer complete flag
DMA2_FLAG_HT3	DMA2 Channel3 half transfer flag
DMA2_FLAG_TE3	DMA2 Channel3 transfer error flag
DMA2_FLAG_GL4	DMA2 Channel4 global flag
DMA2_FLAG_TC4	DMA2 Channel4 transfer complete flag
DMA2_FLAG_HT4	DMA2 Channel4 half transfer flag
DMA2_FLAG_TE4	DMA2 Channel4 transfer error flag
DMA2_FLAG_GL5	DMA2 Channel5 global flag
DMA2_FLAG_TC5	DMA2 Channel5 transfer complete flag
DMA2_FLAG_HT5	DMA2 Channel5 half transfer flag
DMA2_FLAG_TE5	DMA2 Channel5 transfer error flag

**Example:**

```

/* Test if the DMA1 Channel6 half transfer interrupt flag is set or
not */
FlagStatus Status;
Status = DMA_GetFlagStatus(DMA1_FLAG_HT6);

```

## 7.2.8 DMA\_ClearFlag function

[Table 124](#) describes DMA\_ClearFlag function.

**Table 124. DMA\_ClearFlag function**

Function name	DMA_ClearFlag
Function prototype	void DMA_ClearFlag(u32 DMA_FLAG)
Behavior description	Clears the DMAy Channelx's pending flags.
Input parameter	DMA_FLAG: flag to be cleared. More than one flag can be cleared using the “ ” operator. Refer to <a href="#">DMA_FLAG</a> for more details on the allowed values for this parameter. The user can select more than one flag, by ‘ORing’ them.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the DMA1 Channel3 transfer error interrupt pending bit */  
DMA_ClearFlag(DMA1_FLAG_TE3);
```

## 7.2.9 DMA\_GetITStatus function

[Table 125](#) describes DMA\_GetITStatus function.

**Table 125. DMA\_GetITStatus function**

Function name	DMA_GetITStatus
Function prototype	ITStatus DMA_GetITStatus(u32 DMA_IT)
Behavior description	Checks whether the specified DMAy Channelx interrupt has occurred or not.
Input parameter	DMA_IT: DMAy Channelx interrupt source to check. Refer to <a href="#">DMA_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of DMA_IT (SET or RESET).
Required preconditions	None
Called functions	None

### DMA\_IT

The DMA\_IT selects the interrupt that will be checked. See [Table 126](#) for a description of this input parameter.

**Table 126. DMA\_IT values**

DMA_IT	Description
DMA1_IT_GL1	DMA1 Channel1 global interrupt
DMA1_IT_TC1	DMA1 Channel1 transfer complete interrupt
DMA1_IT_HT1	DMA1 Channel1 half transfer interrupt
DMA1_IT_TE1	DMA1 Channel1 transfer error interrupt
DMA1_IT_GL2	DMA1 Channel2 global interrupt
DMA1_IT_TC2	DMA1 Channel2 transfer complete interrupt
DMA1_IT_HT2	DMA1 Channel2 half transfer interrupt
DMA1_IT_TE2	DMA1 Channel2 transfer error interrupt
DMA1_IT_GL3	DMA1 Channel3 global interrupt
DMA1_IT_TC3	DMA1 Channel3 transfer complete interrupt
DMA1_IT_HT3	DMA1 Channel3 half transfer interrupt
DMA1_IT_TE3	DMA1 Channel3 transfer error interrupt
DMA1_IT_GL4	DMA1 Channel4 global interrupt
DMA1_IT_TC4	DMA1 Channel4 transfer complete interrupt
DMA1_IT_HT4	DMA1 Channel4 half transfer interrupt
DMA1_IT_TE4	DMA1 Channel4 transfer error interrupt
DMA1_IT_GL5	DMA1 Channel5 global interrupt
DMA1_IT_TC5	DMA1 Channel5 transfer complete interrupt

Table 126. DMA\_IT values (continued)

DMA_IT	Description
DMA1_IT_HT5	DMA1 Channel5 half transfer interrupt
DMA1_IT_TE5	DMA1 Channel5 transfer error interrupt
DMA1_IT_GL6	DMA1 Channel6 global interrupt
DMA1_IT_TC6	DMA1 Channel6 transfer complete interrupt
DMA1_IT_HT6	DMA1 Channel6 half transfer interrupt
DMA1_IT_TE6	DMA1 Channel6 transfer error interrupt
DMA1_IT_GL7	DMA1 Channel7 global interrupt
DMA1_IT_TC7	DMA1 Channel7 transfer complete interrupt
DMA1_IT_HT7	DMA1 Channel7 half transfer interrupt
DMA1_IT_TE7	DMA1 Channel7 transfer error interrupt
DMA2_IT_GL1	DMA2 Channel1 global interrupt
DMA2_IT_TC1	DMA2 Channel1 transfer complete interrupt
DMA2_IT_HT1	DMA2 Channel1 half transfer interrupt
DMA2_IT_TE1	DMA2 Channel1 transfer error interrupt
DMA2_IT_GL2	DMA2 Channel2 global interrupt
DMA2_IT_TC2	DMA2 Channel2 transfer complete interrupt
DMA2_IT_HT2	DMA2 Channel2 half transfer interrupt
DMA2_IT_TE2	DMA2 Channel2 transfer error interrupt
DMA2_IT_GL3	DMA2 Channel3 global interrupt
DMA2_IT_TC3	DMA2 Channel3 transfer complete interrupt
DMA2_IT_HT3	DMA2 Channel3 half transfer interrupt
DMA2_IT_TE3	DMA2 Channel3 transfer error interrupt
DMA2_IT_GL4	DMA2 Channel4 global interrupt
DMA2_IT_TC4	DMA2 Channel4 transfer complete interrupt
DMA2_IT_HT4	DMA2 Channel4 half transfer interrupt
DMA2_IT_TE4	DMA2 Channel4 transfer error interrupt
DMA2_IT_GL5	DMA2 Channel5 global interrupt
DMA2_IT_TC5	DMA2 Channel5 transfer complete interrupt
DMA2_IT_HT5	DMA2 Channel5 half transfer interrupt
DMA2_IT_TE5	DMA2 Channel5 transfer error interrupt

**Example:**

```

/* Test if the DMA1 Channel7 transfer complete interrupt has
occurred or not */
ITStatus Status;
Status = DMA_GetITStatus(DMA1_IT_TC7);

```

### 7.2.10 DMA\_ClearITPendingBit function

[Table 127](#) describes DMA\_ClearITPendingBit function.

**Table 127. DMA\_ClearITPendingBit function**

Function name	DMA_ClearITPending Bit
Function prototype	void DMA_ClearITPendingBit(u32 DMA_IT)
Behavior description	Clears the DMAy Channelx's interrupt pending bits.
Input parameter	DMA_IT: DMAy Channelx interrupt pending bit to clear. More than one interrupt can be cleared using the “ ” operator. Refer to <a href="#">DMA_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the DMA1 Channel5 global interrupt pending bit */  
DMA_ClearITPendingBit(DMA1_IT_GL5);
```

## 8 External interrupt/event controller (EXTI)

The External interrupt/event controller (EXTI) consists of up to 19-edge detectors which are used to generate event/interrupt requests. Each input line can be independently configured to select the type (pulse or pending) and the corresponding trigger event (rising, falling or both). Each line can be masked independently. A pending register maintains the status of the interrupt requests.

[Section 8.1: EXTI register structure](#) describes the data structures used in the EXTI firmware library. [Section 8.2: Firmware library functions](#) presents the firmware library functions.

### 8.1 EXTI register structure

The EXTI register structure, `EXTI_TypeDef`, is defined in the `stm32f10xstm32f10x_map.h` file as follows:

```
typedef struct
{
    vu32 IMR;
    vu32 EMR;
    vu32 RTSR;
    vu32 FTSR;
    vu32 SWIER;
    vu32 PR;
} EXTI_TypeDef;
```

[Table 128](#) shows the list of all EXTI registers.

**Table 128. EXTI registers**

Register	Description
IMR	Interrupt Mask Register
EMR	Event Mask Register
RTSR	Rising Trigger Selection Register
FTSR	Falling Trigger Selection Register
SWIR	Software Interrupt Event Register
PR	Pending Register

The EXTI peripheral is declared in the same file, as follows:

```
...
#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE     PERIPH_BASE
#define APB2PERIPH_BASE     (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE      (PERIPH_BASE + 0x20000)
...
#define EXTI_BASE            (APB2PERIPH_BASE + 0x0400)

#ifndef DEBUG
...
#ifdef _EXTI
#define EXTI                  ((EXTI_TypeDef *) EXTI_BASE)
#endif /* _EXTI */
```



```

...
#else   /* DEBUG */
...
#ifdef _EXTI
    EXT EXTI_TypeDef *EXTI;
#endif /* _EXTI */
...
#endif

```

When using the Debug mode, EXTI pointer is initialized in *stm32f10x\_lib.c* file:

```

#ifdef _EXTI
EXTI = (EXTI_TypeDef *) EXTI_BASE;
#endif /* _EXTI */

```

To access the EXTI registers, `_EXTI` must be defined in *stm32f10x\_conf.h* as follows:

```
#define _EXTI
```

## 8.2 Firmware library functions

[Table 129](#) lists the various functions of the EXTI firmware library.

**Table 129. EXTI Firmware library functions**

Function name	Description
EXTI_DeInit	Resets the EXTI peripheral registers to their default reset values.
EXTI_Init	Initializes the EXTI peripheral according to the specified parameters in the EXTI_InitStruct.
EXTI_StructInit	Fills each EXTI_InitStruct member with its default value.
EXTI_GenerateSWInterrupt	Generates a software interrupt.
EXTI_GetFlagStatus	Checks whether the specified EXTI line flag is set or not.
EXTI_ClearFlag	Clears the EXTI's line pending flags.
EXTI_GetITStatus	Checks whether the specified EXTI line is asserted or not.
EXTI_ClearITPendingBit	Clears the EXTI's line pending bits.

## 8.2.1 EXTI\_DeInit function

[Table 130](#) describes the EXTI\_DeInit function.

**Table 130. EXTI\_DeInit function**

Function name	EXTI_DeInit
Function prototype	void EXTI_DeInit(void)
Behavior description	Resets the EXTI peripheral registers to their default reset values.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### Example:

```
/* Resets the EXTI registers to their default reset value */
EXTI_DeInit();
```

## 8.2.2 EXTI\_Init function

[Table 131](#) describes the EXTI\_DeInit function.

**Table 131. EXTI\_DeInit function**

Function name	EXTI_Init
Function prototype	void EXTI_Init(EXTI_InitTypeDef* EXTI_InitStruct)
Behavior description	Initializes the EXTI peripheral according to the parameters specified in the EXTI_InitStruct.
Input parameter	EXTI_InitStruct: pointer to a EXTI_InitTypeDef structure that contains the configuration information for the specified EXTI peripheral. Refer to <a href="#">EXTI_InitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## EXTI\_InitTypeDef structure

The EXTI\_InitTypeDef structure is defined in *stm32f10x\_exti.h*:

```
typedef struct
{
    u32 EXTI_Line;
    EXTIMode_TypeDef EXTI_Mode;
    EXTIrigger_TypeDef EXTI_Trigger;
    FunctionalState EXTI_LineCmd;
} EXTI_InitTypeDef;
```

### EXTI\_Line

EXTI\_Line selects the external lines to be enabled or disabled. The values taken by this member are given in [Table 132](#).

**Table 132. EXTI\_Line values**

EXTI_Line	Description
EXTI_Line0	External interrupt line 0
EXTI_Line1	External interrupt line 1
EXTI_Line2	External interrupt line 2
EXTI_Line3	External interrupt line 3
EXTI_Line4	External interrupt line 4
EXTI_Line5	External interrupt line 5
EXTI_Line6	External interrupt line 6
EXTI_Line7	External interrupt line 7
EXTI_Line8	External interrupt line 8
EXTI_Line9	External interrupt line 9
EXTI_Line10	External interrupt line 10
EXTI_Line11	External interrupt line 11
EXTI_Line12	External interrupt line 12
EXTI_Line13	External interrupt line 13
EXTI_Line14	External interrupt line 14
EXTI_Line15	External interrupt line 15
EXTI_Line16	External interrupt line 16
EXTI_Line17	External interrupt line 17
EXTI_Line18	External interrupt line 18

### EXTI\_Mode

EXTI\_Mode configures the mode for the enabled lines. The values taken by this member are given in [Table 133](#).

**Table 133. EXTI\_Mode values**

EXTI_Mode	Description
EXTI_Mode_Event	EXTI lines configured as event request
EXTI_Mode_Interrupt	EXTI lines configured as interrupt request

### EXTI\_Trigger

EXTI configures the trigger signal active edge for the enabled lines. The values taken by this member are given in [Table 134](#).

**Table 134. EXTI\_Trigger values**

EXTI_Trigger	Description
EXTI_Trigger_Falling	Interrupt request configured on falling edge of the input line
EXTI_Trigger_Rising	Interrupt request configured on rising edge of the input line
EXTI_Trigger_Rising_Falling	Interrupt request configured on rising and falling edge of the input line

### EXTI\_LineCmd

This member is used to define the new state of the selected line. It can be set either to ENABLE or DISABLE.

#### Example:

```
/* Enables external lines 12 and 14 interrupt generation on falling
edge */
EXTI_InitTypeDef EXTI_InitStructure;
EXTI_InitStructure.EXTI_Line = EXTI_Line12 | EXTI_Line14;
EXTI_InitStructure.EXTI_Mode = EXTI_Mode_Interrupt;
EXTI_InitStructure.EXTI_Trigger = EXTI_Trigger_Falling;
EXTI_InitStructure.EXTI_LineCmd = ENABLE;
EXTI_Init(&EXTI_InitStructure);
```

### 8.2.3 EXTI\_Struct function

*Table 135* describes the EXTI\_StructInit function.

**Table 135. EXTI\_StructInit function**

Function name	EXTI_StructInit
Function prototype	void EXTI_StructInit(EXTI_InitTypeDef*EXTI_InitStruct)
Behavior description	Fills each EXTI_InitStruct member with its default value.
Input parameter	EXTI_InitStruct: pointer to a EXTI_InitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

*Table 136* gives the EXTI\_InitStruct members default values:

**Table 136. EXTI\_InitStruct default values**

Member	Default value
EXTI_Line	EXTI_LineNone
EXTI_Mode	EXTI_Mode_Interrupt
EXTI_Trigger	EXTI_Trigger_Falling
EXTI_LineCmd	DISABLE

**Example:**

```
/* Initialize the EXTI Init Structure parameters */
EXTI_InitTypeDef EXTI_InitStructure;
EXTI_StructInit(&EXTI_InitStructure);
```

## 8.2.4 EXTI\_GenerateSWInterrupt function

[Table 137](#) describes the EXTI\_GenerateSWInterrupt function.

**Table 137. EXTI\_GenerateSWInterrupt function**

Function name	EXTI_GenerateSWInterrupt
Function prototype	void EXTI_GenerateSWInterrupt(u32 EXTI_Line)
Behavior description	Generates a software interrupt.
Input parameter	EXTI_Line: EXTI lines to be enabled or disabled. Refer to <a href="#">EXTI_Line</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Generate a software interrupt request */
EXTI_GenerateSWInterrupt(EXTI_Line6);
```

## 8.2.5 EXTI\_GetFlagStatus function

[Table 138](#) describes the EXTI\_GetFlagStatus function.

**Table 138. EXTI\_GetFlagStatus function**

Function name	EXTI_GetFlagStatus
Function prototype	FlagStatus EXTI_GetFlagStatus(u32 EXTI_Line)
Behavior description	Checks whether the specified EXTI line flag is set or not.
Input parameter	EXTI_Line: EXTI lines flag to check. Refer to <a href="#">EXTI_Line</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of EXTI_Line (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the status of EXTI line 8 */
FlagStatus EXTIStatus;
EXTIStatus = EXTI_GetFlagStatus(EXTI_Line8);
```

## 8.2.6 EXTI\_ClearFlag function

[Table 139](#) describes the EXTI\_ClearFlag function.

**Table 139. EXTI\_ClearFlag function**

Function name	EXTI_ClearFlag
Function prototype	void EXTI_ClearFlag(u32 EXTI_Line)
Behavior description	Clears the EXTI line pending flags.
Input parameter	EXTI_Line: EXTI lines flags to clear. Refer to <a href="#">EXTI_Line</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the EXTI line 2 pending flag */
EXTI_ClearFlag(EXTI_Line2);
```

## 8.2.7 EXTI\_GetITStatus function

[Table 140](#) describes the EXTI\_GetITStatus function.

**Table 140. EXTI\_GetITStatus function**

Function name	EXTI_GetITStatus
Function prototype	ITStatus EXTI_GetITStatus(u32 EXTI_Line)
Behavior description	Checks whether the specified EXTI line is asserted or not.
Input parameter	EXTI_Line: EXTI lines pending bits to check. Refer to <a href="#">EXTI_Line</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of EXTI_Line (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the status of EXTI line 8 */
ITStatus EXTIStatus;
EXTIStatus = EXTI_GetITStatus(EXTI_Line8);
```

### 8.2.8 EXTI\_ClearITPendingBit function

*Table 141* describes the EXTI\_ClearITPendingBit function.

**Table 141. EXTI\_ClearITPendingBit function**

Function name	EXTI_ClearITPendingBit
Function prototype	void EXTI_ClearITPendingBit(u32 EXTI_Line)
Behavior description	Clears the EXTI's line pending bits.
Input parameter	EXTI_Line: EXTI lines pending bits to clear. Refer to <a href="#">EXTI_Line</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clears the EXTI line 2 interrupt pending bit */  
EXTI_ClearITpendingBit(EXTI_Line2);
```



## 9 Flash memory (FLASH)

[Section 9.1: FLASH register structures](#) describes the data structures used in the FLASH Firmware Library. [Section 9.2: Firmware library functions](#) presents the Firmware Library functions.

### 9.1 FLASH register structures

The FLASH register structures, *FLASH\_TypeDef* and *OB\_TypeDef*, are defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32 ACR;
    vu32 KEYR;
    vu32 OPTKEYR;
    vu32 SR;
    vu32 CR;
    vu32 AR;
    vu32 RESERVED;
    vu32 OBR;
    vu32 WRPR;
} FLASH_TypeDef;

typedef struct
{
    vu16 RDP;
    vu16 USER;
    vu16 Data0;
    vu16 Data1;
    vu16 WRP0;
    vu16 WRP1;
    vu16 WRP2;
    vu16 WRP3;
} OB_TypeDef;
```

[Table 142](#) and [Table 143](#) give the list of the FLASH registers and Option Byte registers (OB), respectively.

**Table 142. FLASH registers**

Register	Description
ACR	Flash Access Control Register
KEYR	FPEC Key Register
OPTKEYR	Option Byte Key Register
SR	Flash Status Register
CR	Flash Control Register
AR	Flash Address Register
OBR	Option Byte and Status Register
WRPR	Option Byte write protection Register

**Table 143. Option Bytes registers (OB)**

Register	Description
RDP	Read Out Option Byte
USER	User Option Byte
Data0	Data0 Option Byte
Data1	Data1 Option Byte
WRP0	Write Protection 0 Option Byte
WRP1	Write Protection 1 Option Byte
WRP2	Write Protection 2 Option Byte
WRP3	Write Protection 3 Option Byte

The FLASH peripheral is declared in *stm32f10x\_map.h*:

```

/* Flash registers base address */
#define FLASH_BASE          ((u32)0x40022000)

/* Flash Option Bytes base address */
#define OB_BASE              ((u32)0x1FFFF800)
#ifndef DEBUG
...
#ifdef _FLASH
    #define FLASH              ((FLASH_TypeDef *) FLASH_BASE)
    #define OB                  ((OB_TypeDef *) OB_BASE)
#endif /* _FLASH */
...
#else /* DEBUG */
...
#ifdef _FLASH
    EXT FLASH_TypeDef          *FLASH;
    EXT OB_TypeDef              *OB;
#endif /* _FLASH */
...
#endif

```

When using the Debug mode, FLASH and OB pointers are initialized in *stm32f10x\_lib.c* file:

```

#ifdef _FLASH
FLASH = (FLASH_TypeDef *) FLASH_BASE;
OB = (OB_TypeDef *) OB_BASE;
#endif /* _FLASH */

```

To access the FLASH registers, `_FLASH` must be defined in *stm32f10x\_conf.h* as follows:

```
#define _FLASH
```

By default only the functions performing FLASH configuration (latency, prefetch, half cycle) are enabled (see [Table 144](#)).

To enable FLASH program/erase/protectsions functions, `_FLASH_PROG` must be defined in *stm32f10x\_conf.h* as follows:

```
#define _FLASH_PROG
```

## 9.2 Firmware library functions

*Table 144* lists the various functions of the FLASH library.

**Table 144. FLASH library function**

Function name	Description
FLASH_SetLatency	Sets the code latency value.
FLASH_HalfCycleAccessCmd	Enables or disables the Half cycle FLASH access.
FLASH_PrefetchBufferCmd	Enables or disables the Prefetch Buffer.
FLASH_Unlock	Unlocks the FLASH Program Erase Controller.
FLASH_Lock	Locks the Flash Program Erase Controller.
FLASH_ErasePage	Erases a specified FLASH page.
FLASH_EraseAllPages	Erases all FLASH pages.
FLASH_EraseOptionBytes	Erases the FLASH option bytes.
FLASH_ProgramWord	Programs a word at a specified address.
FLASH_ProgramHalfWord	Programs a half word at a specified address.
FLASH_ProgramOptionByteData	Programs a half word at a specified Option Byte Data address.
FLASH_EnableWriteProtection	Write protects the desired pages
FLASH_ReadOutProtection	Enables or disables the read out protection.
FLASH_UserOptionByteConfig	Programs the FLASH User Option Byte: IWDG_SW / RST_STOP / RST_STDBY.
FLASH_GetUserOptionByte	Returns the FLASH User Option Bytes values.
FLASH_GetWriteProtectionOptionByte	Returns the FLASH Write Protection Option Bytes Register value.
FLASH_GetReadOutProtectionStatus	Checks whether the FLASH Read Out Protection Status is set or not.
FLASH_GetPrefetchBufferStatus	Checks whether the FLASH Prefetch Buffer status is set or not.
FLASH_ITConfig	Enables or disables the specified FLASH interrupts.
FLASH_GetFlagStatus	Checks whether the specified FLASH flag is set or not.
FLASH_ClearFlag	Clears the FLASH pending flags.
FLASH_GetStatus	Returns the FLASH Status.
FLASH_WaitForLastOperation	Waits for a Flash operation to complete or a TIMEOUT to occur.

### 9.2.1 FLASH\_SetLatency function

[Table 145](#) describes the FLASH\_SetLatency function.

**Table 145. FLASH\_SetLatency function**

Function name	FLASH_SetLatency
Function prototype	void FLASH_SetLatency(u32 FLASH_Latency)
Behavior description	Sets the code latency value.
Input parameter	FLASH_Latency specifies the FLASH Latency value. Refer to <a href="#">FLASH_Latency</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### FLASH\_Latency

FLASH\_Latency is used to configure the FLASH Latency value. See [Table 146](#) for the values of this parameter.

**Table 146. FLASH\_Latency values**

FLASH_Latency	Description
FLASH_Latency_0	Zero Latency cycle.
FLASH_Latency_1	One Latency cycle.
FLASH_Latency_2	Two Latency cycles.

#### Example:

```
/* Configure the Latency cycle: Set 2 Latency cycles */  
FLASH_SetLatency(FLASH_Latency_2);
```

### 9.2.2 FLASH\_HalfCycleAccessCmd function

[Table 147](#) describes the FLASH\_HalfCycleAccessCmd function.

**Table 147. FLASH\_HalfCycleAccessCmd function**

Function name	FLASH_HalfCycleAccessCmd
Function prototype	void FLASH_HalfCycleAccessCmd(u32 FLASH_HalfCycleAccess)
Behavior description	Enables or disables the Half cycle Flash access.
Input parameter	FLASH_HalfCycle: FLASH Half cycle mode. Refer to <a href="#">FLASH_HalfCycleAccess</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### FLASH\_HalfCycleAccess

FLASH\_HalfCycleAccess is used to select the FLASH Half Cycle access mode. See [Table 148](#) for the values of this parameter.

**Table 148. FLASH\_HalfCycleAccess values**

FLASH_HalfCycleAccess	Description
FLASH_HalfCycleAccess_Enable	Half Cycle Access Enable
FLASH_HalfCycleAccess_Disable	Half Cycle Access Disable

#### Example:

```
/* Enable the Half Cycle Flash access */
FLASH_HalfCycleAccessCmd(FLASH_HalfCycleAccess_Enable);
```

### 9.2.3 FLASH\_PrefetchBufferCmd function

[Table 149](#) describes the FLASH\_PrefetchBufferCmd function.

**Table 149. FLASH\_PrefetchBufferCmd function**

Function name	FLASH_PrefetchBufferCmd
Function prototype	void FLASH_PrefetchBufferCmd(u32 FLASH_PrefetchBuffer)
Behavior description	Enables or disables the Prefetch Buffer.
Input parameter	FLASH_PrefetchBuffer: Prefetch buffer status. Refer to <a href="#">FLASH_PrefetchBuffer</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### FLASH\_PrefetchBuffer

FLASH\_PrefetchBuffer is used to select the FLASH Prefetch Buffer status. See [Table 150](#) for the values of this parameter.

**Table 150. FLASH\_PrefetchBuffer values**

FLASH_PrefetchBuffer	Description
FLASH_PrefetchBuffer_Enable	Prefetch Buffer Enable
FLASH_PrefetchBuffer_Disable	Prefetch Buffer Disable

#### Example:

```
/* Enable The Prefetch Buffer */  
FLASH_PrefetchBufferCmd(FLASH_PrefetchBuffer_Enable);
```

## 9.2.4 FLASH\_Unlock function

*Table 151* describes the FLASH\_Unlock function.

**Table 151. FLASH\_Unlock function**

Function name	FLASH_Unlock
Function prototype	void FLASH_Unlock(void)
Behavior description	Unlocks the FLASH Program Erase Controller.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Unlocks the Flash */  
FLASH_Unlock();
```

## 9.2.5 FLASH\_Lock function

*Table 152* describes the FLASH\_Lock function.

**Table 152. FLASH\_Lock function**

Function name	FLASH_Lock
Function prototype	void FLASH_Lock(void)
Behavior description	Locks the FLASH Program Erase Controller.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Locks the Flash */  
FLASH_Lock();
```

## 9.2.6 FLASH\_ErasePage function

[Table 153](#) describes the FLASH\_ErasePage function.

**Table 153. FLASH\_ErasePage function**

Function name	FLASH_ErasePage
Function prototype	FLASH_Status FLASH_ErasePage(u32 Page_Address)
Behavior description	Erases a FLASH page.
Input parameter	FLASH_Page: page to be erased
Output parameter	None
Return parameter	The Erase operation Status.
Required preconditions	None
Called functions	None

**Example:**

```
/* Erases the Flash Page 0 */  
FLASH_Status status = FLASH_COMPLETE;  
status = FLASH_ErasePage(0x08000000);
```

## 9.2.7 FLASH\_EraseAllPages function

[Table 154](#) describes FLASH\_EraseAllPages function.

**Table 154. FLASH\_EraseAllPages function**

Function name	FLASH_EraseAllPages
Function prototype	FLASH_Status FLASH_EraseAllPages(void)
Behavior description	Erases all FLASH pages.
Input parameter	None
Output parameter	None
Return parameter	The Erase operation Status
Required preconditions	None
Called functions	None

**Example:**

```
/* Erases the Flash */  
FLASH_Status status = FLASH_COMPLETE;  
status = FLASH_EraseAllPages();
```



## 9.2.8 FLASH\_EraseOptionBytes function

*Table 155* describes the FLASH\_EraseOptionBytes function.

**Table 155. FLASH\_EraseOptionBytes function**

Function name	FLASH_EraseOptionBytes
Function prototype	FLASH_Status FLASH_EraseOptionBytes(void)
Behavior description	Erases the FLASH option bytes.
Input parameter	None
Output parameter	None
Return parameter	The Erase operation Status
Required preconditions	None
Called functions	None

**Example:**

```
/* Erases the Flash Option Bytes */
FLASH_Status status = FLASH_COMPLETE;
status = FLASH_EraseOptionBytes();
```

## 9.2.9 FLASH\_ProgramWord function

*Table 156* describes the FLASH\_ProgramWord function.

**Table 156. FLASH\_ProgramWord function**

Function name	FLASH_ProgramWord
Function prototype	FLASH_Status FLASH_ProgramWord(u32 Address, u32 Data)
Behavior description	Programs a word at a specified address.
Input parameter1	Address: address to be programmed.
Input parameter2	Data: specifies the data to be programmed.
Output parameter	None
Return parameter	The Program operation Status.
Required preconditions	None
Called functions	None

**Example:**

```
/* Writes the Data1 at the Address1 */
FLASH_Status status = FLASH_COMPLETE;
u32 Data1 = 0x1234567;
u32 Address1 = 0x8000000;
status = FLASH_ProgramWord(Address1, Data1);
```

### 9.2.10 FLASH\_ProgramHalfWord function

*Table 157* describes the FLASH\_ProgramHalfWord function.

**Table 157. FLASH\_ProgramHalfWord function**

Function name	FLASH_ProgramHalfWord
Function prototype	FLASH_Status FLASH_ProgramHalfWord(u32 Address, u16 Data)
Behavior description	Programs a half word at a specified address.
Input parameter1	Address: address to be programmed.
Input parameter2	Data: half-word data to be programmed.
Output parameter	None
Return parameter	The Program operation Status.
Required preconditions	None
Called functions	None

**Example:**

```
/* Writes the Data1 at the Address1 */
FLASH_Status status = FLASH_COMPLETE;
u16 Data1 = 0x1234;
u32 Address1 = 0x8000004;
status = FLASH_ProgramHalfWord(Address1, Data1);
```

### 9.2.11 FLASH\_ProgramOptionByteData function

*Table 158* describes the FLASH\_ProgramOptionByteData function.

**Table 158. FLASH\_ProgramOptionByteData function**

Function name	FLASH_ProgramOptionByteData
Function prototype	FLASH_Status FLASH_ProgramOptionByteData(u32 Address, u8 Data)
Behavior description	Programs a half word at a specified Option Byte Data address.
Input parameter1	Address: address to be programmed. This parameter can be 0x1FFFF804 or 0x1FFFF806.
Input parameter2	Data: specifies the data to be programmed.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Writes the Data1 at the Address1 */
FLASH_Status status = FLASH_COMPLETE;
u8 Data1 = 0x12;
u32 Address1 = 0x1FFFF804;
status = FLASH_ProgramOptionByteData(Address1, Data1);
```

## 9.2.12 FLASH\_EnableWriteProtection function

[Table 159](#) describes the FLASH\_EnableWriteProtection function.

**Table 159. FLASH\_EnableWriteProtection function**

Function name	FLASH_EnableWriteProtection
Function prototype	FLASH_Status FLASH_EnableWriteProtection(u32 FLASH_Pages)
Behavior description	Write protects the desired pages.
Input parameter	FLASH_Pages: address of the pages to be write protected. Refer to <a href="#">FLASH_Pages</a> for more details on the values of this parameter.
Output parameter	None
Return parameter	The write protection operation Status.
Required preconditions	None
Called functions	None

### FLASH\_Pages

FLASH\_Pages is used to configure the FLASH write protection pages. [Table 160](#) and [Table 161](#) give the values taken by this parameter for Medium-density STM32F10xxx devices (FLASH page size equal to 1 KB) and High-density STM32F10xxx devices (FLASH page size equal to 2 KB), respectively.

**Table 160. FLASH\_Pages values for Medium-density devices**

FLASH_Pages	Description
FLASH_WRProt_Pages0to3	Write protection of page 0 to 3.
FLASH_WRProt_Pages4to7	Write protection of page 4 to 7.
FLASH_WRProt_Pages8to11	Write protection of page 8 to 11.
FLASH_WRProt_Pages12to15	Write protection of page 12 to 15.
FLASH_WRProt_Pages16to19	Write protection of page 16 to 19.
FLASH_WRProt_Pages20to23	Write protection of page 20 to 23.
FLASH_WRProt_Pages24to27	Write protection of page 24 to 27.
FLASH_WRProt_Pages28to31	Write protection of page 28 to 31.
FLASH_WRProt_Pages32to35	Write protection of page 32 to 35.
FLASH_WRProt_Pages36to39	Write protection of page 36 to 39.
FLASH_WRProt_Pages40to43	Write protection of page 40 to 43.
FLASH_WRProt_Pages44to47	Write protection of page 44 to 47.
FLASH_WRProt_Pages48to51	Write protection of page 48 to 51.
FLASH_WRProt_Pages52to55	Write protection of page 52 to 55.
FLASH_WRProt_Pages56to59	Write protection of page 56 to 59.
FLASH_WRProt_Pages60to63	Write protection of page 60 to 63.
FLASH_WRProt_Pages64to67	Write protection of page 64 to 67.

**Table 160. FLASH\_Pages values for Medium-density devices (continued)**

FLASH_Pages	Description
FLASH_WRProt_Pages68to71	Write protection of page 68 to 71.
FLASH_WRProt_Pages72to75	Write protection of page 72 to 75.
FLASH_WRProt_Pages76to79	Write protection of page 76 to 79.
FLASH_WRProt_Pages80to83	Write protection of page 80 to 83.
FLASH_WRProt_Pages84to87	Write protection of page 84 to 87.
FLASH_WRProt_Pages88to91	Write protection of page 88 to 91.
FLASH_WRProt_Pages92to95	Write protection of page 92 to 95.
FLASH_WRProt_Pages96to99	Write protection of page 96 to 99.
FLASH_WRProt_Pages100to103	Write protection of page 100 to 103.
FLASH_WRProt_Pages104to107	Write protection of page 104 to 107.
FLASH_WRProt_Pages108to111	Write protection of page 108 to 111.
FLASH_WRProt_Pages112to115	Write protection of page 112 to 115.
FLASH_WRProt_Pages116to119	Write protection of page 115 to 119.
FLASH_WRProt_Pages120to123	Write protection of page 120 to 123.
FLASH_WRProt_Pages124to127	Write protection of page 124 to 127.
FLASH_WRProt_AllPages	Write protection all Pages.

**Table 161. FLASH\_Pages values for High-density devices**

FLASH_Pages	Description
FLASH_WRProt_Pages0to1	Write protection of page 0 to 1.
FLASH_WRProt_Pages2to3	Write protection of page 2 to 3.
FLASH_WRProt_Pages4to5	Write protection of page 4 to 5.
FLASH_WRProt_Pages6to7	Write protection of page 6 to 7.
FLASH_WRProt_Pages8to9	Write protection of page 8 to 9.
FLASH_WRProt_Pages10to11	Write protection of page 10 to 11.
FLASH_WRProt_Pages12to13	Write protection of page 12 to 13.
FLASH_WRProt_Pages14to15	Write protection of page 14 to 15.
FLASH_WRProt_Pages16to17	Write protection of page 16 to 17.
FLASH_WRProt_Pages18to19	Write protection of page 18 to 19.
FLASH_WRProt_Pages20to21	Write protection of page 20 to 21.
FLASH_WRProt_Pages22to23	Write protection of page 22 to 23.
FLASH_WRProt_Pages24to25	Write protection of page 24 to 25.
FLASH_WRProt_Pages26to27	Write protection of page 26 to 27.
FLASH_WRProt_Pages28to29	Write protection of page 28 to 29.
FLASH_WRProt_Pages30to31	Write protection of page 30 to 31.

**Table 161. FLASH\_Pages values for High-density devices (continued)**

FLASH_Pages	Description
FLASH_WRProt_Pages32to33	Write protection of page 32 to 33.
FLASH_WRProt_Pages34to35	Write protection of page 34 to 35.
FLASH_WRProt_Pages36to37	Write protection of page 36 to 37.
FLASH_WRProt_Pages38to39	Write protection of page 38 to 39.
FLASH_WRProt_Pages40to41	Write protection of page 40 to 41.
FLASH_WRProt_Pages42to43	Write protection of page 42 to 43.
FLASH_WRProt_Pages44to45	Write protection of page 44 to 45.
FLASH_WRProt_Pages46to47	Write protection of page 46 to 47.
FLASH_WRProt_Pages48to49	Write protection of page 48 to 49.
FLASH_WRProt_Pages50to51	Write protection of page 50 to 51.
FLASH_WRProt_Pages52to53	Write protection of page 52 to 53.
FLASH_WRProt_Pages54to55	Write protection of page 54 to 55.
FLASH_WRProt_Pages56to57	Write protection of page 56 to 57.
FLASH_WRProt_Pages58to59	Write protection of page 58 to 59.
FLASH_WRProt_Pages60to61	Write protection of page 60 to 61.
FLASH_WRProt_Pages62to255	Write protection of page 62 to 255.
FLASH_WRProt_AllPages	Write protection all Pages.

**Example:**

```
/* Protects the Pages0to3 and Pages108to111 */
FLASH_Status status = FLASH_COMPLETE;
status = FLASH_EnableWriteProtection
(FLASH_WRProt_Pages0to3 | FLASH_WRProt_Pages108to111);
```

**9.2.13 FLASH\_ReadOutProtection function**

*Table 162* describes the FLASH\_ReadOutProtection function.

**Table 162. FLASH\_ReadOutProtection function**

Function name	FLASH_ReadOutProtection
Function prototype	FLASH_Status FLASH_ReadOutProtection(FunctionalState NewState)
Behavior description	Enables or disables the read out protection.
Input parameter	NewState: new state of the Read Out protection. This parameter can be set either to ENABLE or DISABLE.
Output parameter	None
Return parameter	The protection operation Status.
Required preconditions	If the user has already programmed the other option bytes before calling this function, he must re-program them since this function erases all option bytes.
Called functions	None

**Example:**

```
/* Disables the ReadOut Protection */
FLASH_Status status = FLASH_COMPLETE;
status = FLASH_ReadOutProtection(DISABLE);
```

**Note:** To safely program the option bytes, the user has to follow the order of the operations described below:

1. Call the `FLASH_ReadOutProtection` function, if there is a need to read-protect the Flash memory
2. Call the `FLASH_EnableWriteProtection` function in order to write-protect some pages or all the Flash memory
3. Call the `FLASH_UserOptionByteConfig` to program the user option byte: `IWDG_SW` / `RST_STOP` / `RST_STDBY`
4. Call the `FLASH_ProgramOptionByteData` to program a half-word to the specified option byte data addresses
5. Generate a reset to load the new option bytes

### 9.2.14 FLASH\_UserOptionByteConfig function

[Table 163](#) describes the `FLASH_UserOptionByteConfig` function.

**Table 163. FLASH\_UserOptionByteConfig function**

Function name	FLASH_UserOptionByteConfig
Function prototype	FLASH_Status FLASH_UserOptionByteConfig(u16 OB_IWDG, u16 OB_STOP, u16 OB_STDBY)
Behavior description	Programs the FLASH User Option Byte: <code>IWDG_SW</code> / <code>RST_STOP</code> / <code>RST_STDBY</code> .
Input parameter1	OB_IWDG: Selects the IWDG mode. Refer to <a href="#">OB_IWDG</a> for more details on the values of this parameter.
Input parameter2	OB_STOP: Reset event when entering Stop mode. Refer to <a href="#">OB_STOP</a> for more details on the values of this parameter.
Input parameter3	OB_STDBY: Reset event when entering Standby mode. Refer to <a href="#">OB_STDBY</a> for more details on the values of this parameter.
Output parameter	None
Return parameter	The Option Byte program Status.
Required preconditions	None
Called functions	None

**OB\_IWDG**

This parameter configures the IWDG mode. See [Table 164](#) for the values taken by OB\_IWDG.

**Table 164. OB\_IWDG values**

OB_IWDG	Description
OB_IWDG_SW	Software IWDG selected.
OB_IWDG_HW	Hardware IWDG selected.

**OB\_STOP**

This parameter specifies if a Reset is generated or not when entering Stop mode. See [Table 165](#) for the values taken by OB\_STOP.

**Table 165. OB\_STOP values**

OB_STOP	Description
OB_STOP_NoRST	No reset generated when entering Stop mode
OB_STOP_RST	Reset generated when entering Stop mode

**OB\_STDBY**

This parameter specifies if a Reset is generated or not when entering Standby mode. See [Table 166](#) for the values taken by OB\_STBY.

**Table 166. OB\_STDBY values**

OB_STDBY	Description
OB_STDBY_NoRST	No reset generated when entering Standby mode
OB_STDBY_RST	Reset generated when entering Standby mode

**Example:**

```
/* Option Bytes Configuration: software watchdog, Reset generation
when entering in Stop and No reset generation when entering in
Standby */
FLASH_Status status = FLASH_COMPLETE;
status = FLASH_UserOptionByteConfig(OB_IWDG_SW, OB_STOP_RST,
OB_STDBY_NoRST);
```

### 9.2.15 FLASH\_GetUserOptionByte function

*Table 167* describes the FLASH\_GetUserOptionByte function.

**Table 167. FLASH\_GetUserOptionByte function**

Function name	FLASH_GetUserOptionByte
Function prototype	u32 FLASH_GetUserOptionByte(void)
Behavior description	Returns the FLASH User Option Bytes values.
Input parameter	None
Output parameter	None
Return parameter	The FLASH User Option Bytes values: IWDG_SW(Bit0), RST_STOP(Bit1) and RST_STDBY(Bit2).
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the user option byte values */
u32 UserByteValue = 0x0;
u32 IWDGValue = 0x0, RST_STOPValue = 0x0, RST_STDBYValue = 0x0;
UserByteValue = FLASH_GetUserOptionByte();
IWDGValue = UserByteValue & 0x0001;
RST_STOPValue = UserByteValue & 0x0002;
RST_STDBYValue = UserByteValue & 0x0004;
```

### 9.2.16 FLASH\_GetWriteProtectionOptionByte function

*Table 168* describes the FLASH\_GetWriteProtectionOptionByte function.

**Table 168. FLASH\_GetWriteProtectionOptionByte function**

Function name	FLASH_GetWriteProtectionOptionByte
Function prototype	u32 FLASH_GetWriteProtectionOptionByte(void)
Behavior description	Returns the FLASH Write Protection Option Bytes Register value.
Input parameter	None
Output parameter	None
Return parameter	The FLASH Write Protection Option Bytes Register value.
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the Write Protection option byte values */
u32 WriteProtectionValue = 0x0;
WriteProtectionValue = FLASH_GetWriteProtectionOptionByte();
```



### 9.2.17 FLASH\_GetReadOutProtectionStatus function

*Table 169* describes the FLASH\_GetReadOutProtectionStatus function.

**Table 169. FLASH\_GetReadOutProtectionStatus function**

Function name	FLASH_GetReadOutProtectionStatus
Function prototype	FlagStatus FLASH_GetReadOutProtectionStatus(void)
Behavior description	Checks whether the FLASH Read Out Protection Status is set or not.
Input parameter	None
Output parameter	None
Return parameter	FLASH ReadOut Protection Status (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the ReadOut Protection status */
FlagStatus status = RESET;
status = FLASH_GetReadOutProtectionStatus();
```

### 9.2.18 FLASH\_GetPrefetchBufferStatus function

*Table 170* describes the FLASH\_GetPrefetchBufferStatus function.

**Table 170. FLASH\_GetPrefetchBufferStatus function**

Function name	FLASH_GetPrefetchBufferStatus
Function prototype	FlagStatus FLASH_GetPrefetchBufferStatus(void)
Behavior description	Checks whether the FLASH Prefetch Buffer status is set or not.
Input parameter	None
Output parameter	None
Return parameter	FLASH Prefetch Buffer Status (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the Prefetch Buffer status */
FlagStatus status = RESET;
status = FLASH_GetPrefetchBufferStatus();
```

### 9.2.19 FLASH\_ITConfig function

*Table 171* describes the FLASH\_ITConfig function.

**Table 171. FLASH\_ITConfig function**

Function name	FLASH_ITConfig
Function prototype	void FLASH_ITConfig(u16 FLASH_IT, FunctionalState NewState)
Behavior description	Enables or disables the specified FLASH interrupts.
Input parameter1	FLASH_IT: FLASH interrupt sources to be enabled or disabled. Refer to <a href="#">FLASH_IT</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the specified FLASH interrupts. This parameter can be set to ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### FLASH\_IT

This parameter is used to enable or disable FLASH interrupts. One or a combination of the following values can be used:

**Table 172. FLASH\_IT values**

FLASH_IT	Description
FLASH_IT_ERROR	FPEC error interrupt source
FLASH_IT_EOP	End of FLASH Operation Interrupt source

**Example:**

```
/* Enables the EOP Interrupt source */  
FLASH_ITConfig(FLASH_IT_EOP, ENABLE);
```

## 9.2.20 FLASH\_GetFlagStatus function

*Table 173* describes the FLASH\_GetFlagStatus function.

**Table 173. Flah\_GetFlagStatus function**

Function name	FLASH_GetFlagStatus
Function prototype	FlagStatus FLASH_GetFlagStatus(u16 FLASH_FLAG)
Behavior description	Checks whether the specified FLASH flag is set or not.
Input parameter	None
Input parameter	FLASH_FLAG: flag to be checked. Refer to <a href="#">FLASH_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### FLASH\_FLAG

The FLASH flags which can be checked by issuing the FLASH\_GetFlagStatus function are listed in the following table:

**Table 174. FLASH\_FLAG definition**

FLASH_FLAG	Description
FLASH_FLAG_BSY	FLASH Busy flag
FLASH_FLAG_EOP	FLASH end of operation flag
FLASH_FLAG_PGERR	FLASH Program error flag
FLASH_FLAG_WRPRTERR	FLASH Page Write protected error flag
FLASH_FLAG_OPTERR	FLASH Option Byte error flag

#### Example:

```
/* Checks whether the EOP Flag Status is SET or not */
FlagStatus status = RESET;
status = FLASH_GetFlagStatus(FLASH_FLAG_EOP);
```

### 9.2.21 FLASH\_ClearFlag function

*Table 175* describes the FLASH\_ClearFlag function.

**Table 175. FLASH\_ClearFlag function**

Function name	FLASH_ClearFlag
Function prototype	void FLASH_ClearFlag(u16 FLASH_Flag)
Behavior description	Clears the FLASH pending flags
Input parameter	FLASH_FLAG: flag to be cleared Refer to <a href="#">FLASH_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### FLASH\_FLAG

The FLASH flags that can be cleared by issuing the FLASH\_ClearFlag function are listed in the following table:

**Table 176. FLASH\_FLAG definition**

FLASH_FLAG	Description
FLASH_FLAG_BSY	FLASH Busy flag
FLASH_FLAG_EOP	FLASH end of operation flag
FLASH_FLAG_PGERR	FLASH Program error flag
FLASH_FLAG_WRPRTERR	FLASH Page Write protected error flag

**Example:**

```
/* Clears all flags */  
FLASH_ClearFlag(FLASH_FLAG_BSY | FLASH_FLAG_EOP | FLASH_FLAG_PGER  
| FLASH_FLAG_WRPRTERR);
```

### 9.2.22 FLASH\_GetStatus function

[Table 177](#) describes the FLASH\_GetStatus function.

**Table 177. FLASH\_GetStatus function**

Function name	FLASH_GetStatus
Function prototype	FLASH_Status FLASH_GetStatus(void)
Behavior description	Returns the FLASH Status.
Input parameter	None
Output parameter	None
Return parameter	FLASH Status: The returned value can be: FLASH_BUSY, FLASH_ERROR_PG or FLASH_ERROR_WRP or FLASH_COMPLETE
Required preconditions	None
Called functions	None

**Example:**

```
/* Check for the Flash status */
FLASH_Status status = FLASH_COMPLETE;
status = FLASH_GetStatus();
```

### 9.2.23 FLASH\_WaitForLastOperation function

[Table 178](#) describes the FLASH\_WaitForLastOperation function.

**Table 178. FLASH\_WaitForLastOperation function**

Function name	FLASH_WaitForLastOperation
Function prototype	FLASH_Status FLASH_WaitForLastOperation(u32 Timeout)
Behavior description	Waits for a Flash operation to complete or a TIMEOUT to occur.
Input parameter	None
Output parameter	None
Return parameter	Return the appropriate operation Status. This parameter can be FLASH_BUSY, FLASH_ERROR_PG or FLASH_ERROR_WRP or FLASH_COMPLETE or FLASH_TIMEOUT
Required preconditions	None
Called functions	None

**Example:**

```
/* Waits for the Flash operation to be completed */
FLASH_Status status = FLASH_COMPLETE;
status = FLASH_WaitForLastOperation();
```

## 10 General purpose I/O (GPIO)

The GPIO driver can be used for several purposes, including pin configuration, single bit set/reset, lock mechanism, reading from a port pin, and writing data into a port pin.

[Section 10.1: GPIO register structure](#) describes the data structures used in the GPIO Firmware Library. [Section 10.2: Firmware library functions](#) presents the Firmware Library functions.

### 10.1 GPIO register structure

The GPIO register structure, `GPIO_TypeDef`, is defined in the `stm32f10x_map.h` file as follows:

```
typedef struct
{
    vu32 CRL;
    vu32 CRH;
    vu32 IDR;
    vu32 ODR;
    vu32 BSRR;
    vu32 BRR;
    vu32 LCKR;
} GPIO_TypeDef;

typedef struct
{
    vu32 EVCR;
    vu32 MAPR;
    vu32 EXTICR[4];
} AFIO_TypeDef;
```

[Table 179](#) gives the list of the GPIO registers:

**Table 179. GPIO registers**

Register	Description
CRL	Port Control Register low
CRH	Port Control Register High
IDR	Input Data Register
ODR	Output Data Register
BSRR	Bit Set Reset Register
BRR	Bit Reset Register
LCKR	Lock Register
EVCR	Event Control Register
MAPR	Remap Debug and AF Register
EXTICR	EXTI Line 0 to Line 15 Configuration Register

The five GPIO peripherals are declared in *stm32f10x\_map.h*:

```

...
#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE      PERIPH_BASE
#define APB2PERIPH_BASE      (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE       (PERIPH_BASE + 0x20000)
...
#define AFIO_BASE            (APB2PERIPH_BASE + 0x0000)
#define GPIOA_BASE           (APB2PERIPH_BASE + 0x0800)
#define GPIOB_BASE           (APB2PERIPH_BASE + 0x0C00)
#define GPIOC_BASE           (APB2PERIPH_BASE + 0x1000)
#define GPIOD_BASE           (APB2PERIPH_BASE + 0x1400)
#define GPIOE_BASE           (APB2PERIPH_BASE + 0x1800)
#define GPIOF_BASE           (APB2PERIPH_BASE + 0x1C00)
#define GPIOG_BASE           (APB2PERIPH_BASE + 0x2000)

#ifndef DEBUG
...
#ifdef _AFIO
    #define AFIO              ((AFIO_TypeDef *) AFIO_BASE)
#endif /* _AFIO */

#ifdef _GPIOA
    #define GPIOA             ((GPIO_TypeDef *) GPIOA_BASE)
#endif /* _GPIOA */

#ifdef _GPIOB
    #define GPIOB             ((GPIO_TypeDef *) GPIOB_BASE)
#endif /* _GPIOB */

#ifdef _GPIOC
    #define GPIOC             ((GPIO_TypeDef *) GPIOC_BASE)
#endif /* _GPIOC */

#ifdef _GPIOD
    #define GPIOD             ((GPIO_TypeDef *) GPIOD_BASE)
#endif /* _GPIOD */

#ifdef _GPIOE
    #define GPIOE             ((GPIO_TypeDef *) GPIOE_BASE)
#endif /* _GPIOE */
#ifdef _GPIOF
    #define GPIOF             ((GPIO_TypeDef *) GPIOF_BASE)
#endif /* _GPIOF */
#ifdef _GPIOG
    #define GPIOG             ((GPIO_TypeDef *) GPIOG_BASE)
#endif /* _GPIOG */
...
#else /* DEBUG */
...
#ifdef _AFIO
    EXT AFIO_TypeDef          *AFIO;

```

```

#endif /*_AFIO */

#ifdef _GPIOA
    EXT GPIO_TypeDef *GPIOA;
#endif /*_GPIOA */

#ifdef _GPIOB
    EXT GPIO_TypeDef *GPIOB;
#endif /*_GPIOB */

#ifdef _GPIOC
    EXT GPIO_TypeDef *GPIOC;
#endif /*_GPIOC */

#ifdef _GPIOD
    EXT GPIO_TypeDef *GPIOD;
#endif /*_GPIOD */

#ifdef _GPIOE
    EXT GPIO_TypeDef *GPIOE;
#endif /*_GPIOE */
#ifdef _GPIOF
    EXT GPIO_TypeDef *GPIOF;
#endif /*_GPIOF */
#ifdef _GPIOG
    EXT GPIO_TypeDef *GPIOG;
#endif /*_GPIOG */
...
#endif

```

When using the Debug mode, \_AFIO, \_GPIOA, \_GPIOB, \_GPIOC, \_GPIOD, \_GPIOE, \_GPIOF and \_GPIOG pointers are initialized in *stm32f10x\_lib.c* file:

```

#ifdef _GPIOA
    GPIOA = (GPIO_TypeDef *) GPIOA_BASE;
#endif /*_GPIOA */

#ifdef _GPIOB
    GPIOB = (GPIO_TypeDef *) GPIOB_BASE;
#endif /*_GPIOB */

#ifdef _GPIOC
    GPIOC = (GPIO_TypeDef *) GPIOC_BASE;
#endif /*_GPIOC */

#ifdef _GPIOD
    GPIOD = (GPIO_TypeDef *) GPIOD_BASE;
#endif /*_GPIOD */

#ifdef _GPIOE
    GPIOE = (GPIO_TypeDef *) GPIOE_BASE;
#endif /*_GPIOE */

```



```
#ifndef _GPIOF
    GPIOF = (GPIO_TypeDef *) GPIOG_BASE;
#endif /*_GPIOF */
```

```
#ifndef _GPIOG
    GPIOG = (GPIO_TypeDef *) GPIOG_BASE;
#endif /*_GPIOG */
```

```
#ifndef _AFIO
    AFIO = (AFIO_TypeDef *) AFIO_BASE;
#endif /*_AFIO */
```

To access the GPIO registers, \_GPIO, \_AFIO, \_GPIOA, \_GPIOB, \_GPIOC, \_GPIOD, \_GPIOE, \_GPIOF and \_GPIOG must be defined in stm32f10x\_conf.h:

```
#define _GPIO
#define _GPIOA
#define _GPIOB
#define _GPIOC
#define _GPIOD
#define _GPIOE
#define _GPIOF
#define _GPIOG
#define _AFIO
```

## 10.2 Firmware library functions

[Table 180](#) gives the list of the GPIO firmware library functions.

**Table 180. GPIO firmware library functions**

Function name	Description
GPIO_DeInit	Resets the GPIOx peripheral registers to their default reset values.
GPIO_AFIODeInit	Resets the Alternate Functions (remap, event control and EXTI configuration) registers to their default reset values.
GPIO_Init	Initializes the GPIOx peripheral according to the specified parameters in the GPIO_InitStruct.
GPIO_StructInit	Fills each GPIO_InitStruct member with its default value.
GPIO_ReadInputDataBit	Reads the specified input port pin
GPIO_ReadInputData	Reads the specified GPIO input data port
GPIO_ReadOutputDataBit	Reads the specified output data port bit
GPIO_ReadOutputData	Reads the specified GPIO output data port
<b>GPIO_SetBits</b>	Sets the selected data port bits
<b>GPIO_ResetBits</b>	Clears the selected data port bits
GPIO_WriteBit	Sets or clears the selected data port bit
GPIO_Write	Writes data to the specified GPIO data port
GPIO_PinLockConfig	Locks GPIO Pins configuration registers
GPIO_EventOutputConfig	Selects the GPIO pin used as Event output.
GPIO_EventOutputCmd	Enables or disables the Event Output.
GPIO_PinRemapConfig	Changes the mapping of the specified pin.
GPIO_EXTILineConfig	Selects the GPIO pin used as EXTI Line.

### 10.2.1 GPIO\_DeInit function

[Table 181](#) describes the GPIO\_DeInit function.

**Table 181. GPIO\_DeInit function**

Function name	GPIO_DeInit
Function prototype	void GPIO_DeInit(GPIO_TypeDef* GPIOx)
Behavior description	Resets the GPIOx peripheral registers to their default reset values.
Input parameter	GPIOx: where x can be (A..G) to select the GPIO peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_APB2PeriphResetCmd()

**Example:**

```
/* Resets the GPIOA peripheral registers to their default reset
values */
GPIO_DeInit(GPIOA);
```

**10.2.2 GPIO\_AFIODeInit function**

[Table 182](#) describes the GPIO\_AFIODeInit function.

**Table 182. GPIO\_AFIODeInit function**

Function name	GPIO_AFIODeInit
Function prototype	void GPIO_AFIODeInit(void)
Behavior description	Resets the Alternate functions registers (remap, event control and EXTI configuration) to their default reset values.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_APB2PeriphResetCmd()

**Example:**

```
/* Resets the Alternate functions registers to their default reset
values */
GPIO_AFIODeInit();
```

**10.2.3 GPIO\_Init function**

[Table 183](#) describes the GPIO\_Init function.

**Table 183. GPIO\_Init function**

Function name	GPIO_Init
Function prototype	void GPIO_Init(GPIO_TypeDef* GPIOx, GPIO_InitTypeDef* GPIO_InitStruct)
Behavior description	Initializes the GPIOx peripheral according to the specified parameters in the GPIO_InitStruct.
Input parameter1	GPIOx: where x can be (A..G) to select the GPIO peripheral.
Input parameter2	GPIO_InitStruct: pointer to a GPIO_InitTypeDef structure that contains the configuration information for the specified GPIO peripheral. Refer to <a href="#">GPIO_InitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## GPIO\_InitTypeDef structure

The GPIO\_InitTypeDef structure is defined in the *stm32f10x\_gpio.h* file:

```
typedef struct
{
    u16 GPIO_Pin;
    GPIO_Speed_TypeDef GPIO_Speed;
    GPIOMode_TypeDef GPIO_Mode;
} GPIO_InitTypeDef;
```

### GPIO\_Pin

This member selects the GPIO pins to configure. Multiple-pin configuration can be performed by using the 'I' operator. Any combination of the following values can be used:

**Table 184. GPIO\_Pin values**

GPIO_Pin	Description
GPIO_Pin_None	No pin selected
GPIO_Pin_0	Pin 0 Selected
GPIO_Pin_1	Pin 1 Selected
GPIO_Pin_2	Pin 2 Selected
GPIO_Pin_3	Pin 3 Selected
GPIO_Pin_4	Pin 4 Selected
GPIO_Pin_5	Pin 5 Selected
GPIO_Pin_6	Pin 6 Selected
GPIO_Pin_7	Pin 7 Selected
GPIO_Pin_8	Pin 8 Selected
GPIO_Pin_9	Pin 9 Selected
GPIO_Pin_10	Pin 10 Selected
GPIO_Pin_11	Pin 11 Selected
GPIO_Pin_12	Pin 12 Selected
GPIO_Pin_13	Pin 13 Selected
GPIO_Pin_14	Pin 14 Selected
GPIO_Pin_15	Pin 15 Selected
GPIO_Pin_All	All Pins Selected

### GPIO\_Speed

GPIO\_Speed is used to configure the speed for the selected pins. See [Table 185](#) for the values taken by this member.

**Table 185. GPIO\_Speed values**

GPIO_Speed	Description
GPIO_Speed_10MHz	Output Maximum Frequency = 10 MHz
GPIO_Speed_2MHz	Output Maximum Frequency = 2 MHz
GPIO_Speed_50MHz	Output Maximum Frequency = 50 MHz

**GPIO\_Mode**

GPIO\_Mode configures the operating mode for the selected pins. See [Table 186](#) for the values taken by this member.

**Table 186. GPIO\_Mode values**

GPIO_Mode	Description
GPIO_Mode_AIN	Analog Input
GPIO_Mode_IN_FLOATING	Input Floating
GPIO_Mode_IPD	Input Pull-Down
GPIO_Mode_IPU	Input Pull-up
GPIO_Mode_Out_OD	Open Drain Output
GPIO_Mode_Out_PP	Push-Pull Output
GPIO_Mode_AF_OD	Open Drain Output Alternate-Function
GPIO_Mode_AF_PP	Push-Pull Output Alternate-Function

- Note:**
- 1 When a pin is configured in input pull-up or pull-down mode, the Px\_BSRR and Px\_BRR registers are used.
  - 2 GPIO\_Mode allows to configure both the GPIO direction (Input/Output) and the corresponding input/output configuration: bits[7:4] GPIO\_Mode configure the GPIO direction, while bits [4:0] define the configuration. The GPIO direction have the following indexes:
    - GPIO in input mode = 0x00
    - GPIO in output mode = 0x01

[Table 187](#) shows all the GPIO\_Mode indexes and codes.

**Table 187. GPIO\_Mode indexes and codes**

GPIO Direction	Index	Mode	Configuration	Mode Code
GPIO Input	0x00	GPIO_Mode_AIN	0x00	0x00
		GPIO_Mode_IN_FLOATING	0x04	0x04
		GPIO_Mode_IPD	0x08	0x28
		GPIO_Mode_IPU	0x08	0x48
GPIO Output	0x01	GPIO_Mode_Out_OD	0x04	0x14
		GPIO_Mode_Out_PP	0x00	0x10
		GPIO_Mode_AF_OD	0x0C	0x1C
		GPIO_Mode_AF_PP	0x08	0x18

**Example:**

```

/* Configure all the GPIOA in Input Floating mode */
GPIO_InitTypeDef GPIO_InitStructure;
GPIO_InitStructure.GPIO_Pin = GPIO_Pin_All;
GPIO_InitStructure.GPIO_Speed = GPIO_Speed_10MHz;
GPIO_InitStructure.GPIO_Mode = GPIO_Mode_IN_FLOATING;
GPIO_Init(GPIOA, &GPIO_InitStructure);

```

**10.2.4 GPIO\_StructInit function**

[Table 188](#) describes the GPIO\_StructInit function.

**Table 188. GPIO\_StructInit function**

Function name	GPIO_StructInit
Function prototype	void GPIO_StructInit(GPIO_InitTypeDef* GPIO_InitStruct)
Behavior description	Fills each GPIO_InitStruct member with its default value.
Input parameter	GPIO_InitStruct: pointer to a GPIO_InitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The GPIO\_InitStruct default values are given in [Table 189](#).

**Table 189. GPIO\_InitStruct default values**

Member	Default value
GPIO_Pin	GPIO_Pin_All
GPIO_Speed	GPIO_Speed_2MHz
GPIO_Mode	GPIO_Mode_IN_FLOATING

**Example:**

```
/* Initialize the GPIO Init Structure parameters */
GPIO_InitTypeDef GPIO_InitStructure;
GPIO_StructInit(&GPIO_InitStructure);
```

**10.2.5 GPIO\_ReadInputDataBit function**

[Table 190](#) describes the GPIO\_ReadInputDataBit function.

**Table 190. GPIO\_ReadInputDataBit function**

Function name	GPIO_ReadInputDataBit
Function prototype	u8 GPIO_ReadInputDataBit(GPIO_TypeDef* GPIOx, u16 GPIO_Pin)
Behavior description	Reads the specified input port pin.
Input parameter1	GPIOx: where x can be (A..G) to select the GPIO peripheral.
Input parameter2	GPIO_Pin: port bit to be read. Refer to <a href="#">GPIO_Pin</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The input port pin value.
Required preconditions	None
Called functions	None

**Example:**

```
/* Reads the seventh pin of the GPIOB and store it in ReadValue
variable */
u8 ReadValue;
ReadValue = GPIO_ReadInputDataBit(GPIOB, GPIO_Pin_7);
```

**10.2.6 GPIO\_ReadInputData function**

[Table 191](#) describes the GPIO\_ReadInputData function.

**Table 191. GPIO\_ReadInputData function**

Function name	GPIO_ReadInputData
Function prototype	u16 GPIO_ReadInputData(GPIO_TypeDef* GPIOx)
Behavior description	Reads the specified GPIO input data port.
Input parameter	GPIOx: where x can be (A..G) to select the GPIO peripheral.
Output parameter	None
Return parameter	GPIO input data port value.
Required preconditions	None
Called functions	None

**Example:**

```
/*Read the GPIOC input data port and store it in ReadValue
variable*/
```

```
u16 ReadValue;
ReadValue = GPIO_ReadInputData(GPIOC);
```

### 10.2.7 GPIO\_ReadOutputDataBit function

[Table 192](#) describes the GPIO\_ReadOutputDataBit function.

**Table 192. GPIO\_ReadOutputDataBit function**

Function name	GPIO_ReadOutputDataBit
Function prototype	u8 GPIO_ReadOutputDataBit(GPIO_TypeDef* GPIOx, u16 GPIO_Pin)
Behavior description	Reads the specified output data port bit.
Input parameter1	GPIOx: where x can be (A..G) to select the GPIO peripheral.
Input parameter2	GPIO_Pin: port bit to read. Refer to <a href="#">GPIO_Pin</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The output port pin value.
Required preconditions	None
Called functions	None

**Example:**

```
/* Reads the seventh pin of the GPIOB and store it in ReadValue
variable */
u8 ReadValue;
ReadValue = GPIO_ReadOutputDataBit(GPIOB, GPIO_Pin_7);
```

### 10.2.8 GPIO\_ReadOutputData function

[Table 193](#) describes the GPIO\_ReadOutputData function.

**Table 193. GPIO\_ReadOutputData function**

Function name	GPIO_ReadOutputData
Function prototype	u16 GPIO_ReadOutputData(GPIO_TypeDef* GPIOx)
Behavior description	Reads the specified GPIO output data port.
Input parameter	GPIOx: where x can be (A..G) to select the GPIO peripheral.
Output parameter	None
Return parameter	GPIO output data port value.
Required preconditions	None
Called functions	None

**Example:**

```
/* Read the GPIOC output data port and store it in ReadValue
variable */
u16 ReadValue;
ReadValue = GPIO_ReadOutputData(GPIOC);
```



## 10.2.9 GPIO\_SetBits

[Table 193](#) describes the GPIO\_SetBits function.

**Table 194. GPIO\_SetBits function**

Function name	GPIO_SetBits
Function prototype	void GPIO_SetBits(GPIO_TypeDef* GPIOx, u16 GPIO_Pin)
Behavior description	Sets the selected data port bits.
Input parameter1	GPIOx: where x can be (A..G) to select the GPIO peripheral.
Input parameter2	GPIO_Pin: specifies the port bits to be written. This parameter can be any combination of GPIO_Pin_x where x can be (0..15). Refer to <a href="#">GPIO_Pin</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set the GPIOA port pin 10 and pin 15 */
GPIO_SetBits(GPIOA, GPIO_Pin_10 | GPIO_Pin_15);
```

## 10.2.10 GPIO\_ResetBits

[Table 195](#) describes the GPIO\_ResetBits function.

**Table 195. GPIO\_ResetBits function**

Function name	GPIO_ResetBits
Function prototype	void GPIO_ResetBits(GPIO_TypeDef* GPIOx, u16 GPIO_Pin)
Behavior description	Clears the selected data port bits.
Input parameter1	GPIOx: where x can be (A..G) to select the GPIO peripheral.
Input parameter2	GPIO_Pin: specifies the port bits to be written. This parameter can be any combination of GPIO_Pin_x where x can be (0..15). Refer to <a href="#">GPIO_Pin</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clears the GPIOA port pin 10 and pin 15 */
GPIO_ResetBits(GPIOA, GPIO_Pin_10 | GPIO_Pin_15);
```

## 10.2.11 GPIO\_WriteBit function

*Table 196* describes the GPIO\_WriteBit function.

**Table 196. GPIO\_WriteBit function**

Function name	GPIO_WriteBit
Function prototype	void GPIO_WriteBit(GPIO_TypeDef* GPIOx, u16 GPIO_Pin, BitAction BitVal)
Behavior description	Sets or clears the selected data port bit.
Input parameter1	GPIOx: where x can be (A..G) to select the GPIO peripheral.
Input parameter2	GPIO_Pin: port bit to be written. Refer to <a href="#">GPIO_Pin</a> for more details on the allowed values for this parameter.
Input parameter3	BitVal: this parameter specifies the value to be written to the selected bit. BitVal must be one of the BitAction enum values: Bit_RESET: to clear the port pin. Bit_SET: to set the port pin.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set the GPIOA port pin 15 */
GPIO_WriteBit(GPIOA, GPIO_Pin_15, Bit_SET);
```

## 10.2.12 GPIO\_Write function

*Table 197* describes the GPIO\_Write function.

**Table 197. GPIO\_Write function**

Function name	GPIO_Write
Function prototype	void GPIO_Write(GPIO_TypeDef* GPIOx, u16 PortVal)
Behavior description	Writes the passed value in the selected data GPIOx port register.
Input parameter1	GPIOx: where x can be (A..G) to select the GPIO peripheral.
Input parameter2	PortVal: the value to be written to the data port register.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Write data to GPIOA data port */
GPIO_Write(GPIOA, 0x1101);
```

### 10.2.13 GPIO\_PinLockConfig function

[Table 198](#) describes the GPIO\_PinLockConfig function.

**Table 198. GPIO\_PinLockConfig function**

Function name	GPIO_PinLockConfig
Function prototype	void GPIO_PinLockConfig(GPIO_TypeDef* GPIOx, u16 GPIO_Pin)
Behavior description	Locks GPIO pins configuration registers.
Input parameter1	GPIOx: where x can be (A..G) to select the GPIO peripheral.
Input parameter2	GPIO_Pin: port bit to be written. Refer to <a href="#">GPIO_Pin</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Lock GPIOA Pin0 and Pin1 */
GPIO_PinLockConfig(GPIOA, GPIO_Pin_0 | GPIO_Pin_1);
```

### 10.2.14 GPIO\_EventOutputConfig function

[Table 199](#) describes the GPIO\_EventOutputConfig function.

**Table 199. GPIO\_EventOutputConfig function**

Function name	GPIO_EventOutputConfig
Function prototype	void GPIO_EventOutputConfig(u8 GPIO_PortSource, u8 GPIO_PinSource)
Behavior description	Selects the GPIO pin used as Event output.
Input parameter1	GPIO_PortSource: selects the GPIO port to be used as source for Event output. Refer to <a href="#">GPIO_PortSource</a> for more details on the allowed values for this parameter.
Input parameter2	GPIO_PinSource: pin for the Event output. This parameter can be GPIO_PinSourcex where x can be (0..15).
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### GPIO\_PortSource

This parameter is used to select the GPIO port source used as Event output. See [Table 200](#) for the values taken by GPIO\_PortSource.

**Table 200. GPIO\_PortSource values**

GPIO_PortSource	Description
GPIO_PortSourceGPIOA	GPIOA Selected
GPIO_PortSourceGPIOB	GPIOB Selected
GPIO_PortSourceGPIOC	GPIOC Selected
GPIO_PortSourceGPIOD	GPIOD Selected
GPIO_PortSourceGPIOE	GPIOE Selected

**Example:**

```
/* Selects the GPIOE pin 5 for EVENT output */
GPIO_EventOutputConfig(GPIO_PortSourceGPIOE, GPIO_PinSource5);
```

**10.2.15 GPIO\_EventOutputCmd function**

[Table 201](#) describes the GPIO\_EventOutputCmd function.

**Table 201. GPIO\_EventOutputCmd function**

Function name	GPIO_EventOutputCmd
Function prototype	void GPIO_EventOutputCmd(FunctionalState NewState)
Behavior description	Enables or disables the Event Output.
Input parameter	NewState: new state of the Event output. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable Event Output to the GPIOC pin 6 */
GPIO_EventOutputConfig(GPIO_PortSourceGPIOC, GPIO_PinSource6);
GPIO_EventOutputCmd(ENABLE);
```

## 10.2.16 GPIO\_PinRemapConfig function

[Table 202](#) describes the GPIO\_PinRemapConfig function.

**Table 202. GPIO\_PinRemapConfig function**

Function name	GPIO_PinRemapConfig
Function prototype	void GPIO_PinRemapConfig(u32 GPIO_Remap, FunctionalState NewState)
Behavior description	Changes the mapping of the specified pin.
Input parameter1	GPIO_Remap: selects the pin to remap. Refer to <a href="#">GPIO_Remap</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the port pin remapping. This parameter can be set to ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### GPIO\_Remap

GPIO\_Remap parameter is used to change the alternate function mapping. See [Table 203](#) for the values taken by this parameter.

**Table 203. GPIO\_Remap values**

GPIO_Remap	Description
GPIO_Remap_SPI1	SPI1 Alternate Function mapping
GPIO_Remap_I2C1	I2C1 Alternate Function mapping
GPIO_Remap_USART1	USART1 Alternate Function mapping
GPIO_Remap_USART2	USART2 Alternate Function mapping
GPIO_PartialRemap_USART3	USART3 Partial Alternate Function mapping
GPIO_FullRemap_USART3	USART3 Full Alternate Function mapping
GPIO_PartialRemap_TIM1	TIM1 Partial Alternate Function mapping
GPIO_FullRemap_TIM1	TIM1 Full Alternate Function mapping
GPIO_PartialRemap1_TIM2	TIM2 Partial1 Alternate Function mapping
GPIO_PartialRemap2_TIM2	TIM2 Partial2 Alternate Function mapping
GPIO_FullRemap_TIM2	TIM2 Full Alternate Function mapping
GPIO_PartialRemap_TIM3	TIM3 Partial Alternate Function mapping
GPIO_FullRemap_TIM3	TIM3 Full Alternate Function mapping
GPIO_Remap_TIM4	TIM4 Alternate Function mapping
GPIO_Remap1_CAN	CAN Alternate Function mapping
GPIO_Remap2_CAN	CAN Alternate Function mapping

**Table 203. GPIO\_Remap values (continued)**

GPIO_Remap	Description
GPIO_Remap_PD01	PD01 Alternate Function mapping
GPIO_Remap_TIM5CH4_LSI	LSI connected to TIM5 Channel4 input capture for calibration
GPIO_Remap_ADC1_ETRGINJ	ADC1 External Trigger Injected Conversion mapping
GPIO_Remap_ADC1_ETRGREG	ADC1 External Trigger Regular Conversion mapping
GPIO_Remap_ADC2_ETRGINJ	ADC2 External Trigger Injected Conversion mapping
GPIO_Remap_ADC2_ETRGREG	ADC2 External Trigger Regular Conversion mapping
GPIO_Remap_SWJ_NoJTRST	Full SWJ Enabled (JTAG-DP + SW-DP) but without JTRST
GPIO_Remap_SWJ_JTAGDisable	JTAG-DP Disabled and SW-DP Enabled
GPIO_Remap_SWJ_Disable	Full SWJ Disabled (JTAG-DP + SW-DP)

**Example:**

```
/* I2C1_SCL on PB.08, I2C1_SDA on PB.09 */
GPIO_PinRemapConfig(GPIO_Remap_I2C1, ENABLE);
```

**10.2.17 GPIO\_EXTILineConfig function**

[Table 204](#) describes the GPIO\_EXTILineConfig function.

**Table 204. GPIO\_EXTILineConfig function**

Function name	GPIO_EXTILineConfig
Function prototype	void GPIO_EXTILineConfig(u8 GPIO_PortSource, u8 GPIO_PinSource)
Behavior description	Selects the GPIO pin used as EXTI Line.
Input parameter1	GPIO_PortSource: selects the GPIO port to be used as source for EXTI lines. Refer to <a href="#">GPIO_PortSource</a> for more details on the allowed values for this parameter.
Input parameter2	GPIO_PinSource: EXTI line to be configured. This parameter can be GPIO_PinSourcex where x can be (0..15).
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**GPIO\_PortSource**

This parameter is used to select the GPIO port source used as Event output. See [Table 205](#) for the values taken by GPIO\_PortSource.

**Table 205. GPIO\_PortSource values**

GPIO_PortSource	Description
GPIO_PortSourceGPIOA	GPIOA Selected
GPIO_PortSourceGPIOB	GPIOB Selected
GPIO_PortSourceGPIOC	GPIOC Selected
GPIO_PortSourceGPIOD	GPIOD Selected
GPIO_PortSourceGPIOE	GPIOE Selected
GPIO_PortSourceGPIOF	GPIOF Selected
GPIO_PortSourceGPIOG	GPIOG Selected

**Example:**

```
/* Selects PB.08 as EXTI Line 8 */  
GPIO_EXTILineConfig(GPIO_PortSource_GPIOB, GPIO_PinSource8);
```

## 11 Inter-integrated circuit (I<sup>2</sup>C)

The I<sup>2</sup>C bus interface module is the interface between the microcontroller and the serial I<sup>2</sup>C bus. It provides both multi-master and slave functions. It controls all I<sup>2</sup>C bus specific sequencing, protocol, arbitration and timing. It can also perform additional functions such as CRC generation and checking, SMBus and PMBus.

The I<sup>2</sup>C driver can be used to transmit and receive data through the I<sup>2</sup>C interface. The status of the executed action is returned by the I<sup>2</sup>C driver.

[Section 11.1: I2C register structure](#) describes the register structure used in the I<sup>2</sup>C Firmware Library. [Section 11.2: Firmware library functions](#) presents the Firmware Library functions.

### 11.1 I<sup>2</sup>C register structure

The I<sup>2</sup>C register structure, *I2C\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu16 CR1;
    u16 RESERVED0;
    vu16 CR2;
    u16 RESERVED1;
    vu16 OAR1;
    u16 RESERVED2;
    vu16 OAR2;
    u16 RESERVED3;
    vu16 DR;
    u16 RESERVED4;
    vu16 SR1;
    u16 RESERVED5;
    vu16 SR2;
    u16 RESERVED6;
    vu16 CCR;
    u16 RESERVED7;
    vu16 TRISE;
    u16 RESERVED8;
} I2C_TypeDef;
```



Table 206 gives the list of I<sup>2</sup>C registers:

**Table 206. I<sup>2</sup>C registers**

Register	Description
CR1	I <sup>2</sup> C Control Register1
CR2	I <sup>2</sup> C Control Register2
OAR1	I <sup>2</sup> C Own Address Register1
OAR2	I <sup>2</sup> C Own Address Register2 (Dual Address)
DR	I <sup>2</sup> C Data Register
SR1	I <sup>2</sup> C Status Register1
SR2	I <sup>2</sup> C Status Register2
CCR	I <sup>2</sup> C Clock Control Register
TRISE	I <sup>2</sup> C Rise Time Register

The two I<sup>2</sup>C peripherals are declared in *stm32f10x\_map.h*:

```
...
#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE     PERIPH_BASE
#define APB2PERIPH_BASE     (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE      (PERIPH_BASE + 0x20000)
...
#define I2C1_BASE            (APB1PERIPH_BASE + 0x5400)
#define I2C2_BASE            (APB1PERIPH_BASE + 0x5800)
...
#ifndef DEBUG
...
#ifdef _I2C1
    #define I2C1              ((I2C_TypeDef *) I2C1_BASE)
#endif /* _I2C1 */

#ifdef _I2C2
    #define I2C2              ((I2C_TypeDef *) I2C2_BASE)
#endif /* _I2C2 */
...
#else /* DEBUG */
...
#ifdef _I2C1
    EXT I2C_TypeDef           *I2C1;
#endif /* _I2C1 */

#ifdef _I2C2
    EXT I2C_TypeDef           *I2C2;
#endif /* _I2C2 */
...
#endif
```

When using the Debug mode, \_I2C1 and \_I2C2 pointers are initialized in *stm32f10x\_lib.c* file.

```
...
#ifdef _I2C1
    I2C1 = (I2C_TypeDef *) I2C1_BASE;
#endif /*_I2C1 */

#ifdef _I2C2
    I2C2 = (I2C_TypeDef *) I2C2_BASE;
#endif /*_I2C2 */
...
```

To access the I<sup>2</sup>C registers, \_I2C, \_I2C1 and \_I2C2 must be defined in *stm32f10x\_conf.h* as follows:

```
...
#define _I2C
#define _I2C1
#define _I2C2
...
```

## 11.2 Firmware library functions

[Table 207](#) gives the list of the I<sup>2</sup>C firmware library functions.

**Table 207. I<sup>2</sup>C firmware library functions**

Function name	Description
I2C_DeInit	Resets the I2Cx peripheral registers to their default reset values.
I2C_Init	Initializes the I2Cx peripheral according to the specified parameters in the I2C_InitStruct.
I2C_StructInit	Fills each I2C_InitStruct member with its default value.
I2C_Cmd	Enables or disables the specified I <sup>2</sup> C peripheral.
I2C_DMACmd	Enables or disables the specified I <sup>2</sup> C DMA requests.
I2C_DMALastTransferCmd	Specifies that the next DMA transfer is the last one.
I2C_GenerateSTART	Generates I2Cx communication Start condition.
I2C_GenerateSTOP	Generates I2Cx communication Stop condition.
I2C_AcknowledgeConfig	Enables or disables the specified I <sup>2</sup> C acknowledge feature.
I2C_OwnAddress2Config	Configures the specified I <sup>2</sup> C own address2.
I2C_DualAddressCmd	Enables or disables the specified I <sup>2</sup> C dual addressing mode.
I2C_GeneralCallCmd	Enables or disables the specified I <sup>2</sup> C general call feature.
I2C_ITConfig	Enables or disables the specified I <sup>2</sup> C interrupts.
I2C_SendData	Sends a data byte through the I2Cx peripheral.
I2C_ReceiveData	Returns the most recent received data by the I2Cx peripheral.

**Table 207. I<sup>2</sup>C firmware library functions (continued)**

Function name	Description
I2C_Send7bitAddress	Transmits the address byte to select the slave device.
I2C_ReadRegister	Reads the specified I <sup>2</sup> C register and returns its value.
I2C_SoftwareResetCmd	Enables or disables the specified I <sup>2</sup> C software reset.
I2C_SMBusAlertConfig	Drives the SMBAlert pin high or low for the specified I <sup>2</sup> C.
I2C_TransmitPEC	Enables or disables the specified I <sup>2</sup> C PEC transfer.
I2C_PECPositionConfig	Selects the specified I <sup>2</sup> C PEC position.
I2C_CalculatePEC	Enables or disables the PEC value calculation of the transferred bytes.
I2C_GetPEC	Returns the PEC value for the specified I <sup>2</sup> C.
I2C_ARPCmd	Enables or disables the specified I <sup>2</sup> C ARP.
I2C_StretchClockCmd	Enables or disables the specified I <sup>2</sup> C clock stretching.
I2C_FastModeDutyCycleConfig	Selects the specified I <sup>2</sup> C fast mode duty cycle.
I2C_GetLastEvent	Returns the last I2Cx event
I2C_CheckEvent	Checks whether the last I2Cx event is equal to the one passed as parameter.
I2C_GetFlagStatus	Checks whether the specified I <sup>2</sup> C flag is set or not.
I2C_ClearFlag	Clears the I2Cx's pending flags.
I2C_GetITStatus	Checks whether the specified I <sup>2</sup> C interrupt has occurred or not.
I2C_ClearITPendingBit	Clears the I2Cx's interrupt pending bits.

### 11.2.1 I2C\_Delnit function

*Table 208* describes the I2C\_Delnit function.

**Table 208. I2C\_Delnit function**

Function name	I2C_Delnit
Function prototype	void I2C_Delnit(I2C_TypeDef* I2Cx)
Behavior description	Resets the I2Cx peripheral registers to their default reset values.
Input parameter	I2Cx: where x can be 1 or 2 to select the I2C peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_APB1PeriphClockCmd().

#### Example:

```
/* Deinitialize I2C2 interface*/
I2C_DeInit(I2C2);
```

## 11.2.2 I2C\_Init function

[Table 209](#) describes the I2C\_Init function.

**Table 209. I2C\_Init function**

Function name	I2C_Init
Function prototype	void I2C_Init(I2C_TypeDef* I2Cx, I2C_InitTypeDef* I2C_InitStruct)
Behavior description	Initializes the I2Cx peripheral according to the specified parameters in the I2C_InitStruct.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	I2C_InitStruct: pointer to a I2C_InitTypeDef structure that contains the configuration information for the specified I <sup>2</sup> C peripheral. Refer to the <a href="#">I2C_InitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## I2C\_InitTypeDef structure

The I2C\_InitTypeDef structure is defined in the *stm32f10x\_i2c.h* file:

```
typedef struct
{
  u16 I2C_Mode;
  u16 I2C_DutyCycle;
  u16 I2C_OwnAddress1;
  u16 I2C_Ack;
  u16 I2C_AcknowledgedAddress;
  u32 I2C_ClockSpeed;
} I2C_InitTypeDef;
```

## I2C\_Mode

I2C\_Mode is used to configure the I<sup>2</sup>C mode. See [Table 214](#) for the values taken by this member.

**Table 210. I2C\_Mode definition**

I2C_Mode	Description
I2C_Mode_I2C	I <sup>2</sup> C is configured in I <sup>2</sup> C mode
I2C_Mode_SMBusDevice	I <sup>2</sup> C is configured in SMBus device mode
I2C_Mode_SMBusHost	I <sup>2</sup> C is configured in SMBus host mode

## I2C\_DutyCycle

I2C\_DutyCycle is used to select the I<sup>2</sup>C fast mode duty cycle. See [Table 211](#) for the values taken by this member.

**Table 211. I2C\_DutyCycle definition**

I2C_DutyCycle	Description
I2C_DutyCycle_16_9	I <sup>2</sup> C fast mode Tlow/Thigh=16/9
I2C_DutyCycle_2	I <sup>2</sup> C fast mode Tlow/Thigh=2

*Note:* This member is meaningful only when the I<sup>2</sup>C operates in Fast mode (working clock speed greater than 100 kHz).

**I2C\_OwnAddress1**

This member is used to configure the first device own address. It can be a 7-bit or 10-bit address.

**I2C\_Ack**

I2C\_Ack enables or disables the acknowledgement. See [Table 212](#) for the values taken by this member.

**Table 212. I2C\_Ack definition**

I2C_Ack	Description
I2C_Ack_Enable	Enables the acknowledgement
I2C_Ack_Disable	Disables the acknowledgement

**I2C\_AcknowledgedAddress**

I2C\_AcknowledgedAddress defines whether if 7-bit or 10-bit address is acknowledged. See [Table 213](#) for the values taken by this member.

**Table 213. I2C\_AcknowledgedAddress values**

I2C_AcknowledgedAddress	Description
I2C_AcknowledgeAddress_7bit	Acknowledge 7-bit address
I2C_AcknowledgeAddress_10bit	Acknowledge 10-bit address

**I2C\_ClockSpeed**

This member is used to configure the clock frequency. It must be set to a value lower than 400kHz.

**Example:**

```
/* Initialize the I2C1 according to the I2C_InitStructure members */
I2C_InitTypeDef I2C_InitStructure;
I2C_InitStructure.I2C_Mode = I2C_Mode_SMBusHost;
I2C_InitStructure.I2C_DutyCycle = I2C_DutyCycle_2;
I2C_InitStructure.I2C_OwnAddress1 = 0x03A2;
I2C_InitStructure.I2C_Ack = I2C_Ack_Enable;
I2C_InitStructure.I2C_AcknowledgedAddress =
I2C_AcknowledgedAddress_7bit;
I2C_InitStructure.I2C_ClockSpeed = 200000;
I2C_Init(I2C1, &I2C_InitStructure);
```

### 11.2.3 I2C\_StructInit function

Table 214 describes the I2C\_StructInit function.

**Table 214. I2C\_StructInit function**

Function name	I2C_StructInit
Function prototype	void I2C_StructInit(I2C_InitTypeDef* I2C_InitStruct)
Behavior description	Fills each I2C_InitStruct member with its default value.
Input parameter	I2C_InitStruct: pointer to the I2C_InitTypeDef structure to be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The I2C\_InitStruct members have the following default values:

**Table 215. I2C\_InitStruct default values**

Member	Default value
I2C_Mode	I2C_Mode_I2C
I2C_DutyCycle	I2C_DutyCycle_2
I2C_OwnAddress1	0
I2C_Ack	I2C_Ack_Disable
I2C_AcknowledgedAddress	I2C_AcknowledgedAddress_7bit
I2C_ClockSpeed	5000

**Example:**

```
/* Initialize an I2C_InitTypeDef structure */
I2C_InitTypeDef I2C_InitStructure;
I2C_StructInit(&I2C_InitStructure);
```

## 11.2.4 I2C\_Cmd function

*Table 216* describes the I2C\_Cmd function.

**Table 216. I2C\_Cmd function**

Function name	I2C_Cmd
Function prototype	void I2C_Cmd(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Enables or disables the specified I2C peripheral.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the I2Cx peripheral. This parameter can be set to ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable I2C1 peripheral */
I2C_Cmd(I2C1, ENABLE);
```

## 11.2.5 I2C\_DMAMCmd function

*Table 217* describes the I2C\_DMAMCmd function.

**Table 217. I2C\_DMAMCmd function**

Function name	I2C_DMAMCmd
Function prototype	I2C_DMAMCmd(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Enables or disables the specified I2C DMA requests.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the I <sup>2</sup> C DMA transfer. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable I2C2 DMA transfer */
I2C_DMAMCmd(I2C2, ENABLE);
```

### 11.2.6 I2C\_DMALastTransferCmd function

*Table 218* describes the I2C\_DMALastTransferCmd function.

**Table 218. I2C\_DMALastTransferCmd function**

Function name	I2C_DMALastTransferCmd
Function prototype	I2C_DMALastTransferCmd(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Specifies that the next DMA transfer is the last one.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the I <sup>2</sup> C DMA last transfer. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Specify that the next I2C2 DMA transfer is the last one */
I2C_DMALastTransferCmd(I2C2, ENABLE);
```

### 11.2.7 I2C\_GenerateSTART function

*Table 219* describes the I2C\_GenerateSTART function.

**Table 219. I2C\_GenerateSTART function**

Function name	I2C_GenerateSTART
Function prototype	void I2C_GenerateSTART(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Generates I2Cx communication Start condition.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the I2C Start condition generation. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Generate a Start condition on I2C1 */
I2C_GenerateSTART(I2C1, ENABLE);
```



## 11.2.8 I2C\_GenerateSTOP function

[Table 220](#) describes the I2C\_GenerateSTOP function.

**Table 220. I2C\_GenerateSTOP function**

Function name	I2C_GenerateSTOP
Function prototype	void I2C_GenerateSTOP(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Generates I2Cx communication Stop condition.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the I <sup>2</sup> C Stop condition generation. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Generate a Stop condition on I2C2 */
I2C_GenerateSTOP(I2C2, ENABLE);
```

## 11.2.9 I2C\_AcknowledgeConfig function

[Table 221](#) describes the I2C\_AcknowledgeConfig function.

**Table 221. I2C\_AcknowledgeConfig function**

Function name	I2C_AcknowledgeConfig
Function prototype	void I2C_AcknowledgeConfig(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Enables or disables the specified I <sup>2</sup> C acknowledge feature.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the I <sup>2</sup> C Acknowledgement. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the I2C1 Acknowledgement */
I2C_AcknowledgeConfig(I2C1, ENABLE);
```

### 11.2.10 I2C\_OwnAddress2Config function

[Table 222](#) describes the I2C\_OwnAddress2Config function.

**Table 222. I2C\_OwnAddress2Config function**

Function name	I2C_OwnAddress2Config
Function prototype	void I2C_OwnAddress2Config(I2C_TypeDef* I2Cx, u8 Address)
Behavior description	Configures the specified I <sup>2</sup> C own address2.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	Address: specifies the 7-bit I <sup>2</sup> C own address2.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set the I2C1 own address2 to 0x38 */
I2C_OwnAddress2Config(I2C1, 0x38);
```

### 11.2.11 I2C\_DualAddressCmd function

[Table 223](#) describes the I2C\_DualAddressCmd function.

**Table 223. I2C\_DualAddressCmd function**

Function name	I2C_DualAddressCmd
Function prototype	void I2C_DualAddressCmd(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Enables or disables the specified I <sup>2</sup> C dual addressing mode.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the I <sup>2</sup> C dual addressing mode. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the I2C2 dual addressing mode*/
I2C_DualAddressCmd(I2C2, ENABLE);
```

### 11.2.12 I2C\_GeneralCallCmd function

*Table 224* describes the I2C\_GeneralCallCmd function.

**Table 224. I2C\_GeneralCallCmd function**

Function name	I2C_GeneralCallCmd
Function prototype	void I2C_GeneralCallCmd(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Enables or disables the specified I <sup>2</sup> C general call feature.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the I <sup>2</sup> C general call. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the I2C1 general call feature */  
I2C_GeneralCallCmd(I2C1, ENABLE);
```

### 11.2.13 I2C\_ITConfig function

*Table 225* describes the I2C\_ITConfig function.

**Table 225. I2C\_ITConfig function**

Function name	I2C_ITConfig
Function prototype	void I2C_ITConfig(I2C_TypeDef* I2Cx, u16 I2C_IT, FunctionalState NewState)
Behavior description	Enables or disables the specified I <sup>2</sup> C interrupts.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	I2C_IT: I <sup>2</sup> C interrupts sources to be enabled or disabled. Refer to <a href="#">I2C_IT</a> for more details on the allowed values for this parameter.
Input parameter3	NewState: new state of the specified I <sup>2</sup> C interrupts. This parameter can be set to ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### I2C\_IT

This parameter enables or disables I<sup>2</sup>C interrupts. One or a combination of the following values can be used:

**Table 226. I2C\_IT values**

I2C_IT	Description
I2C_IT_BUF	Buffer interrupt mask
I2C_IT_EVT	Event interrupt mask
I2C_IT_ERR	Error interrupt mask

#### Example:

```
/* Enable I2C2 event and buffer interrupts */
I2C_ITConfig(I2C2, I2C_IT_BUF | I2C_IT_EVT, ENABLE);
```

### 11.2.14 I2C\_SendData function

*Table 227* describes the I2C\_SendData function.

**Table 227. I2C\_SendData function**

Function name	I2C_SendData
Function prototype	void I2C_SendData(I2C_TypeDef* I2Cx, u8 Data)
Behavior description	Sends a data byte through the I2Cx peripheral.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	Data: byte to be transmitted.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Transmit 0x5D byte on I2C2 */
I2C_SendData(I2C2, 0x5D);
```

### 11.2.15 I2C\_ReceiveData function

*Table 228* describes the I2C\_ReceiveData function.

**Table 228. I2C\_ReceiveData function**

Function name	I2C_ReceiveData
Function prototype	u8 I2C_ReceiveData(I2C_TypeDef* I2Cx)
Behavior description	Returns the most recent received data by the I2Cx peripheral.
Input parameter	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Output parameter	None
Return parameter	Received byte.
Required preconditions	None
Called functions	None

**Example:**

```
/* Read the received byte on I2C1 */
u8 ReceivedData;
ReceivedData = I2C_ReceiveData(I2C1);
```

## 11.2.16 I2C\_Send7bitAddress function

[Table 229](#) describes the I2C\_Send7bitAddress function.

**Table 229. I2C\_Send7bitAddress function**

Function name	I2C_Send7bitAddress
Function prototype	void I2C_Send7bitAddress(I2C_TypeDef* I2Cx, u8 Address, u8 I2C_Direction)
Behavior description	Transmits the address byte to select the slave device.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	Address: slave address to be transmitted.
Input parameter3	I2C_Direction: specifies whether the I <sup>2</sup> C device will act as a transmitter or a receiver. Refer to <a href="#">I2C_Direction</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### I2C\_Direction

This parameter configures the I<sup>2</sup>C interface in transmitter or receiver mode (see [Table 230](#)).

**Table 230. I2C\_Direction**

I2C_Direction	Description
I2C_Direction_Transmitter	Selects transmission direction
I2C_Direction_Receiver	Selects receive direction

### Example:

```
/* Send, as transmitter, the Slave device address 0xA8 in 7-bit
addressing mode in I2C1 */
I2C_Send7bitAddress(I2C1, 0xA8, I2C_Direction_Transmitter);
```

## 11.2.17 I2C\_ReadRegister function

[Table 231](#) describes the I2C\_ReadRegister function.

**Table 231. I2C\_ReadRegister function**

Function name	I2C_ReadRegister
Function prototype	u16 I2C_ReadRegister(I2C_TypeDef* I2Cx, u8 I2C_Register)
Behavior description	Reads the specified I2C register and returns its value.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	I2C_Register: register to be read. Refer to <a href="#">I2C_Register</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The value of the read register. <sup>(1)</sup>
Required preconditions	None
Called functions	None

1. Some flags could be cleared when the register is read.

### I2C\_Register

The list of the I<sup>2</sup>C registers that can be read by issuing a I2C\_ReadRegister function are listed in [Table 232](#).

**Table 232. Readable I2C registers**

I2C_Register	Description
I2C_Register_CR1	I2C_CR1 register selected for read.
I2C_Register_CR2	I2C_CR2 register selected for read.
I2C_Register_OAR1	I2C_OAR1 register selected for read.
I2C_Register_OAR2	I2C_OAR2 register selected for read.
I2C_Register_DR	I2C_DR register selected for read.
I2C_Register_SR1	I2C_SR1 register selected for read.
I2C_Register_SR2	I2C_SR2 register selected for read.
I2C_Register_CCR	I2C_CCR register selected for read.
I2C_Register_TRISE	I2C_TRISE register selected for read.

#### Example:

```
/* Return the I2C_CR1 register value of I2C2 peripheral */
u16 RegisterValue;
RegisterValue = I2C_ReadRegister(I2C2, I2C_Register_CR1);
```

### 11.2.18 I2C\_SoftwareResetCmd function

*Table 233* describes the I2C\_SoftwareResetCmd function.

**Table 233. I2C\_SoftwareResetCmd function**

Function name	I2C_SoftwareResetCmd
Function prototype	I2C_SoftwareResetCmd(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Enables or disables the specified I <sup>2</sup> C software reset.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the I <sup>2</sup> C software reset. This parameter can be set to ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Put under reset the I2C1 peripheral */  
I2C_SoftwareResetCmd(I2C1, ENABLE);
```



### 11.2.19 I2C\_SMBusAlertConfig function

[Table 234](#) describes the I2C\_SMBusAlertConfig function.

**Table 234. I2C\_SMBusAlertConfig function**

Function name	I2C_SMBusAlertConfig
Function prototype	void I2C_SMBusAlertConfig(I2C_TypeDef* I2Cx, u16 I2C_SMBusAlert)
Behavior description	Drives the SMBusAlert pin High or Low for the specified I <sup>2</sup> C.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	I2C_SMBusAlert: SMBAlert pin level. Refer to <a href="#">I2C_SMBusAlert</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### I2C\_SMBusAlert

This parameter selects the SMBusAlert pin active level (see [Table 235](#)).

**Table 235. I2C\_SMBusAlert values**

I2C_SMBusAlert	Description
I2C_SMBusAlert_Low	SMBAlert pin driven Low
I2C_SMBusAlert_High	SMBAlert pin driven High

#### Example:

```
/* Let the I2C2 SMBusAlert pin High */
I2C_SMBusAlertConfig(I2C2, I2C_SMBusAlert_High);
```

## 11.2.20 I2C\_TransmitPEC function

[Table 236](#) describes the I2C\_TransmitPEC function.

**Table 236. I2C\_TransmitPEC function**

Function name	I2C_TransmitPEC
Function prototype	I2C_TransmitPEC(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Enables or disables the specified I <sup>2</sup> C PEC transfer.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the I2C PEC transfer. This parameter can be set to ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the I2C1 PEC transfer */
I2C_TransmitPEC(I2C1, ENABLE);
```

## 11.2.21 I2C\_PECPositionConfig function

[Table 237](#) describes the I2C\_PECPositionConfig function.

**Table 237. I2C\_PECPositionConfig function**

Function name	I2C_PECPositionConfig
Function prototype	void I2C_PECPositionConfig(I2C_TypeDef* I2Cx, u16 I2C_PECPosition)
Behavior description	Selects the specified I2C PEC position.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	I2C_PECPosition: PEC position. Refer to <a href="#">I2C_PECPosition</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### I2C\_PECPosition

This parameter selects the PEC position (see [Table 238](#)).

**Table 238. I2C\_PECPosition values**

I2C_PECPosition	Description
I2C_PECPosition_Next	PEC bit indicates that the next byte is PEC
I2C_PECPosition_Current	PEC bit indicates that current byte is PEC

**Example:**

```
/* Configure the PEC bit to indicvates that the next byte in shift
register is PEC for I2C2 */
I2C_PECPositionConfig(I2C2, I2C_PECPosition_Next);
```

**11.2.22 I2C\_CalculatePEC function**

[Table 239](#) describes the I2C\_CalculatePEC function.

**Table 239. I2C\_CalculatePEC function**

Function name	I2C_CalculatePEC
Function prototype	void I2C_CalculatePEC(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Enables or disables the PEC calculation for the transferred bytes.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the PEC value calculation. This parameter can be ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the PEC calculation for the transfered bytes from I2C2 */
I2C_CalculatePEC(I2C2, ENABLE);
```

### 11.2.23 I2C\_GetPEC function

*Table 240* describes the I2C\_GetPEC function.

**Table 240. I2C\_GetPEC function**

Function name	I2C_GetPEC
Function prototype	u8 I2C_GetPEC(I2C_TypeDef* I2Cx)
Behavior description	Returns the PEC value for the specified I <sup>2</sup> C interface
Input parameter	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Output parameter	None
Return parameter	The PEC value.
Required preconditions	None
Called functions	None

**Example:**

```
/* Returns the I2C2 PEC value */
u8 PECValue;
PECValue = I2C_GetPEC(I2C2);
```

### 11.2.24 I2C\_ARPCmd function

*Table 241* describes the I2C\_ARPCmd function.

**Table 241. I2C\_ARPCmd function**

Function name	I2C_ARPCmd
Function prototype	void I2C_ARPCmd(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Enables or disables the specified I <sup>2</sup> C ARP.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the I2C xARP. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the I2C1 ARP feature */
I2C_ARPCmd(I2C1, ENABLE);
```

### 11.2.25 I2C\_StretchClockCmd function

[Table 242](#) describes the I2C\_StretchClockCmd function.

**Table 242. I2C\_StretchClockCmd function**

Function name	I2C_StretchClockCmd
Function prototype	void I2C_StretchClockCmd(I2C_TypeDef* I2Cx, FunctionalState NewState)
Behavior description	Enables or disables the specified I2C Clock stretching.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	NewState: new state of the Clock stretching. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the I2C2 clock stretching */
I2C_StretchClockCmd(I2C2, ENABLE);
```

### 11.2.26 I2C\_FastModeDutyCycleConfig function

[Table 243](#) describes the I2C\_FastModeDutyCycleConfig function.

**Table 243. I2C\_FastModeDutyCycleConfig function**

Function name	I2C_FastModeDutyCycleConfig
Function prototype	void I2C_FastModeDutyCycleConfig(I2C_TypeDef* I2Cx, u16 I2C_DutyCycle)
Behavior description	Selects the specified I <sup>2</sup> C fast mode duty cycle.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	I2C_DutyCycle: fast mode duty cycle. Refer to <a href="#">I2C_DutyCycle</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## I2C\_DutyCycle

This parameter configures the I2C fast mode duty cycle (see [Table 244](#)).

**Table 244. I2C\_DutyCycle**

I2C_DutyCycle	Description
I2C_DutyCycle_2	I2C fast mode Tlow/Thigh=2
I2C_DutyCycle_16_9	I2C fast mode Tlow/Thigh=16/9

**Example:**

```
/* Set the fast mode duty cycle to 16/9 for I2C2 */  
I2C_FastModeDutyCycleConfig(I2C2, I2C_DutyCycle_16_9);
```

## 11.2.27 I2C\_GetLastEvent function

[Table 245](#) describes the I2C\_GetLastEvent function.

**Table 245. I2C\_GetLastEvent function**

Function name	I2C_GetLastEvent
Function prototype	u32 I2C_GetLastEvent(I2C_TypeDef* I2Cx)
Behavior description	Returns the last I2Cx event
Input parameter	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Output parameter	None
Return parameter	last I2Cx event
Required preconditions	None
Called functions	None

**Example:**

```
/* Get last I2C1 event */  
u32 Event;  
Event = I2C_GetLastEvent(I2C1);
```

## 11.2.28 I2C\_CheckEvent function

[Table 246](#) describes the I2C\_CheckEvent function.

**Table 246. I2C\_CheckEvent function**

Function name	I2C_CheckEvent
Function prototype	ErrorStatus I2C_CheckEvent(I2C_TypeDef* I2Cx, uint32_t I2C_EVENT)
Behavior description	Checks whether the last I2Cx event is equal to the one passed as parameter.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	I2C_EVENT: specifies the event to be checked. Refer to <a href="#">I2C_EVENT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	An ErrorStatus enumeration value: SUCCESS: Last event is equal to the I2C_EVENT ERROR: Last event is different from the I2C_EVENT
Required preconditions	None
Called functions	None

### I2C\_EVENT

The events that can be checked by issuing an I2C\_CheckEvent function are listed in [Table 247](#).

**Table 247. I2C\_Event**

I2C_EVENT	Description
I2C_EVENT_SLAVE_RECEIVER_ADDRESS_MATCHED	EV1
I2C_EVENT_SLAVE_TRANSMITTER_ADDRESS_MATCHED	EV1
I2C_EVENT_SLAVE_RECEIVER_SECONDADDRESS_MATCHED	EV1
I2C_EVENT_SLAVE_TRANSMITTER_SECONDADDRESS_MATCHED	EV1
I2C_EVENT_SLAVE_GENERALCALLADDRESS_MATCHED	EV1
I2C_EVENT_SLAVE_BYTE_RECEIVED	EV2
I2C_EVENT_SLAVE_BYTE_TRANSMITTED	EV3
I2C_EVENT_SLAVE_ACK_FAILURE	EV3-1
I2C_EVENT_SLAVE_STOP_DETECTED	EV4
I2C_EVENT_MASTER_MODE_SELECT	EV5
I2C_EVENT_MASTER_RECEIVER_MODE_SELECTED	EV6
I2C_EVENT_MASTER_TRANSMITTER_MODE_SELECTED	EV6
I2C_EVENT_MASTER_BYTE_RECEIVED	EV7
I2C_EVENT_MASTER_BYTE_TRANSMITTED	EV8
I2C_EVENT_MASTER_MODE_ADDRESS10	EV9

**Example:**

```

/* Check if the event happen on I2C1 is equal to
I2C_EVENT_MASTER_BYTE_RECEIVED */
ErrorStatus Status;
Status = I2C_CheckEvent(I2C1, I2C_EVENT_MSTER_BYTE_RECEIVED);

```

**11.2.29 I2C\_GetFlagStatus function**

[Table 248](#) describes the I2C\_GetFlagStatus function.

**Table 248. I2C\_GetFlagStatus function**

Function name	I2C_GetFlagStatus
Function prototype	FlagStatus I2C_GetFlagStatus(I2C_TypeDef* I2Cx, u32 I2C_FLAG)
Behavior description	Checks whether the specified I <sup>2</sup> C flag is set or not.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	I2C_FLAG: specifies the flag to be checked Refer to <a href="#">I2C_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of I2C_FLAG (SET or RESET). <sup>(1)</sup>
Required preconditions	None
Called functions	None

1. Some flags could be cleared when the register is read.

**I2C\_FLAG**

The I2C flags that can be checked by issuing an I2C\_GetFlagStatus function are listed in [Table 249](#).

**Table 249. I2C\_FLAG definition**

I2C_FLAG	Description
I2C_FLAG_DUALF	Dual flag (Slave mode)
I2C_FLAG_SMBHOST	SMBus host header (Slave mode)
I2C_FLAG_SMBDEFAULT	SMBus default header (Slave mode)
I2C_FLAG_GENCALL	General call header flag (Slave mode)
I2C_FLAG_TRA	Transmitter/Receiver flag
I2C_FLAG_BUSY	Bus busy flag
I2C_FLAG_MSL	Master/Slave flag
I2C_FLAG_SMBALERT	SMBus Alert flag
I2C_FLAG_TIMEOUT	Timeout or Tlow error flag
I2C_FLAG_PECERR	PEC error in reception flag
I2C_FLAG_OVR	Overrun/Underrun flag (Slave mode)
I2C_FLAG_AF	Acknowledge failure flag



**Table 249. I2C\_FLAG definition (continued)**

I2C_FLAG	Description
I2C_FLAG_ARLO	Arbitration lost flag (Master mode)
I2C_FLAG_BERR	Bus error flag
I2C_FLAG_TXE	Data register empty flag (Transmitter)
I2C_FLAG_RXNE	Data register not empty (Receiver) flag
I2C_FLAG_STOPF	Stop detection flag (Slave mode)
I2C_FLAG_ADD10	10-bit header sent flag (Master mode)
I2C_FLAG_BTF	Byte transfer finished flag
I2C_FLAG_ADDR	Address sent flag (Master mode) "ADSL" Address matched flag (Slave mode) "ENDAD"
I2C_FLAG_SB	Start bit flag (Master mode)

**Note:** Only bits[27:0] are used by the `I2C_GetFlagStatus` function to return the selected flag status. This value corresponds to the flag position in the calculated register which contains the two I2C status register `I2C_SR1` and `I2C_SR2`.

**Example:**

```
/* Return the I2C_FLAG_AF flag state of I2C2 peripheral */
Flagstatus Status;
Status = I2C_GetFlagStatus(I2C2, I2C_FLAG_AF);
```

**11.2.30 I2C\_ClearFlag function**

[Table 250](#) describes the `I2C_ClearFlag` function.

**Table 250. I2C\_ClearFlag function**

Function name	<code>I2C_ClearFlag</code>
Function prototype	<code>void I2C_ClearFlag(I2C_TypeDef* I2Cx, u32 I2C_FLAG)</code>
Behavior description	Clears the I2Cx's pending flags.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	I2C_FLAG: flag to clear. Refer to <a href="#">I2C_FLAG</a> for more details on the allowed values for this parameter. Note: DUALF, SMBHOST, SMBDEFAULT, GENCALL, TRA, BUSY, MSL, TXE and RXNE flags cannot be cleared by issuing this function
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**I2C\_FLAG**

The I<sup>2</sup>C flags that can be cleared by issuing an `I2C_ClearFlag` function are listed in [Table 251](#).

**Table 251. I2C\_FLAG definition**

I2C_FLAG	Description
I2C_FLAG_SMBALERT	SMBus Alert flag
I2C_FLAG_TIMEOUT	Timeout or Tlow error flag
I2C_FLAG_PECERR	PEC error in reception flag
I2C_FLAG_OVR	Overflow/Underflow flag (Slave mode)
I2C_FLAG_AF	Acknowledge failure flag
I2C_FLAG_ARLO	Arbitration lost flag (Master mode)
I2C_FLAG_BERR	Bus error flag
I2C_FLAG_STOPF	Stop detection flag (Slave mode)
I2C_FLAG_ADD10	10-bit header sent flag (Master mode)
I2C_FLAG_BTF	Byte transfer finished flag
I2C_FLAG_ADDR	Address sent flag (Master mode) "ADSL" Address matched flag (Slave mode) "ENDAD"
I2C_FLAG_SB	Start bit flag (Master mode)

**Example:**

```
/* Clear the Stop detection flag on I2C2 */
I2C_ClearFlag(I2C2, I2C_FLAG_STOPF);
```

**11.2.31 I2C\_GetITStatus function**

[Table 252](#) describes the I2C\_GetITStatus function.

**Table 252. I2C\_GetITStatus function**

Function name	I2C_GetITStatus
Function prototype	ITStatus I2C_GetITStatus(I2C_TypeDef* I2Cx, uint32_t I2C_IT)
Behavior description	Checks whether the specified I <sup>2</sup> C interrupt has occurred or not.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	I2C_IT: specifies the interrupt source to check. Refer to <a href="#">I2C_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	New state of I2C_IT (SET or RESET) <sup>(1)</sup>
Required preconditions	None
Called functions	None

1. Some flags could be cleared when the register is read.

**I2C\_IT**

The I2C\_IT parameter is used to select the I<sup>2</sup>C interrupt flags that can be checked by issuing an I2C\_GetITStatus function (see [Table 253](#)).

**Table 253. I2C\_IT definition**

I2C_IT	Description
I2C_IT_SMBALERT	SMBus Alert flag
I2C_IT_TIMEOUT	Timeout or Tlow error flag
I2C_IT_PECERR	PEC error in reception flag
I2C_IT_OVR	Overflow/Underflow flag (Slave mode)
I2C_IT_AF	Acknowledge failure flag
I2C_IT_ARLO	Arbitration lost flag (Master mode)
I2C_IT_BERR	Bus error flag
I2C_IT_TXE	Data register empty flag (Transmitter)
I2C_IT_RXNE	Data register not empty (Receiver) flag
I2C_IT_STOPF	Stop detection flag (Slave mode)
I2C_IT_ADD10	10-bit header sent flag (Master mode)
I2C_IT_BTF	Byte transfer finished flag
I2C_IT_ADDR	Address sent flag (Master mode) "ADSL" Address matched flag (Slave mode) "ENDAD"
I2C_IT_SB	Start bit flag (Master mode)

**Example:**

```

/* Return the I2C_IT_OVR flag state of I2C1 peripheral */
ITStatus Status;
Status = I2C_GetITStatus(I2C1, I2C_IT_OVR);

```

**11.2.32 I2C\_ClearITPendingBit function**

*Table 254* describes the I2C\_ClearITPendingBit function.

**Table 254. I2C\_ClearITPendingBit function**

Function name	I2C_ClearITPendingBit
Function prototype	void I2C_ClearITPendingBit(I2C_TypeDef* I2Cx, uint32_t I2C_IT)
Behavior description	Clears the I2Cx's interrupt pending bits.
Input parameter1	I2Cx: where x can be 1 or 2 to select the I <sup>2</sup> C peripheral.
Input parameter2	I2C_IT: specifies the interrupt pending bit to clear. Refer to <i>I2C_IT</i> for more details on the allowed values for this parameter. Note: DUALF, SMBHOST, SMBDEFAULT, GENCALL, TRA, BUSY, MSL, TXE and RXNE flags cannot be cleared by issuing this function
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## I2C\_IT

The I2C\_IT parameter is used to select the I<sup>2</sup>C interrupt pending flags that can be cleared by issuing an I2C\_ClearITPendingBit function (see [Table 255](#)).

**Table 255. I2C\_IT definition**

I2C_IT	Description
I2C_IT_SMBALERT	SMBus Alert flag
I2C_IT_TIMEOUT	Timeout or Tlow error flag
I2C_IT_PECERR	PEC error in reception flag
I2C_IT_OVR	Overrun/Underrun flag (Slave mode)
I2C_IT_AF	Acknowledge failure flag
I2C_IT_ARLO	Arbitration lost flag (Master mode)
I2C_IT_BERR	Bus error flag
I2C_IT_STOPF	Stop detection flag (Slave mode)
I2C_IT_ADD10	10-bit header sent flag (Master mode)
I2C_IT_BTF	Byte transfer finished flag
I2C_IT_ADDR	Address sent flag (Master mode) "ADSL" Address matched flag (Slave mode) "ENDAD"
I2C_IT_SB	Start bit flag (Master mode)

**Example:**

```
/* Clear the Timeout interrupt opening bit on I2C2 */  
I2C_ClearITPendingBit(I2C2, I2C_IT_TIMEOUT);
```

## 12 Independent watchdog (IWDG)

The Independent watchdog (IWDG) can be used to resolve processor malfunctions due to hardware or software failures. It can operate either in stop or in standby mode.

[Section 12.1: IWDG register structure](#) describes the data structures used in the IWDG Firmware Library. [Section 12.2: Firmware library functions](#) presents the Firmware Library functions.

### 12.1 IWDG register structure

The IWDG register structure, *IWDG\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32 KR;
    vu32 PR;
    vu32 RLR;
    vu32 SR;
} IWDG_TypeDef;
```

[Table 256](#) gives the list of IWDG registers.

**Table 256. IWDG registers**

Register	Description
KR	IWDG Key Register
PR	IWDG Prescaler Register
RLR	IWDG Reload Register
SR	IWDG Status Register

The IWDG peripheral is declared in *stm32f10x\_map.h*:

```
#define PERIPH_BASE                ((u32) 0x40000000)
#define APB1PERIPH_BASE            PERIPH_BASE
#define APB2PERIPH_BASE            (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE             (PERIPH_BASE + 0x20000)

#define IWDG_BASE                   (APB1PERIPH_BASE + 0x3000)

#ifndef DEBUG
...
#define _IWDG
    #define IWDG                      ((IWDG_TypeDef *) IWDG_BASE)
#endif /* _IWDG */
...
#else /* DEBUG */
...
#define _IWDG
    EXT IWDG_TypeDef                  *IWDG;
#endif /* _IWDG */
...
#endif
```

When using the Debug mode, the IWDG pointer is initialized in *stm32f10x\_lib.c*:

```
#ifdef _IWDG
IWDG = (IWDG_TypeDef *) IWDG_BASE;
#endif /*_IWDG */
```

To access the independent watchdog registers, `_IWDG` must be defined in *stm32f10x\_conf.h* as follows:

```
#define _IWDG
```

## 12.2 Firmware library functions

[Table 257](#) gives the list of IWDG firmware library functions.

**Table 257. IWDG firmware library functions**

Function name	Description
IWDG_WriteAccessCmd	Enables or disables write access to IWDG_PR and IWDG_RLR registers.
IWDG_SetPrescaler	Sets IWDG Prescaler value
IWDG_SetReload	Sets IWDG Reload value
IWDG_ReloadCounter	Reloads IWDG counter with value defined in the reload register
IWDG_Enable	Enables IWDG
IWDG_GetFlagStatus	Checks whether the specified IWDG flag is set or not

### 12.2.1 IWDG\_WriteAccessCmd function

[Table 258](#) describes the IWDG\_WriteAccessCmd function.

**Table 258. IWDG\_WriteAccessCmd function**

Function name	IWDG_WriteAccessCmd
Function prototype	void IWDG_WriteAccessCmd(u16 IWDG_WriteAccess)
Behavior description	Enables or disables write access to IWDG_PR and IWDG_RLR registers.
Input parameter	IWDG_WriteAccess: new state of write access to IWDG_PR and IWDG_RLR registers. Refer to <a href="#">IWDG_WriteAccess</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**IWDG\_WriteAccess**

This parameter enables or disables write access to IWDG\_PR and IWDG\_RLR registers (see [Table 259](#)).

**Table 259. IWDG\_WriteAccess definition**

IWDG_WriteAccess	Description
IWDG_WriteAccess_Enable	Write access to IWDG_PR and IWDG_RLR registers enabled
IWDG_WriteAccess_Disable	Write access to IWDG_PR and IWDG_RLR registers disabled

**Example:**

```
/* Enable write access to IWDG_PR and IWDG_RLR registers */
IWDG_WriteAccessCmd(IWDG_WriteAccess_Enable);
```

**12.2.2 IWDG\_SetPrescaler function**

[Table 260](#) describes the IWDG\_SetPrescaler function.

**Table 260. IWDG\_SetPrescaler function**

Function name	IWDG_SetPrescaler
Function prototype	void IWDG_SetPrescaler(u8 IWDG_Prescaler)
Behavior description	Sets IWDG Prescaler value.
Input parameter	IWDG_Prescaler: IWDG Prescaler value. Refer to <a href="#">IWDG_Prescaler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**IWDG\_Prescaler**

This parameter selects the IWDG prescaler (see [Table 261](#)).

**Table 261. IWDG\_Prescaler definition**

IWDG_Prescaler	Description
IWDG_Prescaler_4	IWDG prescaler set to 4
IWDG_Prescaler_8	IWDG prescaler set to 8
IWDG_Prescaler_16	IWDG prescaler set to 16
IWDG_Prescaler_32	IWDG prescaler set to 32
IWDG_Prescaler_64	IWDG prescaler set to 64
IWDG_Prescaler_128	IWDG prescaler set to 128
IWDG_Prescaler_256	IWDG prescaler set to 256

**Example:**

```
/* Set IWDG prescaler to 8 */  
IWDG_SetPrescaler(IWDG_Prescaler_8);
```

### 12.2.3 IWDG\_SetReload function

[Table 262](#) describes the IWDG\_SetReload function.

**Table 262. IWDG\_SetReload function**

Function name	IWDG_SetReload
Function prototype	void IWDG_SetReload(u16 Reload)
Behavior description	Sets IWDG Reload value.
Input parameter	Reload: IWDG Reload value. This parameter must be a number between 0 and 0xFFFF.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set IWDG reload value to 0xFFFF */  
IWDG_SetReload(0xFFFF);
```

### 12.2.4 IWDG\_ReloadCounter function

[Table 263](#) describes the IWDG\_ReloadCounter function.

**Table 263. IWDG\_ReloadCounter function**

Function name	IWDG_ReloadCounter
Function prototype	void IWDG_ReloadCounter(void)
Behavior description	Reloads IWDG counter with the value defined in the reload register (write access to IWDG_PR and IWDG_RLR registers disabled).
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Reload IWDG counter */  
IWDG_ReloadCounter();
```



## 12.2.5 IWDG\_Enable function

[Table 264](#) describes the IWDG\_Enable function.

**Table 264. IWDG\_Enable function**

Function name	IWDG_Enable
Function prototype	void IWDG_Enable(void)
Behavior description	Enables IWDG (write access to IWDG_PR and IWDG_RLR registers disabled).
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable IWDG */
IWDG_Enable();
```

## 12.2.6 IWDG\_GetFlagStatus function

[Table 265](#) describes the IWDG\_GetFlagStatus function.

**Table 265. IWDG\_GetFlagStatus function**

Function name	IWDG_GetFlagStatus
Function prototype	FlagStatus IWDG_GetFlagStatus(u16 IWDG_FLAG)
Behavior description	Checks whether the specified IWDG flag is set or not.
Input parameter	IWDG_FLAG: flag to be checked. Refer to <a href="#">IWDG_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of IWDG_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

## IWDG\_FLAG

The IWDG flags that can be checked by issuing an IWDG\_GetFlagStatus function are listed in [Table 266](#).

**Table 266. IWDG\_FLAG definition**

IWDG_FLAG	Description
IWDG_FLAG_PVU	Prescaler Value Update on going
IWDG_FLAG_RVU	Reload Value Update on going

**Example:**

```
/* Test if a prescaler value update is on going */
FlagStatus Status;
Status = IWDG_GetFlagStatus(IWDG_FLAG_PVU);
if(Status == RESET)
{
    ...
}
else
{
    ...
}
```

## 13 Nested vectored interrupt controller (NVIC)

The NVIC driver can be used for several purposes, such as enabling and disabling IRQ interrupts, enabling and disabling individual IRQ channels, and changing IRQ channel priorities.

[Section 13.1: NVIC register structure](#) describes the data structures used in the NVIC Firmware Library. [Section 13.2: Firmware library functions](#) presents the Firmware Library functions.

### 13.1 NVIC register structure

The NVIC register structure, *NVIC\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32 ISER[2];
    u32 RESERVED0[30];
    vu32 ICER[2];
    u32 RESERVED1[30];
    vu32 ISPR[2];
    u32 RESERVED2[30];
    vu32 ICPR[2];
    u32 RESERVED3[30];
    vu32 IABR[2];
    u32 RESERVED4[62];
    vu32 IPR[11];
} NVIC_TypeDef;

typedef struct
{
    vuc32 CPUID;
    vu32 ICSR;
    vu32 VTOR;
    vu32 AIRCR;
    vu32 SCR;
    vu32 CCR;
    vu32 SHPR[3];
    vu32 SHCSR;
    vu32 CFSR;
    vu32 HFSR;
    vu32 DFSR;
    vu32 MMFAR;
    vu32 BFAR;
    vu32 AFSR;
} SCB_TypeDef; /* System Control Block Structure */
```

[Table 267](#) gives the list of the NVIC registers.

Table 267. NVIC registers

Register	Description
Enable	Interrupt Set Enable Register
Disable	Interrupt Clear Enable Register
Set	Interrupt Set Pending Register
Clear	Interrupt Clear Pending Register
Active	Interrupt Active Bit Register
Priority	Interrupt Priority Register
CPUID	CPUID Base Register
ICSR	Interrupt Control State Register
VTOR	Vector Table Offset Register
AIRCR	Application Interrupt/Reset Control Register
SCR	System Control Register
CCR	Configuration Control Register
SHPR	System Handlers Priority Register
SHCSR	System Handler Control and State Register
CFSR	Configurable Fault Status Registers
HFSR	Hard Fault Status Register
DFSR	Debug Fault Register
MMFAR	Memory Manage Fault Address Register
BFAR	Bus Fault Address Register

The NVIC peripheral is declared in *stm32f10x\_map.h*:

```

...
#define SCS_BASE                ((u32) 0xE000E000)

#define NVIC_BASE                (SCS_BASE + 0x0100)
#define SCB_BASE                (SCS_BASE + 0x0D00)
...

#ifndef DEBUG
...
#define _NVIC
    #define NVIC                ((NVIC_TypeDef *) NVIC_BASE)
    #define SCB                 ((SCB_TypeDef *) SCB_BASE)
#endif /* _NVIC */
...
#else /* DEBUG */
...
#define _NVIC
    EXT NVIC_TypeDef            *NVIC;
    EXT SCB_TypeDef             *SCB;
#endif /* _NVIC */
...
#endif

```

When using the Debug mode, NVIC and SCB pointers are initialized in *stm32f10x\_lib.c* file:

```
#ifndef _NVIC
    NVIC = (NVIC_TypeDef *) NVIC_BASE;
    SCB = (SCB_TypeDef *) SCB_BASE;
#endif /*_NVIC */
```

To access the NVIC registers, `_NVIC` must be defined in *stm32f10x\_conf.h*, as follows:

```
#define _NVIC
```

## 13.2 Firmware library functions

[Table 268](#) gives the list of the NVIC firmware library functions.

**Table 268. NVIC firmware library functions**

Function name	Description
NVIC_DeInit	Resets the NVIC peripheral registers to their default reset values.
NVIC_SCBDeInit	Resets the SCB peripheral registers to their default reset values.
NVIC_PriorityGroupConfig	Configures the priority grouping: pre-emption priority and subpriority.
NVIC_Init	Initializes the NVIC peripheral according to the specified parameters in the <code>NVIC_InitStruct</code> .
NVIC_StructInit	Fills each <code>NVIC_InitStruct</code> member with its default value.
NVIC_SETPRIMASK	Enables the PRIMASK priority: Raises the execution priority to 0.
NVIC_RESETPRIMASK	Disables the PRIMASK priority.
NVIC_SETFAULTMASK	Enables the FAULTMASK priority: Raises the execution priority to -1.
NVIC_RESETFaultMask	Disables the FAULTMASK priority.
NVIC_BASEPRICONFIG	The execution priority can be changed from 15 (lowest configurable priority) to 1. Writing 0 will disable the execution priority mask.
NVIC_GetBASEPRI	Returns the BASEPRI mask value.
NVIC_GetCurrentPendingIRQChannel	Returns the current pending served IRQ channel identifier.
NVIC_GetIRQChannelPendingBitStatus	Checks whether the specified IRQ Channel pending bit is set or not.
NVIC_SetIRQChannelPendingBit	Sets the NVIC interrupt pending bits.
NVIC_ClearIRQChannelPendingBit	Clears the NVIC interrupt pending bits.
NVIC_GetCurrentActiveHandler	Returns the current active Handler (IRQ Channel and SystemHandler) identifier.

**Table 268. NVIC firmware library functions (continued)**

Function name	Description
NVIC_GetIRQChannelActiveBitStatus	Checks whether the specified IRQ Channel active bit is set or not.
NVIC_GetCPUTID	Returns the ID number, the version number and the implementation details of the Cortex-M3 core.
NVIC_SetVectorTable	Sets the vector table location and offset.
NVIC_GenerateSystemReset	Generate a system reset.
NVIC_GenerateCoreReset	Generate a Core (Core + NVIC) reset.
NVIC_SystemLPConfig	Selects the condition for the system to enter low power mode.
NVIC_SystemHandlerConfig	Enables or disables the specified System Handlers.
NVIC_SystemHandlerPriorityConfig	Configures the specified System Handlers priority.
NVIC_GetSystemHandlerPendingBitStatus	Checks whether the specified System handlers pending bit is set or not.
NVIC_SetSystemHandlerPendingBit	Sets System Handler pending bit.
NVIC_ClearSystemHandlerPendingBit	Clears System Handler pending bit.
NVIC_GetSystemHandlerActiveBitStatus	Checks whether the specified System handlers active bit is set or not.
NVIC_GetFaultHandlerSources	Returns the system fault handlers sources.
NVIC_GetFaultAddress	Returns the address of the location that generated a fault handler.

### 13.2.1 NVIC\_DeInit function

[Table 269](#) describes the NVIC\_DeInit function.

**Table 269. NVIC\_DeInit function**

Function name	NVIC_DeInit
Function prototype	void NVIC_DeInit(void)
Behavior description	Resets the NVIC peripheral registers to their default reset values.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Resets the NVIC registers to their default reset value */
NVIC_DeInit();
```

### 13.2.2 NVIC\_SCBDeInit function

[Table 270](#) describes the NVIC\_SCBDeInit function.

**Table 270. NVIC\_SCBDeInit function**

Function name	NVIC_SCBDeInit
Function prototype	void NVIC_SCBDeInit(void)
Behavior description	Resets the SCB peripheral registers to their default reset values.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Resets the SCB registers to their default reset value */
NVIC_SCBDeInit();
```

### 13.2.3 NVIC\_PriorityGroupConfig function

[Table 271](#) describes the NVIC\_PriorityGroupConfig function.

**Table 271. NVIC\_PriorityGroupConfig function**

Function name	NVIC_PriorityGroupConfig
Function prototype	void NVIC_PriorityGroupConfig(u32 NVIC_PriorityGroup)
Behavior description	Configures the priority grouping: pre-emption priority and subpriority.
Input parameter	NVIC_PriorityGroup: priority grouping bits length. Refer to <a href="#">NVIC_PriorityGroup</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	Priority grouping should be configured only once.
Called functions	None

**NVIC\_PriorityGroup**

This parameter configures the priority grouping bit length (see [Table 272](#)).

**Table 272. NVIC\_PriorityGroup**

NVIC_PriorityGroup	Description
NVIC_PriorityGroup_0	0 bits for pre-emption priority 4 bits for subpriority
NVIC_PriorityGroup_1	1 bits for pre-emption priority 3 bits for subpriority
NVIC_PriorityGroup_2	2 bits for pre-emption priority 2 bits for subpriority
NVIC_PriorityGroup_3	3 bits for pre-emption priority 1 bits for subpriority
NVIC_PriorityGroup_4	4 bits for pre-emption priority 0 bits for subpriority

**Example:**

```
/* Configure the Priority Grouping with 1 bit */
NVIC_PriorityGroupConfig(NVIC_PriorityGroup_1);
```

**13.2.4 NVIC\_Init function**

[Table 273](#) describes the NVIC\_Init function.

**Table 273. NVIC\_Init function**

Function name	NVIC_Init
Function prototype	void NVIC_Init(NVIC_InitTypeDef* NVIC_InitStruct)
Behavior description	Initializes the NVIC peripheral according to the parameters specified in the NVIC_InitStruct.
Input parameter	NVIC_InitStruct: pointer to a NVIC_InitTypeDef structure that contains the configuration information for the specified NVIC peripheral. Refer to <a href="#">NVIC_InitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**NVIC\_InitTypeDef structure**

The NVIC\_InitTypeDef structure is defined in the *stm32f10x\_nvic.h* file:



```
typedef struct
{
    u8 NVIC_IRQChannel;
    u8 NVIC_IRQChannelPreemptionPriority;
    u8 NVIC_IRQChannelSubPriority;
    FunctionalState NVIC_IRQChannelCmd;
} NVIC_InitTypeDef;
```

### NVIC\_IRQChannel

This member specifies the IRQ channel to be enabled or disabled. The list of the IRQ channels is given in [Table 274](#).

**Table 274. NVIC\_IRQChannels**

NVIC_IRQChannel	Description
WWDG_IRQChannel	Window WatchDog Interrupt
PVD_IRQChannel	PVD through EXTI Line detection Interrupt
TAMPER_IRQChannel	Tamper Interrupt
RTC_IRQChannel	RTC global Interrupt
FlashItf_IRQChannel	FLASH global Interrupt
RCC_IRQChannel	RCC global Interrupt
EXTI0_IRQChannel	EXTI Line0 Interrupt
EXTI1_IRQChannel	EXTI Line1 Interrupt
EXTI2_IRQChannel	EXTI Line2 Interrupt
EXTI3_IRQChannel	EXTI Line3 Interrupt
EXTI4_IRQChannel	EXTI Line4 Interrupt
DMACHannel1_IRQChannel	DMA Channel1 global Interrupt
DMACHannel2_IRQChannel	DMA Channel2 global Interrupt
DMACHannel3_IRQChannel	DMA Channel3 global Interrupt
DMACHannel4_IRQChannel	DMA Channel4 global Interrupt
DMACHannel5_IRQChannel	DMA Channel5 global Interrupt
DMACHannel6_IRQChannel	DMA Channel6 global Interrupt
DMACHannel7_IRQChannel	DMA Channel7 global Interrupt
ADC_IRQChannel	ADC global Interrupt
USB_HP_CANTX_IRQChannel	USB High Priority or CAN TX Interrupts
USB_LP_CAN_RX0_IRQChannel	USB Low Priority or CAN RX0 Interrupts
CAN_RX1_IRQChannel	CAN RX1 Interrupt
CAN_SCE_IRQChannel	CAN SCE Interrupt
EXTI9_5_IRQChannel	EXTI Line[9:5] Interrupts
TIM1_BRK_IRQChannel	TIM1 Break Interrupt
TIM1_UP_IRQChannel	TIM1 UP Interrupt

**Table 274. NVIC\_IRQChannels (continued)**

NVIC_IRQChannel	Description
TIM1_TRG_COM_IRQChannel	TIM1 Trigger and Commutation Interrupts
TIM1_CC_IRQChannel	TIM1 Capture Compare Interrupt
TIM2_IRQChannel	TIM2 global Interrupt
TIM3_IRQChannel	TIM3 global Interrupt
TIM4_IRQChannel	TIM4 global Interrupt
I2C1_EV_IRQChannel	I2C1 Event Interrupt
I2C1_ER_IRQChannel	I2C1 Error Interrupt
I2C2_EV_IRQChannel	I2C2 Event Interrupt
I2C2_ER_IRQChannel	I2C2 Error Interrupt
SPI1_IRQChannel	SPI1 global Interrupt
SPI2_IRQChannel	SPI2 global Interrupt
USART1_IRQChannel	USART1 global Interrupt
USART2_IRQChannel	USART2 global Interrupt
USART3_IRQChannel	USART3 global Interrupt
EXTI15_10_IRQChannel	EXTI Line[15:10] Interrupts
RTCAlarm_IRQChannel	RTC Alarm through EXTI Line Interrupt
USBWakeUp_IRQChannel	USB WakeUp from suspend through EXTI Line Interrupt
TIM8_BRK_IRQChannel	TIM8 Break Interrupt
TIM8_UP_IRQChannel	TIM8 Update Interrupt
TIM8_TRG_COM_IRQChannel	TIM8 Trigger and Commutation Interrupt
TIM8_CC_IRQChannel	TIM8 Capture Compare Interrupt
ADC3_IRQChannel	ADC3 global Interrupt
FSMC_IRQChannel	FSMC global Interrupt
SDIO_IRQChannel	SDIO global Interrupt
TIM5_IRQChannel	TIM5 global Interrupt
SPI3_IRQChannel	SPI3 global Interrupt
UART4_IRQChannel	UART4 global Interrupt
UART5_IRQChannel	UART5 global Interrupt
TIM6_IRQChannel	TIM6 global Interrupt
TIM7_IRQChannel	TIM7 global Interrupt
DMA2_Channel1_IRQChannel	DMA2 Channel 1 global Interrupt
DMA2_Channel2_IRQChannel	DMA2 Channel 2 global Interrupt
DMA2_Channel3_IRQChannel	DMA2 Channel 3 global Interrupt
DMA2_Channel4_5_IRQChannel	DMA2 Channel 4 and DMA2 Channel 5 global Interrupt

**NVIC\_IRQChannelPreemptionPriority**

This member configures the pre-emption priority for the IRQ channel specified in the `NVIC_IRQChannel` member. The values taken by this member are listed in [Table 275](#).

**NVIC\_IRQChannelSubPriority**

This member configures the subpriority level for the IRQ channel specified in the `NVIC_IRQChannel` member. The values taken by this member are listed in [Table 275](#).

[Table 275](#) gives the allowed values of the pre-emption priority and subpriority according to the Priority Grouping configuration performed by `NVIC_PriorityGroupConfig` function:

**Table 275. Pre-emption priority and subpriority values<sup>(1)(2)</sup>**

NVIC_PriorityGroup	NVIC_IRQChannelPreemptionPriority	NVIC_IRQChannelSubPriority	Description
NVIC_PriorityGroup_0	0	0-15	0 bits for pre-emption priority 4 bits for subpriority
NVIC_PriorityGroup_1	0-1	0-7	1 bits for pre-emption priority 3 bits for subpriority
NVIC_PriorityGroup_2	0-3	0-3	2 bits for pre-emption priority 2 bits for subpriority
NVIC_PriorityGroup_3	0-7	0-1	3 bits for pre-emption priority 1 bits for subpriority
NVIC_PriorityGroup_4	0-15	0	4 bits for pre-emption priority 0 bits for subpriority

1. When `PriorityGroup_0` is selected, `NVIC_IRQChannelPreemptionPriority` member has no effect on the interrupt channel configuration.
2. When `PriorityGroup_4` is selected, `NVIC_IRQChannelSubPriority` member has no effect on the interrupt channel configuration.

**NVIC\_IRQChannelCmd**

This member specifies whether the IRQ channel defined in the `NVIC_IRQChannel` member will be enabled or disabled. This member can be set either to `ENABLE` or `DISABLE`.

**Example:**

```
NVIC_InitTypeDef NVIC_InitStructure;
/* Configure the Priority Grouping with 1 bit */
NVIC_PriorityGroupConfig(NVIC_PriorityGroup_1);

/* Enable TIM3 global interrupt with Preemption Priority 0 and Sub
Priority as 2 */
NVIC_InitStructure.NVIC_IRQChannel = TIM3_IRQChannel;
NVIC_InitStructure.NVIC_IRQChannelPreemptionPriority = 0;
NVIC_InitStructure.NVIC_IRQChannelSubPriority = 2;
NVIC_InitStructure.NVIC_IRQChannelCmd = ENABLE;
NVIC_InitStructure(&NVIC_InitStructure);

/* Enable USART1 global interrupt with Preemption Priority 1 and Sub
Priority as 5 */
NVIC_InitStructure.NVIC_IRQChannel = USART1_IRQChannel;
```

```

NVIC_InitStructure.NVIC_IRQChannelPreemptionPriority = 1;
NVIC_InitStructure.NVIC_IRQChannelSubPriority = 5;
NVIC_InitStructure(&NVIC_InitStructure);

/* Enable RTC global interrupt with Preemption Priority 1 and Sub
Priority as 7 */
NVIC_InitStructure.NVIC_IRQChannel = RTC_IRQChannel;
NVIC_InitStructure.NVIC_IRQChannelSubPriority = 7;
NVIC_InitStructure(&NVIC_InitStructure);

/* Enable EXTI4 interrupt with Preemption Priority 1 and Sub
Priority as 7 */
NVIC_InitStructure.NVIC_IRQChannel = EXTI4_IRQChannel;
NVIC_InitStructure.NVIC_IRQChannelSubPriority = 7;
NVIC_InitStructure(&NVIC_InitStructure);

/* TIM3 interrupt priority is higher than USART1, RTC and EXTI4
interrupts priorities. USART1 interrupt priority is higher than RTC
and EXTI4 interrupts priorities. RTC interrupt priority is higher
than EXTI4 interrupt priority. */

```

### 13.2.5 NVIC\_StructInit function

[Table 276](#) describes the NVIC\_StructInit function.

**Table 276. NVIC\_StructInit function**

Function name	NVIC_StructInit
Function prototype	void NVIC_StructInit (NVIC_InitTypeDef* NVIC_InitStruct)
Behavior description	Fills each NVIC_InitStruct member with its default value.
Input parameter	NVIC_InitStruct: pointer to a NVIC_InitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The NVIC\_InitStruct members have the following default values:

**Table 277. NVIC\_InitStruct default values**

Member	Default value
NVIC_IRQChannel	0x0
NVIC_IRQChannelPreemptionPriority	0
NVIC_IRQChannelSubPriority	0
NVIC_IRQChannelCmd	DISABLE

**Example:**

```
/* The following example illustrates how to initialize a
NVIC_InitTypeDef structure */
NVIC_InitTypeDef NVIC_InitStructure;
NVIC_StructInit(&NVIC_InitStructure);
```

**13.2.6 NVIC\_SETPRIMASK function**

[Table 278](#) describes the NVIC\_SETPRIMASK function.

**Table 278. NVIC\_SETPRIMASK function<sup>(1)(2)(3)</sup>**

Function name	NVIC_SETPRIMASK
Function prototype	void NVIC_SETPRIMASK(void)
Behavior description	Enables the PRIMASK priority: raises the execution priority to 0.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	__SETPRIMASK()

1. This function is coded in assembler.
2. This function only affects the group priority. It has no effect on the sub-priority.
3. Before setting the PRIMASK register, it is recommended to clear it when returning from exception to enable other exceptions.

**Example:**

```
/* Enable the PRIMASK priority */
NVIC_SETPRIMASK();
```

**13.2.7 NVIC\_RESETPRIMASK function**

[Table 279](#) describes the NVIC\_RESETPRIMASK function.

**Table 279. NVIC\_RESETPRIMASK function<sup>(1)</sup>**

Function name	NVIC_RESETPRIMASK
Function prototype	void NVIC_RESETPRIMASK(void)
Behavior description	Disables the PRIMASK priority.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	__RESETPRIMASK()

1. This function is coded in assembler.

**Example:**

```
/* Enable the PRIMASK priority */
NVIC_RESETPRIMASK();
```

### 13.2.8 NVIC\_SETFAULTMASK function

*Table 280* describes the NVIC\_SETFAULTMASK function.

**Table 280. NVIC\_SETFAULTMASK function<sup>(1)(2)(3)</sup>**

Function name	NVIC_SETFAULTMASK
Function prototype	void NVIC_SETFAULTMASK(void)
Behavior description	Enables the FAULTMASK priority: raises the execution priority to -1.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	__SETFAULTMASK()

1. This function is coded in assembler.
2. This function only affects the group priority. It has no effect on the sub-priority.
3. FAULTMASK can only be set when the execution priority is lower than -1. Setting the FaultMask raises the priority of the exception handler to the level of a HardFault. FAULTMASK is cleared automatically on all exception returns except a return from NMI.

**Example:**

```
/* Enable the FAULTMASK priority */
NVIC_SETFAULTMASK();
```

### 13.2.9 NVIC\_RESETFAULTMASK function

*Table 281* describes the NVIC\_RESETFAULTMASK function.

**Table 281. NVIC\_RESETFAULTMASK function<sup>(1)</sup>**

Function name	NVIC_RESETFAULTMASK
Function prototype	void NVIC_RESETFAULTMASK(void)
Behavior description	Disables the FAULTMASK priority.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	__RESETFAULTMASK()

1. This function is coded in assembler.

**Example:**

```
/* Disable the FAULTMASK priority */
NVIC_RESETFAULTMASK();
```

### 13.2.10 NVIC\_BASEPRICONFIG function

[Table 282](#) describes the NVIC\_BASEPRICONFIG function.

**Table 282. NVIC\_BASEPRICONFIG function<sup>(1)(2)(3)</sup>**

Function name	NVIC_BASEPRICONFIG
Function prototype	void NVIC_BASEPRICONFIG(u32 NewPriority)
Behavior description	The execution priority can be changed from 15 (lowest configurable priority) to 1. Writing 0 will disable the execution priority mask.
Input parameter	NewPriority: new priority value of the execution priority.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	__BASEPRICONFIG()

1. This function is coded in assembler.
2. This function only affects the group priority. It has no effect on the sub-priority.
3. BASEPRI value can be changed from N (lowest configurable priority) to 1. Clearing this register to '0' has no effect on the current priority. A non-zero value will act as a priority mask, affecting the execution priority when the priority defined by BASEPRI is higher than the current executing priority.

**Example:**

```
/* Mask the execution priority to 10 */
__BASEPRICONFIG(10);
```

### 13.2.11 NVIC\_GetBASEPRI function

[Table 283](#) describes the NVIC\_GetBASEPRI function.

**Table 283. NVIC\_GetBASEPRI function<sup>(1)</sup>**

Function name	NVIC_GetBASEPRI
Function prototype	u32 NVIC_GetBASEPRI(void)
Behavior description	Returns the BASEPRI mask value.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	__GetBASEPRI()

1. This function is coded in assembler.

**Example:**

```
/* Get the execution priority to value */
u32 BASEPRI_Mask = 0;
BASEPRI_Mask = NVIC_GetBASEPRI();
```

### 13.2.12 NVIC\_GetCurrentPendingIRQChannel function

[Table 284](#) describes the NVIC\_GetCurrentPendingIRQChannel function.

**Table 284. NVIC\_GetCurrentPendingIRQChannel function**

Function name	NVIC_GetCurrentPendingIRQChannel
Function prototype	u16 NVIC_GetCurrentPendingIRQChannel(void)
Behavior description	Returns the current pending IRQ channel identifier.
Input parameter	None
Output parameter	None
Return parameter	Pending IRQ Channel Identifier.
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the current pending IRQ channel identifier */
u16 CurrentPendingIRQChannel;
CurrentPendingIRQChannel = NVIC_GetCurrentPendingIRQChannel();
```

### 13.2.13 NVIC\_GetIRQChannelPendingBitStatus function

[Table 285](#) describes the NVIC\_GetIRQChannelPendingBitStatus function.

**Table 285. NVIC\_GetIRQChannelPendingBitStatus function**

Function name	NVIC_GetIRQChannelPendingBitStatus
Function prototype	ITStatus NVIC_GetIRQChannelPendingBitStatus(u8 NVIC_IRQChannel)
Behavior description	Checks whether the specified IRQ Channel pending bit is set or not.
Input parameter	NVIC_IRQChannel: interrupt pending bit to check. Refer to <a href="#">NVIC_IRQChannel</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of IRQ Channel pending bit (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the IRQ channel pending bit status of the ADC_IRQChannel */
ITStatus IRQChannelPendingBitStatus;
IRQChannelPendingBitStatus =
NVIC_GetIRQChannelPendingBitStatus(ADC_IRQChannel);
```



### 13.2.14 NVIC\_SetIRQChannelPendingBit function

[Table 286](#) describes the NVIC\_SetIRQChannelPendingBitStatus function.

**Table 286. NVIC\_SetIRQChannelPendingBitStatus function**

Function name	NVIC_SetIRQChannelPendingBit
Function prototype	void NVIC_SetIRQChannelPendingBit(u8 NVIC_IRQChannel)
Behavior description	Sets the NVIC interrupt pending bit.
Input parameter	NVIC_IRQChannel: specifies the interrupt pending bit to Set. Refer to <a href="#">NVIC_IRQChannel</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set SPI1 Global interrupt pending bit */
NVIC_SetIRQChannelPendingBit(SPI1_IRQChannel);
```

### 13.2.15 NVIC\_ClearIRQChannelPendingBit function

[Table 287](#) describes the NVIC\_ClearIRQChannelPendingBit function.

**Table 287. NVIC\_ClearIRQChannelPendingBit function**

Function name	NVIC_ClearIRQChannelPendingBit
Function prototype	void NVIC_ClearIRQChannelPendingBit(u8 NVIC_IRQChannel)
Behavior description	Clears the NVIC interrupt pending bit.
Input parameter	NVIC_IRQChannel: specifies the interrupt pending bit to clear. Refer to <a href="#">NVIC_IRQChannel</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear ADC IRQ Channel Pending bit */
NVIC_ClearIRQChannelPendingBit(ADC_IRQChannel);
```

### 13.2.16 NVIC\_GetCurrentActiveHandler function

[Table 288](#) describes the NVIC\_GetCurrentActiveHandler function.

**Table 288. NVIC\_GetCurrentActiveHandler function**

Function name	NVIC_GetCurrentActiveHandler
Function prototype	u16 NVIC_GetCurrentActiveHandler(void)
Behavior description	Returns the current active Handler (IRQ Channel and SystemHandler) identifier.
Input parameter	None
Output parameter	None
Return parameter	Active Handler Identifier.
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the current active Handler identifier */
u16 CurrentActiveHandler;
CurrentActiveHandler = NVIC_GetCurrentActiveHandler();
```

### 13.2.17 NVIC\_GetIRQChannelActiveBitStatus function

[Table 289](#) describes the NVIC\_GetIRQChannelActiveBitStatus function.

**Table 289. NVIC\_GetIRQChannelActiveBitStatus function**

Function name	NVIC_GetIRQChannelActiveBitStatus
Function prototype	ITStatus NVIC_GetIRQChannelActiveBitStatus(u8 NVIC_IRQChannel)
Behavior description	Checks whether the specified IRQ Channel active bit is set or not.
Input parameter	NVIC_IRQChannel: specifies the interrupt active bit to check. Refer to <a href="#">NVIC_IRQChannel</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of IRQ Channel active bit (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the active IRQ channel status of the ADC_IRQChannel */
ITStatus IRQChannelActiveBitStatus;
IRQChannelActiveBitStatus =
NVIC_GetIRQChannelActiveBitStatus(ADC_IRQChannel);
```

### 13.2.18 NVIC\_GetCPUID function

[Table 290](#) describes the NVIC\_GetCPUID function.

**Table 290. NVIC\_GetCPUID function**

Function name	NVIC_GetCPUID
Function prototype	u32 NVIC_GetCPUID(void)
Behavior description	Returns the ID number, version number and the implementation details of the Cortex-M3 core.
Input parameter	None
Output parameter	None
Return parameter	CPU ID.
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the CPU ID */
u32 CM3_CPUID;
CM3_CPUID = NVIC_GetCPUID();
```

### 13.2.19 NVIC\_SetVectorTable function

[Table 291](#) describes the NVIC\_SetVectorTable function.

**Table 291. NVIC\_SetVectorTable function**

Function name	NVIC_SetVectorTable
Function prototype	void NVIC_SetVectorTable(u32 NVIC_VectTab, u32 Offset)
Behavior description	Sets the vector table location and Offset.
Input parameter1	NVIC_VectTab: specifies if the vector table is in RAM or code memory. Refer to <a href="#">NVIC_VectTab</a> for more details on the allowed values for this parameter.
Input parameter2	Offset: Vector Table base offset field. This value must be a multiple of 0x100.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**NVIC\_VectTab**

This parameter defines the table base address (see [Table 292](#)).

**Table 292. NVIC\_VectTab values**

NewTableBase	Description
NVIC_VectTab_FLASH	Vector Table is in FLASH
NVIC_VectTab_RAM	Vector Table is in RAM

**Example:**

```
/* Vector Table is in FLASH at 0x0 */
NVIC_SetVectorTable(NVIC_VectTab_FLASH, 0x0);
```

**13.2.20 NVIC\_GenerateSystemReset function**

[Table 293](#) describes the NVIC\_GenerateSystemReset function.

**Table 293. NVIC\_GenerateSystemReset function**

Function name	NVIC_GenerateSystemReset
Function prototype	void NVIC_GenerateSystemReset(void)
Behavior description	Generate a system reset.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Generate a system reset */
NVIC_GenerateSystemReset();
```

**13.2.21 NVIC\_GenerateCoreReset function**

[Table 294](#) describes the NVIC\_GenerateCoreReset function.

**Table 294. NVIC\_GenerateCoreReset function**

Function name	NVIC_GenerateCoreReset
Function prototype	void NVIC_GenerateCoreReset(void)
Behavior description	Generate a core (core + NVIC) reset.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Generate a core reset */
NVIC_GenerateCoreReset();
```

### 13.2.22 NVIC\_SystemLPConfig function

[Table 295](#) describes the NVIC\_SystemLPConfig function.

**Table 295. NVIC\_SystemLPConfig function**

Function name	NVIC_SystemLPConfig
Function prototype	void NVIC_SystemLPConfig(u8 LowPowerMode, FunctionalState NewState)
Behavior description	Selects the condition for the system to enter low power mode.
Input parameter1	LowPowerMode: new mode for the system to enter low power mode. Refer to <a href="#">LowPowerMode</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the LP condition. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### LowPowerMode

This parameter configures the low power mode of the device (see [Table 296](#)).

**Table 296. LowerPowerMode definition**

LowPowerMode	Description
NVIC_LP_SEVONPEND	Wake-up on Pend
NVIC_LP_SLEEPDEEP	Deep Sleep Enable
NVIC_LP_SLEEPONEXIT	Sleep on ISR exit

#### Example:

```
/* wakeup the system on interrupt pending */
NVIC_SystemLPConfig(SEVONPEND, ENABLE);
```

### 13.2.23 NVIC\_SystemHandlerConfig function

[Table 297](#) describes the NVIC\_SystemHandlerConfig function.

**Table 297. NVIC\_SystemHandlerConfig function**

Function name	NVIC_SystemHandlerConfig
Function prototype	void NVIC_SystemHandlerConfig(u32 SystemHandler, FunctionalState NewState)
Behavior description	Enables or disables the specified System Handlers.
Input parameter1	SystemHandler: system handler to be enabled or disabled. Refer to <a href="#">SystemHandler</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the specified System Handlers. This parameter can be set to ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### SystemHandler

This parameter selects the system handler to be enabled or disabled (see [Table 298](#)).

**Table 298. SystemHandler types**

SystemHandler	Description
SystemHandler_MemoryManage	Memory Manage Handler
SystemHandler_BusFault	Bus Fault Handler
SystemHandler_UsageFault	Usage Fault Handler

The SystemHandler parameter values allow to configure at the same time the NVIC register, the SCB register, and the index bits. The SystemHandler is coded on 23 bits as shown in [Table 299](#), [Table 300](#), [Table 301](#), [Table 302](#), [Table 303](#), [Table 304](#), [Table 305](#), [Table 306](#), [Table 307](#), and [Table 308](#).

#### Example:

```
/* Enable the Memory Manage Handler */
NVIC_SystemHandlerConfig(SystemHandler_MemoryManage, ENABLE);
```

Table 299. SystemHandler definition

System Handler	Bits																				Value	
	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3		2
SystemHandler_ NMI (see <a href="#">Table 300</a> )	Reserved																0x1F				0x1F	
SystemHandler_ HardFault (see <a href="#">Table 301</a> )	Reserved			0		Reserved															0x0	
SystemHandler_ MemoryManage (see <a href="#">Table 302</a> )	0	0		1		0x0			0xD			0	0	Res	0x10			0x43430				
SystemHandler_ BusFault (see <a href="#">Table 303</a> )	1	1		1		1			0xE			1	0	Res	0x11			0x547931				
SystemHandler_ UsageFault (see <a href="#">Table 304</a> )	-	2		1		0x3			Reserved			2	0	Res	0x12			0x24C232				
SystemHandler_ SVCall (see <a href="#">Table 305</a> )	Reserved					0x7			0xF			3	1	Reserved				0x1FF40				
SystemHandler_ DebugMonitor (see <a href="#">Table 306</a> )	Reserved			2		0x8			Reserved			0	2	Reserved				0xA0080				
SystemHandler_ PSV (see <a href="#">Table 307</a> )	Reserved					0xA			Reserved			2	2			0x1C			0x2829C			
SystemHandler_ SysTick (see <a href="#">Table 308</a> )	Reserved					0xB			Reserved			3	2			0x1A			0x2C39A			

Table 300. SystemHandler\_NMI definition

Bits	NMI	
	Registers/Bits	Functions
[4:0]	– IRQControlState – NMIPENDSET[31]	NVIC_SetSystemHandlerPendingBit
5	Not Used	
[7:6]	Not Used	
[9:8]	Not Used	
[13:10]	Not Used	
[17:14]	Not Used	
[19:18]	Not Used	
[21:20]	Not Used	
22	Not Used	

**Table 301. SystemHandler\_HardFault definition**

Bits	Hard Fault	
	Registers/Bits	Functions
[4:0]	Not Used	
5	Not Used	
[7:6]	Not Used	
[9:8]	Not Used	
[13:10]	Not Used	
[17:14]	Not Used	
[19:18]	– HardFaultStatus	NVIC_GetFaultHandlerSources
[21:20]		
22	Not Used	

**Table 302. SystemHandler\_MemoryManage definition**

Bits	Memory Manage	
	Registers/Bits	Functions
[4:0]	– SysHandlerCtrl – MEMFAULTENA[16]	NVIC_SystemHandlerConfig
5	Not Used	
[7:6]	– SystemPriority[0] – PRI_4[7:0]	NVIC_SystemHandlerPriorityConfig
[9:8]		
[13:10]	– SysHandlerCtrl – MEMFAULTPENDEDED[13]	NVIC_GetSystemHandlerPendingBitStatus
[17:14]	– SysHandlerCtrl – MEMFAULTACT[0]	NVIC_GetSystemHandlerActiveBitStatus
[19:18]	– ConfigFaultStatus – [7:0]	NVIC_GetFaultHandlerSources
[21:20]		
22	– MemoryManageFaultAddr	NVIC_GetFaultAddress



**Table 303. SystemHandler\_BusFault definition**

Bits	Bus Fault	
	Registers/Bits	Functions
[4:0]	– SysHandlerCtrl – BUSFAULTENA[17]	NVIC_SystemHandlerConfig
5	Not Used	
[7:6]	– SystemPriority[0]	NVIC_SystemHandlerPriorityConfig
[9:8]	– PRI_5[15:8]	
[13:10]	– SysHandlerCtrl – BUSFAULTPENDEDED[14]	NVIC_GetSystemHandlerPendingBitStatus
[17:14]	– SysHandlerCtrl – BUSFAULTACT[1]	NVIC_GetSystemHandlerActiveBitStatus
[19:18]	– ConfigFaultStatus	NVIC_GetFaultHandlerSources
[21:20]	– [15:8]	
22	– BusFaultAddr	NVIC_GetFaultAddress

**Table 304. SystemHandler\_UsageFault definition**

Bits	Usage Fault	
	Registers/Bits	Functions
[4:0]	– SysHandlerCtrl – USGFAULTENA[18]	NVIC_SystemHandlerConfig
5	Not Used	
[7:6]	– SystemPriority[0]	NVIC_SystemHandlerPriorityConfig
[9:8]	– PRI_6[23:16]	
[13:10]	Not Used	
[17:14]	– SysHandlerCtrl – USGFAULTACT[3]	NVIC_GetSystemHandlerActiveBitStatus
[19:18]	– ConfigFaultStatus	NVIC_GetFaultHandlerSources
[21:20]	– [31:16]	
22	Not Used	

**Table 305. SystemHandler\_SVCall definition**

Bits	SVCall	
	Registers/Bits	Functions
[4:0]	Not Used	
5	Not Used	
[7:6]	– SystemPriority[1] – PRI_11[31:24]	NVIC_SystemHandlerPriorityConfig
[9:8]		
[13:10]	– SysHandlerCtrl – SVCALLPENDE[15]	NVIC_GetSystemHandlerPendingBitStatus
[17:14]	– SysHandlerCtrl – SVCALLACT[7]	NVIC_GetSystemHandlerActiveBitStatus
[19:18]	Not Used	
[21:20]	Not Used	
22	Not Used	

**Table 306. SystemHandler\_DebugMonitor definition**

Bits	Debug Monitor	
	Registers/Bits	Functions
[4:0]	Not Used	
5	Not Used	
[7:6]	– SystemPriority[2] – PRI_12[7:0]	NVIC_SystemHandlerPriorityConfig
[9:8]		
[13:10]	Not Used	
[17:14]	– SysHandlerCtrl – MONITORACT[8]	NVIC_GetSystemHandlerActiveBitStatus
[19:18]	– DebugFaultStatus	NVIC_GetFaultHandlerSources
[21:20]		
22	Not Used	

**Table 307. SystemHandler\_PSV definition**

Bits	PSV	
	Registers/Bits	Functions
[4:0]	– IRQControlState – PENDSVSET[28]	NVIC_SetSystemHandlerPendingBit
	– IRQControlState – PENDSVCLR[27]	NVIC_ClearSystemHandlerPendingBit
5	Not Used	
[7:6]	– SystemPriority[2]	NVIC_SystemHandlerPriorityConfig
[9:8]	– PRI_14[23:16]	
[13:10]	Not Used	
[17:14]	– SysHandlerCtrl – PENDSVACT[10]	NVIC_GetSystemHandlerActiveBitStatus
[19:18]	Not Used	
[21:20]	Not Used	
22	Not Used	

**Table 308. SystemHandler\_SysTick definition**

Bits	SysTick	
	Registers/Bits	Functions
[4:0]	– IRQControlState – PENDSTSET[26]	NVIC_SetSystemHandlerPendingBit
	– IRQControlState – PENDSVCLR[25]	NVIC_ClearSystemHandlerPendingBit
5	Not Used	
[7:6]	– SystemPriority[2] – PRI_15[31:24]	NVIC_SystemHandlerPriorityConfig
[9:8]		
[13:10]	Not Used	
[17:14]	– SysHandlerCtrl – SYSTICKACT[11]	NVIC_GetSystemHandlerActiveBitStatus
[19:18]	Not Used	
[21:20]	Not Used	
22	Not Used	

### 13.2.24 NVIC\_SystemHandlerPriorityConfig function

[Table 309](#) describes the NVIC\_SystemHandlerPriorityConfig function.

**Table 309. NVIC\_SystemHandlerPriorityConfig function**

Function name	NVIC_SystemHandlerPriorityConfig
Function prototype	void NVIC_SystemHandlerPriorityConfig(u32 SystemHandler, u8 SystemHandlerPreemptionPriority, u8 SystemHandlerSubPriority)
Behavior description	Configures the specified System Handlers priority.
Input parameter1	SystemHandler: system handler to be enabled or disabled. Refer to <a href="#">SystemHandler</a> for more details on the allowed values for this parameter.
Input parameter2	SystemHandlerPreemptionPriority: new priority group of the specified system handlers. Refer to <a href="#">NVIC_IRQChannelPreemptionPriority</a> for more details on the allowed values for this parameter.
Input parameter3	SystemHandlerSubPriority: new sub priority of the specified system handlers. Refer to <a href="#">NVIC_IRQChannelSubPriority</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### SystemHandler

This parameter selects the system handler which will be configured (see [Table 310](#)).

**Table 310. SystemHandler types**

SystemHandler	Description
SystemHandler_MemoryManage	Memory Manage Handler
SystemHandler_BusFault	Bus Fault Handler
SystemHandler_UsageFault	Usage Fault Handler
SystemHandler_SVCall	SVCall Handler
SystemHandler_DebugMonitor	Debug Monitor Handler
SystemHandler_PSV	PSV Handler
SystemHandler_SysTick	SysTick Handler

#### Example:

```
/* Enable the Memory Manage Handler */
NVIC_SystemHandlerPriorityConfig(SystemHandler_MemoryManage, 2, 8);
```

### 13.2.25 NVIC\_GetSystemHandlerPendingBitStatus function

[Table 311](#) describes the NVIC\_GetSystemHandlerPendingBitStatus function.

**Table 311. NVIC\_GetSystemHandlerPendingBitStatus function**

Function name	NVIC_GetSystemHandlerPendingBitStatus
Function prototype	ITStatus NVIC_GetSystemHandlerPendingBitStatus(u32 SystemHandler)
Behavior description	Checks whether the specified System handlers pending bit is set or not.
Input parameter	SystemHandler: system handler pending bit to check. Refer to <a href="#">SystemHandler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of System Handler pending bit (SET or RESET).
Required preconditions	None
Called functions	None

#### SystemHandler

This parameter selects the system handler (see [Table 312](#)).

**Table 312. systemHandler types**

SystemHandler	Description
SystemHandler_MemoryManage	Memory Manage Handler
SystemHandler_BusFault	Bus Fault Handler
SystemHandler_SVCall	SVCall Handler

#### Example:

```
/* Check if the Memory Manage Fault has occurred */
ITStatus MemoryHandlerStatus;
MemoryHandlerStatus
=NVIC_GetSystemHandlerPendingBitStatus(SystemHandler_MemoryManage);
```

### 13.2.26 NVIC\_SetSystemHandlerPendingBit function

[Table 313](#) describes the NVIC\_SetSystemHandlerPendingBit function.

**Table 313. NVIC\_SetSystemHandlerPendingBit function**

Function name	NVIC_SetSystemHandlerPendingBit
Function prototype	void NVIC_SetSystemHandlerPendingBit(u32 SystemHandler)
Behavior description	Sets System Handler pending bit.
Input parameter	SystemHandler: system handler pending bit to be set. Refer to <a href="#">SystemHandler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### SystemHandler

This parameter selects the system handler (see [Table 314](#)).

**Table 314. systemHandler types**

SystemHandler	Description
SystemHandler_NMI	NMI Handler
SystemHandler_PSV	PSV Handler
SystemHandler_SysTick	SysTick Handler

#### Example:

```
/* Set NMI Pending Bit */
NVIC_SetSystemHandlerPendingBit(SystemHandler_NMI);
```

### 13.2.27 NVIC\_ClearSystemHandlerPendingBit function

[Table 315](#) describes the NVIC\_ClearSystemHandlerPendingBit function.

**Table 315. NVIC\_ClearSystemHandlerPendingBit function**

Function name	NVIC_ClearSystemHandlerPendingBit
Function prototype	void NVIC_ClearSystemHandlerPendingBit(u32 SystemHandler)
Behavior description	Clears System Handler pending bit.
Input parameter	SystemHandler: system handler pending bit to be reset. Refer to <a href="#">SystemHandler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### SystemHandler

This parameter selects the system handler (see [Table 316](#)).

**Table 316. systemHandler types**

SystemHandler	Description
SystemHandler_PSV	PSV Handler
SystemHandler_SysTick	SysTick Handler

#### Example:

```
/* Clear SysTick Pending Bit */  
NVIC_ClearSystemHandlerPendingBit(SystemHandler_SysTick);
```

### 13.2.28 NVIC\_GetSystemHandlerActiveBitStatus function

[Table 317](#) describes the NVIC\_GetSystemHandlerActiveBitStatus function.

**Table 317. NVIC\_GetSystemHandlerActiveBitStatus function**

Function name	NVIC_GetSystemHandlerActiveBitStatus
Function prototype	ITStatus NVIC_GetSystemHandlerActiveBitStatus(u32 SystemHandler)
Behavior description	Checks whether the specified System handlers active bit is set or not.
Input parameter	SystemHandler: system handler active bit to be checked. Refer to <a href="#">SystemHandler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of System Handler active bit (SET or RESET).
Required preconditions	None
Called functions	None

#### SystemHandler

This parameter selects the system handler (see [Table 318](#)).

**Table 318. systemHandler types**

SystemHandler	Description
SystemHandler_MemoryManage	Memory Manage Handler
SystemHandler_BusFault	Bus Fault Handler
SystemHandler_UsageFault	Usage Fault Handler
SystemHandler_SVCall	SVCall Handler
SystemHandler_DebugMonitor	Debug Monitor Handler
SystemHandler_PSV	PSV Handler
SystemHandler_SysTick	SysTick Handler

#### Example:

```
/* Check if the Bus Fault is active or stacked */
ITStatus BusFaultHandlerStatus;
BusFaultHandlerStatus =
NVIC_GetSystemHandlerActiveBitStatus(SystemHandler_BusFault);
```



### 13.2.29 NVIC\_GetFaultHandlerSources function

[Table 319](#) describes the NVIC\_GetFaultHandlerSources function.

**Table 319. NVIC\_GetFaultHandlerSources function**

Function name	NVIC_GetFaultHandlerSources
Function prototype	u32 NVIC_GetFaultHandlerSources(u32 SystemHandler)
Behavior description	Returns the system handler fault sources.
Input parameter	SystemHandler: system handler of which the fault sources will be returned. Refer to <a href="#">SystemHandler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	Source of the fault handler.
Required preconditions	None
Called functions	None

#### SystemHandler

This parameter selects the system handler (see [Table 320](#)).

**Table 320. systemHandler types**

SystemHandler	Description
SystemHandler_HardFault	Hard Fault Handler
SystemHandler_MemoryManage	Memory Manage Handler
SystemHandler_BusFault	Bus Fault Handler
SystemHandler_UsageFault	Usage Fault Handler
SystemHandler_DebugMonitor	Debug Monitor Handler

#### Example:

```
/* Gets the sources of the Bus Fault Handler */
u32 BusFaultHandlerSource;
BusFaultHandlerSource
=NVIC_GetFaultHandlerSources(SystemHandler_BusFault);
```

### 13.2.30 NVIC\_GetFaultAddress function

[Table 321](#) describes the NVIC\_GetFaultAddress function

**Table 321. NVIC\_GetFaultAddress function**

Function name	NVIC_GetFaultAddress
Function prototype	u32 NVIC_GetFaultAddress(u32 SystemHandler)
Behavior description	Returns the address of the location that generated a fault handler.
Input parameter	SystemHandler: system handler of which the fault address will be returned Refer to <a href="#">SystemHandler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	Fault address.
Required preconditions	None
Called functions	None

#### SystemHandler

This parameter selects the system handler (see [Table 322](#)).

**Table 322. SystemHandler types**

SystemHandler	Description
SystemHandler_MemoryManage	Memory Manage Handler
SystemHandler_BusFault	Bus Fault Handler

#### Example:

```
/* Gets the address of the Bus Fault Handler */  
u32 BusFaultHandlerAddress;  
BusFaultHandlerAddress =  
NVIC_GetFaultAddress(SystemHandler_BusFault);
```

## 14 Power control (PWR)

The PWR is used for a variety of purposes including power management and low power mode selection.

[Section 14.1: PWR register structure](#) describes the data structures used in the PWR Firmware Library. [Section 14.2: Firmware library functions](#) presents the Firmware Library functions.

### 14.1 PWR register structure

The PWR register structure, *PWR\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32 CR;
    vu32 CSR;
} PWR_TypeDef;
```

[Table 323](#) gives the list of PWR registers.

**Table 323. PWR registers**

Register	Description
CR	Power Control Register
CSR	Power Control Status Register

The PWR peripheral is declared in *stm32f10x\_map.h*:

```
#define PERIPH_BASE      ((u32)0x40000000)
#define APB1PERIPH_BASE PERIPH_BASE
#define APB2PERIPH_BASE (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE  (PERIPH_BASE + 0x20000)

#define PWR_BASE         (APB1PERIPH_BASE + 0x7000)

#ifndef DEBUG
...
#define _PWR
#define PWR              ((PWR_TypeDef *) PWR_BASE)
#endif /* _PWR */
...
#else /* DEBUG */
...
#define _PWR
EXT PWR_TypeDef          *PWR;
#endif /* _PWR */
...
#endif
```

When using the Debug mode, PWR pointer is initialized in *stm32f10x\_lib.c* file:

```
#ifndef _PWR
PWR = (PWR_TypeDef *) PWR_BASE;
#endif /*_PWR */
```

To access the PWR registers, `_PWR` must be defined in *stm32f10x\_conf.h* as follows:

```
#define _PWR
```

## 14.2 Firmware library functions

[Table 324](#) gives the list of the various PWR library functions.

**Table 324. PWR firmware library functions**

Function name	Description
PWR_DeInit	Resets the PWR peripheral registers to their default reset values.
PWR_BackupAccessCmd	Enables or disables access to the RTC and backup registers.
PWR_PVDCmd	Enables or disables the Power Voltage Detector(PVD).
PWR_PVDLevelConfig	Configures the voltage threshold detected by the Power Voltage Detector(PVD).
PWR_WakeUpPinCmd	Enables or disables the WakeUp Pin functionality.
PWR_EnterSTOPMode	Enters Stop mode.
PWR_EnterSTANDBYMode	Enters Standby mode.
PWR_GetFlagStatus	Checks whether the specified PWR flag is set or not.
PWR_ClearFlag	Clears the PWR's pending flags.

### 14.2.1 PWR\_DeInit function

[Table 325](#) describes the PWR\_DeInit function.

**Table 325. PWR\_DeInit function**

Function name	PWR_DeInit
Function prototype	void PWR_DeInit(void)
Behavior description	Resets the PWR peripheral registers to their default reset values.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_APB1PeriphResetCmd

**Example:**

```
/* Deinitialize the PWR registers */
PWR_DeInit();
```

### 14.2.2 PWR\_BackupAccessCmd function

[Table 326](#) describes the PWR\_BackupAccessCmd function.

**Table 326. PWR\_BackupAccessCmd function**

Function name	PWR_BackupAccessCmd
Function prototype	void PWR_BackupAccessCmd(FunctionalState NewState)
Behavior description	Enables or disables access to the RTC and backup registers.
Input parameter	NewState: new state of the access to the RTC and backup registers. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable access to the RTC and backup registers */
PWR_BackupAccessCmd (ENABLE) ;
```

### 14.2.3 PWR\_PVDCmd function

[Table 327](#) describes the PWR\_PVDCmd function.

**Table 327. PWR\_PVDCmd function**

Function name	PWR_PVDCmd
Function prototype	void PWR_PVDCmd(FunctionalState NewState)
Behavior description	Enables or disables the Power Voltage Detector(PVD).
Input parameter	NewState: new state of the PVD. This parameter can be set either to ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the Power Voltage Detector (PVD) */
PWR_PVDCmd (ENABLE) ;
```

#### 14.2.4 PWR\_PVDLevelConfig function

[Table 328](#) describes the PWR\_PVDLevelConfig function.

**Table 328. PWR\_PVDLevelConfig function**

Function name	PWR_PVDLevelConfig
Function prototype	void PWR_PVDLevelConfig(u32 PWR_PVDLevel)
Behavior description	Configures the voltage threshold detected by the Power Voltage Detector (PVD).
Input parameter	PWR_PVDLevel: PVD detection level Refer to <a href="#">PWR_PVDLevel</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

##### PWR\_PVDLevel

This parameter configures the PVD detection level value (see [Table 329](#)).

**Table 329. PWR\_PVDLevel values**

PWR_PVDLevel	Description
PWR_PVDLevel_2V2	PVD detection level set to 2.2V
PWR_PVDLevel_2V3	PVD detection level set to 2.3V
PWR_PVDLevel_2V4	PVD detection level set to 2.4V
PWR_PVDLevel_2V5	PVD detection level set to 2.5V
PWR_PVDLevel_2V6	PVD detection level set to 2.6V
PWR_PVDLevel_2V7	PVD detection level set to 2.7V
PWR_PVDLevel_2V8	PVD detection level set to 2.8V
PWR_PVDLevel_2V9	PVD detection level set to 2.9V

##### Example:

```
/* Set PVD detection level to 2.5V */  
PWR_PVDLevelConfig(PWR_PVDLevel_2V5);
```

## 14.2.5 PWR\_WakeUpPinCmd function

[Table 330](#) describes the PWR\_WakeUpPinCmd function.

**Table 330. PWR\_WakeUpPinCmd function**

Function name	PWR_WakeUpPinCmd
Function prototype	void PWR_WakeUpPinCmd(FunctionalState NewState)
Behavior description	Enables or disables the WakeUp Pin functionality.
Input parameter	NewState: new state of the WakeUp Pin functionality. This parameter can be set either to ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* WakeUp pin used for wake-up function */
PWR_WakeUpPinCmd(ENABLE);
```

## 14.2.6 PWR\_EnterSTOPMode function

[Table 331](#) describes the PWR\_EnterSTOPMode function.

**Table 331. PWR\_EnterSTOPMode function**

Function name	PWR_EnterSTOPMode
Function prototype	void PWR_EnterSTOPMode(u32 PWR_Regulator, u8 PWR_STOPEntry)
Behavior description	Enters Stop mode.
Input parameter1	PWR_Regulator: regulator state in Stop mode. Refer to <a href="#">PWR_Regulator</a> for more details on the allowed values for this parameter.
Input parameter2	PWR_STOPEntry: specifies if Stop mode is entered with WFI or WFE instruction. Refer to <a href="#">PWR_STOPEntry</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	__WFI(), __WFE()

### PWR\_Regulator

This parameter configures the regulator state in Stop mode. See [Table 332](#) for the possible values of PWR\_Regulator.

**Table 332. PWR\_Regulator definition**

PWR_Regulator	Description
PWR_Regulator_ON	Stop mode with regulator ON
PWR_Regulator_LowPower	Stop mode with regulator in low power mode

**PWR\_STOPEntry**

This parameter defines the Stop mode entry.

**Table 333. PWR\_STOPEntry definition**

PWR_Regulator	Description
PWR_STOPEntry_WFI	Enter Stop mode with WFI instruction
PWR_STOPEntry_WFE	Enter Stop mode with WFE instruction

**Example:**

```
/* Put the system in Stop mode with regulator on */
PWR_EnterSTOPMode(PWR_Regulator_ON, PWR_STOPEntry_WFE);
```

**14.2.7 PWR\_EnterSTANDBYMode function**

[Table 334](#) describes the PWR\_EnterSTANDBYMode function.

**Table 334. PWR\_EnterSTANDBYMode function**

Function name	PWR_EnterSTANDBYMode
Function prototype	void PWR_EnterSTANDBYMode(void)
Behavior description	Enters Standby mode.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	__WFI()

**Example:**

```
/* Put the system in Standby mode */
PWR_EnterSTANDBYMode();
```



## 14.2.8 PWR\_GetFlagStatus function

[Table 335](#) describes the PWR\_GetFlagStatus function.

**Table 335. PWR\_GetFlagStatus function**

Function name	PWR_GetFlagStatus
Function prototype	FlagStatus PWR_GetFlagStatus(u32 PWR_FLAG)
Behavior description	Checks whether the specified PWR flag is set or not.
Input parameter	PWR_FLAG: flag to be checked. Refer to <a href="#">PWR_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of PWR_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

### PWR\_FLAG

The PWR flags that can be checked by issuing a PWR\_GetFlagStatus function are listed in [Table 336](#).

**Table 336. PWR\_Flag values**

PWR_FLAG	Description
PWR_FLAG_WU	Wake-up flag
PWR_FLAG_SB	StandBy flag
PWR_FLAG_PVDO	PVD Output <sup>(1)</sup>

1. This flag is read only. It cannot be cleared.

#### Example:

```
/* Test if the StandBy flag is set or not */
FlagStatus Status;
Status = PWR_GetFlagStatus(PWR_FLAG_SB);
if(Status == RESET)
{
    ...
}
else
{
    ...
}
```

### 14.2.9 PWR\_ClearFlag function

*Table 337* describes the PWR\_ClearFlag function.

**Table 337. PWR\_ClearFlag function**

Function name	PWR_ClearFlag
Function prototype	void PWR_ClearFlag(u32 PWR_FLAG)
Behavior description	Clears the PWR's pending flags.
Input parameter	PWR_FLAG: flag to be cleared. Refer to <a href="#">PWR_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the StandBy pending flag */  
PWR_ClearFlag(PWR_FLAG_SB);
```

## 15 Reset and clock control (RCC)

The RCC can be used for a variety of purposes, including clock configuration, peripheral reset and clock management.

[Section 15.1: RCC register structure](#) describes the data structures used in the RCC Firmware Library. [Section 15.2: Firmware library functions](#) presents the Firmware Library functions.

### 15.1 RCC register structure

The RCC register structure, *RCC\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32 CR;
    vu32 CFGR;
    vu32 CIR;
    vu32 APB2RSTR;
    vu32 APB1RSTR;
    vu32 AHBENR;
    vu32 APB2ENR;
    vu32 APB1ENR;
    vu32 BDCR;
    vu32 CSR;
} RCC_TypeDef;
```

[Table 338](#) gives the list of RCC registers.

**Table 338. RCC registers**

Register	Description
CR	Clock control register
CFGR	Clock configuration register
CIR	Clock interrupt register
APB2RSTR	APB2 Peripheral reset register
APB1RSTR	APB1 Peripheral reset register
AHBENR	AHB Peripheral Clock enable register
APB2ENR	APB2 Peripheral Clock enable register
APB1ENR	APB1 Peripheral Clock enable register
BDCR	Backup domain control register
CSR	Control/status register

The RCC peripheral is declared in the same file:

```

#define PERIPH_BASE                ((u32)0x40000000)
#define APB1PERIPH_BASE            PERIPH_BASE
#define APB2PERIPH_BASE            (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE             (PERIPH_BASE + 0x20000)
#define RCC_BASE                   (AHBPERIPH_BASE + 0x1000)

#ifndef DEBUG
...
#endif
#define _RCC
#define RCC                        ((RCC_TypeDef *) RCC_BASE)
#endif /* _RCC */
...
#else /* DEBUG */
...
#endif
#define _RCC
EXT RCC_TypeDef                   *RCC;
#endif /* _RCC */
...
#endif

```

When using the Debug mode, RCC pointer is initialized in *stm32f10x\_lib.c* file:

```

#ifdef _RCC
RCC = (RCC_TypeDef *) RCC_BASE;
#endif /* _RCC */

```

To access the reset and clock control registers, `_RCC` must be defined in *stm32f10x\_conf.h* as follows:

```

#define _RCC

```

## 15.2 Firmware library functions

[Table 339](#) gives the list of the various functions of the RCC library.

**Table 339. RCC firmware library functions**

Function name	Description
RCC_DeInit	Resets the RCC clock configuration to the default reset state.
RCC_HSEConfig	Configures the External High Speed oscillator (HSE).
RCC_WaitForHSEStartUp	Waits for HSE start-up.
RCC_AdjustHSICalibrationValue	Adjusts the Internal High Speed oscillator (HSI) calibration value.
RCC_HSICmd	Enables or disables the Internal High Speed oscillator (HSI).
RCC_PLLConfig	Configures the PLL clock source and multiplication factor.
RCC_PLLCmd	Enables or disables the PLL.
RCC_SYSCLKConfig	Configures the system clock (SYSCLK).
RCC_GetSYSCLKSource	Returns the clock source used as system clock.
RCC_HCLKConfig	Configures the AHB clock (HCLK).
RCC_PCLK1Config	Configures the Low Speed APB clock (PCLK1).

**Table 339. RCC firmware library functions (continued)**

Function name	Description
RCC_PCLK2Config	Configures the High Speed APB clock (PCLK2).
RCC_ITConfig	Enables or disables the specified RCC interrupts.
RCC_USBCLKConfig	Configures the USB clock (USBCLK).
RCC_ADCCLKConfig	Configures the ADC clock (ADCCLK).
RCC_LSEConfig	Configures the External Low Speed oscillator (LSE).
RCC_LSICmd	Enables or disables the Internal Low Speed oscillator (LSI).
RCC_RTCCLKConfig	Configures the RTC clock (RTCCLK).
RCC_RTCCLKCmd	Enables or disables the RTC clock.
RCC_GetClocksFreq	Returns the frequencies of different on chip clocks.
RCC_AHBPeriphClockCmd	Enables or disables the AHB peripheral clock.
RCC_APB2PeriphClockCmd	Enables or disables the High Speed APB (APB2) peripheral clock.
RCC_APB1PeriphClockCmd	Enables or disables the Low Speed APB (APB1) peripheral clock.
RCC_APB2PeriphResetCmd	Forces or releases High Speed APB (APB2) peripheral reset.
RCC_APB1PeriphResetCmd	Forces or releases Low Speed APB (APB1) peripheral reset.
RCC_BackupResetCmd	Forces or releases the Backup domain reset.
RCC_ClockSecuritySystemCmd	Enables or disables the Clock Security System.
RCC_MCOConfig	Selects the clock source to output on MCO pin.
RCC_GetFlagStatus	Checks whether the specified RCC flag is set or not.
RCC_ClearFlag	Clears the RCC reset flags.
RCC_GetITStatus	Checks whether the specified RCC interrupt has occurred or not.
RCC_ClearITPendingBit	Clears the RCC's interrupt pending bits.

### 15.2.1 RCC\_DeInit function

[Table 340](#) describes the RCC\_DeInit function.

**Table 340. RCC\_DeInit function<sup>(1)</sup>**

Function name	RCC_DeInit
Function prototype	void RCC_DeInit(void)
Behavior description	Resets the RCC clock configuration to the default reset state.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

1. The default reset state of the clock configuration is given below:

- HSI on
- HSI used as the system clock source
- HSE and PLL off
- AHB, APB1 and APB2 prescaler set to 1 and ADC prescaler set to 2.

**Example:**

```
/* Reset the RCC clock configuration to the default reset state */
RCC_DeInit();
```

### 15.2.2 RCC\_HSEConfig function

[Table 341](#) describes the RCC\_HSEConfig function.

**Table 341. RCC\_HSEConfig function**

Function name	RCC_HSEConfig
Function prototype	void RCC_HSEConfig(u32 RCC_HSE)
Behavior description	Configures the External High Speed oscillator (HSE).
Input parameter	RCC_HSE: new state of the HSE. Refer to <a href="#">RCC_HSE</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	HSE can not be stopped if it is used directly or through the PLL as system clock.
Called functions	None

**RCC\_HSE**

This parameter configures the HSE state (see [Table 342](#)).

**Table 342. RCC\_HSE definition**

RCC_HSE	Description
RCC_HSE_OFF	HSE oscillator OFF
RCC_HSE_ON	HSE oscillator ON
RCC_HSE_Bypass	HSE oscillator bypassed with external clock

**Example:**

```
/* Enable the HSE */
RCC_HSEConfig(RCC_HSE_ON);
```

**15.2.3 RCC\_WaitForHSEStartUp function**

[Table 343](#) describes the RCC\_WaitForHSEStartUp function.

**Table 343. RCC\_WaitForHSEStartUp function**

Function name	RCC_WaitForHSEStartUp
Function prototype	ErrorStatus RCC_WaitForHSEStartUp(void)
Behavior description	Waits for HSE start-up. This functions waits till HSE is ready and exit if Time out is reached.
Input parameter	None
Output parameter	None
Return parameter	An ErrorStatus enumeration value: - SUCCESS: HSE oscillator is stable and ready to use - ERROR: HSE oscillator not yet ready
Required preconditions	None
Called functions	None

**Example:**

```
ErrorStatus HSEStartUpStatus;

/* Enable HSE */
RCC_HSEConfig(RCC_HSE_ON);

/* Wait till HSE is ready and if Time out is reached exit */
HSEStartUpStatus = RCC_WaitForHSEStartUp();

if(HSEStartUpStatus == SUCCESS)
{
    /* Add here PLL and system clock config */
}
else
{
    /* Add here some code to deal with this error */
}
```

## 15.2.4 RCC\_AdjustHSICalibrationValue function

[Table 344](#) describes the RCC\_AdjustHSICalibrationValue function.

**Table 344. RCC\_AdjustHSICalibrationValue function**

Function name	RCC_AdjustHSICalibrationValue
Function prototype	void RCC_AdjustHSICalibrationValue(u8 HSICalibrationValue)
Behavior description	Adjusts the Internal High Speed oscillator (HSI) calibration value.
Input parameter	HSICalibrationValue: calibration trimming value. This parameter must be a number between 0 and 0x1F.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set HSI calibration value to 0x1F (maximum) */
RCC_AdjustHSICalibrationValue(0x1F);
```

## 15.2.5 RCC\_HSICmd function

[Table 345](#) describes the RCC\_HSICmd function.

**Table 345. RCC\_HSICmd function**

Function name	RCC_HSICmd
Function prototype	void RCC_HSICmd(FunctionalState NewState)
Behavior description	Enables or disables the Internal High Speed oscillator (HSI).
Input parameter	NewState: new state of the HSI. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	HSI can not be stopped if it is used directly or through the PLL as system clock, or if a Flash program operation is ongoing.
Called functions	None

**Example:**

```
/* Enable Internal High Speed oscillator */
RCC_HSICmd(ENABLE);
```



## 15.2.6 RCC\_PLLConfig function

[Table 346](#) describes the RCC\_PLLConfig function.

**Table 346. RCC\_PLLConfig function**

Function name	RCC_PLLConfig
Function prototype	void RCC_PLLConfig(u32 RCC_PLLSource, u32 RCC_PLLMul)
Behavior description	Configures the PLL clock source and multiplication factor.
Input parameter1	RCC_PLLSource: PLL entry clock source. Refer to <a href="#">RCC_PLLSource</a> for more details on the allowed values for this parameter.
Input parameter2	RCC_PLLMul: PLL multiplication factor. Refer to <a href="#">RCC_PLLMul</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	This function must be used only when the PLL is disabled.
Called functions	None

### RCC\_PLLSource

This parameter selects the PLL entry clock source (see [Table 347](#)).

**Table 347. RCC\_PLLSource definition**

RCC_PLLSource	Description
RCC_PLLSource_HSI_Div2	PLL clock entry = HSI oscillator clock divided by 2
RCC_PLLSource_HSE_Div1	PLL clock entry = HSE oscillator clock
RCC_PLLSource_HSE_Div2PLL clock entry	PLL clock entry = HSE oscillator clock divided by 2

### RCC\_PLLMul

This parameter selects the PLL multiplication factor (see [Table 348](#)).

**Table 348. RCC\_PLLMul definition**

RCC_PLLMul	Description
RCC_PLLMul_2	PLL clock entry x 2
RCC_PLLMul_3	PLL clock entry x 3
RCC_PLLMul_4	PLL clock entry x 4
RCC_PLLMul_5	PLL clock entry x 5
RCC_PLLMul_6	PLL clock entry x 6
RCC_PLLMul_7	PLL clock entry x 7
RCC_PLLMul_8	PLL clock entry x 8
RCC_PLLMul_9	PLL clock entry x 9

**Table 348. RCC\_PLLMul definition (continued)**

RCC_PLLMul	Description
RCC_PLLMul_10	PLL clock entry x 10
RCC_PLLMul_11	PLL clock entry x 11
RCC_PLLMul_12	PLL clock entry x12
RCC_PLLMul_13	PLL clock entry x 13
RCC_PLLMul_14	PLL clock entry x 14
RCC_PLLMul_15	PLL clock entry x 15
RCC_PLLMul_16	PLL clock entry x 16

---

**Warning:** The software must configure correctly the PLL to generate a PLL output frequency that does not exceed 72 MHz.

---

**Example:**

```
/* Set PLL clock output to 72MHz using HSE (8MHz) as entry clock */
RCC_PLLConfig(RCC_PLLSource_HSE_Div1, RCC_PLLMul_9);
```

**15.2.7 RCC\_PLLCmd function**

[Table 349](#) describes the RCC\_PLLCmd function.

**Table 349. RCC\_PLLCmd function**

Function name	RCC_PLLCmd
Function prototype	void RCC_PLLCmd(FunctionalState NewState)
Behavior description	Enables or disables the PLL.
Input parameter	NewState: new state of the PLL. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	The PLL can not be disabled if it is used as system clock.
Called functions	None

**Example:**

```
/* Enable the PLL */
RCC_PLLCmd(ENABLE);
```

## 15.2.8 RCC\_SYSClkConfig function

[Table 350](#) describes the RCC\_SYSClkConfig function.

**Table 350. RCC\_SYSClkConfig function**

Function name	RCC_SYSClkConfig
Function prototype	void RCC_SYSClkConfig(u32 RCC_SYSClkSource)
Behavior description	Configures the system clock (SYSClk).
Input parameter	RCC_SYSClkSource: clock source used as system clock. Refer to <a href="#">RCC_SYSClkSource</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### RCC\_SYSClkSource

This parameter selects the system clock source (see [Table 351](#)).

**Table 351. RCC\_SYSClkSource definition**

RCC_SYSClkSource	Description
RCC_SYSClkSource_HSI	HSI selected as system clock
RCC_SYSClkSource_HSE	HSE selected as system clock
RCC_SYSClkSource_PLLCLK	PLL selected as system clock

### Example:

```
/* Select the PLL as system clock source */
RCC_SYSClkConfig(RCC_SYSClkSource_PLLCLK);
```

### 15.2.9 RCC\_GetSYSCLKSource function

*Table 352* describes the RCC\_GetSYSCLKSource function.

**Table 352. RCC\_GetSYSCLKSource function**

Function name	RCC_GetSYSCLKSource
Function prototype	u8 RCC_GetSYSCLKSource(void)
Behavior description	Returns the clock source used as system clock.
Input parameter	None
Output parameter	None
Return parameter	The clock source used as system clock. The returned value can be one of the following: <ul style="list-style-type: none"><li>– 0x00: HSI used as system clock</li><li>– 0x04: HSE used as system clock</li><li>– 0x08: PLL used as system clock</li></ul>
Required preconditions	None
Called functions	None

**Example:**

```
/* Test if HSE is used as system clock */
if(RCC_GetSYSCLKSource() != 0x04)
{
}
else
{
}
```

### 15.2.10 RCC\_HCLKConfig function

[Table 353](#) describes the RCC\_HCLKConfig function.

**Table 353. RCC\_HCLKConfig function**

Function name	RCC_HCLKConfig
Function prototype	void RCC_HCLKConfig(u32 RCC_HCLK)
Behavior description	Configures the AHB clock(HCLK).
Input parameter	RCC_HCLK: defines the AHB clock. This clock is derived from the system clock (SYSCLK). Refer to <a href="#">RCC_HCLK</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### RCC\_HCLK

RCC\_HCLK configures the AHB clock. Refer to [Table 354](#) for the values taken by this parameter.

**Table 354. RCC\_HCLK values**

RCC_HCLK	Description
RCC_SYSCLK_Div1	AHB clock = SYSCLK
RCC_SYSCLK_Div2	AHB clock = SYSCLK/2
RCC_SYSCLK_Div4	AHB clock = SYSCLK/4
RCC_SYSCLK_Div8	AHB clock = SYSCLK/8
RCC_SYSCLK_Div16	AHB clock = SYSCLK/16
RCC_SYSCLK_Div64	AHB clock = SYSCLK/64
RCC_SYSCLK_Div128	AHB clock = SYSCLK/128
RCC_SYSCLK_Div256	AHB clock = SYSCLK/256
RCC_SYSCLK_Div512	AHB clock = SYSCLK/512

#### Example:

```
/* Configure HCLK such as HCLK = SYSCLK */
RCC_HCLKConfig(RCC_SYSCLK_Div1);
```

### 15.2.11 RCC\_PCLK1Config function

[Table 355](#) describes the RCC\_PCLK1Config function.

**Table 355. RCC\_PCLK1Config function**

Function name	RCC_PCLK1Config
Function prototype	<code>void RCC_PCLK1Config(u32 RCC_PCLK1)</code>
Behavior description	Configures the Low Speed APB clock (PCLK1).
Input parameter	RCC_PCLK1: defines the APB1 clock. This clock is derived from the AHB clock (HCLK). Refer to <a href="#">RCC_PCLK1</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### RCC\_PCLK1

RCC\_PCLK1 configures the APB1 clock. Refer to [Table 356](#) for the values taken by this parameter.

**Table 356. RCC\_PCLK1 values**

RCC_PCLK1	Description
RCC_HCLK_Div1	APB1 clock = HCLK
RCC_HCLK_Div2	APB1 clock = HCLK/2
RCC_HCLK_Div4	APB1 clock = HCLK/4
RCC_HCLK_Div8	APB1 clock = HCLK/8
RCC_HCLK_Div16	APB1 clock = HCLK/16

#### Example:

```
/* Configure PCLK1 such as PCLK1 = HCLK/2 */
RCC_PCLK1Config(RCC_HCLK_Div2);
```

### 15.2.12 RCC\_PCLK2Config function

[Table 357](#) describes the RCC\_PCLK2Config function.

**Table 357. RCC\_PCLK2Config function**

Function name	RCC_PCLK2Config
Function prototype	<code>void RCC_PCLK2Config(u32 RCC_PCLK2)</code>
Behavior description	Configures the High Speed APB clock (PCLK2).
Input parameter	RCC_PCLK2: defines the APB2 clock. This clock is derived from the AHB clock (HCLK). Refer to <a href="#">RCC_PCLK2</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### RCC\_PCLK2

RCC\_PCLK2 configures the APB2 clock. Refer to [Table 358](#) for the values taken by this parameter.

**Table 358. RCC\_PCLK2 values**

RCC_PCLK2	Description
RCC_HCLK_Div1	APB2 clock = HCLK
RCC_HCLK_Div2	APB2 clock = HCLK/2
RCC_HCLK_Div4	APB2 clock = HCLK/4
RCC_HCLK_Div8	APB2 clock = HCLK/8
RCC_HCLK_Div16	APB2 clock = HCLK/16

#### Example:

```
/* Configure PCLK2 such as PCLK2 = HCLK */
RCC_PCLK2Config(RCC_HCLK_Div1);
```

### 15.2.13 RCC\_ITConfig function

[Table 359](#) describes the RCC\_ITConfig function.

**Table 359. RCC\_ITConfig function**

Function name	RCC_ITConfig
Function prototype	<code>void RCC_ITConfig(u8 RCC_IT, FunctionalState NewState)</code>
Behavior description	Enables or disables the specified RCC interrupts.
Input parameter1	RCC_IT: specifies the RCC interrupt sources to be enabled or disabled. Refer to <a href="#">RCC_IT</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the specified RCC interrupts. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### RCC\_IT

RCC\_IT enables or disables RCC interrupts. One or a combination of the following values can be used:

**Table 360. RCC\_IT values**

RCC_IT	Description
RCC_IT_LSIRDY	LSI ready interrupt
RCC_IT_LSERDY	LSE ready interrupt
RCC_IT_HSIRDY	HSI ready interrupt
RCC_IT_HSERDY	HSE ready interrupt
RCC_IT_PLLRDY	PLL ready interrupt

**Example:**

```
/* Enable PLL Ready interrupt */
RCC_ITConfig(RCC_IT_PLLRDY, ENABLE);
```



### 15.2.14 RCC\_USBCLKConfig function

[Table 361](#) describes the RCC\_USBCLKConfig function.

**Table 361. RCC\_USBCLKConfig function**

Function name	RCC_USBCLKConfig
Function prototype	<code>void RCC_USBCLKConfig(u32 RCC_USBCLKSource)</code>
Behavior description	Configures the USB clock (USBCLK).
Input parameter	RCC_USBCLKSource specifies the USB clock source. This clock is derived from the PLL output. Refer to <a href="#">RCC_USBCLKSource</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	The USB needs a 48 MHz clock to operate correctly. The user must select the USB division factor according to the PLL multiplication factor and PLL clock source frequency in order to obtain a 48 MHz frequency. Once the USB clock is enabled, the USB division factor cannot be modified.
Called functions	None

#### RCC\_USBCLKSource

This parameter selects the USB clock source (see [Table 362](#)).

**Table 362. RCC\_USBCLKSource values**

RCC_USBCLKSource	Description
RCC_USBCLKSource_PLLCLK_1Div5	USB clock source = PLL clock divided by 1.5 selected
RCC_USBCLKSource_PLLCLK_Div1	USB clock source = PLL clock selected

#### Example:

```
/* PLL clock divided by 1.5 used as USB clock source */
RCC_USBCLKConfig(RCC_USBCLKSource_PLLCLK_1Div5);
```

### 15.2.15 RCC\_ADCCLKConfig function

[Table 363](#) describes the RCC\_ADCCLKConfig function.

**Table 363. RCC\_ADCCLKConfig function**

Function name	RCC_ADCCLKConfig
Function prototype	<code>void RCC_ADCCLKConfig(u32 RCC_ADCCLK)</code>
Behavior description	Configures the ADC clock (ADCCLK).
Input parameter	RCC_ADCCLK defines the ADC clock. This clock is derived from the APB2 clock (PCLK2). Refer to <a href="#">RCC_ADCCLK</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### RCC\_ADCCLK

RCC\_ADCCLK configures the ADC clock. Refer to [Table 364](#) for the values taken by this parameter.

**Table 364. RCC\_ADCCLK values**

RCC_ADCCLK	Description
RCC_PCLK2_Div2	ADC clock = PCLK2/2
RCC_PCLK2_Div4	ADC clock = PCLK2/4
RCC_PCLK2_Div6	ADC clock = PCLK2/6
RCC_PCLK2_Div8	ADC clock = PCLK2/8

#### Example:

```
/* Configure ADCCLK such as ADCCLK = PCLK2/2 */
RCC_ADCCLKConfig(RCC_PCLK2_Div2);
```

## 15.2.16 RCC\_LSEConfig function

[Table 365](#) describes the RCC\_LSEConfig function.

**Table 365. RCC\_LSEConfig function**

Function name	RCC_LSEConfig
Function prototype	void RCC_LSEConfig(u32 RCC_LSE)
Behavior description	Configures the External Low Speed oscillator (LSE).
Input parameter	RCC_LSE: new state of the LSE. Refer to <a href="#">RCC_LSE</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### RCC\_LSE

This parameter configures the LSE state (see [Table 366](#)).

**Table 366. RCC\_LSE values**

RCC_LSE	Description
RCC_LSE_OFF	LSE oscillator OFF
RCC_LSE_ON	LSE oscillator ON
RCC_LSE_Bypass	LSE oscillator bypassed with external clock

#### Example:

```
/* Enable the LSE */  
RCC_LSEConfig(RCC_LSE_ON);
```

### 15.2.17 RCC\_LSICmd function

[Table 367](#) describes the RCC\_LSICmd function.

**Table 367. RCC\_LSICmd function**

Function name	RCC_LSICmd
Function prototype	<code>void RCC_LSICmd(FunctionalState NewState)</code>
Behavior description	Enables or disables the Internal Low Speed oscillator (LSI).
Input parameter	NewState: new state of the LSI. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	LSI can not be disabled if the IWDG is running.
Called functions	None

**Example:**

```
/* Enable the Internal Low Speed oscillator */
RCC_LSICmd(ENABLE);
```

### 15.2.18 RCC\_RTCCLKConfig function

[Table 368](#) describes the RCC\_RTCCLKConfig function.

**Table 368. RCC\_RTCCLKConfig function**

Function name	RCC_RTCCLKConfig
Function prototype	<code>void RCC_RTCCLKConfig(u32 RCC_RTCCLKSource)</code>
Behavior description	Configures the RTC clock (RTCCLK).
Input parameter	RCC_RTCCLKSource: RTC clock source. Refer to <a href="#">RCC_RTCCLKSource</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	Once the RTC clock is selected it cannot be changed unless the Backup domain is reset.
Called functions	None

**RCC\_RTCCLKSource**

This parameter selects the RTC clock source (see [Table 369](#)).

**Table 369. RCC\_RTCCLKSource values**

RCC_RTCCLKSource	Description
RCC_RTCCLKSource_LSE	LSE selected as RTC clock
RCC_RTCCLKSource_LSI	LSI selected as RTC clock
RCC_RTCCLKSource_HSE_Div128	HSE clock divided by 128 selected as RTC clock

**Example:**

```
/* Select the LSE as RTC clock source */
RCC_RTCCLKConfig(RCC_RTCCLKSource_LSE);
```

**15.2.19 RCC\_RTCCLKCmd function**

[Table 370](#) describes the RCC\_RTCCLKCmd function.

**Table 370. RCC\_RTCCLKCmd function**

Function name	RCC_RTCCLKCmd
Function prototype	void RCC_RTCCLKCmd(FunctionalState NewState)
Behavior description	Enables or disables the RTC clock.
Input parameter	NewState: new state of the RTC clock. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	This function must be used only after the RTC clock was selected using the RCC_RTCCLKConfig function.
Called functions	None

**Example:**

```
/* Enable the RTC clock */
RCC_RTCCLKCmd(ENABLE);
```

## 15.2.20 RCC\_GetClocksFreq function

[Table 371](#) describes the RCC\_GetClocksFreq function.

**Table 371. RCC\_GetClocksFreq function**

Function name	RCC_GetClocksFreq
Function prototype	<code>void RCC_GetClocksFreq(RCC_ClocksTypeDef* RCC_Clocks)</code>
Behavior description	Returns the frequencies of different on chip clocks.
Input parameter	RCC_Clocks: pointer to an RCC_ClocksTypeDef structure which contains the clock frequencies. Refer to the <a href="#">RCC_ClocksTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## RCC\_ClocksTypeDef structure

The RCC\_ClocksTypeDef structure is defined in the *stm32f10x\_rcc.h* file:

```
typedef struct
{
    u32 SYSCLK_Frequency;
    u32 HCLK_Frequency;
    u32 PCLK1_Frequency;
    u32 PCLK2_Frequency;
    u32 ADCCLK_Frequency;
}RCC_ClocksTypeDef;
```

### **SYSCLK\_Frequency**

This member returns SYSCLK clock frequency expressed in Hz.

### **HCLK\_Frequency**

This member returns HCLK clock frequency expressed in Hz.

### **PCLK1\_Frequency**

This member returns PCLK1 clock frequency expressed in Hz.

### **PCLK2\_Frequency**

This member returns PCLK2 clock frequency expressed in Hz.

### **ADCCLK\_Frequency**

This member returns ADCCLK clock frequency expressed in Hz.

**Example:**

```
/* Get the frequencies of different on chip clocks */
RCC_ClocksTypeDef RCC_Clocks;
RCC_GetClocksFreq(&RCC_Clocks);
```

**15.2.21 RCC\_AHBPeriphClockCmd function**

[Table 372](#) describes the RCC\_AHBPeriphClockCmd function.

**Table 372. RCC\_AHBPeriphClockCmd function**

Function name	RCC_AHBPeriphClockCmd
Function prototype	void RCC_AHBPeriphClockCmd(u32 RCC_AHBPeriph, FunctionalState NewState)
Behavior description	Enables or disables the AHB peripheral clock.
Input parameter1	RCC_AHBPeriph: AHB peripheral to gate the clock. Refer to <a href="#">RCC_AHBPeriph</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the specified peripheral clock. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**RCC\_AHBPeriph**

This parameter selects the AHB peripheral that gates the clock. One or a combination of the following values can be used:

**Table 373. RCC\_AHBPeriph values<sup>(1)</sup>**

RCC_AHBPeriph	Description
RCC_AHBPeriph_DMA1	DMA1 clock
RCC_AHBPeriph_DMA2	DMA2 clock
RCC_AHBPeriph_SRAM	SRAM clock
RCC_AHBPeriph_FLITF	FLITF clock
RCC_AHBPeriph_CRC	CRC clock
RCC_AHBPeriph_FSMC	FSMC clock
RCC_AHBPeriph_SDIO	SDIO clock

1. SRAM and FLITF clock can be disabled only during sleep mode.

**Example:**

```
/* Enable DMA1 clock */
RCC_AHBPeriphClockCmd(RCC_AHBPeriph_DMA1);
```

### 15.2.22 RCC\_APB2PeriphClockCmd function

[Table 374](#) describes the RCC\_APB2PeriphClockCmd function.

**Table 374. RCC\_APB2PeriphClockCmd function**

Function name	RCC_APB2PeriphClockCmd
Function prototype	void RCC_APB2PeriphClockCmd(u32 RCC_APB2Periph, FunctionalState NewState)
Behavior description	Enables or disables the High Speed APB (APB2) peripheral clock.
Input parameter1	RCC_APB2Periph: APB2 peripheral to gate the clock. Refer to <a href="#">RCC_APB2Periph</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the specified peripheral clock. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### RCC\_APB2Periph

This parameter selects the APB2 peripheral that gates the clock. One or a combination of the following values can be used:

**Table 375. RCC\_APB2Periph values**

RCC_APB2Periph	Description
RCC_APB2Periph_AFIO	Alternate Function I/O clock
RCC_APB2Periph_GPIOA	IO port A clock
RCC_APB2Periph_GPIOB	IO port B clock
RCC_APB2Periph_GPIOC	IO port C clock
RCC_APB2Periph_GPIOD	IO port D clock
RCC_APB2Periph_GPIOE	IO port E clock
RCC_APB2Periph_GPIOF	IO port F clock
RCC_APB2Periph_GPIOG	IO port G clock
RCC_APB2Periph_ADC1	ADC 1 interface clock
RCC_APB2Periph_ADC2	ADC 2 interface clock
RCC_APB2Periph_TIM1	TIM1 clock
RCC_APB2Periph_SPI1	SPI1 clock
RCC_APB2Periph_TIM8	TIM8 clock
RCC_APB2Periph_USART1	USART1 clock
RCC_APB2Periph_ADC3	ADC3 interface clock
RCC_APB2Periph_ALL	All APB2 peripheral clock



**Example:**

```
/* Enable GPIOA, GPIOB and SPI1 clocks */
RCC_APB2PeriphClockCmd(RCC_APB2Periph_GPIOA | RCC_APB2Periph_GPIOB
|
                        RCC_APB2Periph_SPI1, ENABLE);
```

**15.2.23 RCC\_APB1PeriphClockCmd function**

[Table 376](#) describes the RCC\_APB1PeriphClockCmd function.

**Table 376. RCC\_APB1PeriphClockCmd function**

Function name	RCC_APB1PeriphClockCmd
Function prototype	void RCC_APB1PeriphClockCmd(u32 RCC_APB1Periph, FunctionalState NewState)
Behavior description	Enables or disables the Low Speed APB (APB1) peripheral clock.
Input parameter1	RCC_APB1Periph: APB1 peripheral to gates its clock. Refer to <a href="#">RCC_APB1Periph</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the specified peripheral clock. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**RCC\_APB1Periph**

This parameter selects the APB1 peripheral that gates the clock. One or a combination of the following values can be used:

**Table 377. RCC\_APB1Periph values**

RCC_APB1Periph	Description
RCC_APB1Periph_TIM2	TIM2 clock
RCC_APB1Periph_TIM3	TIM3 clock
RCC_APB1Periph_TIM4	TIM4 clock
RCC_APB1Periph_TIM5	TIM5 clock
RCC_APB1Periph_TIM6	TIM6 clock
RCC_APB1Periph_TIM7	TIM7 clock
RCC_APB1Periph_WWDG	Window Watchdog clock
RCC_APB1Periph_SPI2	SPI2 clock
RCC_APB1Periph_SPI3	SPI3 clock
RCC_APB1Periph_USART2	USART2 clock
RCC_APB1Periph_USART3	USART3 clock

**Table 377. RCC\_APB1Periph values (continued)**

RCC_APB1Periph	Description
RCC_APB1Periph_UART4	UART4 clock
RCC_APB1Periph_UART5	UART5 clock
RCC_APB1Periph_I2C1	I2C1 clock
RCC_APB1Periph_I2C2	I2C2 clock
RCC_APB1Periph_USB	USB clock
RCC_APB1Periph_CAN	CAN clock
RCC_APB1Periph_BKP	Backup interface clock
RCC_APB1Periph_PWR	Power Controller interface clock
RCC_APB1Periph_DAC	DAC interface clock
RCC_APB1Periph_ALL	All APB1 peripheral clock

**Example:**

```
/* Enable BKP and PWR clocks */
RCC_APB1PeriphClockCmd(RCC_APB1Periph_BKP | RCC_APB1Periph_PWR,
ENABLE);
```

**15.2.24 RCC\_APB2PeriphResetCmd function**

[Table 378](#) describes the `RCC_APB2PeriphResetCmd` function.

**Table 378. RCC\_APB2PeriphResetCmd function**

Function name	RCC_APB2PeriphResetCmd
Function prototype	void RCC_APB2PeriphResetCmd(u32 RCC_APB2Periph, FunctionalState NewState)
Behavior description	Forces or releases High Speed APB (APB2) peripheral reset.
Input parameter1	RCC_APB2Periph: APB2 peripheral to reset. Refer to <a href="#">RCC_APB2Periph</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the specified peripheral reset. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enter the SPI1 peripheral to reset */
RCC_APB2PeriphResetCmd(RCC_APB2Periph_SPI1, ENABLE);

/* Exit the SPI1 peripheral from reset */
RCC_APB2PeriphResetCmd(RCC_APB2Periph_SPI1, DISABLE);
```

### 15.2.25 RCC\_APB1PeriphResetCmd function

[Table 379](#) describes the RCC\_APB1PeriphResetCmd function.

**Table 379. RCC\_APB1PeriphResetCmd function**

Function name	RCC_APB1PeriphResetCmd
Function prototype	void RCC_APB1PeriphResetCmd(u32 RCC_APB1Periph, FunctionalState NewState)
Behavior description	Forces or releases Low Speed APB (APB1) peripheral reset.
Input parameter1	RCC_APB1Periph: specifies the APB1 peripheral to reset. Refer to <a href="#">RCC_APB1Periph</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the specified peripheral reset. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enter the SPI2 peripheral to reset */
RCC_APB1PeriphResetCmd(RCC_APB1Periph_SPI2, ENABLE);

/* Exit the SPI2 peripheral from reset */
RCC_APB1PeriphResetCmd(RCC_APB1Periph_SPI2, DISABLE);
```

### 15.2.26 RCC\_BackupResetCmd function

[Table 380](#) describes the RCC\_BackupResetCmd function.

**Table 380. RCC\_BackupResetCmd function**

Function name	RCC_BackupResetCmd
Function prototype	void RCC_BackupResetCmd(FunctionalState NewState)
Behavior description	Forces or releases the Backup domain reset.
Input parameter	NewState: new state of the Backup domain reset. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Reset the entire Backup domain */
RCC_BackupResetCmd(ENABLE);
```

### 15.2.27 RCC\_ClockSecuritySystemCmd function

[Table 381](#) describes the RCC\_ClockSecuritySystemCmd function.

**Table 381. RCC\_ClockSecuritySystemCmd function**

Function name	RCC_ClockSecuritySystemCmd
Function prototype	void RCC_ClockSecuritySystemCmd(FunctionalState NewState)
Behavior description	Enables or disables the Clock Security System.
Input parameter	NewState: new state of the Clock Security System. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the Clock Security System */
RCC_ClockSecuritySystemCmd(ENABLE);
```

### 15.2.28 RCC\_MCOConfig function

[Table 382](#) describes the RCC\_MCOConfig function.

**Table 382. RCC\_MCOConfig function**

Function name	RCC_MCOConfig
Function prototype	void RCC_MCOConfig(u8 RCC_MCO)
Behavior description	Selects the clock source to output on MCO pin.
Input parameter	RCC_MCO: specifies the clock source to output. Refer to <a href="#">RCC_MCO</a> or more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### RCC\_MCO

RCC\_MCO selects the clock source to output on MCO pin. Refer to [Table 383](#) for the values taken by this parameter.

**Table 383. RCC\_MCO values**

RCC_MCO	Description
RCC_MCO_NoClock	No clock selected
RCC_MCO_SYSCLK	System clock selected
RCC_MCO_HSI	HSI oscillator clock selected
RCC_MCO_HSE	HSE oscillator clock selected
RCC_MCO_PLLCLK_Div2	PLL clock divided by 2 selected

---

**Warning:** When selecting the System Clock to be output onto MCO, make sure that its frequency does not exceed 50 MHz (the maximum I/O speed).

---

**Example:**

```
/* Output PLL clock divided by 2 on MCO pin */
RCC_MCOConfig(RCC_MCO_PLLCLK_Div2);
```

**15.2.29 RCC\_GetFlagStatus function**

*Table 384* describes the `RCC_GetFlagStatus` function.

**Table 384. RCC\_GetFlagStatus function**

Function name	<code>RCC_GetFlagStatus</code>
Function prototype	<code>FlagStatus RCC_GetFlagStatus(u8 RCC_FLAG)</code>
Behavior description	Checks whether the specified RCC flag is set or not.
Input parameter	RCC_FLAG: the flag to check. Refer to <a href="#">RCC_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of RCC_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

## RCC\_FLAG

The RCC flags that can be checked by issuing an `RCC_GetFlagStatus` function are listed in [Table 385](#).

**Table 385. RCC\_FLAG values**

RCC_FLAG	Description
RCC_FLAG_HSIRDY	HSI oscillator clock ready
RCC_FLAG_HSERDY	HSE oscillator clock ready
RCC_FLAG_PLLRDY	PLL clock ready
RCC_FLAG_LSERDY	LSE oscillator clock ready
RCC_FLAG_LSIRDY	LSI oscillator clock ready
RCC_FLAG_PINRST	Pin reset
RCC_FLAG_PORRST	POR/PDR reset
RCC_FLAG_SFTRST	Software reset
RCC_FLAG_IWDGRST	Independent Watchdog reset
RCC_FLAG_WWDGRST	Window Watchdog reset
RCC_FLAG_LPWRST	Low Power reset

**Example:**

```
/* Test if the PLL clock is ready or not */
FlagStatus Status;
Status = RCC_GetFlagStatus(RCC_FLAG_PLLRDY);
if (Status == RESET)
{
    ...
}
else
{
    ...
}
```

### 15.2.30 RCC\_ClearFlag function

[Table 386](#) describes the RCC\_ClearFlag function.

**Table 386. RCC\_ClearFlag function**

Function name	RCC_ClearFlag
Function prototype	void RCC_ClearFlag(void)
Behavior description	Clears the RCC reset flags. The reset flags are: RCC_FLAG_PINRST, RCC_FLAG_PORRST, RCC_FLAG_SFTRST, RCC_FLAG_IWDGRST, RCC_FLAG_WWDGRST, RCC_FLAG_LPWRST
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the reset flags */
RCC_ClearFlag();
```

### 15.2.31 RCC\_GetITStatus function

[Table 387](#) describes the RCC\_GetITStatus function.

**Table 387. RCC\_GetITStatus function**

Function name	RCC_GetITStatus
Function prototype	ITStatus RCC_GetITStatus(u8 RCC_IT)
Behavior description	Checks whether the specified RCC interrupt has occurred or not.
Input parameter	RCC_IT: RCC interrupt source to check. Refer to <a href="#">RCC_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of RCC_IT (SET or RESET).
Required preconditions	None
Called functions	None

**RCC\_IT**

RCC\_IT enables or disables RCC interrupts. One or a combination of the following values can be used:

**Table 388. RCC\_IT values**

RCC_IT	Description
RCC_IT_LSIRDY	LSI ready interrupt
RCC_IT_LSERDY	LSE ready interrupt
RCC_IT_HSIRDY	HSI ready interrupt
RCC_IT_HSERDY	HSE ready interrupt
RCC_IT_PLLRDY	PLL ready interrupt
RCC_IT_CSS	Clock Security System interrupt

**Example:**

```

/* Test if the PLL Ready interrupt has occurred or not */
ITStatus Status;
Status = RCC_GetITStatus(RCC_IT_PLLRDY);
if (Status == RESET)
{
    ...
}
else
{
    ...
}

```

**15.2.32 RCC\_ClearITPendingBit function**

[Table 389](#) describes the RCC\_ClearITPendingBit function.

**Table 389. RCC\_ClearITPendingBit function**

Function name	RCC_ClearITPendingBit
Function prototype	void RCC_ClearITPendingBit(u8 RCC_IT)
Behavior description	Clears the RCC's interrupt pending bits.
Input parameter	RCC_IT: specifies the interrupt pending bit to clear. Refer to <a href="#">RCC_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None



**RCC\_IT**

RCC\_IT enables or disables RCC interrupts. One or a combination of the following values can be used:

**Table 390. RCC\_IT values**

RCC_IT	Description
RCC_IT_LSIRDY	LSI ready interrupt
RCC_IT_LSERDY	LSE ready interrupt
RCC_IT_HSIRDY	HSI ready interrupt
RCC_IT_HSERDY	HSE ready interrupt
RCC_IT_PLLRDY	PLL ready interrupt
RCC_IT_CSS	Clock Security System interrupt

**Example:**

```
/* Clear the PLL Ready interrupt pending bit */  
RCC_ClearITPendingBit(RCC_IT_PLLRDY);
```

## 16 Real-time clock (RTC)

The RTC provides a set of continuously running counters which can be used, with suitable software, to provide a clock-calendar function. The counter values can be written to set the current time/date of the system.

[Section 16.1: RTC register structure](#) describes the data structures used in the RTC Firmware Library. [Section 16.2: Firmware library functions](#) presents the Firmware Library functions.

### 16.1 RTC register structure

The RTC register structure, `RTC_TypeDef`, is defined in the `stm32f10x_map.h` file as follows:

```
typedef struct
{
    vu16 CRH;
    u16 RESERVED1;
    vu16 CRL;
    u16 RESERVED2;
    vu16 PRLH;
    u16 RESERVED3;
    vu16 PRL;
    u16 RESERVED4;
    vu16 DIVH;
    u16 RESERVED5;
    vu16 DIVL;
    u16 RESERVED6;
    vu16 CNTH;
    u16 RESERVED7;
    vu16 CNTL;
    u16 RESERVED8;
    vu16 ALRH;
    u16 RESERVED9;
    vu16 ALRL;
    u16 RESERVED10;
} RTC_TypeDef;
```

[Table 391](#) gives the list of the RTC registers.

**Table 391. RTC registers**

Register	Description
CRH	Control Register High
CRL	Control Register Low
PRLH	Prescaler Load Register High
PRL	Prescaler Load Register Low
DIVH	Divider Register High
DIVL	Divider Register Low
CNTH	Counter Register High
CNTL	Counter Register Low
ALRH	Alarm Register High
ALRL	Alarm Register Low

The RTC peripheral is declared in *stm32f10x\_map.h*:

```
...
#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE      PERIPH_BASE
#define APB2PERIPH_BASE      (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE       (PERIPH_BASE + 0x20000)
...
#define RTC_BASE              (APB1PERIPH_BASE + 0x2800)

#ifndef DEBUG
...
#ifdef _RTC
    #define RTC                ((RTC_TypeDef *) RTC_BASE)
#endif /* _RTC */
...
#else /* DEBUG */
...
#ifdef _RTC
    EXT RTC_TypeDef             *RTC;
#endif /* _RTC */
...
#endif
```

When using the Debug mode, RTC pointer is initialized in *stm32f10x\_lib.c* file:

```
#ifdef _RTC
    RTC = (RTC_TypeDef *) RTC_BASE;
#endif /* _RTC */
```

To access the RTC registers, `_RTC` must be defined in *stm32f10x\_conf.h* as follows:

```
#define _RTC
```

## 16.2 Firmware library functions

[Table 392](#) gives the list of the various RTC library functions.

**Table 392. RTC firmware library functions**

Function name	Description
RTC_ITConfig	Enables or disables the specified RTC interrupts.
RTC_EnterConfigMode	Enters the RTC configuration mode.
RTC_ExitConfigMode	Exits from the RTC configuration mode.
RTC_GetCounter	Gets the RTC counter value.
RTC_SetCounter	Sets the RTC counter value.
RTC_SetPrescaler	Sets the RTC prescaler value.
RTC_SetAlarm	Sets the RTC Alarm value.
RTC_GetDivider	Gets the RTC Divider value.
RTC_WaitForLastTask	Waits until last write operation on RTC registers is completed
RTC_WaitForSynchro	Waits until the RTC registers (RTC_CNT, RTC_ALR and RTC_PRL) are synchronized with RTC APB clock.
RTC_GetFlagStatus	Checks whether the specified RTC flag is set or not.
RTC_ClearFlag	Clears the RTC pending flags.
RTC_GetITStatus	Checks whether the specified RTC interrupt has occurred or not.
RTC_ClearITPendingBit	Clears the RTC interrupt pending bits.

## 16.2.1 RTC\_ITConfig function

[Table 393](#) describes the RTC\_ITConfig function.

**Table 393. RTC\_ITConfig function**

Function name	RTC_ITConfig
Function prototype	void RTC_ITConfig(u16 RTC_IT, FunctionalState NewState)
Behavior description	Enables or disables the specified RTC interrupts.
Input parameter1	RTC_IT: RTC interrupts sources to be enabled or disabled. Refer to <a href="#">RTC_IT</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the specified RTC interrupts. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	Before using this function, you must call RTC_WaitForLastTask() function (wait until RTOFF flag is set).
Called functions	None

### RTC\_IT

RTC\_IT enables or disables RTC interrupts. One or a combination of the following values can be used:

**Table 394. RTC\_IT values**

RTC_IT	Description
RTC_IT_OW	Overflow interrupt enabled
RTC_IT_ALR	Alarm interrupt enabled
RTC_IT_SEC	Second interrupt enabled

#### Example:

```
/* Wait until last write operation on RTC registers is terminated */
RTC_WaitForLastTask();
```

```
/* Alarm interrupt enabled */
RTC_ITConfig(RTC_IT_ALR, ENABLE);
```

## 16.2.2 RTC\_EnterConfigMode function

[Table 395](#) describes RTC\_EnterConfigMode function.

**Table 395. RTC\_EnterConfigMode function**

Function name	RTC_EnterConfigMode
Function prototype	void RTC_EnterConfigMode(void)
Behavior description	Enters the RTC configuration mode.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the configuration mode */  
RTC_EnterConfigMode();
```

## 16.2.3 RTC\_ExitConfigMode function

[Table 396](#) describes the RTC\_ExitConfigMode function.

**Table 396. RTC\_ExitConfigMode function**

Function name	RTC_ExitConfigMode
Function prototype	void RTC_ExitConfigMode(void)
Behavior description	Exits from the RTC configuration mode.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Exit the configuration mode */  
RTC_ExitConfigMode();
```

## 16.2.4 RTC\_GetCounter function

[Table 397](#) describes the RTC\_GetCounter function.

**Table 397.** RTC\_GetCounter function

Function name	RTC_GetCounter
Function prototype	u32 RTC_GetCounter(void)
Behavior description	Gets the RTC counter value.
Output parameter	None
Return parameter	RTC counter value
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the counter value */
u32 RTCCounterValue;
RTCCounterValue = RTC_GetCounter();
```

## 16.2.5 RTC\_SetCounter function

[Table 398](#) describes RTC\_SetCounter function.

**Table 398.** RTC\_SetCounter function

Function name	RTC_SetCounter
Function prototype	void RTC_SetCounter(u32 CounterValue)
Behavior description	Sets the RTC counter value.
Input parameter	CounterValue: RTC counter new value.
Output parameter	None
Return parameter	None
Required preconditions	Before issuing this function, call RTC_WaitForLastTask() function (wait until RTOFF flag is set)
Called functions	RTC_EnterConfigMode() RTC_ExitConfigMode()

**Example:**

```
/* Wait until last write operation on RTC registers is terminated */
RTC_WaitForLastTask();

/* Sets Counter value to 0xFFFF5555 */
RTC_SetCounter(0xFFFF5555);
```

## 16.2.6 RTC\_SetPrescaler function

[Table 399](#) describes the RTC\_SetPrescaler function.

**Table 399. RTC\_SetPrescaler function**

Function name	RTC_SetPrescaler
Function prototype	void RTC_SetPrescaler(u32 PrescalerValue)
Behavior description	Sets the RTC prescaler value.
Input parameter	PrescalerValue: RTC prescaler new value.
Output parameter	None
Return parameter	None
Required preconditions	Before using this function, call RTC_WaitForLastTask() function (wait until RTOFF flag is set).
Called functions	RTC_EnterConfigMode() RTC_ExitConfigMode()

**Example:**

```
/* Wait until last write operation on RTC registers is terminated */
RTC_WaitForLastTask();

/* Sets Prescaler value to 0x7A12 */
RTC_SetPrescaler(0x7A12);
```

## 16.2.7 RTC\_SetAlarm function

[Table 400](#) describes the RTC\_SetAlarm function.

**Table 400. RTC\_SetAlarm function**

Function name	RTC_SetAlarm
Function prototype	void RTC_SetAlarm(u32 AlarmValue)
Behavior description	Sets the RTC alarm value.
Input parameter	AlarmValue: RTC alarm new value.
Output parameter	None
Return parameter	None
Required preconditions	Before using this function, call <i>RTC_WaitForLastTask()</i> function (wait until RTOFF flag is set).
Called functions	RTC_EnterConfigMode() RTC_ExitConfigMode()

**Example:**

```
/* Wait until last write operation on RTC registers is terminated */
RTC_WaitForLastTask();

/* Sets Alarm value to 0xFFFFFFFFFA */
RTC_SetAlarm(0xFFFFFFFFFA);
```



## 16.2.8 RTC\_GetDivider function

[Table 401](#) describes RTC\_GetDivider function.

**Table 401. RTC\_GetDivider function**

Function name	RTC_GetDivider
Function prototype	u32 RTC_GetDivider(void)
Behavior description	Gets the RTC Divider value.
Output parameter	None
Return parameter	RTC divider value
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the current RTC Divider value */
u32 RTCDividerValue;
RTCDividerValue = RTC_GetDivider();
```

## 16.2.9 RTC\_WaitForLastTask function

[Table 402](#) describes RTC\_WaitForLastTask function.

**Table 402. RTC\_WaitForLastTask function**

Function name	RTC_WaitForLastTask
Function prototype	void RTC_WaitForLastTask(void)
Behavior description	Waits until last write operation on RTC registers is completed. This function must be called before any write operation to an RTC register.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Wait until last write operation on RTC registers is terminated */
RTC_WaitForLastTask();
/* Sets Alarm value to 0x10 */
RTC_SetAlarm(0x10);
```

### 16.2.10 RTC\_WaitForSynchro function

[Table 403](#) describes RTC\_WaitForSynchro function.

**Table 403. RTC\_WaitForSynchro function**

Function name	RTC_WaitForSynchro
Function prototype	<code>void RTC_WaitForSynchro(void)</code>
Behavior description	Waits until the RTC registers (RTC_CNT, RTC_ALR and RTC_PRL) are synchronized with RTC APB clock. This function must be called before any read operation after an APB reset or an APB clock stop.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Wait until the RTC registers are synchronized with RTC APB clock
 */
RTC_WaitForSynchro();
```

### 16.2.11 RTC\_GetFlagStatus function

[Table 404](#) describes RTC\_GetFlagStatus function

**Table 404. RTC\_GetFlagStatus function**

Function name	RTC_GetFlagStatus
Function prototype	<code>FlagStatus RTC_GetFlagStatus(u16 RTC_FLAG)</code>
Behavior description	Checks whether the specified RTC flag is set or not.
Input parameter	RTC_FLAG: specifies the flag to check. Refer to <a href="#">RTC_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of RTC_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

## RTC\_FLAG

The RTC flags that can be checked by issuing an `RTC_GetFlagStatus` function are listed in [Table 405](#).

**Table 405. RTC\_FLAG values**

RTC_FLAG	Description
RTC_FLAG_RTOFF	RTC operation OFF Flag
RTC_FLAG_RSOF	Registers Synchronized Flag
RTC_FLAG_OW	Overflow interrupt Flag
RTC_FLAG_ALR	Alarm interrupt Flag
RTC_FLAG_SEC	Second interrupt Flag

**Example:**

```
/* Gets the RTC overflow interrupt status */
FlagStatus OverrunFlagStatus;
OverrunFlagStatus = RTC_GetFlagStatus(RTC_Flag_OW);
```

## 16.2.12 RTC\_ClearFlag function

[Table 406](#) describes `RTC_ClearFlag` function.

**Table 406. RTC\_ClearFlag function**

Function name	RTC_ClearFlag
Function prototype	void RTC_ClearFlag(u16 RTC_FLAG)
Behavior description	Clears the RTC's pending flags.
Input parameter	RTC_FLAG: flag to be cleared. Refer to <a href="#">RTC_FLAG</a> for more details on the allowed values for this parameter. The RTC_FLAG_RTOFF cannot be cleared by software. The RTC_FLAG_RSOF is cleared only after an APB reset or an APB clock stop.
Output parameter	None
Return parameter	None
Required preconditions	Before using this function, call <code>RTC_WaitForLastTask()</code> function (wait until RTOFF flag is set).
Called functions	None

**Example:**

```
/* Wait until last write operation on RTC registers is terminated */
RTC_WaitForLastTask();

/* Clears the RTC overflow flag */
RTC_ClearFlag(RTC_FLAG_OW);
```

### 16.2.13 RTC\_GetITStatus function

[Table 407](#) describes the RTC\_GetITStatus function.

**Table 407. RTC\_GetITStatus function**

Function name	RTC_GetITStatus
Function prototype	ITStatus RTC_GetITStatus(u16 RTC_IT)
Behavior description	Checks whether the specified RTC interrupt has occurred or not.
Input parameter	RTC_IT: RTC interrupt source to check. Refer to <a href="#">RTC_IT</a> or more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of the RTC_IT(SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the RTC Second interrupt status */
ITStatus SecondITStatus;
SecondITStatus = RTC_GetITStatus(RTC_IT_SEC);
```

### 16.2.14 RTC\_ClearITPendingBit function

[Table 408](#) describes the RTC\_ClearITPendingBit function.

**Table 408. RTC\_ClearITPendingBit function**

Function name	RTC_ClearITPendingBit
Function prototype	void RTC_ClearITPendingBit(u16 RTC_IT)
Behavior description	Clears the RTC's interrupt pending bits.
Input parameter	RTC_IT: interrupt pending bit to clear. Refer to <a href="#">RTC_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	Before using this function, call RTC_WaitForLastTask() function (wait until RTOFF flag is set).
Called functions	None

**Example:**

```
/* Wait until last write operation on RTC registers is terminated */
RTC_WaitForLastTask();

/* Clears the RTC Second interrupt */
RTC_ClearITPendingBit(RTC_IT_SEC);
```

## 17 Serial peripheral interface (SPI)

The Serial Peripheral Interface (SPI) allows synchronous serial communication with external devices. The interface can be configured to operate in master or slave mode.

[Section 17.1: SPI register structure](#) describes the data structures used in the SPI Firmware Library. [Section 17.2: Firmware library functions](#) presents the Firmware Library functions.

### 17.1 SPI register structure

The SPI register structure, *SPI\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu16 CR1;
    u16 RESERVED0;
    vu16 CR2;
    u16 RESERVED1;
    vu16 SR;
    u16 RESERVED2;
    vu16 DR;
    u16 RESERVED3;
    vu16 CRCPR;
    u16 RESERVED4;
    vu16 RXCRCR;
    u16 RESERVED5;
    vu16 TXCRCR;
    u16 RESERVED6;
    vu16 I2SCFGR;
    u16 RESERVED7;
    vu16 I2SPR;
    u16 RESERVED8;
} SPI_TypeDef;
```

[Table 409](#) gives the list of SPI registers.

**Table 409. SPI registers**

Register	Description
CR1	SPI Control Register1
CR2	SPI Control Register2
SR	SPI Status Register
DR	SPI Data Register
CRCPR	SPI CRC Polynomial Register
RxCRCR	SPI Rx CRC Register
TxCRCR	SPI Tx CRC Register
I2SCFGR	I <sup>2</sup> S Configuration Register
I2SPR	I <sup>2</sup> S Prescaler Register

The two SPI peripherals are declared in *stm32f10x\_map.h*:

```
...
#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE     PERIPH_BASE
#define APB2PERIPH_BASE     (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE      (PERIPH_BASE + 0x20000)
...
#define SPI1_BASE           (APB2PERIPH_BASE + 0x3000)
#define SPI2_BASE           (APB1PERIPH_BASE + 0x3800)
#define SPI3_BASE           (APB1PERIPH_BASE + 0x3C00)
...
#ifndef DEBUG
...
#ifdef _SPI1
    #define SPI1              ((SPI_TypeDef *) SPI1_BASE)
#endif /*_SPI1 */

#ifdef _SPI2
    #define SPI2              ((SPI_TypeDef *) SPI2_BASE)
#endif /*_SPI2 */
#ifdef _SPI3
    #define SPI3 ((SPI_TypeDef *) SPI3_BASE)
#endif /*_SPI3 */
...
#else /* DEBUG */
...
#ifdef _SPI1
    EXT SPI_TypeDef           *SPI1;
#endif /*_SPI1 */

#ifdef _SPI2
    EXT SPI_TypeDef           *SPI2;
#endif /*_SPI2 */

#ifdef _SPI3
    EXT SPI_TypeDef           *SPI3;
#endif /*_SPI3 */
...
#endif
```

When using the Debug mode, *\_SPI1*, *\_SPI2* and *\_SPI3* pointers are initialized in *stm32f10x\_lib.c* file:

```
...
#ifdef _SPI1
    SPI1 = (SPI_TypeDef *) SPI1_BASE;
#endif /*_SPI1 */

#ifdef _SPI2
    SPI2 = (SPI_TypeDef *) SPI2_BASE;
#endif /*_SPI2 */

#ifdef _SPI3
    SPI3 = (SPI_TypeDef *) SPI3_BASE;
#endif /*_SPI3 */
...
```

To access the SPI registers, `_SPI`, `_SPI1` and `_SPI2` must be defined in `stm32f10x_conf.h` as follows:

```
...
#define _SPI
#define _SPI1
#define _SPI2
#define _SPI3
...
```

## 17.2 Firmware library functions

[Table 410](#) lists the various functions of the SPI library.

**Table 410. SPI firmware library functions**

Function name	Description
<code>SPI_I2S_DeInit</code>	Re-initializes the SPIx peripheral registers to their default reset values.
<code>SPI_Init</code>	Initializes the SPIx peripheral according to the specified parameters in the <code>SPI_InitStruct</code> .
<code>I2S_Init</code>	Initializes the SPIx peripheral according to the specified parameters in the <code>I2S_InitStruct</code> .
<code>SPI_StructInit</code>	Fills each <code>SPI_InitStruct</code> member with its default value.
<code>I2S_StructInit</code>	Fills each <code>I2S_InitStruct</code> member with its default value.
<code>SPI_Cmd</code>	Enables or disables the specified SPI peripheral.
<code>I2S_Cmd</code>	Enables or disables the specified SPI peripheral (in I <sup>2</sup> S mode).
<code>SPI_I2S_ITConfig</code>	Enables or disables the specified SPI/I2S interrupts.
<code>SPI_I2S_DMACmd</code>	Enables or disables the SPIx/I2Sx DMA interface.
<code>SPI_I2S_SendData</code>	Transmits data through the SPIx/I2Sx peripheral.
<code>SPI_I2S_ReceiveData</code>	Returns the most recent received data through the SPIx/I2Sx peripheral.
<code>SPI_NSSInternalSoftwareConfig</code>	Configures internally by software the NSS pin for the selected SPI.
<code>SPI_SSOutputCmd</code>	Enables or disables the SS output for the selected SPI.
<code>SPI_DataSizeConfig</code>	Configures the data size for the selected SPI.
<code>SPI_TransmitCRC</code>	Transmits the SPIx CRC value
<code>SPI_CalculateCRC</code>	Enables or disables the CRC value calculation of the transferred bytes.
<code>SPI_GetCRC</code>	Returns the transmit or the receive CRC register value for the specified SPI.
<code>SPI_GetCRCPolynomial</code>	Returns the CRC Polynomial register value for the specified SPI.
<code>SPI_BiDirectionalLineConfig</code>	Selects the data transfer direction in bidirectional mode for the specified SPI.
<code>SPI_I2S_GetFlagStatus</code>	Checks whether the specified SPI/I2S flag is set or not.
<code>SPI_I2S_ClearFlag</code>	Clears the SPIx/I2Sx pending flags.
<code>SPI_I2S_GetITStatus</code>	Checks whether the specified SPI/I2S interrupt has occurred or not.
<code>SPI_I2S_ClearITPendingBit</code>	Clears the SPIx/I2Sx interrupt pending bits.

## 17.2.1 SPI\_I2S\_DeInit function

[Table 411](#) describes the SPI\_I2S\_DeInit function.

**Table 411. SPI\_DeInit function**

Function name	SPI_I2S_DeInit
Function prototype	void SPI_I2S_DeInit(SPI_TypeDef* SPIx)
Behavior description	Resets the SPIx/I2Sx peripheral registers to their default reset values.
Input parameter	SPIx: where x can be 1 or 2 to select the SPI peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_APB2PeriphClockCmd() for SPI1 RCC_APB1PeriphClockCmd() for SPI2 and SPI3

**Example:**

```
/* Deinitialize the SPI2 */
SPI_DeInit(SPI2);
/* Deinitialize the I2S3 */
SPI_DeInit(SPI3);
```

## 17.2.2 SPI\_Init function

[Table 412](#) describes the SPI\_Init function.

**Table 412. SPI\_Init function**

Function name	SPI_Init
Function prototype	void SPI_Init(SPI_TypeDef* SPIx, SPI_InitTypeDef* SPI_InitStruct)
Behavior description	Initializes the SPIx peripheral according to the parameters specified in the SPI_InitStruct.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Input parameter2	SPI_InitStruct: pointer to a SPI_InitTypeDef structure that contains the configuration information for the specified SPI peripheral. Refer to the <a href="#">SPI_InitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None



## SPI\_InitTypeDef structure

The SPI\_InitTypeDef structure is defined in the *stm32f10x\_spi.h* file:

```
typedef struct
{
  u16 SPI_Direction;
  u16 SPI_Mode;
  u16 SPI_DataSize;
  u16 SPI_CPOL;
  u16 SPI_CPHA;
  u16 SPI_NSS;
  u16 SPI_BaudRatePrescaler;
  u16 SPI_FirstBit;
  u16 SPI_CRCPolynomial;
} SPI_InitTypeDef;
```

### SPI\_Direction

SPI\_Direction configures the SPI unidirectional or bidirectional data mode. Refer to [Table 413](#) for the values taken by this member.

**Table 413. SPI\_Direction definition**

SPI_Direction	Description
SPI_Direction_2Lines_FullDuplex	SPI configured as 2 lines unidirectional full duplex
SPI_Direction_2Lines_RxOnly	SPI configured as 2 lines unidirectional Rx only
SPI_Direction_1Line_Rx	SPI configured as 1 line bidirectional Rx only
SPI_Direction_1Line_Tx	SPI configured as 1 line bidirectional Tx only

### SPI\_Mode

SPI\_Mode configures the SPI operating mode. Refer to [Table 414](#) for the values taken by this member.

**Table 414. SPI\_Mode definition**

SPI_Mode	Description
SPI_Mode_Master	SPI configured as a master
SPI_Mode_Slave	SPI configured as a slave

### SPI\_DataSize

SPI\_DataSize configures the SPI data size. Refer to [Table 415](#) for the values taken by this member.

**Table 415. SPI\_DataSize definition**

SPI_DataSize	Description
SPI_DataSize_16b	SPI 16-bit data frame format for transmission and reception
SPI_DataSize_8b	SPI 8-bit data frame format for transmission and reception

**SPI\_CPOL**

SPI\_CPOL selects the serial clock steady state. Refer to [Table 416](#) for the values taken by this member.

**Table 416. SPI\_CPOL definition**

SPI_CPOL	Description
SPI_CPOL_High	Clock idle high
SPI_CPOL_Low	Clock idle low

**SPI\_CPHA**

SPI\_CPHA configures the clock active edge for the bit capture. Refer to [Table 417](#) for the values taken by this member.

**Table 417. SPI\_CPHA definition**

SPI_CPHA	Description
SPI_CPHA_2Edge	Data is captured on the second edge
SPI_CPHA_1Edge	Data is captured on the first edge

**SPI\_NSS**

SPI\_NSS specifies whether the NSS signal is managed by hardware (NSS pin) or by software using the SSI bit. Refer to [Table 418](#) for the values taken by this member.

**Table 418. SPI\_NSS definition**

SPI_NSS	Description
SPI_NSS_Hard	NSS managed by external pin
SPI_NSS_Soft	Internal NSS signal controlled by SSI bit

**SPI\_BaudRatePrescaler**

SPI\_BaudRatePrescaler is used to define the Baud Rate prescaler value which will be used to configure the transmit and receive SCK clock. Refer to [Table 419](#) for the values taken by this member.

**Table 419. SPI\_BaudRatePrescaler definition**

SPI_BaudratePrescaler	Description
SPI_BaudRatePrescaler2	Baud Rate Prescaler equal to 2
SPI_BaudRatePrescaler4	Baud Rate Prescaler equal to 4
SPI_BaudRatePrescaler8	Baud Rate Prescaler equal to 8
SPI_BaudRatePrescaler16	Baud Rate Prescaler equal to 16
SPI_BaudRatePrescaler32	Baud Rate Prescaler equal to 32
SPI_BaudRatePrescaler64	Baud Rate Prescaler equal to 64
SPI_BaudRatePrescaler128	Baud Rate Prescaler equal to 128
SPI_BaudRatePrescaler256	Baud Rate Prescaler equal to 256

**Note:** The communication clock is derived from the master clock. The slave clock does not need to be set.

### SPI\_FirstBit

SPI\_FirstBit specifies whether data transfers start from MSB or LSB bit. Refer to [Table 420](#) for the values taken by this member.

**Table 420. SPI\_FirstBit definition**

SPI_FirstBit	Description
SPI_FisrtBit_MSB	First bit to transfer is the MSB
SPI_FisrtBit_LSB	First bit to transfer is the LSB

### SPI\_CRCPolynomial

SPI\_CRCPolynomial defines the polynomial used for the CRC calculation.

**Example:**

```
/* Initialize the SPI1 according to the SPI_InitStructure members */
SPI_InitTypeDef SPI_InitStructure;
SPI_InitStructure.SPI_Direction = SPI_Direction_2Lines_FullDuplex;
SPI_InitStructure.SPI_Mode = SPI_Mode_Master;
SPI_InitStructure.SPI_DatSize = SPI_DatSize_16b;
SPI_InitStructure.SPI_CPOL = SPI_CPOL_Low;
SPI_InitStructure.SPI_CPHA = SPI_CPHA_2Edge;
SPI_InitStructure.SPI_NSS = SPI_NSS_Soft;
SPI_InitStructure.SPI_BaudRatePrescaler =
SPI_BaudRatePrescaler_128;
SPI_InitStructure.SPI_FirstBit = SPI_FirstBit_MSB;
SPI_InitStructure.SPI_CRCPolynomial = 7;
SPI_Init(SPI1, &SPI_InitStructure);
```

## 17.2.3 I2S\_Init function

[Table 421](#) describes the I2S\_Init function.

**Table 421. I2S\_Init function**

Function name	I2S_Init
Function prototype	void I2S_Init(SPI_TypeDef* SPIx, I2S_InitTypeDef* I2S_InitStruct)
Behavior description	Initializes the SPIx peripheral (in I <sup>2</sup> S mode) according to the parameters specified in I2S_InitStruct.
Input parameter1	SPIx: where x can be 2 or 3 to select the SPI peripheral (in I <sup>2</sup> S mode).
Input parameter2	I2S_InitStruct: pointer to an I2S_InitTypeDef structure that contains the configuration information for the specified SPI peripheral (in I <sup>2</sup> S mode). Refer to <a href="#">I2S_InitTypeDef</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_GetClocksFreq()

### I2S\_InitTypeDef

The I2S\_InitTypeDef structure is defined in the *stm32f10x\_spi.h* file:

```
typedef struct
{
  u16 I2S_Mode;
  u16 I2S_Standard;
  u16 I2S_DataFormat;
  u16 I2S_MCLKOutput;
  u16 I2S_AudioFreq;
  u16 I2S_CPOL;
} I2S_InitTypeDef;
```

- **I2S\_Mode**

Specifies the I<sup>2</sup>S peripheral Master/Slave and Transmitter/Receiver configuration as shown in [Table 422](#).

**Table 422. I<sup>2</sup>S peripheral configuration**

I2S_Mode	Description
I2S_Mode_SlaveTx	I <sup>2</sup> S peripheral is configured as Slave and Transmitter
I2S_Mode_SlaveRx	I <sup>2</sup> S peripheral is configured as Slave and Receiver
I2S_Mode_MasterTx	I <sup>2</sup> S peripheral is configured as Master and Transmitter
I2S_Mode_MasterRx	I <sup>2</sup> S peripheral is configured as Master and Receiver

- **I2S\_Standard**

Specifies the standard used for the I<sup>2</sup>S communication as shown in [Table 423](#).

**Table 423. Used standard**

I2S_Standard	Description
I2S_Standardd_Phillips	Uses the Phillips I <sup>2</sup> S standard
I2S_Standard_MSB	Uses the MSB standard
I2S_Standard_LSB	Uses the LSB standard
I2S_Standard_PCMShort	Uses PCM mode with short frame
I2S_Standard_PCMLong	Uses PCM mode with long frame

- **I2S\_DataFormat**

Specifies the data format for the I<sup>2</sup>S communication as shown in [Table 424](#).

**Table 424. Used data format**

I2S_DataFormat	Description
I2S_DataFormat_16b	Data are 16 bits long in 16 bits packet frame
I2S_DataFormat_16bextended	Data are 16 bits long in 32 bits packet frame
I2S_DataFormat_24b	Data are 24 bits long in 32 bits packet frame
I2S_DataFormat_32b	Data are 32 bits long in 32 bits packet frame

- **I2S\_MCLKOutput**

Specifies whether the I<sup>2</sup>S MCLK output is enabled or not as shown in [Table 425](#).

**Table 425. I<sup>2</sup>S MCLK output**

I2S_MCLKOutput	Description
I2S_MCLKOutput_Enable	I <sup>2</sup> S MCLK output is enabled
I2S_MCLKOutput_Disable	I <sup>2</sup> S MCLK output is disabled

- **I2S\_AudioFreq**

Specifies the frequency selected for the I<sup>2</sup>S communication as shown in [Table 426](#).

**Table 426. Selecting the I<sup>2</sup>S frequency**

I2S_AudioFreq	Description
I2S_AudioFreq_48K	Configures the I <sup>2</sup> S baud rate to 48 kHz.
I2S_AudioFreq_44K	Configures the I <sup>2</sup> S baud rate to 44.1 kHz.
I2S_AudioFreq_22K	Configures the I <sup>2</sup> S baud rate to 22.05 kHz.
I2S_AudioFreq_16K	Configures the I <sup>2</sup> S baud rate to 16 kHz.
I2S_AudioFreq_8K	Configures the I <sup>2</sup> S baud rate to 8 kHz.
I2S_AudioFreq_Default	Configures I2SDIV and ODD to their default values: 0x02 and 0x00, respectively.

- **I2S\_CPOL**

Specifies the idle state of the I2S clock as shown in [Table 427](#).

**Table 427. I<sup>2</sup>S clock idle state**

I2S_CPOL	Description
I2S_CPOL_Low	I2S clock's idle state is low
I2S_CPOL_High	I2S clock's idle state is high

**Example:**

```
/* Initialize the SPI2 according to the I2S_InitStructure members */
I2S_InitTypeDef I2S_InitStructure;

I2S_InitStructure.I2S_Mode = I2S_Mode_MasterTx;
I2S_InitStructure.I2S_Standard = I2S_Standard_Phillips;
I2S_InitStructure.I2S_DataFormat = I2S__DataFormat_16bextended;
I2S_InitStructure.I2S_MCLKOutput = I2S_MCLKOutput_Enable;
I2S_InitStructure.I2S_AudioFreq = I2S_AudioFreq_16K;
I2S_InitStructure.I2S_CPOL = SPI_CPOL_Low;

I2S_Init(SPI2, &I2S_InitStructure);
```

## 17.2.4 SPI\_StructInit function

[Table 428](#) describes the SPI\_StructInit function.

**Table 428. SPI\_StructInit function**

Function name	SPI_StructInit
Function prototype	void SPI_StructInit(SPI_InitTypeDef* SPI_InitStruct)
Behavior description	Fills each SPI_InitStruct member with its default value.
Input parameter	SPI_InitStruct: pointer to a SPI_InitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

Refer to [Table 429](#) for the SPI\_InitStruct member default values.

**Table 429. SPI\_InitStruct default values**

Member	Default value
SPI_Direction	SPI_Direction_2Lines_FullDuplex
SPI_Mode	SPI_Mode_Slave
SPI_DataSize	SPI_DataSize_8b
SPI_CPOL	SPI_CPOL_Low
SPI_CPHA	SPI_CPHA_1Edge
SPI_NSS	SPI_NSS_Hard
SPI_BaudRatePrescaler	SPI_BaudRatePrescaler_2
SPI_FirstBit	SPI_FirstBit_MSB
SPI_CRCPolynomial	7

**Example:**

```
/* Initialize an SPI_InitTypeDef structure */
SPI_InitTypeDef SPI_InitStructure;
SPI_StructInit(&SPI_InitStructure);
```

**17.2.5 I2S\_StructInit function**

[Table 430](#) describes the I2S\_StructInit function.

**Table 430. I2S\_StructInit function**

Function name	I2S_StructInit
Function prototype	void I2S_StructInit(I2S_InitTypeDef* I2S_InitStruct)
Behavior description	Fills each I2S_InitStruct member with its default value.
Input parameter	I2S_InitStruct: pointer to an I2S_InitTypeDef structure that will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The I2S\_InitStruct members have the default values given in [Table 431](#).

**Table 431. Default I2S\_InitStruct values**

Member	Default value
I2S_Mode	I2S_Mode_SlaveTx
I2S_Standard	I2S_Standard_Phillips
I2S_DataFormat	I2S_DataFormat_16b
I2S_MCLKOutput	I2S_MCLKOutput_Disable
I2S_AudioFreq	I2S_AudioFreq_Default
I2S_CPOL	I2S_CPOL_Low

**Example:**

```
/* Initialize an I2S_InitTypeDef structure */
I2S_InitTypeDef I2S_InitStructure;
I2S_StructInit(&I2S_InitStructure);
```

**17.2.6 SPI\_Cmd function**

[Table 432](#) describes the SPI\_Cmd function.

**Table 432. SPI\_Cmd function**

Function name	SPI_Cmd
Function prototype	void SPI_Cmd(SPI_TypeDef* SPIx, FunctionalState NewState)
Behavior description	Enables or disables the specified SPI peripheral.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Input parameter2	NewState: new state of the SPIx peripheral. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable SPI3 */
SPI_Cmd(SPI3, ENABLE);
```

**17.2.7 I2S\_Cmd**

[Table 430](#) describes the I2S\_Cmd function.

**Table 433. I2S\_Cmd function**

Function name	I2S_Cmd
Function prototype	void I2S_Cmd(SPI_TypeDef* SPIx, FunctionalState NewState)
Behavior description	Enables or disables the specified SPI peripheral in I <sup>2</sup> S mode.
Input parameter1	SPIx: where x can be 2 or 3 to select the SPI peripheral (in I <sup>2</sup> S mode).
Input parameter2	NewState: new state of the SPIx peripheral. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable I2S3 */
I2S_Cmd(SPI3, ENABLE);
```



## 17.2.8 SPI\_I2S\_ITConfig function

[Table 434](#) describes the SPI\_I2S\_ITConfig function.

**Table 434. SPI\_I2S\_ITConfig function**

Function name	SPI_I2S_ITConfig
Function prototype	void SPI_I2S_ITConfig(SPI_TypeDef* SPIx, u8 SPI_I2S_IT, FunctionalState NewState)
Behavior description	Enables or disables the specified SPI/I2S interrupts.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Input parameter2	SPI_I2S_IT: SPI interrupt source to be enabled or disabled. Refer to <a href="#">SPI_I2S_IT</a> for more details on the allowed values for this parameter.
Input parameter3	NewState: new state of the specified SPI/I2S interrupt. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### SPI\_I2S\_IT

SPI\_I2S\_IT enables or disables SPI/I2S interrupts. See [Table 435](#) for the values taken by this parameter.

**Table 435. SPI\_I2S\_IT flags**

SPI_I2S_IT	Description
SPI_I2S_IT_TXE	Tx buffer empty interrupt mask
SPI_I2S_IT_RXNE	Rx buffer not empty interrupt mask
SPI_I2S_IT_ERR	Error interrupt mask

#### Example:

```
/* Enable SPI2 Tx buffer empty interrupt */
SPI_I2S_ITConfig(SPI2, SPI_I2S_IT_TXE, ENABLE);
```

## 17.2.9 SPI\_I2S\_DMACmd function

[Table 436](#) describes the SPI\_I2S\_DMACmd function.

**Table 436. SPI\_I2S\_DMACmd function**

Function name	SPI_I2S_DMACmd
Function prototype	void SPI_I2S_DMACmd(SPI_TypeDef* SPIx, u16 SPI_I2S_DMAReq, FunctionalState NewState)
Behavior description	Enables or disables the SPIx/I2Sx DMA interface.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Input parameter2	SPI_I2S_DMAReq: SPI DMA transfer request to be enabled or disabled. Refer to <a href="#">SPI_I2S_DMAReq</a> for more details on the allowed values for this parameter.
Input parameter3	NewState: new state of the selected SPI/I2S DMA transfer request. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### SPI\_I2S\_DMAReq

SPI\_I2S\_DMAReq enables or disables SPI Tx or/and Rx DMA transfer requests. See [Table 437](#) for the values taken by this parameter.

**Table 437. SPI\_I2S\_DMAReq values**

SPI_I2S_DMAReq	Description
SPI_I2S_DMAReq_Tx	Selects Tx buffer DMA transfer request
SPI_I2S_DMAReq_Rx	Selects Rx buffer DMA transfer request

### Example:

```
/* Enable SPI2 Rx buffer DMA transfer request */
SPI_I2S_DMACmd(SPI2, SPI_I2S_DMAReq_Rx, ENABLE);

/* Enable I2S3 Rx buffer DMA transfer request */
SPI_I2S_DMACmd(SPI3, SPI_I2S_DMAReq_Rx, ENABLE);
```

### 17.2.10 SPI\_I2S\_SendData function

[Table 438](#) describes the SPI\_I2S\_SendData function.

**Table 438. SPI\_I2S\_SendData function**

Function name	SPI_I2S_SendData
Function prototype	<code>void SPI_I2S_SendData(SPI_TypeDef* SPIx, u16 Data)</code>
Behavior description	Transmits data through the SPIx/I2Sx peripheral.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Input parameter 2	Data: Byte or half word (in SPI mode), or half word (in I <sup>2</sup> S mode) to be transmitted.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Send 0xA5 through the SPI1 peripheral */
SPI_I2S_SendData(SPI1, 0xA5);
```

### 17.2.11 SPI\_I2S\_ReceiveData function

[Table 439](#) describes the SPI\_I2S\_ReceiveData function.

**Table 439. SPI\_I2S\_ReceiveData function**

Function name	SPI_I2S_ReceiveData
Function prototype	<code>u16 SPI_I2S_ReceiveData(SPI_TypeDef* SPIx)</code>
Behavior description	Returns the most recent data received through the SPIx/I2Sx peripheral.
Input parameter	SPIx: where x can be 1, 2 or 3 to select the SPI/I <sup>2</sup> S <sup>?</sup> peripheral.
Output parameter	None
Return parameter	The value of the received data.
Required preconditions	None
Called functions	None

**Example:**

```
/* Read the most recent data received by the SPI2 peripheral */
u16 ReceivedData;
ReceivedData = SPI_I2S_ReceiveData(SPI2);
```

### 17.2.12 SPI\_NSSInternalSoftwareConfig function

[Table 440](#) describes the SPI\_NSSInternalSoftwareConfig function.

**Table 440. SPI\_NSSInternalSoftwareConfig function**

Function name	SPI_NSSInternalSoftwareConfig
Function prototype	void SPI_NSSInternalSoftwareConfig(SPI_TypeDef* SPIx, u16 SPI_NSSInternalSoft)
Behavior description	Internally configures by software the NSS pin for the specified SPIx interface.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Input parameter2	SPI_NSSInternalSoft: SPI NSS internal state. Refer to <a href="#">SPI_NSSInternalSoft</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### SPI\_NSSInternalSoft

SPI\_NSSInternalSoft internally sets or resets the NSS pin. See [Table 441](#) for the values taken by this parameter.

**Table 441. SPI\_NSSInternalSoft values**

SPI_NSSInternalSoft	Description
SPI_NSSInternalSoft_Set	Set NSS pin internally
SPI_NSSInternalSoft_Reset	Reset NSS pin internally

#### Example:

```
/* Set internally by software the SPI1 NSS pin */
SPI_NSSInternalSoftwareConfig(SPI1, SPI_NSSInternalSoft_Set);

/* Reset internally by software the SPI2 NSS pin */
SPI_NSSInternalSoftwareConfig(SPI2, SPI_NSSInternalSoft_Reset);
```

### 17.2.13 SPI\_SSOutputCmd function

[Table 442](#) describes the SPI\_SSOutputCmd function.

**Table 442. SPI\_SSOutputCmd function**

Function name	SPI_SSOutputCmd
Function prototype	void SPI_SSOutputCmd(SPI_TypeDef* SPIx, FunctionalState NewState)
Behavior description	Enables or disables the SS output for the selected SPI.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Input parameter2	NewState: new state of the SPIx SS output. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the SPI1 SS output: single master mode */
SPI_SSOutputCmd(SPI1, ENABLE);
```

### 17.2.14 SPI\_DataSizeConfig function

[Table 443](#) describes the SPI\_DataSizeConfig function.

**Table 443. SPI\_DataSizeConfig function**

Function name	SPI_DataSizeConfig
Function prototype	void SPI_DataSizeConfig(SPI_TypeDef* SPIx, u16 SPI_DataSize)
Behavior description	Configures the data size for the selected SPI peripheral
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Input parameter2	SPI_DataSize: SPI data size. Refer to <a href="#">SPI_DataSize</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**SPI\_DataSize**

SPI\_DataSize sets 8-bit or 16-bit data frame format. See [Table 444](#) for the values taken by this parameter.

**Table 444. SPI\_DataSize values**

SPI_NSSInternalSoft	Description
SPI_DataSize_8b	Set 8-bit data size
SPI_DataSize_16b	Set 16-bit data size

**Example:**

```

/* Set 8bit data frame format for SPI1 */
SPI_DataSizeConfig(SPI1, SPI_DataSize_8b);

/* Set 16bit data frame format for SPI2 */
SPI_DataSizeConfig(SPI2, SPI_DataSize_16b);

```

**17.2.15 SPI\_TransmitCRC function**

[Table 445](#) describes the SPI\_TransmitCRC function.

**Table 445. SPI\_TransmitCRC function**

Function name	SPI_TransmitCRC
Function prototype	void SPI_TransmitCRC(SPI_TypeDef* SPIx)
Behavior description	Transmit of the SPIx CRC value.
Input parameter	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```

/* Enable the CRC transfer for SPI1 */
SPI_TransmitCRC(SPI1);

```

### 17.2.16 SPI\_CalculateCRC function

[Table 446](#) describes the SPI\_CalculateCRC function.

**Table 446. SPI\_CalculateCRC function**

Function name	SPI_CalculateCRC
Function prototype	void SPI_CalculateCRC(SPI_TypeDef* SPIx, FunctionalState NewState)
Behavior description	Enables or disables the CRC value calculation of the transferred bytes.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Input parameter2	NewState: new state of the SPIx CRC value calculation. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the CRC calculation for the transferred bytes from SPI2 */
SPI_CalculateCRC(SPI2, ENABLE);
```

### 17.2.17 SPI\_GetCRC function

[Table 447](#) describes the SPI\_GetCRC function.

**Table 447. SPI\_GetCRC function**

Function name	SPI_GetCRC
Function prototype	u16 SPI_GetCRC(SPI_TypeDef* SPIx, u8 SPI_CRC)
Behavior description	Returns the transmit or the receive CRC register value for the specified SPI peripheral.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Input parameter2	SPI_CRC: CRC register to be read. Refer to <a href="#">SPI_CRC</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The selected CRC register value.
Required preconditions	None
Called functions	None

#### SPI\_CRC

SPI\_CRC selects the SPI Rx or SPI Tx CRC register. See [Table 448](#) for the values taken by this parameter.

**Table 448. SPI\_CRC values**

SPI_CRC	Description
SPI_CRC_Tx	Selects Tx CRC register
SPI_CRC_Rx	Selects Rx CRC register

**Example:**

```
/* Returns the SPI1 transmit CRC register */
u16 CRCValue;
CRCValue = SPI_GetCRC(SPI1, SPI_CRC_Tx);
```

**17.2.18 SPI\_GetCRCPolynomial function**

[Table 449](#) describes the SPI\_GetCRCPolynomial function.

**Table 449. SPI\_GetCRCPolynomial function**

Function name	SPI_GetCRCPolynomial
Function prototype	u16 SPI_GetCRCPolynomial(SPI_TypeDef* SPIx)
Behavior description	Returns the CRC Polynomial register value for the specified SPI.
Input parameter	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Output parameter	None
Return parameter	The CRC Polynomial register value.
Required preconditions	None
Called functions	None

**Example:**

```
/* Returns the SPI2 CRC polynomial register */
u16 CRCPolyValue;
CRCPolyValue = SPI_GetCRCPolynomial(SPI2);
```



### 17.2.19 SPI\_BiDirectionalLineConfig function

[Table 450](#) describes the SPI\_BiDirectionalLineConfig function.

**Table 450. SPI\_BiDirectionalLineConfig function**

Function name	SPI_BiDirectionalLineConfig
Function prototype	SPI_BiDirectionalLineConfig(SPI_TypeDef* SPIx, u16 SPI_Direction)
Behavior description	Selects the data transfer direction in bidirectional mode for the specified SPI.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI peripheral.
Input parameter2	SPI_Direction: data transfer direction in bidirectional mode. Refer to <a href="#">SPI_Direction</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### SPI\_Direction

SPI\_Direction configures data transfer direction in bidirectional mode. See [Table 451](#) for the values taken by this parameter.

**Table 451. SPI\_Direction values**

SPI_Direction	Description
SPI_Direction_Tx	Selects Tx transmission direction
SPI_Direction_Rx	Selects Rx receive direction

#### Example:

```
/* Set the SPI2 in bidirectional transmit only mode */
SPI_BiDirectionalLineConfig(SPI_Direction_Tx);
```

## 17.2.20 SPI\_I2S\_GetFlagStatus function

[Table 452](#) describes the SPI\_I2S\_GetFlagStatus function.

**Table 452. SPI\_I2S\_GetFlagStatus function**

Function name	SPI_I2S_GetFlagStatus
Function prototype	FlagStatus SPI_I2S_GetFlagStatus(SPI_TypeDef* SPIx, u16 SPI_I2S_FLAG)
Behavior description	Checks whether the specified SPI/I2S flag is set or not.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI/I2S peripheral.
Input parameter2	SPI_I2S_FLAG: flag to be checked. Refer to <a href="#">SPI_I2S_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of SPI_I2S_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

### SPI\_I2S\_FLAG

The SPI/I2S flags that can be checked by issuing an SPI\_I2S\_GetFlagStatus function are listed in [Table 453](#).

**Table 453. SPI\_I2S\_FLAG flags**

SPI_I2S_FLAG	Description
SPI_I2S_FLAG_BSY	Busy flag
SPI_I2S_FLAG_OVR	Overrun flag
SPI_I2S_FLAG_MODF	Mode fault flag
SPI_I2S_FLAG_CRCERR	CRC error flag
I2S_FLAG_UDR	Underrun flag
I2S_FLAG_CHSIDE	Channel side flag
SPI_I2S_FLAG_TXE	Transmit buffer empty flag
SPI_I2S_FLAG_RXNE	Receive buffer not empty flag

#### Example:

```
/* Test if the SPI1 transmit buffer empty flag is set or not */
FlagStatus Status;
Status = SPI_I2S_GetFlagStatus(SPI1, SPI_I2S_FLAG_TXE);

/* Get the I2S3 received (or to be transmitted) data channel side
(left or right) */
FlagStatus Status;
Status = SPI_I2S_GetFlagStatus(SPI3, I2S_FLAG_CHSIDE);
```

### 17.2.21 SPI\_I2S\_ClearFlag function

[Table 454](#) describes the SPI\_I2S\_ClearFlag function.

**Table 454. SPI\_I2S\_ClearFlag function**

Function name	SPI_I2S_ClearFlag
Function prototype	void SPI_I2S_ClearFlag(SPI_TypeDef* SPIx, u16 SPI_I2S_FLAG)
Behavior description	Clears the SPIx/I2Sx pending flags.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI/I2S peripheral.
Input parameter2	SPI_I2S_FLAG: flag to be cleared. Refer to <a href="#">SPI_I2S_FLAG</a> for more details on the allowed values for this parameter. Note: BSY, TXE and RXNE flags are reset by hardware
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the SPI2 Overrun pending bit */
SPI_I2S_ClearFlag(SPI2, SPI_I2S_FLAG_OVR);

/* Clear the I2S3 Underrun pending bit */
SPI_I2S_ClearFlag(SPI3, I2S_FLAG_UDR);
```

## 17.2.22 SPI\_I2S\_GetITStatus function

[Table 455](#) describes the SPI\_I2S\_GetITStatus function.

**Table 455. SPI\_I2S\_GetITStatus function**

Function name	SPI_I2S_GetITStatus
Function prototype	ITStatus SPI_I2S_GetITStatus(SPI_TypeDef* SPIx, u8 SPI_I2S_IT)
Behavior description	Checks whether the specified SPI interrupt has occurred or not.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPI/I2S peripheral.
Input parameter2	SPI_I2S_IT: SPI/I2S interrupt source to be checked. Refer to <a href="#">SPI_I2S_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of SPI_I2S_IT (SET or RESET).
Required preconditions	None
Called functions	None

### SPI\_I2S\_IT

The SPI/I2S interrupt that can be checked by issuing an SPI\_I2S\_GetITStatus function are listed in [Table 456](#).

**Table 456. SPI\_I2S\_IT flags**

SPI_I2S_IT	Description
SPI_I2S_IT_OVR	Overrun interrupt flag
SPI_I2S_IT_MODF	Mode Fault interrupt flag
SPI_I2S_IT_CRCERR	CRC Error interrupt flag
SPI_I2S_IT_TXE	Transmit buffer empty interrupt flag
SPI_I2S_IT_RXNE	Receive buffer not empty interrupt flag

#### Example:

```
/* Test if the SPI1 Overrun interrupt has occurred or not */
ITStatus Status;
Status = SPI_I2S_GetITStatus(SPI1, SPI_I2S_IT_OVR);

/* Test if the I2S2 Underrun interrupt has occurred or not */
ITStatus Status;
Status = SPI_I2S_GetITStatus(SPI2, I2S_IT_UDR);
```

### 17.2.23 SPI\_I2S\_ClearITPendingBit function

[Table 457](#) describes the SPI\_I2S\_ClearITPendingBit function.

**Table 457. SPI\_I2S\_ClearITPendingBit function**

Function name	SPI_I2S_ClearITPendingBit
Function prototype	void SPI_I2S_ClearITPendingBit(SPI_TypeDef* SPIx, u8 SPI_I2S_IT)
Behavior description	Clears the SPIx/I2Sx interrupt pending bits.
Input parameter1	SPIx: where x can be 1, 2 or 3 to select the SPIx/I2Sx peripheral.
Input parameter2	SPI_I2S_IT: specifies the SPI/I2S interrupt pending bit to clear. Refer to <a href="#">SPI_I2S_IT</a> for more details on the allowed values for this parameter. Note: TXE and RXNE interrupt flags are reset by hardware
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the SPI2 CRC error interrupt pending bit */
SPI_I2S_ClearITPendingBit(SPI2, SPI_I2S_IT_CRCERR);

/* Clear the I2S2 UDR error interrupt pending bit */
SPI_I2S_ClearITPendingBit(SPI2, I2S_IT_UDR);
```

## 18 Cortex system timer (SysTick)

The SysTick provides a simple 24-bit decrementing wrap-on-zero clear-on-write counter with a flexible control mechanism.

[Section 18.1: SysTick register structure](#) describes the data structures used in the SysTick Firmware Library. [Section 18.2: Firmware library functions](#) presents the Firmware Library functions.

### 18.1 SysTick register structure

The SysTick register structure, *SysTick\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32 CTRL;
    vu32 LOAD;
    vu32 VAL;
    vuc32 CALIB;
} SysTick_TypeDef;
```

[Table 458](#) gives the list of the SysTick registers.

**Table 458. SysTick registers**

Register	Description
CTRL	SysTick Control and Status Register
LOAD	SysTick Reload value Register
VAL	SysTick Current value Register
CALIB	SysTick Calibration value Register

The SysTick peripheral is declared in *stm32f10x\_map.h*:

```
#define SCS_BASE                ((u32)0xE000E000)
#define SysTick_BASE            (SCS_BASE + 0x0010)
#ifndef DEBUG
...
#ifdef _SysTick
    #define SysTick              ((SysTick_TypeDef *) SysTick_BASE)
#endif /* _SysTick */
...
#else /* DEBUG */
...
#ifdef _SysTick
    EXT SysTick_TypeDef          *SysTick;
#endif /* _SysTick */
...
#endif
```

When using the Debug mode, SysTick pointer is initialized in *stm32f10x\_lib.c* file:

```

#ifdef _SysTick
SysTick = (SysTick_TypeDef *) SysTick_BASE;
#endif /*_SysTick */

```

To access the SysTick registers, `_SysTick` must be defined in *stm32f10x\_conf.h* as follows:

```
#define _SysTick
```

## 18.2 Firmware library functions

[Table 459](#) gives the list of the various functions of the SysTick library.

**Table 459. SysTick firmware library functions**

Function name	Description
SysTick_CLKSourceConfig	Configures the SysTick clock source.
SysTick_SetReload	Sets SysTick Reload value.
SysTick_CounterCmd	Enables or disables the SysTick counter.
SysTick_ITConfig	Enables or disables the SysTick Interrupt.
SysTick_GetCounter	Gets SysTick counter value.
SysTick_GetFlagStatus	Checks whether the specified SysTick flag is set or not.

### 18.2.1 SysTick\_CLKSourceConfig function

[Table 460](#) describes the SysTick\_CLKSourceConfig function.

**Table 460. SysTick\_CLKSourceConfig function**

Function name	SysTick_CLKSourceConfig
Function prototype	<code>void SysTick_CLKSourceConfig(u32 SysTick_CLKSource)</code>
Behavior description	Configures the SysTick clock source.
Input parameter	SysTick_CLKSource: SysTick clock source. Refer to <a href="#">SysTick_CLKSource</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### SysTick\_CLKSource

SysTick\_CLKSource selects the SysTick clock source. Refer to [Table 461](#) for the values taken by this parameter.

**Table 461. SysTick\_CLKSource values**

SysTick_CLKSource	Description
SysTick_CLKSource_HCLK_Div8	SysTick clock source = AHB clock divided by 8
SysTick_CLKSource_HCLK	SysTick clock source = AHB clock

**Example:**

```
/* AHB clock selected as SysTick clock source */
SysTick_CLKSourceConfig(SysTick_CLKSource_HCLK);
```

**18.2.2 SysTick\_SetReload function**

[Table 462](#) describes the SysTick\_SetReload function.

**Table 462. SysTick\_SetReload function**

Function name	SysTick_SetReload
Function prototype	void SysTick_SetReload(u32 Reload)
Behavior description	Sets SysTick Reload value.
Input parameter	Reload: SysTick Reload new value. This parameter must be a number between 1 and 0x00FFFFFF.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set SysTick reload value to 0xFFFF */
SysTick_SetReload(0xFFFF);
```



### 18.2.3 SysTick\_CounterCmd function

[Table 463](#) describes the SysTick\_CounterCmd function.

**Table 463. SysTick\_CounterCmd function**

Function name	SysTick_CounterCmd
Function prototype	<code>void SysTick_CounterCmd(u32 SysTick_Counter)</code>
Behavior description	Enables or disables the SysTick counter.
Input parameter	SysTick_Counter: new state of the SysTick counter. Refer to <a href="#">SysTick_Counter</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### SysTick\_Counter

SysTick\_Counter selects the SysTick counter state. Refer to [Table 464](#) for the values taken by this parameter.

**Table 464. SysTick\_Counter values**

SysTick_Counter	Description
SysTick_Counter_Disable	Disable counter
SysTick_Counter_Enable	Enable counter
SysTick_Counter_Clear	Clear counter value to 0

**Example:**

```
/* Enable SysTick counter */  
SysTick_CounterCmd(SysTick_Counter_Enable);
```

## 18.2.4 SysTick\_ITConfig function

[Table 465](#) describes the SysTick\_ITConfig function.

**Table 465. SysTick\_ITConfig function**

Function name	SysTick_ITConfig
Function prototype	<code>void SysTick_ITConfig(FunctionalState NewState)</code>
Behavior description	Enables or disables the SysTick Interrupt.
Input parameter	NewState: new state of the SysTick Interrupt. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable SysTick interrupt */  
SysTick_ITConfig(ENABLE);
```

## 18.2.5 SysTick\_GetCounter function

[Table 466](#) describes the SysTick\_GetCounter function.

**Table 466. SysTick\_GetCounter function**

Function name	SysTick_GetCounter
Function prototype	<code>u32 SysTick_GetCounter(void)</code>
Behavior description	Gets SysTick counter value.
Input parameter	None
Output parameter	None
Return parameter	SysTick current value.
Required preconditions	None
Called functions	None

**Example:**

```
/* Get SysTick current counter value */  
u32 SysTickCurrentCounterValue;  
SysTickCurrentCounterValue = SysTick_GetCounter();
```

## 18.2.6 SysTick\_GetFlagStatus function

[Table 467](#) describes the SysTick\_GetFlagStatus function.

**Table 467. SysTick\_GetFlagStatus function**

Function name	SysTick_GetFlagStatus
Function prototype	FlagStatus SysTick_GetFlagStatus(u8 SysTick_FLAG)
Behavior description	Checks whether the specified SysTick flag is set or not.
Input parameter	SysTick_FLAG: flag to be checked. Refer to <a href="#">SysTick_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of SysTick_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

### SysTick\_FLAG

The SysTick flags that can be checked by issuing a SysTick\_GetFlagStatus function are listed in the following table:

**Table 468. SysTick flags**

SysTick_FLAG	Description
SysTick_FLAG_COUNT	1 = timer counted to 0 since last time this was read.
SysTick_FLAG_SKEW	1 = the calibration value is not exactly 10ms because of clock frequency.
SysTick_FLAG_NOREF	1 = the reference clock is not provided

#### Example:

```
/* Test if the Count flag is set or not */
FlagStatus Status;
Status = SysTick_GetFlagStatus(SysTick_FLAG_COUNT);
if(Status == RESET)
{
    ...
}
else
{
    ...
}
```

## 19 Advanced-control timer, general-purpose timer and basic timer (TIM)

Each TIM timer consists of a 16-bit auto-reload counter driven by a programmable prescaler.

The advanced-control and general-purpose timers can be used for a variety of purposes, including the measurement of input signal pulse lengths (input capture) or the generation of output waveforms (output compare, PWM, complementary PWM with dead-time insertion for advanced-control timers, etc.).

Pulse lengths and waveform periods can be modulated from a few microseconds to several milliseconds using the timer prescaler and the CPU clock prescaler.

The basic timers may be used as generic timers for time-base generation but they are also specifically used to drive the digital-to-analog converter (DAC). The basic timers are internally connected to the DAC and are able to drive it through their trigger outputs.

[Section 18.1: SysTick register structure](#) describes the data structures used in the TIM firmware library. [Section 18.2: Firmware library functions](#) presents the firmware library functions.

### 19.1 TIM register structure

The TIM register structure, `TIM_TypeDef`, is defined in the `stm32f10x_map.h` file as follows:

```
typedef struct
{
    vu16 CR1;
    u16 RESERVED0;
    vu16 CR2;
    u16 RESERVED1;
    vu16 SMCR;
    u16 RESERVED2;
    vu16 DIER;
    u16 RESERVED3;
    vu16 SR;
    u16 RESERVED4;
    vu16 EGR;
    u16 RESERVED5;
    vu16 CCMR1;
    u16 RESERVED6;
    vu16 CCMR2;
    u16 RESERVED7;
    vu16 CCER;
    u16 RESERVED8;
    vu16 CNT;
    u16 RESERVED9;
    vu16 PSC;
    u16 RESERVED10;
    vu16 ARR;
    u16 RESERVED11;
```

```

vu16 RCR;
u16 RESERVED12;
vu16 CCR1;
u16 RESERVED13;
vu16 CCR2;
u16 RESERVED14;
vu16 CCR3;
u16 RESERVED15;
vu16 CCR4;
u16 RESERVED16;
vu16 BDTR;
u16 RESERVED17;
vu16 DCR;
u16 RESERVED18;
vu16 DMAR;
u16 RESERVED19;
} TIM_TypeDef;

```

[Table 469](#) gives the list of TIM registers.

**Table 469. TIM registers**

Register	Description
CR1	Control Register1
CR2	Control Register2
SMCR	Slave Mode Control Register
DIER	DMA and Interrupt Enable Register
SR	Status Register
EGR	Event Generation Register
CCMR1	Capture/Compare Mode Register 1
CCMR2	Capture/Compare Mode Register 2
CCER	Capture/Compare Enable Register
CNT	Counter Register
PSC	Prescaler Register
ARR	Auto-Reload Register
RCR	Repetition Counter Register
CCR1	Capture/Compare Register 1
CCR2	Capture/Compare Register 2
CCR3	Capture/Compare Register 3
CCR4	Capture/Compare Register 4
BDTR	Break and Dead Time Register
DCR	DMA Control Register
DMAR	DMA Address for Burst mode Register

The TIM peripheral is declared in the *stm32f10x\_map* file:

```

...
#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE     PERIPH_BASE
#define APB2PERIPH_BASE     (PERIPH_BASE + 0x10000)
#define APB3PERIPH_BASE     (PERIPH_BASE + 0x18000)
#define AHBPERIPH_BASE      (PERIPH_BASE + 0x20000)
...
#define TIM2_BASE            (APB1PERIPH_BASE + 0x0000)
#define TIM3_BASE            (APB1PERIPH_BASE + 0x0400)
#define TIM4_BASE            (APB1PERIPH_BASE + 0x0800)
#define TIM5_BASE            (APB1PERIPH_BASE + 0x0C00)
#define TIM6_BASE            (APB1PERIPH_BASE + 0x1000)
#define TIM7_BASE            (APB1PERIPH_BASE + 0x1400)
...
#define TIM1_BASE            (APB2PERIPH_BASE + 0x2C00)
....
#define TIM8_BASE            (APB2PERIPH_BASE + 0x3400)
...
#ifndef DEBUG
...
#ifdef _TIM2
    #define TIM2 ((TIM_TypeDef *) TIM2_BASE)
#endif /* _TIM2 */
#ifdef _TIM3
    #define TIM3 ((TIM_TypeDef *) TIM3_BASE)
#endif /* _TIM3 */
#ifdef _TIM4
    #define TIM4 ((TIM_TypeDef *) TIM4_BASE)
#endif /* _TIM4 */
#ifdef _TIM5
    #define TIM5 ((TIM_TypeDef *) TIM5_BASE)
#endif /* _TIM5 */
#ifdef _TIM6
    #define TIM6 ((TIM_TypeDef *) TIM6_BASE)
#endif /* _TIM6 */
#ifdef _TIM7
    #define TIM7 ((TIM_TypeDef *) TIM7_BASE)
#endif /* _TIM7 */
....
#ifdef _TIM1
    #define TIM1 ((TIM_TypeDef *) TIM1_BASE)
#endif /* _TIM1 */
....
#ifdef _TIM8
    #define TIM8 ((TIM_TypeDef *) TIM8_BASE)
#endif /* _TIM8 */
...
#else /* DEBUG */
...
#ifdef _TIM2
    EXT_TIM_TypeDef          *TIM2;
#endif /* _TIM2 */

```

```

#ifdef _TIM3
    EXT TIM_TypeDef          *TIM3;
#endif /*_TIM3 */
#ifdef _TIM4
    EXT TIM_TypeDef          *TIM4;
#endif /*_TIM4 */

#ifdef _TIM5
    EXT TIM_TypeDef          *TIM5;
#endif /*_TIM5 */
#ifdef _TIM6
    EXT TIM_TypeDef          *TIM6;
#endif /*_TIM6 */
#ifdef _TIM7
    EXT TIM_TypeDef          *TIM7;
#endif /*_TIM7 */
...
#ifdef _TIM1
    EXT TIM_TypeDef          *TIM1;
#endif /*_TIM */
..
#ifdef _TIM8
    EXT TIM_TypeDef          *TIM8;
#endif /*_TIM8 */
..
#endif

```

When using the Debug mode, \_TIM pointer is initialized in the *stm32f10x\_lib.c* file:

```

...
#ifdef _TIM1
    TIM1 = (TIM_TypeDef *) TIM1_BASE;
#endif /*_TIM */

#ifdef _TIM2
    TIM2 = (TIM_TypeDef *) TIM2_BASE;
#endif /*_TIM2 */

#ifdef _TIM3
    TIM3 = (TIM_TypeDef *) TIM3_BASE;
#endif /*_TIM3 */

#ifdef _TIM4
    TIM4 = (TIM_TypeDef *) TIM4_BASE;
#endif /*_TIM4 */

#ifdef _TIM5
    TIM5 = (TIM_TypeDef *) TIM5_BASE;
#endif /*_TIM5 */

#ifdef _TIM6
    TIM6 = (TIM_TypeDef *) TIM6_BASE;
#endif /*_TIM6 */

```

```

#ifdef _TIM7
    TIM7 = (TIM_TypeDef *) TIM7_BASE;
#endif /*_TIM7 */

#ifdef _TIM8
    TIM8 = (TIM_TypeDef *) TIM8_BASE;
#endif /*_TIM8 */
...
To access TIM registers, _TIM must be defined in stm32f10x_conf.h as
follows:
...
#define _TIM
#define _TIM1
#define _TIM2
#define _TIM3
#define _TIM4
#define _TIM5
#define _TIM6
#define _TIM7
#define _TIM8
...

```

## 19.2 Firmware library functions

[Table 470](#) gives the list of the various functions of the TIM library.

**Table 470. TIM firmware library functions**

Function name	Description
TIM_DeInit	Resets the TIM peripheral registers to their default reset values.
TIM_TimeBaseInit	Initializes the TIM Time Base Unit according to the specified parameters in the TIM_TimeBaseInitStruct.
TIM_OC1Init	Initializes the TIM Channel1 according to the specified parameters in the TIM_OCInitStruct.
TIM_OC2Init	Initializes the TIM Channel2 according to the specified parameters in the TIM_OCInitStruct.
TIM_OC3Init	Initializes the TIM Channel3 according to the specified parameters in the TIM_OCInitStruct.
TIM_OC4Init	Initializes the TIM Channel4 according to the specified parameters in the TIM_OCInitStruct.
TIM_ICInit	Initializes the TIM peripheral according to the specified parameters in the TIM_ICInitStruct.
TIM_PWMConfig	Configures the TIM peripheral in PWM Input Mode according to the specified parameters in the TIM_ICInitStruct.
TIM_BDTRConfig	Configures the: Break feature, dead time, Lock level, OSSR, OSSI, OSSI State and AOE (automatic output enable).
TIM_TimeBaseStructInit	Fills each TIM_TimeBaseInitStruct member with its default value.
TIM_OCStructInit	Fills each TIM_OCInitStruct member with its default value.



Table 470. TIM firmware library functions (continued)

Function name	Description
TIM_ICStructInit	Fills each TIM_ICInitStruct member with its default value.
TIM_BDTRStructInit	Fills each TIM_BDTRInitStruct member with its default value.
TIM_Cmd	Enables or disables the specified TIM peripheral.
TIM_CtrlPWMOutputs	Enables or disables the TIM peripheral main outputs.
TIM_ITConfig	Enables or disables the specified TIM interrupts.
TIM_GenerateEvent	Configures the TIM event to be generated by software.
TIM_DMAConfig	Configures the TIM DMA interface.
TIM_DMACmd	Enables or disables the TIM DMA requests.
TIM_InternalClockConfig	Configures the TIM's internal Clock.
TIM_ITRxExternalClockConfig	Configures the TIM's internal trigger as external clock.
TIM_TlxExternalClockConfig	Configures the TIM trigger as external clock.
TIM_ETRClockMode1Config	Configures the TIM's external clock Mode1.
TIM_ETRClockMode2Config	Configures the TIM's external clock Mode2.
TIM_ETRConfig	Configures the TIM's external trigger (ETR).
TIM_PrescalerConfig	Configures the TIM prescaler.
TIM_CounterModeConfig	Specifies the TIM counter mode to be used.
TIM_SelectInputTrigger	Selects the TIM input trigger source.
TIM_EncoderInterfaceConfig	Configures the TIM encoder interface.
TIM_ForcedOC1Config	Forces the TIM Channel1 output waveform to active or inactive level.
TIM_ForcedOC2Config	Forces the TIM Channel2 output waveform to active or inactive level.
TIM_ForcedOC3Config	Forces the TIM Channel3 output waveform to active or inactive level.
TIM_ForcedOC4Config	Forces the TIM Channel4 output waveform to active or inactive level.
TIM_ARRPreloadConfig	Enables or disables the TIM peripheral Preload register on ARR.
TIM_SelectCOM	Selects the TIM peripheral Commutation event.
TIM_SelectCCDMA	Selects the TIM peripheral Capture Compare DMA source.
TIM_CCPreloadControl	Sets or Resets the TIM peripheral Capture Compare Preload Control bit.
TIM_OC1PreloadConfig	Enables or disables the TIM peripheral Preload Register on CCR1.
TIM_OC2PreloadConfig	Enables or disables the TIM peripheral Preload Register on CCR2.
TIM_OC3PreloadConfig	Enables or disables the TIM peripheral Preload Register on CCR3.
TIM_OC4PreloadConfig	Enables or disables the TIM peripheral Preload Register on CCR4.
TIM_OC1FastConfig	Configures the TIM Capture Compare 1 Fast feature.
TIM_OC2FastConfig	Configures the TIM Capture Compare 2 Fast feature.
TIM_OC3FastConfig	Configures the TIM Capture Compare 3 Fast feature.
TIM_OC4FastConfig	Configures the TIM Capture Compare 4 Fast feature.
TIM_ClearOC1Ref	Clears or safeguards the OCREF1 signal on an external event

Table 470. TIM firmware library functions (continued)

Function name	Description
TIM_ClearOC2Ref	Clears or safeguards the OCREF2 signal on an external event
TIM_ClearOC3Ref	Clears or safeguards the OCREF3 signal on an external event
TIM_ClearOC4Ref	Clears or safeguards the OCREF4 signal on an external event
TIM_OC1PolarityConfig	Configures the TIM Channel 1 polarity.
TIM_OC1NPolarityConfig	Configures the TIM Channel 1N polarity.
TIM_OC2PolarityConfig	Configures the TIM Channel 2 polarity.
TIM_OC2NPolarityConfig	Configures the TIM Channel 2N polarity.
TIM_OC3PolarityConfig	Configures the TIM Channel 3 polarity.
TIM_OC3NPolarityConfig	Configures the TIM Channel 3N polarity.
TIM_OC4PolarityConfig	Configures the TIM Channel 4 polarity.
TIM_CCxCmd	Enables or disables the TIM Capture Compare Channel x.
TIM_CCxNCmd	Enables or disables the TIM Capture Compare Channel xN.
TIM_SelectOCxM	Selects the TIM Output Compare mode. This function disables the selected channel before changing the Output Compare mode. User has to enable this channel using TIM_CCxCmd and TIM_CCxNCmd functions.
TIM_UpdateDisableConfig	Enables or Disables the TIM update event.
TIM_UpdateRequestConfig	Selects the TIM update request interrupt source.
TIM_SelectHallSensor	Enables or disables the TIM's hall sensor interface.
TIM_SelectOnePulseMode	Enables or disables the TIM's one-pulse mode.
TIM_SelectOutputTrigger	Selects the TIM trigger output mode.
TIM_SelectSlaveMode	Selects the TIM slave mode.
TIM_SelectMasterSlaveMode	Sets or resets the TIM master/slave mode.
TIM_SetCounter	Sets the TIM Counter Register value.
TIM_SetAutoreload	Sets the TIM Autoreload Register value.
TIM_SetCompare1	Sets the TIM Capture Compare1 Register value.
TIM_SetCompare2	Sets the TIM Capture Compare2 Register value.
TIM_SetCompare3	Sets the TIM Capture Compare3 Register value.
TIM_SetCompare4	Sets the TIM Capture Compare4 Register value.
TIM_SetIC1Prescaler	Sets the TIM Input Capture 1 prescaler.
TIM_SetIC2Prescaler	Sets the TIM Input Capture 2 prescaler.
TIM_SetIC3Prescaler	Sets the TIM Input Capture 3 prescaler.
TIM_SetIC4Prescaler	Sets the TIM Input Capture 4 prescaler.
TIM_SetClockDivision	Sets the TIM clock division value.
TIM_GetCapture1	Gets the TIM Input Capture 1 value.
TIM_GetCapture2	Gets the TIM Input Capture 2 value.

**Table 470. TIM firmware library functions (continued)**

Function name	Description
TIM_GetCapture3	Gets the TIM Input Capture 3 value.
TIM_GetCapture4	Gets the TIM Input Capture 4 value.
TIM_GetCounter	Gets the TIM counter value.
TIM_GetPrescaler	Gets the Prescaler value.
TIM_GetFlagStatus	Checks whether the specified TIM flag is set or not.
TIM_ClearFlag	Clears the TIM's pending flags.
TIM_GetITStatus	Checks whether the specified TIM interrupt has occurred or not.
TIM_ClearITPendingBit	Clears the TIM's interrupt pending bits.

### 19.2.1 TIM\_DeInit function

*Table 471* describes the TIM\_DeInit function.

**Table 471. TIM\_DeInit function**

Function name	TIM_DeInit
Function prototype	<code>void TIM_DeInit(TIM_TypeDef* TIMx)</code>
Behavior description	Resets the TIM peripheral registers to their default reset values.
Input parameter	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_APB2PeriphResetCmd and RCC_APB1PeriphResetCmd

**Example:**

```
/* Resets TIM1 */
TIM_DeInit(TIM1);
```

## 19.2.2 TIM\_TimeBaseInit function

[Table 472](#) describes the TIM\_TimeBaseInit function.

**Table 472. TIM\_TimeBaseInit function**

Function name	TIM_TimeBaseInit
Function prototype	void TIM_TimeBaseInit(TIM_TypeDef* TIMx, TIM_TimeBaseInitTypeDef* TIM_TimeBaseInitStruct)
Behavior description	Initializes the TIM Time Base Unit according to the parameters specified in the TIM_TimeBaseInitStruct.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_TimeBaseInitStruct: pointer to a TIM_TimeBaseInitTypeDef structure that contains the configuration information for the specified TIM Time Base Unit. Refer to <a href="#">TIM_TimeBaseInitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## TIM\_TimeBaseInitTypeDef structure

The TIM\_TimeBaseInitTypeDef structure is defined in the *stm32f10x\_TIM.h* file:

```
typedef struct
{
    u16 TIM_Period;
    u16 TIM_Prescaler;
    u16 TIM_ClockDivision;
    u16 TIM_CounterMode;
    u8 TIM_RepetitionCounter;
} TIM_TimeBaseInitTypeDef;
```

This structure is used with all TIMx except for TIM6 and TIM7.

### TIM\_Period

TIM\_Period configures the period value to be loaded into the active Auto-Reload Register at the next update event. This member must be a number between 0x0000 and 0xFFFF.

### TIM\_Prescaler

TIM\_Prescaler configures the prescaler value used to divide the TIM clock. This member must be a number between 0x0000 and 0xFFFF.

### TIM\_ClockDivision

TIM\_ClockDivision configures the clock division. This member can be set to one of the following values:

**Table 473. TIM\_ClockDivision definition**

TIM_ClockDivision	Description
TIM_CKD_DIV1	$T_{DTS} = T_{ck\_tim}$
TIM_CKD_DIV2	$T_{DTS} = 2 \times T_{ck\_tim}$
TIM_CKD_DIV4	$T_{DTS} = 4 \times T_{ck\_tim}$

**TIM\_CounterMode**

TIM\_CounterMode selects the counter mode. This member can be set to one of the following values:

**Table 474. TIM\_CounterMode definition**

TIM_CounterMode	Description
TIM_Counter_Up	TIM Upcounting mode.
TIM_Counter_Down	TIM Downcounting mode.
TIM_Counter_CenterAligned1	TIM CenterAligned Mode1 Counting mode.
TIM_Counter_CenterAligned2	TIM CenterAligned Mode2 Counting mode.
TIM_Counter_CenterAligned3	TIM CenterAligned Mode3 Counting mode.

**TIM\_RepetitionCounter**

TIM\_RepetitionCounter configures the repetition counter value. Each time the RCR downcounter reaches zero, an update event is generated and counting restarts from the RCR value (N).

This means in PWM mode that (N+1) corresponds to:

- the number of PWM periods in edge-aligned mode
- the number of half PWM period in center-aligned mode

This member must be a number between 0x00 and 0xFF. This parameter is valid only for TIM1 and TIM8.

### 19.2.3 TIM\_OC1Init function

[Table 475](#) describes the TIM\_OC1Init function.

**Table 475. TIM\_OC1Init function**

Function name	TIM_OC1Init
Function prototype	void TIM_OC1Init(TIM_TypeDef* TIMx, TIM_OCInitTypeDef* TIM_OCInitStruct)
Behavior description	Initializes the TIM Channel 1 according to the parameters specified in the TIM_OCInitStruct.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCInitStruct: pointer to a TIM_OCInitTypeDef structure that contains the configuration information for the specified TIM peripheral. Refer to <a href="#">TIM_OCInitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### TIM\_OCInitTypeDef structure

The TIM\_OCInitTypeDef structure is defined in the *stm32f10x\_tim.h* file:

```
typedef struct
{
  u16 TIM_OCMode;
  u16 TIM_OutputState;
  u16 TIM_OutputNState;
  u16 TIM_Pulse;
  u16 TIM_OCPolarity;
  u16 TIM_OCNPolarity;
  u16 TIM_OCIdleState;
  u16 TIM_OCNIdleState;
} TIM_OCInitTypeDef;
```

TIM\_OutputNState, TIM\_OCNPolarity, TIM\_OCIdleState and TIM\_OCNIdleState parameters are used only with TIM1 and TIM8, which can generate complementary signals.

### TIM\_OCMode

TIM\_OCMode selects the TIM mode. This member can be set to one of the following values:

**Table 476. TIM\_OCMode definition**

TIM_OCMode	Description
TIM_OCMode_Timing	TIM Output Compare Timing mode.
TIM_OCMode_Active	TIM Output Compare Active mode.
TIM_OCMode_Inactive	TIM Output Compare Inactive mode.

**Table 476. TIM\_OCMode definition (continued)**

<b>TIM_OCMode</b>	<b>Description</b>
TIM_OCMode_Toggle	TIM Output Compare Toggle mode.
TIM_OCMode_PWM1	TIM Pulse Width Modulation mode1.
TIM_OCMode_PWM2	TIM Pulse Width Modulation mode2.

**TIM\_OutputState**

TIM\_OutputState selects the TIM Output Compare state. This member can be set to one of the following values:

**Table 477. TIM\_OutputState definition**

<b>TIM_OutputState</b>	<b>Description</b>
TIM_OutputState_Disable	Disables the TIM Output Compare state.
TIM_OutputState_Enable	Enables the TIM Output Compare state.

**TIM\_OutputNState**

TIM\_OutputNState selects the TIM complementary Output Compare state. This member can be set to one of the following values:

**Table 478. TIM\_OutputNState definition**

<b>TIM_OutputNState</b>	<b>Description</b>
TIM_OutputNState_Disable	Disables the TIM Output N Compare state.
TIM_OutputNState_Enable	Enables the TIM Output N Compare state.

**TIM\_Pulse**

TIM\_Pulse configures the pulse value to be loaded into the Capture Compare Register. This member must be a number between 0x0000 and 0xFFFF.

**TIM\_OCPolarity**

TIM\_OCPolarity configures the output polarity. This member can be set to one of the following values:

**Table 479. TIM\_OCPolarity definition**

<b>TIM_OCPolarity</b>	<b>Description</b>
TIM_OCPolarity_High	Sets the TIM Output Compare polarity to high.
TIM_OCPolarity_Low	Sets the TIM Output Compare polarity to low.

**TIM\_OCNPolarity**

TIM\_OCNPolarity configures the complementary output polarity. This member can be set to one of the following values:

**Table 480. TIM\_OCNPolarity definition**

TIM_OCNPolarity	Description
TIM_OCNPolarity_High	Sets the Output Compare N Polarity to high.
TIM_OCNPolarity_Low	Sets the Output Compare N Polarity to low.

**TIM\_OCIdleState**

TIM\_OCIdleState selects the TIM Output Compare pin state during Idle state. This member can be set to one of the following values:

**Table 481. TIM\_OCIdleState definition**

TIM_OCIdleState	Description
TIM_OCIdleState_Set	TIM Output OC Idle state set when MOE = 0
TIM_OCIdleState_Reset	TIM Output OC Idle state reset when MOE = 0

**TIM\_OCNIdleState**

TIM\_OCNIdleState selects the TIM Output Compare pin state during Idle state. This member can be one of the following values:

**Table 482. TIM\_OCNIdleState definition**

TIM_OCNIdleState	Description
TIM_OCNIdleState_Set	TIM Output OCN Idle state set when MOE = 0
TIM_OCNIdleState_Reset	TIM Output OCN Idle state reset when MOE = 0

**Example:**

```
/* Configures the TIM1 Channel1 in PWM Mode */
TIM_OCInitTypeDef TIM_OCInitStructure;
TIM_OCInitStructure.TIM_OCMode = TIM_OCMode_PWM1;
TIM_OCInitStructure.TIM_OutputState = TIM_OutputState_Enable;
TIM_OCInitStructure.TIM_OutputNState = TIM_OutputNState_Enable;
TIM_OCInitStructure.TIM_Pulse = 0x7FF;
TIM_OCInitStructure.TIM_OCPolarity = TIM_OCPolarity_Low;
TIM_OCInitStructure.TIM_OCNPolarity = TIM_OCNPolarity_Low;
TIM_OCInitStructure.TIM_OCIdleState = TIM_OCIdleState_Set;
TIM_OCInitStructure.TIM_OCNIdleState = TIM_OCNIdleState_Reset;
TIM_OC1Init(TIM1, &TIM_OCInitStructure);
```

```
/* Configures the TIM3 Channel1 in Toggle Mode */
TIM_OCInitTypeDef TIM_OCInitStructure;
TIM_OCInitStructure.TIM_OCMode = TIM_OCMode_Toggle;
TIM_OCInitStructure.TIM_OutputState = TIM_OutputState_Enable;
TIM_OCInitStructure.TIM_Pulse = 0x7FF;
TIM_OCInitStructure.TIM_OCPolarity = TIM_OCPolarity_Low;

TIM_OC1Init(TIM3, &TIM_OCInitStructure);
```



## 19.2.4 TIM\_OC2Init function

[Table 483](#) describes the TIM\_OC2Init function.

**Table 483. TIM\_OC2Init function**

Function name	TIM_OC2Init
Function prototype	void TIM_OC2Init(TIM_TypeDef* TIMx, TIM_OCInitTypeDef* TIM_OCInitStruct)
Behavior description	Initializes the TIM Channel 2 according to the parameters specified in the TIM_OCInitStruct.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCInitStruct: pointer to a TIM_OCInitTypeDef structure that contains the configuration information for the specified TIM peripheral. Refer to <a href="#">TIM_OCInitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### Example:

```
/* Configures the TIM1 Channel1 in PWM Mode */
TIM_OCInitTypeDef TIM_OCInitStructure;
TIM_OCInitStructure.TIM_OCMode = TIM_OCMode_PWM1;
TIM_OCInitStructure.TIM_OutputState = TIM_OutputState_Enable;
TIM_OCInitStructure.TIM_OutputNState = TIM_OutputNState_Enable;
TIM_OCInitStructure.TIM_Pulse = 0x7FF;
TIM_OCInitStructure.TIM_OCPolarity = TIM_OCPolarity_Low;
TIM_OCInitStructure.TIM_OCNPolarity = TIM_OCNPolarity_Low;
TIM_OCInitStructure.TIM_OCIdleState = TIM_OCIdleState_Set;
TIM_OCInitStructure.TIM_OCNIdleState = TIM_OCIdleState_Reset;
TIM_OC2Init(TIM1, &TIM_OCInitStructure);

/* Configures the TIM3 Channel1 in Toggle Mode */
TIM_OCInitTypeDef TIM_OCInitStructure;
TIM_OCInitStructure.TIM_OCMode = TIM_OCMode_Toggle;
TIM_OCInitStructure.TIM_OutputState = TIM_OutputState_Enable;
TIM_OCInitStructure.TIM_Pulse = 0x7FF;
TIM_OCInitStructure.TIM_OCPolarity = TIM_OCPolarity_Low;
TIM_OC2Init(TIM3, &TIM_OCInitStructure);
```

## 19.2.5 TIM\_OC3Init function

[Table 484](#) describes the TIM\_OC3Init function.

**Table 484. TIM\_OC3Init function**

Function name	TIM_OC3Init
Function prototype	void TIM_OC3Init(TIM_TypeDef* TIMx, TIM_OCInitTypeDef* TIM_OCInitStruct)
Behavior description	Initializes the TIM Channel 3 according to the parameters specified in the TIM_OCInitStruct.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCInitStruct: pointer to a TIM_OCInitTypeDef structure that contains the configuration information for the specified TIM peripheral. Refer to <a href="#">TIM_OCInitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### Example:

```
/* Configures the TIM1 Channel1 in PWM Mode */
TIM_OCInitTypeDef TIM_OCInitStructure;
TIM_OCInitStructure.TIM_OCMode = TIM_OCMode_PWM1;
TIM_OCInitStructure.TIM_OutputState = TIM_OutputState_Enable;
TIM_OCInitStructure.TIM_OutputNState = TIM_OutputNState_Enable;
TIM_OCInitStructure.TIM_Pulse = 0x7FF;
TIM_OCInitStructure.TIM_OCPolarity = TIM_OCPolarity_Low;
TIM_OCInitStructure.TIM_OCNPolarity = TIM_OCNPolarity_Low;
TIM_OCInitStructure.TIM_OCIdleState = TIM_OCIdleState_Set;
TIM_OCInitStructure.TIM_OCNIdleState = TIM_OCNIdleState_Reset;

TIM_OC3Init(TIM1, &TIM_OCInitStructure);

/* Configures the TIM3 Channel1 in Toggle Mode */
TIM_OCInitTypeDef TIM_OCInitStructure;
TIM_OCInitStructure.TIM_OCMode = TIM_OCMode_Toggle;
TIM_OCInitStructure.TIM_OutputState = TIM_OutputState_Enable;
TIM_OCInitStructure.TIM_Pulse = 0x7FF;
TIM_OCInitStructure.TIM_OCPolarity = TIM_OCPolarity_Low;

TIM_OC3Init(TIM3, &TIM_OCInitStructure);
```

## 19.2.6 TIM\_OC4Init function

[Table 485](#) describes the TIM\_OC4Init function.

**Table 485. TIM\_OC4Init function**

Function name	TIM_OC4Init
Function prototype	void TIM_OC4Init(TIM_TypeDef* TIMx, TIM_OCInitTypeDef* TIM_OCInitStruct)
Behavior description	Initializes the TIM Channel 4 according to the specified parameters in the TIM_OCInitStruct.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCInitStruct: pointer to a TIM_OCInitTypeDef structure that contains the configuration information for the specified TIM peripheral. Refer to <a href="#">TIM_OCInitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### Example:

```
/* Configures the TIM1 Channel4 in PWM Mode */
TIM_OCInitTypeDef TIM_OCInitStructure;

TIM_OCInitStructure.TIM_OCMode = TIM_OCMode_PWM1;
TIM_OCInitStructure.TIM_OutputState = TIM_OutputState_Enable;
TIM_OCInitStructure.TIM_Pulse = 0x7FF;
TIM_OCInitStructure.TIM_OCPolarity = TIM_OCPolarity_Low;
TIM_OCInitStructure.TIM_OCIdleState = TIM_OCIdleState_Set;

TIM_OC4Init(TIM1, &TIM_OCInitStructure);

/* Configures the TIM3 Channel4 in PWM Mode */
TIM_OCInitTypeDef TIM_OCInitStructure;

TIM_OCInitStructure.TIM_OCMode = TIM_OCMode_PWM1;
TIM_OCInitStructure.TIM_OutputState = TIM_OutputState_Enable;
TIM_OCInitStructure.TIM_Pulse = 0x7FF;
TIM_OCInitStructure.TIM_OCPolarity = TIM_OCPolarity_Low;

TIM_OC4Init(TIM3, &TIM_OCInitStructure);
```

## 19.2.7 TIM\_ICInit function

[Table 486](#) describes the TIM\_ICInit function.

**Table 486. TIM\_ICInit function**

Function name	TIM_ICInit
Function prototype	void TIM_ICInit(TIM_TypeDef* TIMx, TIM_ICInitTypeDef* TIM_ICInitStruct)
Behavior description	Initializes the TIM according to the parameters specified in the TIM_ICInitStruct.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_ICInitStruct: pointer to a TIM_ICInitTypeDef structure that contains the configuration information for the specified TIM peripheral. Refer to <a href="#">TIM_ICInitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## TIM\_ICInitTypeDef structure

The TIM\_ICInitTypeDef structure is defined in the *stm32f10x\_tim.h* file:

```
typedef struct
{
  u16 TIM_Channel;
  u16 TIM_ICPolarity;
  u16 TIM_ICSelection;
  u16 TIM_ICPrescaler;
  u8 TIM_ICFilter;
} TIM_ICInitTypeDef;
```

## TIM\_Channel

TIM\_Channel selects the TIM channel. This member can be set to one of the following values:

**Table 487. TIM\_Channel definition**

TIM_Channel	Description
TIM_Channel_1	TIM Channel 1 is used.
TIM_Channel_2	TIM Channel 2 is used.
TIM_Channel_3	TIM Channel 3 is used.
TIM_Channel_4	TIM Channel 4 is used.

**TIM\_ICPolarity**

TIM\_ICPolarity selects the active edge of the input signal. This member can be set to one of the following values:

**Table 488. TIM\_ICPolarity definition**

TIM_ICPolarity	Description
TIM_ICPolarity_Rising	The active edge is the TIM Input Capture rising edge.
TIM_ICPolarity_Falling	The active edge is the TIM Input Capture falling edge.

**TIM\_ICSelection**

TIM\_ICSelection selects the input. This member can be set to one of the following values:

**Table 489. TIM\_ICSelection definition**

TIM_ICSelection	Description
TIM_ICSelection_DirectTI	TIM Input 1, 2, 3 or 4 is selected to be connected to IC1, IC2, IC3 or IC4, respectively.
TIM_ICSelection_IndirectTI	TIM Input 1, 2, 3 or 4 is selected to be connected to IC2, IC1, IC4 or IC3, respectively.
TIM_ICSelection_TRC	TIM Input 1, 2, 3 or 4 is selected to be connected to TRC.

**TIM\_ICPrescaler**

TIM\_ICPrescaler configures the Input Capture Prescaler. This member can be set to one of the following value:

**Table 490. TIM\_ICPrescaler definition**

TIM_ICPrescaler	Description
TIM_ICPSC_DIV1	Capture performed each time an edge is detected on the capture input.
TIM_ICPSC_DIV2	Capture performed once every 2 events.
TIM_ICPSC_DIV4	Capture performed once every 4 events.
TIM_ICPSC_DIV8	Capture performed once every 8 events.

**TIM\_ICFilter**

TIM\_ICFilter specifies the input capture filter. This member can be set to a value between 0x0 and 0xF.

**Example:**

```
/* TIM3 Input Capture Channel 1 mode Configuration */

TIM_ICInitTypeDef TIM_ICInitStructure;

TIM_ICInitStructure.TIM_Channel = TIM_Channel_1;
TIM_ICInitStructure.TIM_ICPolarity = TIM_ICPolarity_Falling;
TIM_ICInitStructure.TIM_ICSelection = TIM_ICSelection_DirectTI;
```

```
TIM_ICInitStructure.TIM_ICPrescaler = TIM_ICPSC_DIV2;
TIM_ICInitStructure.TIM_ICFilter = 0x0;

TIM_ICInit(TIM3, &TIM_ICInitStructure);
```

## 19.2.8 TIM\_PWMICConfig function

[Table 491](#) describes the TIM\_PWMICConfig function.

**Table 491. TIM\_PWMICConfig function**

Function name	TIM_PWMICConfig
Function prototype	TIM_PWMICConfig(TIM_TypeDef* TIMx, TIM_ICInitTypeDef* TIM_ICInitStruct)
Behavior description	Configures the TIM peripheral in PWM Input mode according to the parameters specified in the TIM_ICInitStruct.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_ICInitStruct: pointer to a TIM_ICInitTypeDef structure that contains the configuration information for the specified TIM peripheral. Refer to <a href="#">TIM_OCInitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### Example:

```
/* TIM1 PWM Input Channel 1 mode Configuration */

TIM_ICInitTypeDef TIM_ICInitStructure;

TIM_ICInitStructure.TIM_Channel = TIM_Channel_1;
TIM_ICInitStructure.TIM_ICPolarity = TIM_ICPolarity_Rising;
TIM_ICInitStructure.TIM_ICSelection = TIM_ICSelection_DirectTI;
TIM_ICInitStructure.TIM_ICPrescaler = TIM_ICPSC_DIV1;
TIM_ICInitStructure.TIM_ICFilter = 0x0;

TIM_PWMICConfig(TIM1, &TIM_ICInitStructure);
```

## 19.2.9 TIM\_BDTRConfig function

[Table 492](#) describes the TIM\_BDTRConfig function.

**Table 492. TIM\_BDTRConfig function**

Function name	TIM_BDTRConfig
Function prototype	void TIM_BDTRConfig(TIM_TypeDef* TIMx, TIM_BDTRInitTypeDef *TIM_BDTRInitStruct)
Behavior description	Configure the break feature, dead time, Lock level, OSSR, OSSR State and AOE (automatic output enable).
Input parameter1	TIMx: where x can be 1 or 8 to select the TIM peripheral.
Input parameter2	TIM_BDTRInitStruct: pointer to a TIM_BDTRInitTypeDef structure that contains the BDTR Register configuration information for the TIM peripheral. Refer to <a href="#">TIM_BDTRInitStruct structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## TIM\_BDTRInitStruct structure

The TIM\_BDTRInitStruct structure is defined in the *stm32f10x\_tim.h* file:

```
typedef struct
{
    u16 TIM_OSSRState;
    u16 TIM_OSSIState;
    u16 TIM_LOCKLevel;
    u16 TIM_DeadTime;
    u16 TIM_Break;
    u16 TIM_BreakPolarity;
    u16 TIM_AutomaticOutput;
} TIM_BDTRInitTypeDef;
```

## TIM\_OSSRState

TIM\_OSSRState configures the Off-State selection used in Run mode. This member can be set to one of the following values:

**Table 493. TIM\_OSSRState definition**

TIM_OSSRState	Description
TIM_OSSRState_Enable	TIM OSSR State is enabled
TIM_OSSRState_Disable	TIM OSSR State is disabled

**TIM\_OSSIState**

TIM\_OSSIState selects the Off-State used in Idle state. This member can be set to one of the following values:

**Table 494. TIM\_OSSIState definition**

TIM_OSSIState	Description
TIM_OSSIState_Enable	TIM OSSI State is enabled
TIM_OSSIState_Disable	TIM OSSI State is disabled

**TIM\_LOCKLevel**

TIM\_LOCKLevel configures the LOCK level parameters. This member can be set to one of the following values:

**Table 495. TIM\_LOCKLevel definition**

TIM_LOCKLevel	Description
TIM_LOCKLevel_OFF	No bit is locked.
TIM_LOCKLevel_1	LOCK level 1 is used.
TIM_LOCKLevel_2	LOCK level 2 is used.
TIM_LOCKLevel_3	LOCK level 3 is used.

**TIM\_DeadTime**

TIM\_DeadTime specifies the delay time between the switching-off and the switching-on of the outputs.

**TIM\_Break**

TIM\_Break enables or disables the TIM Break input. This member can be set to one of the following values:

**Table 496. TIM\_Break definition**

TIM_Break	Description
TIM_Break_Enable	TIM Break Input is enabled
TIM_Break_Disable	TIM Break Input is disabled

**TIM\_BreakPolarity**

TIM\_BreakPolarity configures the TIM Break Input pin polarity. This member can be set to one of the following values:

**Table 497. TIM\_BreakPolarity definition**

TIM_BreakPolarity	Description
TIM_BreakPolarity_Low	Sets the TIM Break input pin polarity to low.
TIM_BreakPolarity_High	Sets the TIM Break Input pin polarity to high.



**TIM\_AutomaticOutput**

TIM\_AutomaticOutput enables or disables the Automatic Output feature. This member can be set to one of the following values:

**Table 498. TIM\_AutomaticOutput definition**

TIM_AutomaticOutput	Description
TIM_AutomaticOutput_Enable	Enables the TIM Automatic Output.
TIM_AutomaticOutput_Disable	Disables the TIM Automatic Output.

**Example:**

```
/* OSSR, OSSR, Automatic Output enable, Break, dead time and Lock
Level configuration*/
TIM_BDTRInitTypeDef TIM_BDTRInitStructure;

TIM_BDTRInitStructure.TIM_OSSRState = TIM_OSSRState_Enable;
TIM_BDTRInitStructure.TIM_OSSIState = TIM_OSSIState_Enable;
TIM_BDTRInitStructure.TIM_LOCKLevel = TIM_LOCKLevel_1;
TIM_BDTRInitStructure.TIM_DeadTime = 0x05;
TIM_BDTRInitStructure.TIM_Break = TIM_Break_Enable;
TIM_BDTRInitStructure.TIM_BreakPolarity = TIM_BreakPolarity_High;
TIM_BDTRInitStructure.TIM_AutomaticOutput =
TIM_AutomaticOutput_Enable;

TIM_BDTRConfig(TIM1, &TIM_BDTRInitStructure);
```

**19.2.10 TIM\_TimeBaseStructInit function**

[Table 499](#) describes the TIM\_TimeBaseStructInit function.

**Table 499. TIM\_TimeBaseStructInit function**

Function name	TIM_TimeBaseStructInit
Function prototype	void TIM_TimeBaseStructInit(TIM_TimeBaseInitTypeDef* TIM_TimeBaseInitStruct)
Behavior description	Fills each TIM_TimeBaseInitStruct member with its default value.
Input parameter	TIM_TimeBaseInitStruct: pointer to a TIM_TimeBaseInitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The TIM\_TimeBaseInitStruct members have the following default values:

**Table 500. TIM\_TimeBaseInitStruct default values**

Member	Default value
TIM_Period	0xFFFF
TIM_Prescaler	0x0000
TIM_CKD	TIM_CKD_DIV1
TIM_CounterMode	TIM_CounterMode_Up
TIM_RepetitionCounter	0x0000

**Example:**

```

/* The following example illustrates how to initialize a
TIM_TimeBaseInitTypeDef structure */
TIM_TimeBaseInitTypeDef TIM_TimeBaseInitStructure;
TIM_TimeBaseStructInit(& TIM_TimeBaseInitStructure);

```

**19.2.11 TIM\_OCStructInit function**

[Table 501](#) describes the TIM\_OCStructInit function.

**Table 501. TIM\_OCStructInit function**

Function name	TIM_OCStructInit
Function prototype	void TIM_OCStructInit(TIM_OCInitTypeDef* TIM_OCInitStruct)
Behavior description	Fills each TIM_OCInitStruct member with its default value.
Input parameter	TIM_OCInitStruct: pointer to a TIM_OCInitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The TIM\_OCInitStruct members have the following default values:

**Table 502. TIM\_OCInitStruct default values**

Member	Default value
TIM_OCMode	TIM_OCMode_Timing
TIM_OutputState	TIM_OutputState_Disable
TIM_OutputNState	TIM_OutputNState_Disable
TIM_Pulse	0x0000
TIM_OCPolarity	TIM_OCPolarity_High
TIM_OCNPolarity	TIM_OCNPolarity_High
TIM_OCIdleState	TIM_OCIdleState_Reset
TIM_OCNIIdleState	TIM_OCNIIdleState_Reset

**Example:**

```
/* The following example illustrates how to initialize a
TIM_OCInitTypeDef structure */
TIM_OCInitTypeDef TIM_OCInitStructure;
TIM_OCStructInit(& TIM_OCInitStructure);
```

**19.2.12 TIM\_ICStructInit function**

[Table 503](#) describes the TIM\_ICStructInit function.

**Table 503. TIM\_ICStructInit function**

Function name	TIM_ICStructInit
Function prototype	void TIM_ICStructInit(TIM_ICInitTypeDef* TIM_ICInitStruct)
Behavior description	Fills each TIM_ICInitStruct member with its default value.
Input parameter	TIM_ICInitStruct: pointer to a TIM_ICInitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The TIM\_ICInitStruct members have the following default values:

**Table 504. TIM\_ICInitStruct default values**

Member	Default value
TIM_Channel	TIM_Channel_1
TIM_ICSelection	TIM_ICSelection_DirectTI
TIM_ICPrescaler	TIM_ICPSC_DIV1
TIM_ICPolarity	TIM_ICPolarity_Rising
TIM_ICFilter	0x00

**Example:**

```
/* The following example illustrates how to initialize a
TIM_ICInitTypeDef structure */
TIM_ICInitTypeDef TIM_ICInitStructure;
TIM_ICStructInit(& TIM_ICInitStructure);
```

### 19.2.13 TIM\_BDTRStructInit function

Table 505 describes the TIM\_BDTRStructInit function.

**Table 505. TIM\_BDTRStructInit function**

Function name	TIM_BDTRStructInit
Function prototype	void TIM_BDTRStructInit(TIM_BDTRInitTypeDef* TIM_BDTRInitStruct)
Behavior description	Fills each TIM_BDTRInitStruct member with its default value.
Input parameter	TIM_BDTRInitStruct: pointer to a TIM_BDTRInitStruct structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The TIM\_BDTRInitStruct members have the following default values:

**Table 506. TIM\_BDTRInitStruct default values**

Member	Default value
TIM_OSSRState	TIM_OSSRState_Disable
TIM_OSSIState	TIM_OSSIState_Disable
TIM_LOCKLevel	TIM_LOCKLevel_OFF
TIM_DeadTime	0x00
TIM_Break	TIM_Break_Disable
TIM_BreakPolarity	TIM_BreakPolarity_Low
TIM_AutomaticOutput	TIM_AutomaticOutput_Disable

**Example:**

```
/* The following example illustrates how to initialize a
TIM_BDTRInitTypeDef structure */
TIM_BDTRInitTypeDef TIM_BDTRInitStructure;
TIM_BDTRStructInit(& TIM_BDTRInitStructure);
```

### 19.2.14 TIM\_Cmd function

*Table 507* describes the TIM\_Cmd function.

**Table 507. TIM\_Cmd function**

Function name	TIM_Cmd
Function prototype	void TIM_Cmd(TIM_TypeDef* TIMx, FunctionalState NewState)
Behavior description	Enables or disables the specified TIM peripheral.
Input parameter1	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Input parameter2	NewState: new state of the TIM peripheral. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the TIM counter */
TIM_Cmd(ENABLE);
```

### 19.2.15 TIM\_CtrlPWMOutputs function

*Table 508* describes the TIM\_CtrlPWMOutputs function.

**Table 508. TIM\_CtrlPWMOutputs function**

Function name	TIM_CtrlPWMOutputs
Function prototype	void TIM_CtrlPWMOutputs(TIM_TypeDef* TIMx, FunctionalState Newstate)
Behavior description	Enables or disables the TIM peripheral's main outputs.
Input parameter1	TIMx: where x can be 1 or 8 to select the TIM peripheral.
Input parameter2	NewState: new state of the TIM peripheral's main outputs. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the TIM8 peripheral Main Outputs. */
TIM_CtrlPWMOutputs(TIM8, ENABLE);
```

## 19.2.16 TIM\_ITConfig function

[Table 509](#) describes the TIM\_ITConfig function.

**Table 509. TIM\_ITConfig function**

Function name	TIM_ITConfig
Function prototype	void TIM_ITConfig(TIM_TypeDef* TIMx, u16 TIM_IT, FunctionalState NewState)
Behavior description	Enables or disables the specified TIM interrupts.
Input parameter1	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Input parameter2	TIM_IT: TIMx interrupt sources to be enabled or disabled. Refer to <a href="#">TIM_IT</a> for more details on the allowed values for this parameter.
Input parameter3	NewState: new state of the specified TIM interrupts. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### TIM\_IT

TIM\_IT enables or disables TIM interrupts. One or a combination of the following values can be used:

*Note: TIM6 and TIM7 can only generate an update interrupt. TIM\_IT\_COM and TIM\_IT\_Break are used only with TIM1 and TIM8.*

**Table 510. TIM\_IT values**

TIM_IT	Description
TIM_IT_Update	TIM Update Interrupt source
TIM_IT_CC1	TIM Capture/Compare 1 Interrupt source
TIM_IT_CC2	TIM Capture/Compare 2 Interrupt source
TIM_IT_CC3	TIM Capture/Compare 3 Interrupt source
TIM_IT_CC4	TIM Capture/Compare 4 Interrupt source
TIM_IT_COM	TIM COM Interrupt source
TIM_IT_Trigger	TIM Trigger Interrupt source
TIM_IT_Break	TIM Break Interrupt source

### Example:

```
/* Enables the TIM5 Capture Compare channel 1 Interrupt source */
TIM_ITConfig(TIM5, TIM_IT_CC1, ENABLE );
```

## 19.2.17 TIM\_GenerateEvent function

[Table 511](#) describes the TIM\_GenerateEvent function.

**Table 511. TIM\_GenerateEvent function**

Function name	TIM_GenerateEvent
Function prototype	void TIM_GenerateEvent(TIM_TypeDef* TIMx, u16 TIM_EventSource)
Behavior description	Configures the TIM event to be generated by software.
Input parameter1	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Input parameter2	TIM_EventSource: specifies the TIM software event sources. Refer to <a href="#">TIM_EventSource</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### TIM\_EventSource

The TIM event software source can be selected by using one or a combination of the values provided in [Table 512](#).

*Note: TIM6 and TIM7 can only generate an update event. TIM\_EventSource\_COM and TIM\_EventSource\_Break are used only with TIM1 and TIM8.*

**Table 512. TIM\_EventSource values**

TIM_EventSource	Description
TIM_EventSource_Update	TIM update event source
TIM_EventSource_CC1	TIM Capture/Compare 1 event source
TIM_EventSource_CC2	TIM Capture/Compare 2 event source
TIM_EventSource_CC3	TIM Capture/Compare 3 event source
TIM_EventSource_CC4	TIM Capture/Compare 4 event source
TIM_EventSource_COM	TIM COM event source
TIM_EventSource_Trigger	TIM Trigger event source
TIM_EventSource_Break	TIM Break event source

### Example:

```
/* Selects the Capture compare4 software event generation for TIM4
*/
TIM_GenerateEvent(TIM4, TIM_EventSource_CC4);
```

## 19.2.18 TIM\_DMAConfig function

[Table 513](#) describes the TIM\_DMAConfig function.

**Table 513. TIM\_DMAConfig function**

Function name	TIM_DMAConfig
Function prototype	<code>void TIM_DMAConfig(TIM_TypeDef* TIMx, u8 TIM_DMABase, u16 TIM_DMBurstLength)</code>
Behavior description	Configures the TIM's DMA interface.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_DMABase: DMA Base address. Refer to <a href="#">TIM_DMABase</a> for more details on the allowed values for this parameter.
Input parameter3	TIM_DMBurstLength: DMA Burst length. Refer to <a href="#">TIM_DMBurstLength</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### TIM\_DMABase

TIM\_DMABase selects the TIM DMA's base address (see [Table 514](#)).

**Table 514. TIM\_DMABase values**

TIM_DMABase	Description
TIM_DMABase_CR1	CR1 register used as DMA Base
TIM_DMABase_CR2	CR2 register used as DMA Base
TIM_DMABase_SMCR	SMCR register used as DMA Base
TIM_DMABase_DIER	DIER register used as DMA Base
TIM_DMABase_SR	SR register used as DMA Base
TIM_DMABase_EGR	EGR register used as DMA Base
TIM_DMABase_CCMR1	CCMR1 register used as DMA Base
TIM_DMABase_CCMR2	CCMR2 register used as DMA Base
TIM_DMABase_CCER	CCER register used as DMA Base
TIM_DMABase_CNT	CNT register used as DMA Base
TIM_DMABase_PSC	PSC register used as DMA Base
TIM_DMABase_ARR	ARR register used as DMA Base
TIM_DMABase_RCR	RCR register used as DMA Base
TIM_DMABase_CCR1	CCR1 register used as DMA Base
TIM_DMABase_CCR2	CCR2 register used as DMA Base



**Table 514. TIM\_DMABase values (continued)**

TIM_DMABase	Description
TIM_DMABase_CCR3	CCR3 register used as DMA Base
TIM_DMABase_CCR4	CCR4 register used as DMA Base
TIM_DMABase_BDTR	BDTR register used as DMA Base
TIM_DMABase_DCR	DCR register used as DMA Base

**TIM\_DMABurstLength**

TIM\_DMABurstLength configures the TIM DMA burst length as shown in [Table 515](#).

**Table 515. TIM\_DMABurstLength values**

TIM_DMABurstLength	Description
TIM_DMABurstLength_1Byte	DMA Burst length 1 byte
TIM_DMABurstLength_2Bytes	DMA Burst length 2 bytes
TIM_DMABurstLength_3Bytes	DMA Burst length 3 bytes
TIM_DMABurstLength_4Bytes	DMA Burst length 4 bytes
TIM_DMABurstLength_5Bytes	DMA Burst length 5 bytes
TIM_DMABurstLength_6Bytes	DMA Burst length 6 bytes
TIM_DMABurstLength_7Bytes	DMA Burst length 7 bytes
TIM_DMABurstLength_8Bytes	DMA Burst length 8 bytes
TIM_DMABurstLength_9Bytes	DMA Burst length 9 bytes
TIM_DMABurstLength_10Bytes	DMA Burst length 10 bytes
TIM_DMABurstLength_11Bytes	DMA Burst length 11 bytes
TIM_DMABurstLength_12Bytes	DMA Burst length 12 bytes
TIM_DMABurstLength_13Bytes	DMA Burst length 13 bytes
TIM_DMABurstLength_14Bytes	DMA Burst length 14 bytes
TIM_DMABurstLength_15Bytes	DMA Burst length 15 bytes
TIM_DMABurstLength_16Bytes	DMA Burst length 16 bytes
TIM_DMABurstLength_17Bytes	DMA Burst length 17 bytes
TIM_DMABurstLength_18Bytes	DMA Burst length 18 bytes

**Example:**

```
/* Configures the TIM1 DMA Interface to transfer 1 byte and to use
the CCR1 as base address */
TIM_DMAConfig(TIM1, TIM_DMABase_CCR1, TIM_DMABurstLength_1Byte)
```

### 19.2.19 TIM\_DMAMCmd function

[Table 516](#) describes the TIM\_DMAMCmd function.

**Table 516. TIM\_DMAMCmd function**

Function name	TIM_DMAMCmd
Function prototype	void TIM_DMAMCmd(TIM_TypeDef* TIMx, u16 TIM_DMASource, FunctionalState Newstate)
Behavior description	Enables or disables the TIM DMA Requests.
Input parameter1	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Input parameter2	TIM_DMASource: DMA Request sources. Refer to <a href="#">TIM_DMASource</a> for more details on the allowed values for this parameter.
Input parameter3	NewState: new state of the DMA Request sources. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### TIM\_DMASource

TIM\_DMASource selects the TIM DMA request source. One or a combination of the following values can be used:

**Table 517. TIM\_DMASource values**

TIM_DMASource	Description
TIM_DMA_Update	TIM Update DMA source
TIM_DMA_CC1	TIM Capture/Compare 1 DMA source
TIM_DMA_CC2	TIM Capture/Compare 2 DMA source
TIM_DMA_CC3	TIM Capture/Compare 3 DMA source
TIM_DMA_CC4	TIM Capture/Compare 4 DMA source
TIM_DMA_COM	TIM COM DMA source
TIM_DMA_Trigger	TIM Trigger DMA source

[Table 518](#) shows the DMA requests for each timer.

**Table 518. TIM DMA requests**

Requests	TIM1	TIM2	TIM3	TIM4	TIM5	TIM6	TIM7	TIM8
TIM_DMA_Update	x	x	x	x	x	x	x	x
TIM_DMA_CC1	x	x	x	x	x			x
TIM_DMA_CC2	x	x		x	x			x
TIM_DMA_CC2	x	x	x	x	x			x
TIM_DMA_CC3	x	x	x		x			x
TIM_DMA_CC4	x							x
TIM_DMA_Trigger	x		x	x	x			x

**Example:**

```
/* TIM5 Capture Compare 1 DMA Request Configuration */
TIM_DMACmd(TIM5, TIM_DMA_CC1, ENABLE);
```

**19.2.20 TIM\_InternalClockConfig function**

*Table 519* describes the TIM\_InternalClockConfig function.

**Table 519. TIM\_InternalClockConfig function**

Function name	TIM_InternalClockConfig
Function prototype	void TIM_InternalClockConfig(TIM_TypeDef* TIMx)
Behavior description	Configures the TIM internal clock
Input parameter	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the internal clock for TIM2 */
TIM_InternalClockConfig(TIM2);
```

### 19.2.21 TIM\_ITRxExternalClockConfig function

[Table 520](#) describes the TIM\_ITRxExternalClockConfig function.

**Table 520. TIM\_ITRxExternalClockConfig function**

Function name	TIM_ITRxExternalClockConfig
Function prototype	void TIM_ITRxExternalClockConfig(TIM_TypeDef* TIMx, u16 TIM_InputTriggerSource)
Behavior description	Configures the TIM's internal trigger as the external clock.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_InputTriggerSource: input trigger source. Refer to <a href="#">TIM_InputTriggerSource</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### TIM\_InputTriggerSource

TIM\_InputTriggerSource selects the TIM Input trigger (see [Table 521](#)).

**Table 521. TIM\_InputTriggerSource values**

TIM_InputTriggerSource	Description
TIM_TS_ITR0	TIM Internal Trigger 0
TIM_TS_ITR1	TIM Internal Trigger 1
TIM_TS_ITR2	TIM Internal Trigger 2
TIM_TS_ITR3	TIM Internal Trigger 3

#### Example:

```
/* TIM1 internal trigger 3 used as clock source */
TIM_ITRxExternalClockConfig(TIM1, TIM_TS_ITR3);
```

## 19.2.22 TIM\_TlxEternalClockConfig function

Table 522 describes the TIM\_TlxEternalClockConfig function.

**Table 522. TIM\_TlxEternalClockConfig function**

Function name	TIM_TlxEternalClockConfig
Function prototype	void TIM_TlxEternalClockConfig(TIM_TypeDef* TIMx, u16 TIM_TlxEternalCLKSource, u16 TIM_ICPolarity, u16 ICFilter)
Behavior description	Configures the TIM trigger as the external clock.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_TlxEternalCLKSource: Trigger source. Refer to <a href="#">TIM_TlxEternalCLKSource</a> for more details on the allowed values for this parameter.
Input parameter3	TIM_ICPolarity: TI polarity. Refer to <a href="#">TIM_ICPolarity</a> for more details on the allowed values for this parameter.
Input parameter4	ICFilter: Specifies the input capture filter. This member can be a value between 0x0 and 0xF.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### TIM\_TlxEternalCLKSource

TIM\_TlxEternalCLKSource selects the Tlx external clock source of the TIM. One of the following values can be used:

**Table 523. TIM\_TlxEternalCLKSource values**

TIM_TlxEternalCLKSource	Description
TIM_TS_TI1FP1	IC1 is mapped on TI1.
TIM_TS_TI2FP2	IC2 is mapped on TI2.
TIM_TS_TI1F_ED	IC1 is mapped on TI1: edge detector is used

#### Example:

```
/* Selects the TI1 as clock for TIM1: the external clock is
connected to TI1 input pin, the rising edge is the active edge and
no filter sampling is done (ICFilter = 0) */
TIM_TlxEternalClockConfig(TIM1, TIM_TS_TI1FP1,
TIM_ICPolarity_Rising, 0);
```

### 19.2.23 TIM\_ETRClockMode1Config function

[Table 524](#) describes the TIM\_ETRClockMode1Config function.

**Table 524. TIM\_ETRClockMode1Config function**

Function name	TIM_ETRClockMode1Config
Function prototype	<code>void TIM_ETRClockMode1Config(TIM_TypeDef* TIMx, u16 TIM_ExtTRGPrescaler, u16 TIM_ExtTRGPolarity, u16 ExtTRGFilter)</code>
Behavior description	Configures the TIM's External clock Mode1.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_ExtTRGPrescaler: external trigger prescaler. Refer to <a href="#">TIM_ExtTRGPrescaler</a> for more details on the allowed values for this parameter.
Input parameter3	TIM_ExtTRGPolarity: external clock polarity. Refer to <a href="#">TIM_ExtTRGPolarity</a> for more details on the allowed values for this parameter.
Input parameter4	ExtTRGFilter: Specifies the external trigger filter. This member can assume a value between 0x0 and 0xF.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### TIM\_ExtTRGPrescaler

TIM\_ExtTRGPrescaler selects the external trigger prescaler. This member can be set to one of the following values:

**Table 525. TIM\_ExtTRGPrescaler values**

TIM_ExtTRGPrescaler	Description
TIM_ExtTRGPSC_OFF	ETRP Prescaler OFF.
TIM_ExtTRGPSC_DIV2	ETRP frequency divided by 2.
TIM_ExtTRGPSC_DIV4	ETRP frequency divided by 4.
TIM_ExtTRGPSC_DIV8	ETRP frequency divided by 8.

#### TIM\_ExtTRGPolarity

TIM\_ExtTRGPolarity configures the external trigger polarity. This member can be set to one of the following values:

**Table 526. TIM\_ExtTRGPolarity values**

TIM_ExtTRGPolarity	Description
TIM_ExtTRGPolarity_Inverted	External trigger polarity inverted: active low or falling edge active.
TIM_ExtTRGPolarity_NonInverted	External trigger polarity noninverted: active high or rising edge active.

**Example:**

```
/* Selects the external clock Mode 1 for TIM1: the external clock is
connected to ETR input pin, the rising edge is the active edge, no
filter sampling is done (ExtTRGFilter = 0) and the prescaler is
fixed to TIM_ExtTRGPSC_DIV2 */
TIM_ExternalCLK1Config(TIM1, TIM_ExtTRGPSC_DIV2,
TIM_ExtTRGPolarity_NonInverted, 0x0);
```

**19.2.24 TIM\_ETRClockMode2Config function**

[Table 527](#) describes the TIM\_ETRClockMode2Config function.

**Table 527. TIM\_ETRClockMode2Config function**

Function name	TIM_ETRClockMode2Config
Function prototype	void TIM_ETRClockMode2Config(TIM_TypeDef* TIMx, u16 TIM_ExtTRGPrescaler, u16 TIM_ExtTRGPolarity, u16 ExtTRGFilter)
Behavior description	Configures the TIM's external clock mode2.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_ExtTRGPrescaler: specifies the external trigger prescaler. Refer to <a href="#">TIM_ExtTRGPrescaler</a> for more details on the allowed values for this parameter.
Input parameter3	TIM_ExtTRGPolarity: specifies the external clock polarity. Refer to <a href="#">TIM_ExtTRGPolarity</a> for more details on the allowed values for this parameter.
Input parameter4	ExtTRGFilter: specifies the external trigger Filter. This member can assume a value between 0x0 and 0xF.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the external clock Mode 2 for TIM1: the external clock is
connected to ETR input pin, the rising edge is the active edge, no
filter sampling is done (ExtTRGFilter = 0) and the prescaler is
fixed to TIM_ExtTRGPSC_DIV2 */
TIM_ExternalCLK2Config(TIM1, TIM_ExtTRGPSC_DIV2,
TIM_ExtTRGPolarity_NonInverted, 0x0);
```

### 19.2.25 TIM\_ETRConfig

[Table 527](#) describes the TIM\_ETRConfig function.

**Table 528. TIM\_ETRConfig function**

Function name	TIM_ETRConfig
Function prototype	void TIM_ETRConfig(TIM_TypeDef* TIMx, u16 TIM_ExtTRGPrescaler, u16 TIM_ExtTRGPolarity, u8 ExtTRGFilter)
Behavior description	Configures the TIM's external trigger (ETR).
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_ExtTRGPrescaler: specifies the external trigger prescaler. Refer to <a href="#">TIM_ExtTRGPrescaler</a> for more details on the allowed values for this parameter.
Input parameter3	TIM_ExtTRGPolarity: specifies the external clock polarity. Refer to <a href="#">TIM_ExtTRGPolarity</a> for more details on the allowed values for this parameter.
Input parameter4	ExtTRGFilter: specifies the external trigger Filter. This member can assume a value between 0x0 and 0xF.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Configure the External Trigger (ETR) for TIM1: the rising edge is
the active edge, no filter sampling is done (ExtTRGFilter = 0) and
the prescaler is fixed to TIM_ExtTRGPSC_DIV2 */
TIM_ExternalCLK2Config(TIM1, TIM_ExtTRGPSC_DIV2,
TIM_ExtTRGPolarity_NonInverted, 0x0);
```



## 19.2.26 TIM\_PrescalerConfig function

[Table 529](#) describes the TIM\_PrescalerConfig function.

**Table 529. TIM\_PrescalerConfig function**

Function name	TIM_PrescalerConfig
Function prototype	void TIM_PrescalerConfig(TIM_TypeDef* TIMx, u16 Prescaler, u16 TIM_PSCReloadMode)
Behavior description	Configures the TIM prescaler.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	Prescaler: new TIM prescaler value.
Input parameter3	TIM_PSCReloadMode: TIM prescaler reload mode. Refer to <a href="#">TIM_PSCReloadMode</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### TIM\_PSCReloadMode

To select the TIM Prescaler Reload mode use one of the following values:

**Table 530. TIM\_PSCReloadMode values**

TIM_PSCReloadMode	Description
TIM_PSCReloadMode_Update	The Prescaler is loaded at the update event.
TIM_PSCReloadMode_Immediate	The Prescaler is loaded immediately.

#### Example:

```
/* Sets the TIM1 new Prescaler value */
u16 TIMPrescaler = 0xFF00;
TIM_SetPrescaler(TIM1, TIMPrescaler, TIM_PSCReloadMode_Update);
```

### 19.2.27 TIM\_CounterModeConfig function

[Table 531](#) describes the TIM\_CounterModeConfig function.

**Table 531. TIM\_CounterModeConfig function**

Function name	TIM_CounterModeConfig
Function prototype	void TIM_CounterModeConfig(TIM_TypeDef* TIMx, u16 TIM_CounterMode)
Behavior description	Specifies the TIM counter mode to be used.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_CounterMode: counter mode to be used. Refer to <a href="#">TIM_CounterMode</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the Center Aligned counter Mode 1 for the TIM1 */
TIM_CounterModeConfig(TIM1, TIM_Counter_CenterAligned1);
```

### 19.2.28 TIM\_SelectInputTrigger function

[Table 532](#) describes the TIM\_SelectInputTrigger function.

**Table 532. TIM\_SelectInputTrigger function**

Function name	TIM_SelectInputTrigger
Function prototype	void TIM_SelectInputTrigger(TIM_TypeDef* TIMx, u16 TIM_InputTriggerSource)
Behavior description	Selects the TIM's input trigger source.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_InputTriggerSource: input trigger source. Refer to <a href="#">TIM_InputTriggerSource</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**TIM\_InputTriggerSource**

TIM\_InputTriggerSource selects the TIM's input trigger source. This member can be set to one of the following values:

**Table 533. TIM\_InputTriggerSource values**

TIM_InputTriggerSource	Description
TIM_TS_ITR0	TIM Internal Trigger 0.
TIM_TS_ITR1	TIM Internal Trigger 1.
TIM_TS_ITR2	TIM Internal Trigger 2.
TIM_TS_ITR3	TIM Internal Trigger 3.
TIM_TS_TI1F_ED	TIM TI1 Edge Detector.
TIM_TS_TI1FP1	TIM Filtered Timer Input 1.
TIM_TS_TI2FP2	TIM Filtered Timer Input 2.
TIM_TS_ETRF	TIM External Trigger input.

**Example:**

```
/* Selects the Internal Trigger 3 as input trigger for TIM1 */
void TIM_SelectInputTrigger(TIM1, TIM_TS_ITR3);
```

**19.2.29 TIM\_EncoderInterfaceConfig function**

[Table 534](#) describes the TIM\_EncoderInterfaceConfig function.

**Table 534. TIM\_EncoderInterfaceConfig function**

Function name	TIM_EncoderInterfaceConfig
Function prototype	void TIM_EncoderInterfaceConfig(TIM_TypeDef* TIMx, u16 TIM_EncoderMode, u16 TIM_IC1Polarity, u16 TIM_IC2Polarity)
Behavior description	Configures the TIM encoder interface.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_EncoderMode: TIM encoder mode. Refer to <a href="#">TIM_EncoderMode</a> for more details on the allowed values for this parameter.
Input parameter3	TIM_IC1Polarity: TI1 Polarity. Refer to <a href="#">TIM_ICPolarity</a> for more details on the allowed values for this parameter.
Input parameter4	TIM_IC2Polarity: TI2 Polarity. Refer to <a href="#">TIM_ICPolarity</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**TIM\_EncoderMode**

TIM\_EncoderMode selects the TIMx encoder mode (see [Table 535](#)).

**Table 535. TIM\_EncoderMode definition**

TIM_EncoderMode	Description
TIM_EncoderMode_TI1	TIM encoder mode 1 is used.
TIM_EncoderMode_TI2	TIM encoder mode 2 is used.
TIM_EncoderMode_TI12	TIM encoder mode 3 is used.

**Example:**

```
/* uses of the TIM1 Encoder interface */
TIM_EncoderInterfaceConfig(TIM1, TIM_EncoderMode_1,
TIM_ICPolarity_Rising,
TIM_ICPolarity_Rising);
```

**19.2.30 TIM\_ForcedOC1Config function**

[Table 536](#) describes the TIM\_ForcedOC1Config function.

**Table 536. TIM\_ForcedOC1Config function**

Function name	TIM_ForcedOC1Config
Function prototype	void TIM_ForcedOC1Config(TIM_TypeDef* TIMx, u16 TIM_ForcedAction)
Behavior description	Forces the TIM Channel 1 output waveform to active or inactive level.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_ForcedAction: specified action to be forced on the output waveform. Refer to <a href="#">TIM_ForcedAction</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**TIM\_ForcedAction**

The forced actions that can be used are listed in [Table 537](#).

**Table 537. TIM\_ForcedAction values**

TIM_ForcedAction	Description
TIM_ForcedAction_Active	Forces active level on OCxREF.
TIM_ForcedAction_InActive	Forces inactive level on OCxREF.

**Example:**

```
/* Forces the TIM1 Channel1 Output to the active level */
TIM_ForcedOC1Config(TIM1, TIM_ForcedAction_Active);
```

### 19.2.31 TIM\_ForceOC2Config function

[Table 538](#) describes the TIM\_ForceOC2Config function.

**Table 538. TIM\_ForceOC2Config function**

Function name	TIM_ForceOC2Config
Function prototype	void TIM_ForceOC2Config(TIM_TypeDef* TIMx, u16 TIM_ForceAction)
Behavior description	Forces the TIM Channel2 output waveform to active or inactive level.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_ForceAction: specifies the action to be forced on the output waveform. Refer to <a href="#">TIM_ForceAction</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Forces the TIM1 Channel2 Output to the active level */
TIM_ForceOC2Config(TIM1, TIM_ForceAction_Active);
```

### 19.2.32 TIM\_ForceOC3Config function

[Table 539](#) describes the TIM\_ForceOC3Config function.

**Table 539. TIM\_ForceOC3Config function**

Function name	TIM_ForceOC3Config
Function prototype	void TIM_ForceOC3Config(TIM_TypeDef* TIMx, u16 TIM_ForceAction)
Behavior description	Forces the TIM Channel3 output waveform to active or inactive level.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_ForceAction: specifies the action to be forced on the output waveform. Refer to section <a href="#">TIM_ForceAction on page 372</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Forces the TIM1 Channel3 Output to the active level */
TIM_ForceOC3Config(TIM1, TIM_ForceAction_Active);
```

### 19.2.33 TIM\_ForceOC4Config function

[Table 540](#) describes the TIM\_ForceOC4Config function.

**Table 540. TIM\_ForceOC4Config function**

Function name	TIM_ForceOC4Config
Function prototype	void TIM_ForceOC4Config(TIM_TypeDef* TIMx, u16 TIM_ForceAction)
Behavior description	Forces the TIM Channel4 output waveform to active or inactive level.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_ForceAction: specifies the action to be forced on the output waveform. Refer to <a href="#">TIM_ForceAction</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Forces the TIM1 Channel4 Output to the active level */
TIM_ForceOC4Config(TIM1, TIM_ForceAction_Active);
```

### 19.2.34 TIM\_ARRPreloadConfig function

[Table 541](#) describes the TIM\_ARRPreloadConfig function.

**Table 541. TIM\_ARRPreloadConfig function**

Function name	TIM_ARRPreloadConfig
Function prototype	void TIM_ARRPreloadConfig(TIM_TypeDef* TIMx, FunctionalState Newstate)
Behavior description	Enables or disables the TIM peripheral Preload register on ARR.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter3	NewState: new state of the ARPE bit in the TIM_CR1 register. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the TIM1 Preload on ARR Register */
TIM_ARRPreloadConfig(TIM1, ENABLE);
```

### 19.2.35 TIM\_SelectCOM function

[Table 542](#) describes the TIM\_SelectCOM function.

**Table 542. TIM\_SelectCOM function**

Function name	TIM_SelectCOM
Function prototype	void TIM_SelectCOM(TIM_TypeDef* TIMx, FunctionalState Newstate)
Behavior description	Selects the TIM peripheral commutation event.
Input parameter1	TIMx: where x can be 1 or 8 to select the TIM peripheral.
Input parameter2	Newstate: new state of the commutation event. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the TIM1 Commutation event */
TIM_SelectCOM(TIM1, ENABLE);
```

### 19.2.36 TIM\_SelectCCDMA function

[Table 543](#) describes the TIM\_SelectCCDMA function.

**Table 543. TIM\_SelectCCDMA function**

Function name	TIM_SelectCCDMA
Function prototype	void TIM_SelectCCDMA(TIM_TypeDef* TIMx, FunctionalState Newstate)
Behavior description	Selects the TIM peripheral Capture Compare DMA source.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter3	NewState: new state of the Capture Compare DMA source. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the TIM1 Capture Compare DMA source */
TIM_SelectCCDMA(TIM1, ENABLE);
```

### 19.2.37 TIM\_CCPreloadControl function

[Table 544](#) describes the TIM\_CCPreloadControl function.

**Table 544. TIM\_CCPreloadControl function**

Function name	TIM_CCPreloadControl
Function prototype	void TIM_CCPreloadControl(TIM_TypeDef* TIMx, FunctionalState Newstate)
Behavior description	Sets or resets the TIM peripheral Capture Compare Preload Control bit.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	Newstate: new state of the Capture Compare Preload Control bit. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the TIM1 Capture Compare Preload Control */
TIM_CCPreloadControl(TIM1, ENABLE);
```

### 19.2.38 TIM\_OC1PreloadConfig function

[Table 545](#) describes the TIM\_OC1PreloadConfig function.

**Table 545. TIM\_OC1PreloadConfig function**

Function name	TIM_OC1PreloadConfig
Function prototype	void TIM_OC1PreloadConfig(TIM_TypeDef* TIMx, u16 TIM_OCPreload)
Behavior description	Enables or disables the TIM Preload register on CCR1.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCPreload: Output Compare Preload state. Refer to <a href="#">TIM_OCPreload</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None



**TIM\_OCPreload**

The Output Compare Preload states are listed in [Table 546](#).

**Table 546. TIM\_OCPreload states**

TIM_OCPreload	Description
TIM_OCPreload_Enable	TIM Preload register on CCR1 enable.
TIM_OCPreload_Disable	TIM Preload register on CCR1 disable.

**Example:**

```
/* Enables the TIM1 Preload on CC1 Register */
TIM_OC1PreloadConfig(TIM1, TIM_OCPreload_Enable);
```

**19.2.39 TIM\_OC2PreloadConfig function**

[Table 547](#) describes the TIM\_OC2PreloadConfig function.

**Table 547. TIM\_OC2PreloadConfig function**

Function name	TIM_OC2PreloadConfig
Function prototype	void TIM_OC2PreloadConfig(TIM_TypeDef* TIMx, u16 TIM_OCPreload)
Behavior description	Enables or disables the TIM Preload register on CCR2.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCPreload: Output Compare Preload state. Refer to <a href="#">TIM_OCPreload</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the TIM1 Preload on CC2 Register */
TIM_OC2PreloadConfig(TIM1, TIM_OCPreload_Enable);
```

### 19.2.40 TIM\_OC3PreloadConfig function

[Table 548](#) describes the TIM\_OC3PreloadConfig function.

**Table 548. TIM\_OC3PreloadConfig function**

Function name	TIM_OC3PreloadConfig
Function prototype	void TIM_OC3PreloadConfig(TIM_TypeDef* TIMx, u16 TIM_OCPreload)
Behavior description	Enables or disables the TIM Preload register on CCR3.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCPreload: specifies the Output Compare Preload state. Refer to <a href="#">TIM_OCPreload</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the TIM1 Preload on CC3 Register */
TIM_OC3PreloadConfig(TIM1, TIM_OCPreload_Enable);
```

### 19.2.41 TIM\_OC4PreloadConfig function

[Table 549](#) describes the TIM\_OC4PreloadConfig function.

**Table 549. TIM\_OC4PreloadConfig function**

Function name	TIM_OC4PreloadConfig
Function prototype	void TIM_OC4PreloadConfig(TIM_TypeDef* TIMx, u16 TIM_OCPreload)
Behavior description	Enables or disables the TIM Preload register on CCR4.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCPreload: Output Compare Preload state. Refer to <a href="#">TIM_OCPreload</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the TIM1 Preload on CC4 Register */
TIM_OC4PreloadConfig(TIM1, TIM_OCPreload_Enable);
```

## 19.2.42 TIM\_OC1FastConfig function

[Table 550](#) describes the TIM\_OC1FastConfig function.

**Table 550. TIM\_OC1FastConfig function**

Function name	TIM_OC1FastConfig
Function prototype	void TIM_OC1FastConfig(TIM_TypeDef* TIMx, u16 TIM_OCFast)
Behavior description	Configures the TIM Output Compare 1 Fast feature.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCFast: Output Compare fast feature state. Refer to <a href="#">TIM_OCFast</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### TIM\_OCFast

The Output Compare Preload states are listed in [Table 551](#).

**Table 551. TIM\_OCFast states**

TIM_OCFast	Description
TIM_OCFast_Enable	TIM Output Compare Fast capability enable.
TIM_OCFast_Disable	TIM Output Compare Fast capability disable.

#### Example:

```
/* Use the TIM1 OC1 in fast Mode */
TIM_OC1FastConfig(TIM1, TIM_OCFast_Enable);
```

### 19.2.43 TIM\_OC2FastConfig function

[Table 552](#) describes the TIM\_OC2FastConfig function.

**Table 552. TIM\_OC2FastConfig function**

Function name	TIM_OC2FastConfig
Function prototype	void TIM_OC2FastConfig(TIM_TypeDef* TIMx, u16 TIM_OCFast)
Behavior description	Configures the TIM Output Compare 2 Fast feature.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCFast: Output Compare fast feature state. Refer to <a href="#">TIM_OCFast</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Use the TIM1 OC2 in fast Mode */
TIM_OC2FastConfig(TIM1, TIM_OCFast_Enable);
```

### 19.2.44 TIM\_OC3FastConfig function

[Table 553](#) describes the TIM\_OC3FastConfig function.

**Table 553. TIM\_OC3FastConfig function**

Function name	TIM_OC3FastConfig
Function prototype	void TIM_OC3FastConfig(TIM_TypeDef* TIMx, u16 TIM_OCFast)
Behavior description	Configures the TIM Output Compare 3 Fast feature.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCFast: Output Compare fast feature state. Refer to <a href="#">TIM_OCFast</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Use the TIM1 OC3 in fast Mode */
TIM_OC3FastConfig(TIM1, TIM_OCFast_Enable);
```

## 19.2.45 TIM\_OC4FastConfig function

[Table 554](#) describes the TIM\_OC4FastConfig function.

**Table 554. TIM\_OC4FastConfig function**

Function name	TIM_OC4FastConfig
Function prototype	void TIM_OC4FastConfig(TIM_TypeDef* TIMx, u16 TIM_OCFast)
Behavior description	Configures the TIM Output Compare 4 Fast feature.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCFast: specifies the Output Compare fast feature state. Refer to <a href="#">TIM_OCFast</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Use the TIM1 OC4 in fast Mode */
TIM_OC4FastConfig(TIM1, TIM_OCFast_Enable);
```

## 19.2.46 TIM\_ClearOC1Ref

[Table 555](#) describes the TIM\_ClearOC1Ref function.

**Table 555. TIM\_ClearOC1Ref function**

Function name	TIM_ClearOC1Ref
Function prototype	void TIM_ClearOC1Ref(TIM_TypeDef* TIMx, u16 TIM_OCClear)
Behavior description	Clears or safeguards the OCREF1 signal on an external event.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCClear: new state of the Output Compare Clear Enable Bit. Refer to <a href="#">TIM_OCClear</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**TIM\_OCClear**

The values of the Output Compare Reference Clear bit that can be used are listed in [Table 556](#):

**Table 556. TIM\_OCClear**

TIM_OCClear	Description
TIM_OCClear_Enable	TIMx Output Compare Clear enable.
TIM_OCClear_Disable	TIMx Output Compare Clear disable.

**Example:**

```
/* Enable the TIM1 Channel1 Output Compare Reference clear bit */
TIM_ClearOC1Ref(TIM1, TIM_OCClear_Enable);
```

**19.2.47 TIM\_ClearOC2Ref**

[Table 557](#) describes the TIM\_ClearOC2Ref function.

**Table 557. TIM\_ClearOC2Ref function**

Function name	TIM_ClearOC2Ref
Function prototype	void TIM_ClearOC2Ref(TIM_TypeDef* TIMx, u16 TIM_OCClear)
Behavior description	Clears or safeguards the OCREF2 signal on an external event.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCClear: new state of the Output Compare Clear Enable Bit. Refer to <a href="#">TIM_OCClear</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the TIM1 Channel2 Output Compare Reference clear bit */
TIM_ClearOC2Ref(TIM1, TIM_OCClear_Enable);
```

**19.2.48 TIM\_ClearOC3Ref**

[Table 558](#) describes the TIM\_ClearOC3Ref function.

**Table 558. TIM\_ClearOC3Ref function**

Function name	TIM_ClearOC3Ref
Function prototype	void TIM_ClearOC3Ref(TIM_TypeDef* TIMx, u16 TIM_OCClear)
Behavior description	Clears or safeguards the OCREF3 signal on an external event.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCClear: new state of the Output Compare Clear Enable Bit. Refer to <a href="#">TIM_OCClear</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the TIM1 Channel3 Ouput Compare Refence clear bit */
TIM_ClearOC3Ref(TIM1, TIM_OCClear_Enable);
```

**19.2.49 TIM\_ClearOC4Ref**

[Table 559](#) describes the TIM\_ClearOC4Ref function.

**Table 559. TIM\_ClearOC4Ref function**

Function name	TIM_ClearOC4Ref
Function prototype	void TIM_ClearOC4Ref(TIM_TypeDef* TIMx, u16 TIM_OCClear)
Behavior description	Clears or safeguards the OCREF4 signal on an external event.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCClear: new state of the Output Compare Clear Enable Bit. Refer to <a href="#">TIM_OCClear</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the TIM1 Channel4 Ouput Compare Refence clear bit */
TIM_ClearOC4Ref(TIM1, TIM_OCClear_Enable);
```

### 19.2.50 TIM\_OC1PolarityConfig function

[Table 560](#) describes the TIM\_OC1PolarityConfig function.

**Table 560. TIM\_OC1PolarityConfig function**

Function name	TIM_OC1PolarityConfig
Function prototype	void TIM_OC1PolarityConfig(TIM_TypeDef* TIMx, u16 TIM_OCPolarity)
Behavior description	Configures the TIM Channel 1 polarity.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCPolarity: Output compare polarity. Refer to <a href="#">TIM_OCPolarity</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### TIM\_OCPolarity

TIM\_OCPolarity selects the TIM polarity (see [Table 561](#)).

**Table 561. TIM\_OCPolarity values**

TIM_OCPolarity	Description
TIM_OCPolarity_High	Sets the TIM Output Polarity to high.
TIM_OCPolarity_Low	Sets the TIM Output Polarity to low.

#### Example:

```
/* Selects the Polarity high for TIM1 channel 1 output compare */
TIM_OC1PolarityConfig(TIM1, TIM_OCPolarity_High);
```



### 19.2.51 TIM\_OC1NPolarityConfig function

[Table 562](#) describes the TIM\_OC1NPolarityConfig function.

**Table 562. TIM\_OC1NPolarityConfig function**

Function name	TIM_OC1NPolarityConfig
Function prototype	void TIM_OC1NPolarityConfig(TIM_TypeDef* TIMx, u16 TIM_OCNPolarity)
Behavior description	Configures the TIM Channel 1N polarity.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCNPolarity: Output compare N polarity. Refer to <a href="#">TIM_OCPolarity</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the Polarity high for TIM1 channel 1N output compare */
TIM_OC1NPolarityConfig(TIM1, TIM_OCNPolarity_High);
```

### 19.2.52 TIM\_OC2PolarityConfig function

[Table 563](#) describes the TIM\_OC2PolarityConfig function.

**Table 563. TIM\_OC2PolarityConfig function**

Function name	TIM_OC2PolarityConfig
Function prototype	void TIM_OC2PolarityConfig(TIM_TypeDef* TIMx, u16 TIM_OCPolarity)
Behavior description	Configures the TIM Channel 2 polarity.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCPolarity: Output compare polarity. Refer to <a href="#">TIM_OCPolarity</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the Polarity high for TIM1 channel 2 output compare */
TIM_OC2PolarityConfig(TIM1, TIM_OCPolarity_High);
```

### 19.2.53 TIM\_OC2NPolarityConfig function

[Table 564](#) describes the TIM\_OC2NPolarityConfig function.

**Table 564. TIM\_OC2NPolarityConfig function**

Function name	TIM_OC2NPolarityConfig
Function prototype	void TIM_OC2NPolarityConfig(TIM_TypeDef* TIMx, u16 TIM_OCNPolarity)
Behavior description	Configures the TIM Channel 2N polarity.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCNPolarity: Output compare N polarity. Refer to <a href="#">TIM_OCPolarity</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the Polarity high for TIM1 channel 2N output compare */
TIM_OC2NPolarityConfig(TIM1, TIM_OCNPolarity_High);
```

### 19.2.54 TIM\_OC3PolarityConfig function

[Table 565](#) describes the TIM\_OC3PolarityConfig function.

**Table 565. TIM\_OC3PolarityConfig function**

Function name	TIM_OC3PolarityConfig
Function prototype	void TIM_OC3PolarityConfig(TIM_TypeDef* TIMx, u16 TIM_OCPolarity)
Behavior description	Configures the TIM Channel 3 polarity.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCPolarity: Output compare polarity. Refer to <a href="#">TIM_OCPolarity</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the Polarity high for TIM1 channel 3 output compare */
TIM_OC3PolarityConfig(TIM1, TIM_OCPolarity_High);
```

### 19.2.55 TIM\_OC3NPolarityConfig function

[Table 566](#) describes the TIM\_OC3NPolarityConfig function.

**Table 566. TIM\_OC3NPolarityConfig function**

Function name	TIM_OC3NPolarityConfig
Function prototype	void TIM_OC3NPolarityConfig(TIM_TypeDef* TIMx, u16 TIM_OCNPolarity)
Behavior description	Configures the TIM Channel 3 N polarity.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCNPolarity: Output compare N polarity. Refer to <a href="#">TIM_OCPolarity</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the Polarity high for TIM1 channel 3N output compare */
TIM_OC3NPolarityConfig(TIM1, TIM_OCNPolarity_High);
```

### 19.2.56 TIM\_OC4PolarityConfig function

[Table 567](#) describes the TIM\_OC4PolarityConfig function.

**Table 567. TIM\_OC4PolarityConfig function**

Function name	TIM_OC4PolarityConfig
Function prototype	void TIM_OC4PolarityConfig(TIM_TypeDef* TIMx, u16 TIM_OCPolarity)
Behavior description	Configures the TIM Channel 4 polarity.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_OCPolarity: Output compare polarity. Refer to <a href="#">TIM_OCPolarity</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the Polarity high for TIM1 channel 4 output compare */
TIM_OC4PolarityConfig(TIM1, TIM_OCPolarity_High);
```

## 19.2.57 TIM\_CCxCmd function

[Table 568](#) describes the TIM\_CCxCmd function.

**Table 568. TIM\_CCxCmd function**

Function name	TIM_CCxCmd
Function prototype	void TIM_CCxCmd(TIM_TypeDef* TIMx, u16 TIM_Channel, FunctionalState Newstate)
Behavior description	Enables or disables the TIM Capture Compare Channel x.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_Channel: TIM Channel. Refer to <a href="#">TIM_Channel</a> for more details on the allowed values for this parameter.
Input parameter3	Newstate: specifies the TIM Channel CCxE bit new state. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the TIM1 channel 4 */
TIM_CCxCmd(TIM1, TIM_Channel_4, ENABLE);
```

## 19.2.58 TIM\_CCxNCmd function

[Table 569](#) describes the TIM\_CCxNCmd function.

**Table 569. TIM\_CCxNCmd function**

Function name	TIM_CCxNCmd
Function prototype	void TIM_CCxNCmd(TIM_TypeDef* TIMx, u16 TIM_Channel, FunctionalState Newstate)
Behavior description	Enables or disables the TIM Capture Compare Channel xN.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_Channel: TIM Channel. Refer to <a href="#">TIM_Channel</a> for more details on the allowed values for this parameter.
Input parameter3	Newstate: specifies the TIM Channel CCxNE bit new state. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the TIM1 channel 3N */
TIM_CCxNCmd(TIM1, TIM_Channel_3, ENABLE);
```

**19.2.59 TIM\_SelectOCxM function**

[Table 570](#) describes the TIM\_SelectOCxM function.

**Table 570. TIM\_SelectOCxM function**

Function name	TIM_SelectOCxM
Function prototype	void TIM_SelectOCxM(TIM_TypeDef* TIMx, u16 TIM_Channel, u16 TIM_OCMode)
Behavior description	Selects the TIM Output Compare mode.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_Channel: TIM Channel. Refer to <a href="#">TIM_Channel</a> for more details on the allowed values for this parameter.
Input parameter3	TIM_OCMode: TIM Output Compare mode. Refer to <a href="#">TIM_OCMode</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	This function disables the selected channel before changing the Output Compare mode. The user has to enable this channel using the TIM_CCxCmd and TIM_CCxNCmd functions.
Called functions	None

**TIM\_OCMode**

TIM\_OCMode selects the TIM Output Compare mode (see [Table 571](#)).

**Table 571. TIM\_OCMode definition**

TIM_OCMode	Description
TIM_OCMode_Timing	TIM Output Compare Timing Mode.
TIM_OCMode_Active	TIM Output Compare Active Mode.
TIM_OCMode_Inactive	TIM Output Compare Inactive Mode.
TIM_OCMode_Toggle	TIM Output Compare Toggle Mode.
TIM_OCMode_PWM1	TIM Pulse Width Modulation Mode1.
TIM_OCMode_PWM2	TIM Pulse Width Modulation Mode2.
TIM_ForcedAction_Active	Force active level on OCxREF.
TIM_ForcedAction_InActive	Force inactive level on OCxREF.

**Example:**

```
/* Selects the TIM1 Channel 1 PWM2 Mode */
TIM_SelectOCxM(TIM1, TIM_Channel_1, TIM_OCMode_PWM2);
```

### 19.2.60 TIM\_UpdateDisableConfig function

[Table 572](#) describes the TIM\_UpdateDisableConfig function.

**Table 572. TIM\_UpdateDisableConfig function**

Function name	TIM_UpdateDisableConfig
Function prototype	void TIM_UpdateDisableConfig(TIM_TypeDef* TIMx, FunctionalState Newstate)
Behavior description	Enables or disables the TIM update event.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	NewState: new state of the UDIS bit in TIM_CR1 register. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the Update event for TIM1 */
TIM_UpdateDisableConfig(TIM1, DISABLE);
```

### 19.2.61 TIM\_UpdateRequestConfig function

[Table 573](#) describes the TIM\_UpdateRequestConfig function.

**Table 573. TIM\_UpdateRequestConfig function**

Function name	TIM_UpdateRequestConfig
Function prototype	void TIM_UpdateRequestConfig(TIM_TypeDef* TIMx, u8 TIM_UpdateSource)
Behavior description	Selects the TIM update request source.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_UpdateSource: Update Request sources. Refer to <a href="#">TIM_UpdateSource</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**TIM\_UpdateSource**

TIM\_UpdateSource selects the TIM Update source (see [Table 574](#)).

**Table 574. TIM\_UpdateSource values**

TIM_UpdateSource	Description
TIM_UpdateSource_Global	Source of update is the counter overflow/underflow or the setting of UG bit, or an update generation through the slave mode controller.
TIM_UpdateSource_Regular	Source of update is counter overflow/underflow.

**Example:**

```
/* Selects the regular update source for TIM1 */
TIM_UpdateRequestConfig(TIM1, TIM_UpdateSource_Regular);
```

**19.2.62 TIM\_SelectHallSensor function**

[Table 575](#) describes the TIM\_SelectHallSensor function.

**Table 575. TIM\_SelectHallSensor function**

Function name	TIM_SelectHallSensor
Function prototype	void TIM_SelectHallSensor(TIM_TypeDef* TIMx, FunctionalState Newstate)
Behavior description	Enables or disables the TIM Hall sensor interface.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	NewState: new state of the TI1S bit in the TIM_CR2 register. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Selects the Hall Sensor Interface for TIM1 */
TIM_SelectHallSensor(TIM1, ENABLE);
```

### 19.2.63 TIM\_SelectOnePulseMode function

[Table 576](#) describes the TIM\_SelectOnePulseMode function.

**Table 576. TIM\_SelectOnePulseMode function**

Function name	TIM_SelectOnePulseMode
Function prototype	void TIM_SelectOnePulseMode(TIM_TypeDef* TIMx, u16 TIM_OPMode)
Behavior description	Selects the TIM One-pulse mode.
Input parameter1	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Input parameter2	TIM_OPMode: specifies the One-pulse mode to be used. Refer to <a href="#">TIM_OPMode</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### TIM\_OPMode

TIM\_OPMode selects the TIM Update source (see [Table 577](#)).

**Table 577. TIM\_OPMode definition**

TIM_OPMode	Description
TIM_OPMode_Single	TIM single One-pulse mode.
TIM_OPMode_Repetitive	TIM repetitive One-pulse mode.

#### Example:

```
/* Selects the single One-pulse mode for TIM1 */
TIM_SelectOnePulseMode(TIM1, TIM_OPMode_Single);
```



## 19.2.64 TIM\_SelectOutputTrigger function

[Table 578](#) describes the TIM\_SelectOutputTrigger function.

**Table 578. TIM\_SelectOutputTrigger function**

Function name	TIM_SelectOutputTrigger
Function prototype	void TIM_SelectOutputTrigger(TIM_TypeDef* TIMx, u16 TIM_TRGOSource)
Behavior description	Selects the TIM Trigger Output mode.
Input parameter1	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Input parameter2	TIM_TRGOSource: TRGO sources. Refer to <a href="#">TIM_TRGOSource</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### TIM\_TRGOSource

TIM\_TRGOSource selects the TIM TRGO source (see [Table 579](#)).

**Table 579. TIM8TRGOSource values**

TIM_TRGOSource	Description
TIM_TRGOSource_Reset	The UG bit in the TIM_EGR register is used as the trigger output (TRGO).
TIM_TRGOSource_Enable	The Counter Enable CEN is used as the trigger output (TRGO).
TIM_TRGOSource_Update	The update event is selected as the trigger output (TRGO).
TIM_TRGOSource_OC1	The trigger output sends a positive pulse when the CC1IF flag is to be set, as soon as a capture or compare match occurs (TRGO).
TIM_TRGOSource_OC1Ref	OC1REF signal is used as the trigger output (TRGO).
TIM_TRGOSource_OC2Ref	OC2REF signal is used as the trigger output (TRGO).
TIM_TRGOSource_OC3Ref	OC3REF signal is used as the trigger output (TRGO).
TIM_TRGOSource_OC4Ref	OC4REF signal is used as the trigger output (TRGO).

**Note:** TIM6 and TIM7 can only generate TIM\_TRGOSource\_Reset, TIM\_TRGOSource\_Enable or TIM\_TRGOSource\_Update as trigger outputs.

### Example:

```
/* Selects the update event as TRGO for TIM1 */
TIM_SelectOutputTrigger(TIM1, TIM_TRGOSource_Update);
```

## 19.2.65 TIM\_SelectSlaveMode function

[Table 580](#) describes the TIM\_SelectSlaveMode function.

**Table 580. TIM\_SelectSlaveMode function**

Function name	TIM_SelectSlaveMode
Function prototype	void TIM_SelectSlaveMode(TIM_TypeDef* TIMx, u16 TIM_SlaveMode)
Behavior description	Selects the TIM slave mode.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_SlaveMode: TIM slave mode. Refer to <a href="#">TIM_SlaveMode</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### TIM\_SlaveMode

TIM\_SlaveMode selects the TIMx slave mode (see [Table 581](#)).

**Table 581. TIM\_SlaveMode definition**

TIM_SlaveMode	Description
TIM_SlaveMode_Reset	Rising edge of the selected trigger signal (TRGI) re-initializes the counter and triggers an update of the registers.
TIM_SlaveMode_Gated	The counter clock is enabled when the trigger signal (TRGI) is high.
TIM_SlaveMode_Trigger	The counter starts at a rising edge of the trigger TRGI.
TIM_SlaveMode_External1	Rising edges of the selected trigger (TRGI) clock the counter.

#### Example:

```
/* Selects the Gated Mode as Slave Mode for TIM1 */
TIM_SelectSlaveMode(TIM1, TIM_SlaveMode_Gated);
```

## 19.2.66 TIM\_SelectMasterSlaveMode function

[Table 582](#) describes the TIM\_SelectMasterSlaveMode function.

**Table 582. TIM\_SelectMasterSlaveMode function**

Function name	TIM_SelectMasterSlaveMode
Function prototype	void TIM_SelectMasterSlaveMode(TIM_TypeDef* TIMx, u16 TIM_MasterSlaveMode)
Behavior description	Sets or resets the TIM master/slave mode.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_MasterSlaveMode: Timer master slave mode. Refer to <a href="#">TIM_MasterSlaveMode</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### TIM\_MasterSlaveMode

TIM\_MasterSlaveMode select the TIMx master slave mode (see [Table 583](#)).

**Table 583. TIM\_MasterSlaveMode definition**

TIM_MasterSlaveMode	Description
TIM_MasterSlaveMode_Enable	Enables the master slave mode.
TIM_MasterSlaveMode_Disable	Disables the master slave mode.

#### Example:

```
/* Enables the Master Slave Mode for TIM2 */
TIM_SelectMasterSlaveMode(TIM2, TIM_MasterSlaveMode_Enable);
```

## 19.2.67 TIM\_SetCounter function

[Table 584](#) describes the TIM\_SetCounter function.

**Table 584. TIM\_SetCounter function**

Function name	TIM_SetCounter
Function prototype	void TIM_SetCounter(TIM_TypeDef* TIMx, u16 Counter)
Behavior description	Sets the TIMx Counter Register value.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	Counter: specifies the new counter register value.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Sets the TIM1 new Counter value */
u16 TIMCounter = 0xFFFF;
TIM_SetCounter(TIM1, TIMCounter);
```

**19.2.68 TIM\_SetAutoreload function**

[Table 585](#) describes the TIM\_SetAutoreload function.

**Table 585. TIM\_SetAutoreload function**

Function name	TIM_SetAutoreload
Function prototype	void TIM_SetAutoreload(TIM_TypeDef* TIMx, u16 Autoreload)
Behavior description	Sets the TIM Autoreload Register value.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	Autoreload: new TIM period value.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Sets the TIM1 new Autoreload value */
u16 TIMAutoreload = 0xFFFF;
TIM_SetAutoreload(TIM1, TIMAutoreload);
```

**19.2.69 TIM\_SetCompare1 function**

[Table 586](#) describes the TIM\_SetCompare1 function.

**Table 586. TIM\_SetCompare1 function**

Function name	TIM_SetCompare1
Function prototype	void TIM_SetCompare1(TIM_TypeDef* TIMx, u16 Compare1)
Behavior description	Sets the TIM Capture Compare 1 value.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	Compare1: new TIM Capture Compare 1 Register value.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Sets the new TIM1 Output Compare 1 value */
u16 TIMCompare1 = 0x7FFF;
TIM_SetCompare1(TIM1, TIMCompare1);
```

### 19.2.70 TIM\_SetCompare2 function

[Table 587](#) describes the TIM\_SetCompare2 function.

**Table 587. TIM\_SetCompare2 function**

Function name	TIM_SetCompare2
Function prototype	void TIM_SetCompare2(TIM_TypeDef* TIMx, u16 Compare2)
Behavior description	Sets the TIM Capture Compare 2 Register value.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	Compare2: new TIM Capture Compare 2 Register value.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Sets the new TIM1 Output Compare 2 value */
u16 TIMCompare2 = 0x7FFF;
TIM_SetCompare2(TIM1, TIMCompare2);
```

### 19.2.71 TIM\_SetCompare3 function

[Table 588](#) describes the TIM\_SetCompare3 function.

**Table 588. TIM\_SetCompare3 function**

Function name	TIM_SetCompare3
Function prototype	void TIM_SetCompare3(TIM_TypeDef* TIMx, u16 Compare3)
Behavior description	Sets the TIM Capture Compare 3 value.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	Compare3: new TIM Capture Compare 3 Register value.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Sets the new TIM1 Output Compare 3 value */
u16 TIMCompare3 = 0x7FFF;
TIM_SetCompare3(TIM1, TIMCompare3);
```

### 19.2.72 TIM\_SetCompare4 function

[Table 589](#) describes the TIM\_SetCompare4 function.

**Table 589. TIM\_SetCompare4 function**

Function name	TIM_SetCompare4
Function prototype	void TIM_SetCompare4(TIM_TypeDef* TIMx, u16 Compare4)
Behavior description	Sets the TIM Capture Compare 4 value.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	Compare4: new TIM Capture Compare 4 Register value.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Sets the new TIM1 Output Compare 4 value */
u16 TIMCompare4 = 0x7FFF;
TIM_SetCompare4(TIM1, TIMCompare4);
```

### 19.2.73 TIM\_SetIC1Prescaler function

[Table 590](#) describes the TIM\_SetIC1Prescaler function.

**Table 590. TIM\_SetIC1Prescaler function**

Function name	TIM_SetIC1Prescaler
Function prototype	void TIM_SetIC1Prescaler(TIM_TypeDef* TIMx, u16 TIM_IC1Prescaler)
Behavior description	Sets the TIM Input Capture 1 Prescaler.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_IC1Prescaler: Input Capture 1 Prescaler. Refer to <a href="#">TIM_ICPrescaler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**TIM\_ICPrescaler**

TIM\_ICPrescaler selects the TIM Input Capture prescaler (see [Table 591](#)).

**Table 591. TIM\_ICPrescaler values**

TIM_ICPrescaler	Description
TIM_ICPSC_DIV1	Capture is done each time an edge is detected on the capture input.
TIM_ICPSC_DIV2	Capture is done once every 2 events.
TIM_ICPSC_DIV4	Capture is done once every 4 events.
TIM_ICPSC_DIV8	Capture is done once every 8 events.

**Example:**

```
/* Sets the TIM1 Input Capture 1 Prescaler */
TIM_SetIC1Prescaler(TIM1, TIM_ICPSC_Div2);
```

**19.2.74 TIM\_SetIC2Prescaler function**

[Table 592](#) describes the TIM\_SetIC2Prescaler function.

**Table 592. TIM\_SetIC2Prescaler function**

Function name	TIM_SetIC2Prescaler
Function prototype	void TIM_SetIC2Prescaler(TIM_TypeDef* TIMx, u16 TIM_IC2Prescaler)
Behavior description	Sets the TIM Input Capture 2 Prescaler.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_IC2Prescaler: Input Capture 2 prescaler. Refer to <a href="#">TIM_ICPrescaler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Sets the TIM1 Input Capture 2 Prescaler */
TIM_SetIC2Prescaler(TIM1, TIM_ICPSC_Div2);
```

### 19.2.75 TIM\_SetIC3Prescaler function

[Table 593](#) describes the TIM\_SetIC3Prescaler function.

**Table 593. TIM\_SetIC3Prescaler function**

Function name	TIM_SetIC3Prescaler
Function prototype	void TIM_SetIC3Prescaler(TIM_TypeDef* TIMx, u16 TIM_IC3Prescaler)
Behavior description	Sets the TIM Input Capture 3 prescaler.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_IC3Prescaler: Input Capture 3 Prescaler. Refer to <a href="#">TIM_ICPrescaler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Sets the TIM1 Input Capture 3 Prescaler */
TIM_SetIC3Prescaler(TIM1, TIM_ICPSC_Div2);
```

### 19.2.76 TIM\_SetIC4Prescaler function

[Table 594](#) describes the TIM\_SetIC4Prescaler function.

**Table 594. TIM\_SetIC4Prescaler function**

Function name	TIM_SetIC4Prescaler
Function prototype	void TIM_SetIC4Prescaler(TIM_TypeDef* TIMx, u16 TIM_IC4Prescaler)
Behavior description	Sets the TIM Input Capture 4 prescaler.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_IC4Prescaler: Input Capture 4 Prescaler. Refer to <a href="#">TIM_ICPrescaler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Sets the TIM Input Capture 4 Prescaler */
TIM_SetIC4Prescaler(TIM_ICPSC_Div2);
```



## 19.2.77 TIM\_SetClockDivision function

[Table 595](#) describes the TIM\_SetClockDivision function.

**Table 595. TIM\_SetClockDivision function**

Function name	TIM_SetClockDivision
Function prototype	void TIM_SetClockDivision(TIM_TypeDef* TIMx, u16 TIM_CKD)
Behavior description	Sets the TIM clock division value.
Input parameter1	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Input parameter2	TIM_CKD: clock division value. Refer to <a href="#">TIM_ClockDivision</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### TIM\_CKD

TIM\_CKD selects the TIM clock division (see [Table 596](#)).

**Table 596. TIM\_CKD values**

TIM_CKD	Description
TIM_CKD_DIV1	$T_{DTS} = T_{ck\_tim}$
TIM_CKD_DIV2	$T_{DTS} = 2 \times T_{ck\_tim}$
TIM_CKD_DIV4	$T_{DTS} = 4 \times T_{ck\_tim}$

### Example:

```
/* Sets the TIM1 CKD value */
TIM_SetClockDivision(TIM1, TIM_CKD_DIV4);
```

## 19.2.78 TIM\_GetCapture1 function

[Table 597](#) describes the TIM\_GetCapture1 function.

**Table 597. TIM\_GetCapture1 function**

Function name	TIM_GetCapture1
Function prototype	u16 TIM_GetCapture1(TIM_TypeDef* TIMx)
Behavior description	Gets the TIM input capture 1 value.
Input parameter	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the Input Capture 1 value of TIM1 */
u16 IC1value = TIM_GetCapture1(TIM1);
```

**19.2.79 TIM\_GetCapture2 function**

[Table 598](#) describes the TIM\_GetCapture2 function.

**Table 598. TIM\_GetCapture2 function**

Function name	TIM_GetCapture2
Function prototype	u16 TIM_GetCapture2(TIM_TypeDef* TIMx)
Behavior description	Gets the TIM Input Capture 2 value.
Input parameter	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the Input Capture 2 value of TIM1 */
u16 IC2value = TIM_GetCapture2(TIM1);
```

**19.2.80 TIM\_GetCapture3 function**

[Table 599](#) describes the TIM\_GetCapture3 function.

**Table 599. TIM\_GetCapture3 function**

Function name	TIM_GetCapture3
Function prototype	u16 TIM_GetCapture3(TIM_TypeDef* TIMx)
Behavior description	Gets the TIM Input Capture 3 value.
Input parameter	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the Input Capture 3 value of TIM1 */
u16 IC3value = TIM_GetCapture3(TIM1);
```

### 19.2.81 TIM\_GetCapture4 function

[Table 600](#) describes the TIM\_GetCapture4 function.

**Table 600. TIM\_GetCapture4 function**

Function name	TIM_GetCapture4
Function prototype	u16 TIM_GetCapture4(TIM_TypeDef* TIMx)
Behavior description	Gets the TIM Input Capture 4 value.
Input parameter	TIMx: where x can be 1, 2, 3, 4, 5 or 8 to select the TIM peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets the Input Capture 4 value of TIM1 */
u16 IC4value = TIM_GetCapture4(TIM1);
```

### 19.2.82 TIM\_GetCounter function

[Table 601](#) describes the TIM\_GetCounter function.

**Table 601. TIM\_GetCounter function**

Function name	TIM_GetCounter
Function prototype	void TIM_GetCounter(TIM_TypeDef* TIMx)
Behavior description	Gets the TIM counter value.
Input parameter	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Gets TIM1 counter value */
u16 TIMCounter = TIM_GetCounter(TIM1);
```

### 19.2.83 TIM\_GetPrescaler function

[Table 602](#) describes the TIM\_GetPrescaler function.

**Table 602. TIM\_GetPrescaler function**

Function name	TIM_GetPrescaler
Function prototype	<code>void TIM_GetPrescaler(TIM_TypeDef* TIMx)</code>
Behavior description	Gets the TIM prescaler value.
Input parameter	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```

/* Gets TIM1 prescaler value */
u16 TIMPrescaler = TIM_GetPrescaler(TIM1);

```

### 19.2.84 TIM\_GetFlagStatus function

[Table 603](#) describes the TIM\_GetFlagStatus function.

**Table 603. TIM\_GetFlagStatus function**

Function name	TIM_GetFlagStatus
Function prototype	<code>FlagStatus TIM_GetFlagStatus(TIM_TypeDef* TIMx, u16 TIM_FLAG)</code>
Behavior description	Checks whether the specified TIM flag is set or not.
Input parameter1	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Input parameter2	TIM_FLAG: specifies the flag to check. Refer to <a href="#">TIM_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of TIM_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

**TIM\_FLAG**

The TIM flags that can be checked are listed in [Table 604](#).

**Table 604. TIM\_FLAG definition**

TIM_FLAG	Description
TIM_FLAG_Update	TIM Update flag
TIM_FLAG_CC1	TIM Capture/Compare 1 flag
TIM_FLAG_CC2	TIM Capture/Compare 2 flag
TIM_FLAG_CC3	TIM Capture/Compare 3 flag
TIM_FLAG_CC4	TIM Capture/Compare 4 flag
TIM_FLAG_COM	TIM COM flag
TIM_FLAG_Trigger	TIM Trigger flag
TIM_FLAG_Break	TIM Break flag
TIM_FLAG_CC1OF	TIM Capture/Compare 1 Overflow flag
TIM_FLAG_CC2OF	TIM Capture/Compare 2 Overflow flag
TIM_FLAG_CC3OF	TIM Capture/Compare 3 Overflow flag
TIM_FLAG_CC4OF	TIM Capture/Compare 4 Overflow flag

**Note:** *TIM6 and TIM7 can have only one update flag. TIM\_FLAG\_COM and TIM\_FLAG\_Break are used only with TIM1 and TIM8.*

**Example:**

```
/* Check if the TIM1 Capture Compare 1 flag is set or reset */
if(TIM_GetFlagStatus(TIM1, TIM_FLAG_CC1) == SET)
{
}
```

### 19.2.85 TIM\_ClearFlag function

[Table 605](#) describes the TIM\_ClearFlag function.

**Table 605. TIM\_ClearFlag function**

Function name	TIM_ClearFlag
Function prototype	void TIM_ClearFlag(TIM_TypeDef* TIMx, u16 TIM_Flag)
Behavior description	Clears the pending TIM flags.
Input parameter1	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Input parameter2	TIM_FLAG: flag to clear. Refer to <a href="#">TIM_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Note:** TIM6 and TIM7 can have only one update flag. TIM\_FLAG\_COM and TIM\_FLAG\_Break are used only with TIM1 and TIM8.

**Example:**

```
/* Clear the TIM1 Capture Compare 1 flag */
TIM_ClearFlag(TIM1, TIM_FLAG_CC1);
```

### 19.2.86 TIM\_GetITStatus function

[Table 606](#) describes the TIM\_GetITStatus function.

**Table 606. TIM\_GetITStatus function**

Function name	TIM_GetITStatus
Function prototype	ITStatus TIM_GetITStatus(TIM_TypeDef* TIMx, u16 TIM_IT)
Behavior description	Checks whether the specified TIM interrupt has occurred or not.
Input parameter1	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Input parameter2	TIM_IT: specifies the TIM interrupt source to check. Refer to <a href="#">TIM_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of TIM_IT (SET or RESET).
Required preconditions	None
Called functions	None

**Note:** TIM6 and TIM7 can generate only one update interrupt. TIM\_IT\_COM and TIM\_IT\_Break are used only with TIM1 and TIM8.

**Example:**

```
/*Check if the TIM1 Capture Compare 1 interrupt has occurred or not*/
```

```

if(TIM_GetITStatus(TIM1, TIM_IT_CC1) == SET)
{
}

```

### 19.2.87 TIM\_ClearITPendingBit function

[Table 607](#) describes the TIM\_ClearITPendingBit function.

**Table 607. TIM\_ClearITPendingBit function**

Function name	TIM_ClearITPending Bit
Function prototype	void TIM_ClearITPendingBit(TIM_TypeDef* TIMx, u16 TIM_IT)
Behavior description	Clears the TIM interrupt pending bits.
Input parameter1	TIMx: where x can be 1 to 8 to select the TIM peripheral.
Input parameter2	TIM_IT: specifies the interrupt pending bit to clear. Refer to <a href="#">TIM_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Note:** *TIM6 and TIM7 can generate only one update interrupt. TIM\_IT\_COM and TIM\_IT\_Break are used only with TIM1 and TIM8.*

**Example:**

```

/* Clear the TIM1 Capture Compare 1 interrupt pending bit */
TIM_ClearITPendingBit(TIM1, TIM_IT_CC1);

```

## 20 Universal synchronous asynchronous receiver transmitter (USART)

The Universal synchronous/asynchronous receiver transmitter (USART) performs flexible full-duplex data exchange with external equipment requiring industry-standard NRZ asynchronous serial data format. The SCI offers a very wide range of baud rates based on fractional baud rate generator systems. The USART interface also supports the Smart Card Protocol compliant with IrDA SIR ENDEC specifications. It can perform single-wire half-duplex communications, synchronous transmissions and modem operations (CTS/RTS).

[Section 20.1: USART register structure](#) describes the data structures used in the USART Firmware Library. [Section 20.2: Firmware library functions](#) presents the Firmware Library functions.

### 20.1 USART register structure

The USART register structure, `USART_TypeDef`, is defined in the `stm32f10x_map.h` file as follows:

```
typedef struct
{
    vu16 SR;
    u16 RESERVED1;
    vu16 DR;
    u16 RESERVED2;
    vu16 BRR;
    u16 RESERVED3;
    vu16 CR1;
    u16 RESERVED4;
    vu16 CR2;
    u16 RESERVED5;
    vu16 CR3;
    u16 RESERVED6;
    vu16 GTPR;
    u16 RESERVED7;
} USART_TypeDef;
```

[Table 608](#) gives the list of USART registers.

**Table 608. USART registers**

Register	Description
SR	USART Status Register
DR	USART Data Register
BRR	USART BaudRate Register
CR1	USART Control Register 1
CR2	USART Control Register 2
CR3	USART Control Register 3
GTPR	USART Guard-Time and Prescaler Register



The three USART peripherals are declared in *stm32f10x\_map.h*:

```
...
#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE     PERIPH_BASE
#define APB2PERIPH_BASE     (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE      (PERIPH_BASE + 0x20000)

#define USART1_BASE         (APB2PERIPH_BASE + 0x3800)
#define USART2_BASE         (APB1PERIPH_BASE + 0x4400)
#define USART3_BASE         (APB1PERIPH_BASE + 0x4800)
#define UART4_BASE          (APB1PERIPH_BASE + 0x4C00)
#define UART5_BASE          (APB1PERIPH_BASE + 0x5000)

#ifndef DEBUG
...
#ifdef _USART1
    #define USART1          ((USART_TypeDef *) USART1_BASE)
#endif /*_USART1 */

#ifdef _USART2
    #define USART2          ((USART_TypeDef *) USART2_BASE)
#endif /*_USART2 */

#ifdef _USART3
    #define USART3          ((USART_TypeDef *) USART3_BASE)
#endif /*_USART3 */

#ifdef _UART4
    #define UART4 ((USART_TypeDef *) UART4_BASE)
#endif /*_UART4 */

#ifdef _UART5
    #define UART5 ((USART_TypeDef *) UART5_BASE)
#endif /*_UART5 */
...
#else /* DEBUG */
...
#ifdef _USART1
    EXT USART_TypeDef      *USART1;
#endif /*_USART1 */

#ifdef _USART2
    EXT USART_TypeDef      *USART2;
#endif /*_USART2 */

#ifdef _USART3
    EXT USART_TypeDef      *USART3;
#endif /*_USART3 */

#ifdef _UART4
    EXT USART_TypeDef      *UART4;
#endif /*_UART4 */

```

```
#ifdef _UART5
    EXT USART_TypeDef          *UART5;
#endif /*_UART5 */
...
#endif
```

When using the Debug mode, the `_USART1`, `_USART2`, `_USART3`, `_UART4` and `_UART5` pointers are initialized in the *stm32f10x\_lib.c* file:

```
...
#ifdef _USART1
    USART1 = (USART_TypeDef *) USART1_BASE;
#endif /*_USART1 */

#ifdef _USART2
    USART2 = (USART_TypeDef *) USART2_BASE;
#endif /*_USART2 */

#ifdef _USART3
    USART3 = (USART_TypeDef *) USART3_BASE;
#endif /*_USART3 */

#ifdef _UART4
    UART4 = (USART_TypeDef *) UART4_BASE;
#endif /*_USART4 */

#ifdef _UART5
    UART5 = (USART_TypeDef *) UART5_BASE;
#endif /*_UART5 */
...
```

To access the USART registers, `_USART`, `_USART1`, `_USART2`, `_USART3`, `_UART4` and `_UART5` must be defined in *stm32f10x\_conf.h* as follows:

```
...
#define _USART
#define _USART1
#define _USART2
#define _USART3
#define _UART4
#define _UART5
```

## 20.2 Firmware library functions

*Table 609* lists the various functions of the USART library.

**Table 609. USART firmware library functions**

Function name	Description
USART_DeInit	Resets the USARTx peripheral registers to their default reset values.
USART_Init	Initializes the USARTx peripheral according to the specified parameters in the USART_InitStruct.
USART_StructInit	Fills each USART_InitStruct member with its default value.
USART_ClockInit	Initializes the USARTx peripheral clock according to the specified parameters in the USART_ClockInitStruct.
USART_ClockStructInit	Fills each USART_ClockInitStruct member with its default value.
USART_Cmd	Enables or disables the specified USART peripheral.
USART_ITConfig	Enables or disables the specified USART interrupts.
USART_DMACmd	Enables or disables the USART DMA interface.
USART_SetAddress	Sets the address of the USART node.
USART_WakeUpConfig	Selects the USART WakeUp method.
USART_ReceiverWakeUpCmd	Determines if the USART is in mute mode or not.
USART_LINBreakDetectionConfig	Sets the USART LIN Break detection length.
USART_LINCmd	Enables or disables the USARTx LIN mode.
USART_SendData	Transmits single data through the USARTx peripheral.
USART_ReceiveData	Returns the most recent received data by the USARTx peripheral.
USART_SendBreak	Transmits break characters.
USART_SetGuardTime	Sets the specified USART guard time.
USART_SetPrescaler	Sets the USART clock prescaler.
USART_SmartCardCmd	Enables or disables the USART Smart Card mode.
USART_SmartCardNackCmd	Enables or disables NACK transmission.
USART_HalfDuplexCmd	Enables or disables the USART Half Duplex mode.
USART_IrDAConfig	Configures the USART IrDA mode.
USART_IrDACmd	Enables or disables the USART IrDA mode.
USART_GetFlagStatus	Checks whether the specified USART flag is set or not.
USART_ClearFlag	Clears the USARTx pending flags.
USART_GetITStatus	Checks whether the specified USART interrupt has occurred or not.
USART_ClearITPendingBit	Clears the USARTx interrupt pending bits.

## 20.2.1 USART\_DeInit function

[Table 610](#) describes the USART\_DeInit function.

**Table 610. USART\_DeInit function**

Function name	USART_DeInit
Function prototype	void USART_DeInit(USART_TypeDef* USARTx)
Behavior description	Resets the USARTx peripheral registers to their default reset values.
Input parameter	USARTx: selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_APB2PeriphResetCmd() RCC_APB1PeriphResetCmd()

**Example:**

```
/* Resets the USART1 registers to their default reset value */
USART_DeInit(USART1);
```

## 20.2.2 USART\_Init function

[Table 611](#) describes the USART\_Init function. This function uses the USART\_InitTypeDef structure, which is used in asynchronous mode.

**Table 611. USART\_Init function**

Function name	USART_Init
Function prototype	void USART_Init(USART_TypeDef* USARTx, USART_InitTypeDef* USART_InitStruct)
Behavior description	Initializes the USARTx peripheral according to the parameters specified in the USART_InitStruct.
Input parameter1	USARTx: selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	USART_InitStruct: pointer to a USART_InitTypeDef structure that contains the configuration information for the specified USART peripheral. Refer to <a href="#">USART_InitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## USART\_InitTypeDef structure

The USART\_InitTypeDef structure is defined in the *stm32f10x\_usart.h* file:

```
typedef struct
{
    u32 USART_BaudRate;
    u16 USART_WordLength;
    u16 USART_StopBits;
    u16 USART_Parity;
    u16 USART_HardwareFlowControl;
    u16 USART_Mode;
} USART_InitTypeDef;
```

[Table 612](#) describes the USART\_InitTypeDef structure members which are used in asynchronous and in synchronous mode.

**Table 612. USART\_InitTypeDef members versus USART mode**

Members	Asynchronous mode	Synchronous mode
USART_BaudRate	X	X
USART_WordLength	X	X
USART_StopBits	X	X
USART_Parity	X	X
USART_HardwareFlowControl	X	X
USART_Mode	X	X
USART_Clock		X
USART_CPOL		X
USART_CPHA		X
USART_LastBit		X

### USART\_BaudRate

This member configures the USART communication baud rate. The baud rate is computed using the following formula:

$$\text{IntegerDivider} = ((\text{APBClock}) / (16 * (\text{USART\_InitStruct->USART\_BaudRate})))$$

$$\text{FractionalDivider} = ((\text{IntegerDivider} - ((\text{u32}) \text{IntegerDivider})) * 16) + 0.5$$

### USART\_WordLength

USART\_WordLength indicates the number of data bits transmitted or received in a frame. See [Table 613](#) for the values of this member.

**Table 613. USART\_WordLength definition**

USART_WordLength	Description
USART_WordLength_8b	8 bits Data
USART_WordLength_9b	9 bits Data

**USART\_StopBits**

USART\_StopBits defines the number of stop bits transmitted. See [Table 614](#) for the values of this member.

**Table 614. USART\_StopBits definition**

USART_StopBits	Description
USART_StopBits_1	1 stop bit is transmitted at the end of frame
USART_StopBits_0_5	0.5 stop bit is transmitted at the end of frame
USART_StopBits_2	2 stop bits are transmitted at the end of frame
USART_StopBits_1_5	1.5 stop bit is transmitted at the end of frame

**USART\_Parity**

USART\_Parity defines the parity mode. See [Table 615](#) for the values of this member.

**Table 615. USART\_Parity definition**

USART_Parity	Description
USART_Parity_No	Parity Disable
USART_Parity_Even	Even Parity
USART_Parity_Odd	Odd Parity

*Note:* When parity is enabled, the computed parity is inserted at the MSB position of the transmitted data (9<sup>th</sup> bit when the word length is set to 9 data bits; 8<sup>th</sup> bit when the word length is set to 8 data bits).

**USART\_HardwareFlowControl**

USART\_HardwareFlowControl specifies whether the hardware flow control mode is enabled or disabled. See [Table 616](#) for the values of this member.

**Table 616. USART\_HardwareFlowControl definition**

USART_HardwareFlowControl	Description
USART_HardwareFlowControl_None	HFC Disabled
USART_HardwareFlowControl_RTS	RTS enabled
USART_HardwareFlowControl_CTS	CTS enabled
USART_HardwareFlowControl_RTS_CTS	RTS and CTS enabled

**USART\_Mode**

USART\_Mode specifies whether the Receive or Transmit mode is enabled or disabled. See [Table 617](#) for the values of this member.

**Table 617. USART\_Mode definition**

USART_Mode	Description
USART_Mode_Tx	Transmit enabled
USART_Mode_Rx	Receive enabled

**Example:**

```
/* The following example illustrates how to configure the USART1 */  
USART_InitTypeDef USART_InitStructure;
```

```
USART_InitStructure.USART_BaudRate = 9600;  
USART_InitStructure.USART_WordLength = USART_WordLength_8b;  
USART_InitStructure.USART_StopBits = USART_StopBits_1;  
USART_InitStructure.USART_Parity = USART_Parity_Odd;  
USART_InitStructure.USART_HardwareFlowControl =  
USART_HardwareFlowControl_RTS_CTS;  
USART_InitStructure.USART_Mode = USART_Mode_Tx | USART_Mode_Rx;  
USART_InitStructure.USART_Clock = USART_Clock_Disable;  
USART_InitStructure.USART_CPOL = USART_CPOL_High;  
USART_InitStructure.USART_CPHA = USART_CPHA_1Edge;  
USART_InitStructure.USART_LastBit = USART_LastBit_Enable;  
USART_Init(USART1, &USART_InitStructure);
```

### 20.2.3 USART\_StructInit function

[Table 618](#) describes the USART\_StructInit function.

**Table 618. USART\_StructInit function**

Function name	USART_StructInit
Function prototype	void USART_StructInit(USART_InitTypeDef* USART_InitStruct)
Behavior description	Fills each USART_InitStruct member with its default value.
Input parameter	USART_InitStruct: pointer to the USART_InitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The USART\_InitStruct members have the following default values:

**Table 619. USART\_InitStruct default values**

Member	Default value
USART_BaudRate	9600
USART_WordLength	USART_WordLength_8b
USART_StopBits	USART_StopBits_1
USART_Parity	USART_Parity_No
USART_HardwareFlowControl	USART_HardwareFlowControl_None
USART_Mode	USART_Mode_Rx   USART_Mode_Tx
USART_Clock	USART_Clock_Disable
USART_CPOL	USART_CPOL_Low
USART_CPHA	USART_CPHA_1Edge
USART_LastBit	USART_LastBit_Disable

**Example:**

```
/* The following example illustrates how to initialize a
USART_InitTypeDef structure */
USART_InitTypeDef USART_InitStructure;
USART_StructInit(&USART_InitStructure);
```

### 20.2.4 USART\_ClockInit function

[Table 620](#) describes the USART\_ClockInit function. This function uses the USART\_ClockInitTypeDef structure, which is used in synchronous mode.



**Table 620. USART\_ClockInit function**

Function name	USART_ClockInit
Function prototype	void USART_ClockInit(USART_TypeDef* USARTx, USART_ClockInitTypeDef* USART_ClockInitStruct)
Behavior description	Initializes the USARTx peripheral Clock according to the specified parameters in the USART_ClockInitStruct.
Input parameter1	USARTx: where x can be 1, 2, 3 to select the USART peripheral. <b>Note:</b> The Smart Card mode is not available for UART4 and UART5.
Input parameter2	USART_ClockInitStruct: pointer to a USART_ClockInitTypeDef structure that contains the configuration information for the specified USART peripheral clock. Refer to <a href="#">USART_ClockInitTypeDef structure</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## USART\_ClockInitTypeDef structure

The USART\_InitTypeDef structure is defined in the *stm32f10x\_usart.h* file:

```
typedef struct
{
    u16 USART_Clock;
    u16 USART_CPOL;
    u16 USART_CPHA;
    u16 USART_LastBit;
} USART_ClockInitTypeDef;
```

## USART\_Clock

USART\_Clock indicates whether the USART clock specified in the USART\_Clock member is enabled or disabled. See [Table 621](#) for the values of this member.

**Table 621. USART\_Clock definition**

USART_Clock	Description
USART_Clock_Enable	USART Clock enabled
USART_Clock_Disable	USART Clock disabled

**USART\_CPOL**

USART\_CPOL specifies the steady state value of the serial clock. See [Table 622](#) for the values of this member.

**Table 622. USART\_CPOL definition**

USART_CPOL	Description
USART_CPOL_High	Clock is active high
USART_CPOL_Low	Clock is active low

**USART\_CPHA**

USART\_CPHA defines the clock transition on which the bit capture is made. See [Table 623](#) for the values of this member.

**Table 623. USART\_CPHA definition**

USART_CPHA	Description
USART_CPHA_1Edge	Data are captured on the first clock edge
USART_CPHA_2Edge	Data are captured on the second clock edge

**USART\_LastBit**

USART\_LastBit defines whether the clock pulse corresponding to the last transmitted data bit (MSB) has to be output on the SCLK pin in synchronous mode. See [Table 624](#) for the values of this member.

**Table 624. USART\_LastBit definition**

USART_LastBit	Description
USART_LastBit_Disable	The clock pulse of the last data bit is not output on the SCLK pin.
USART_LastBit_Enable	The clock pulse of the last data bit is output on the SCLK pin.

**Example:**

```
/* The following example illustrates how to configure the USART1
Clock */
USART_ClockInitTypeDef USART_ClockInitStructure;

USART_ClockInitStructure.USART_Clock = USART_Clock_Disable;
USART_ClockInitStructure.USART_CPOL = USART_CPOL_High;
USART_ClockInitStructure.USART_CPHA = USART_CPHA_1Edge;
USART_ClockInitStructure.USART_LastBit = USART_LastBit_Enable;
USART_Init(USART1, &USART_ClockInitStructure);
```

## 20.2.5 USART\_ClockStructInit function

Table 618 describes the USART\_ClockStructInit function.

**Table 625. USART\_ClockStructInit function**

Function name	USART_ClockStructInit
Function prototype	void USART_ClockStructInit(USART_InitTypeDef* USART_ClockInitStruct)
Behavior description	Fills each USART_ClockInitStruct member with its default value.
Input parameter	USART_ClockInitStruct: pointer to the USART_ClockInitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The USART\_ClockInitStruct members have the following default values:

**Table 626. USART\_ClockInitStruct default values**

Member	Default value
USART_Clock	USART_Clock_Disable
USART_CPOL	USART_CPOL_Low
USART_CPHA	USART_CPHA_1Edge
USART_LastBit	USART_LastBit_Disable

**Example:**

```
/* The following example illustrates how to initialize a
USART_ClockInitTypeDef structure */
USART_ClockInitTypeDef USART_ClockInitStructure;
USART_ClockStructInit(&USART_ClockInitStructure);
```

## 20.2.6 USART\_Cmd function

[Table 627](#) describes the USART\_Cmd function.

**Table 627. USART\_Cmd function**

Function name	USART_Cmd
Function prototype	void USART_Cmd(USART_TypeDef* USARTx, FunctionalState NewState)
Behavior description	Enables or disables the specified USART peripheral.
Input parameter1	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	NewState: new state of the USARTx peripheral. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the USART1 */
USART_Cmd(USART1, ENABLE);
```

## 20.2.7 USART\_ITConfig function

[Table 628](#) describes the USART\_ITConfig function.

**Table 628. USART\_ITConfig function**

Function name	USART_ITConfig
Function prototype	void USART_ITConfig(USART_TypeDef* USARTx, u16 USART_IT, FunctionalState NewState)
Behavior description	Enables or disables the specified USART interrupts.
Input parameter1	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	USART_IT: specifies the USART interrupt sources to be enabled or disabled. Refer to <a href="#">USART_IT</a> for more details on the allowed values for this parameter.
Input parameter3	NewState: new state of the specified USARTx interrupts. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## USART\_IT

USART\_IT is used to enable or disable USART interrupts. Refer to [Table 629](#) for the values taken by this parameter.

**Table 629. USART\_IT values**

USART_IT	Description
USART_IT_PE	Parity Error interrupt
USART_IT_TXE	Transmit Data Register empty interrupt
USART_IT_TC	Transmission complete interrupt
USART_IT_RXNE	Receive Data register not empty interrupt
USART_IT_IDLE	Idle line detection interrupt
USART_IT_LBD	LIN break detection interrupt
USART_IT_CTS	CTS change interrupt (not available for UART4 and UART5)
USART_IT_ERR	Error interrupt (Frame error, noise error, overrun error)

### Example:

```
/* Enables the USART1 transmit interrupt */
USART_ITConfig(USART1, USART_IT_TXE ENABLE);
```

## 20.2.8 USART\_DMAMCmd function

[Table 630](#) describes the USART\_DMAMCmd function.

**Table 630. USART\_DMAMCmd function**

Function name	USART_DMAMCmd
Function prototype	void USART_DMAMCmd(USART_TypeDef* USARTx, u16 USART_DMAMReq, FunctionalState Newstate)
Behavior description	Enables or disables the USART DMA interface.
Input parameter1	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3 or UART4. <b>Note:</b> The DMA mode is not available for UART5.
Input parameter2	USART_DMAMReq: specifies the DMA request. Refer to <a href="#">USART_DMAMReq</a> for more details on the allowed values for this parameter.
Input parameter3	NewState: new state of the DMA Request sources. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**USART\_DMAReq**

USART\_DMAReq selects the DMA request to be enabled or disabled. Refer to [Table 631](#) for the values taken by this parameter.

**Table 631. USART\_DMAReq values**

<i>USART_DMAReq</i>	Description
USART_DMAReq_Tx	Transmit DMA request
USART_DMAReq_Rx	Receive DMA request

**Example:**

```
/* Enable the DMA transfer on Rx and Tx action for USART2 */
USART_DMACmd(USART2, USART_DMAReq_Rx | USART_DMAReq_Tx, ENABLE);
```

**20.2.9 USART\_SetAddress function**

[Table 632](#) describes the USART\_SetAddress function.

**Table 632. USART\_SetAddress function**

Function name	USART_SetAddress
Function prototype	void USART_SetAddress(USART_TypeDef* USARTx, u8 USART_Address)
Behavior description	Sets the address of the USART node.
Input parameter1	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	USART_Address indicates the address of the USART node.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Sets the USART2 address node to 0x5 */
USART_SetAddress(USART2, 0x5);
```

## 20.2.10 USART\_WakeUpConfig function

[Table 633](#) describes the USART\_WakeUpConfig function.

**Table 633. USART\_WakeUpConfig function**

Function name	USART_WakeUpConfig
Function prototype	void USART_WakeUpConfig(USART_TypeDef* USARTx, u16 USART_WakeUp)
Behavior description	Selects the USART WakeUp method.
Input parameter1	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	USART_WakeUp: specifies the USART wake-up method. Refer to <a href="#">USART_WakeUp</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### USART\_WakeUp

USART\_WakeUp selects the wake-up method. Refer to [Table 634](#) for the values taken by this parameter.

**Table 634. USART\_WakeUp values**

<i>USART_WakeUp</i>	Description
USART_WakeUp_IdleLine	Wakeup by an idle line detection
USART_WakeUp_AddressMark	Wakeup by an address mark

**Example:**

```
/* Selects the IDLE Line as USART1 WakeUp */  
USART_WakeUpConfig(USART1, USART_WakeUp_IdleLine);
```

## 20.2.11 USART\_ReceiverWakeUpCmd function

[Table 635](#) describes the USART\_ReceiverWakeUpCmd function.

**Table 635. USART\_ReceiverWakeUpCmd function**

Function name	USART_ReceiverWakeUpCmd
Function prototype	<code>void USART_ReceiverWakeUpCmd(USART_TypeDef* USARTx, FunctionalState Newstate)</code>
Behavior description	Determines if the USART is in mute mode or not.
Input parameter1	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	NewState: new state of the USART mute mode. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* USART3 in normal mode */
USART_ReceiverWakeUpCmd(USART3, DISABLE);
```

## 20.2.12 USART\_LINBreakDetectLengthConfig function

[Table 636](#) describes the USART\_LINBreakDetectLengthConfig function.

**Table 636. USART\_LINBreakDetectLengthConfig function**

Function name	USART_LINBreakDetectLengthConfig
Function prototype	<code>void USART_LINBreakDetectLengthConfig(USART_TypeDef* USARTx, u16 USART_LINBreakDetectLength)</code>
Behavior description	Sets the USART LIN Break detection length.
Input parameter1	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	USART_LINBreakDetectLength specifies the LIN break detection length. Refer to <a href="#">USART_LINBreakDetectLength</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None



**USART\_LINBreakDetectLength**

USART\_LINBreakDetectLength selects the LIN break detection length. Refer to [Table 637](#) for the values taken by this parameter.

**Table 637. USART\_LINBreakDetectionLength values**

USART_LINBreakDetectionLength	Description
USART_LINBreakDetectLength_10b	10 bit break detection
USART_LINBreakDetectLength_11b	11 bit break detection

**Example:**

```
/* Selects 10 bit break detection for USART1 */
USART_LINBreakDetectLengthConfig(USART1,
USART_LINBreakDetectLength_10b);
```

**20.2.13 USART\_LINCmd function**

[Table 638](#) describes the USART\_LINCmd function.

**Table 638. USART\_LINCmd function**

Function name	USART_LINCmd
Function prototype	void USART_LINCmd(USART_TypeDef* USARTx, FunctionalState Newstate)
Behavior description	Enables or disables the USART LIN mode.
Input parameter1	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	NewState: new state of the USART LIN mode. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the USART2 LIN mode */
USART_LINCmd(USART2, ENABLE);
```

## 20.2.14 USART\_SendData function

*Table 639* describes the USART\_SendData function.

**Table 639. USART\_SendData function**

Function name	USART_SendData
Function prototype	void USART_SendData(USART_TypeDef* USARTx, u16 Data)
Behavior description	Transmits single data through the USARTx peripheral.
Input parameter1	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	Data: the data to transmit.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Send one HalfWord on USART3 */
USART_SendData(USART3, 0x26);
```

## 20.2.15 USART\_ReceiveData function

*Table 640* describes the USART\_ReceiveData function.

**Table 640. USART\_ReceiveData function**

Function name	USART_ReceiveData
Function prototype	u16 USART_ReceiveData(USART_TypeDef* USARTx)
Behavior description	Returns the most recent data received through the USARTx peripheral.
Input parameter	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Output parameter	None
Return parameter	The received data.
Required preconditions	None
Called functions	None

**Example:**

```
/* Receive one halfword on USART2 */
u16 RxData;
RxData = USART_ReceiveData(USART2);
```

## 20.2.16 USART\_SendBreak function

[Table 641](#) describes the USART\_SendBreak function.

**Table 641. USART\_SendBreak function**

Function name	USART_SendBreak
Function prototype	void USART_SendBreak(USART_TypeDef* USARTx)
Behavior description	Transmits a break character
Input parameter	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Send break character on USART1 */
USART_SendBreak(USART1);
```

## 20.2.17 USART\_SetGuardTime function

[Table 642](#) describes the USART\_SetGuardTime function.

**Table 642. USART\_SetGuardTime function**

Function name	USART_SetGuardTime
Function prototype	void USART_SetGuardTime(USART_TypeDef* USARTx, u8 USART_GuardTime)
Behavior description	Sets the specified USART guard time.
Input parameter1	USARTx: where x can be 1, 2 or 3 to select the USART peripheral. <b>Note:</b> The guard time bits are not available for UART4 and UART5.
Input parameter2	USART_GuardTime: specifies the guard time.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set the guard time to 0x78 */
USART_SetGuardTime(0x78);
```

## 20.2.18 USART\_SetPrescaler function

[Table 643](#) describes the USART\_SetPrescaler function.

**Table 643. USART\_SetPrescaler function**

Function name	USART_SetPrescaler
Function prototype	void USART_SetPrescaler(USART_TypeDef* USARTx, u8 USART_Prescaler)
Behavior description	Sets the USART clock prescaler.
Input parameter1	USARTx: Selects the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5. <b>Note:</b> This function is used for IrDA mode with UART4 and UART5.
Input parameter2	USART_Prescaler: specifies the prescaler.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set the system clock prescaler to 0x56 */
USART_SetPrescaler(0x56);
```

## 20.2.19 USART\_SmartCardCmd function

[Table 644](#) describes the USART\_SmartCardCmd function.

**Table 644. USART\_SmartCardCmd function**

Function name	USART_SmartCardCmd
Function prototype	void USART_SmartCardCmd(USART_TypeDef* USARTx, FunctionalState Newstate)
Behavior description	Enables or disables the USART Smartcard mode.
Input parameter1	USARTx: where x can be 1, 2 or 3 to select the USART peripheral. <b>Note:</b> The Smartcard mode is not available for UART4 and UART5.
Input parameter2	NewState: new state of the Smart Card mode. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the USART1 Smart Card mode */
USART_SmartCardCmd(USART1, ENABLE);
```

## 20.2.20 USART\_SmartCardNACKCmd function

[Table 645](#) describes the USART\_SmartCardNACKCmd function.

**Table 645. USART\_SmartCardNACKCmd function**

Function name	USART_SmartCardNACKCmd
Function prototype	void USART_SmartCardNACKCmd(USART_TypeDef* USARTx, FunctionalState Newstate)
Behavior description	Enables or disables NACK transmission.
Input parameter1	USARTx: where x can be 1, 2 or 3 to select the USART peripheral. <b>Note:</b> The Smartcard mode is not available for UART4 and UART5.
Input parameter3	NewState: new state of the NACK transmission. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the USART1 NACK transmission during parity error */
USART_SmartCardNACKCmd(USART1, ENABLE);
```

## 20.2.21 USART\_HalfDuplexCmd function

[Table 646](#) describes the USART\_HalfDuplexCmd function.

**Table 646. USART\_HalfDuplexCmd function**

Function name	USART_HalfDuplexCmd
Function prototype	void USART_HalfDuplexCmd(USART_TypeDef* USARTx, FunctionalState Newstate)
Behavior description	Enables or disables the USART's Half Duplex mode.
Input parameter1	USARTx: Select the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	NewState: new state of the Half Duplex mode. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enabe HalfDuplex mode for USART2 */
USART_HalfDuplexCmd(USART2, ENABLE);
```

## 20.2.22 USART\_IrDAConfig function

[Table 647](#) describes the USART\_IrDAConfig function.

**Table 647. USART\_IrDAConfig function**

Function name	USART_IrDAConfig
Function prototype	void USART_IrDAConfig(USART_TypeDef* USARTx, u16 USART_IrDAMode)
Behavior description	Configures the USART IrDA mode.
Input parameter1	USARTx: Select the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	USART_IrDAMode: specifies the IrDA mode. Refer to <a href="#">USART_IrDAMode</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### USART\_IrDAMode

USART\_IrDAMode select the IrDA mode. Refer to [Table 648](#) for the values taken by this parameter.

**Table 648. USART\_IrDAMode values**

<i>USART_IrDAMode</i>	Description
USART_IrDAMode_LowPower	IrDA low Power mode
USART_IrDAMode_Normal	IrDA normal mode

### Example:

```
/* USART2 IrDA Low Power Selection */
USART_IrDAConfig(USART2, USART_IrDAMode_LowPower);
```

## 20.2.23 USART\_IrDACmd function

[Table 649](#) describes the USART\_IrDACmd function.

**Table 649. USART\_IrDACmd function**

Function name	USART_IrDACmd
Function prototype	void USART_IrDACmd(USART_TypeDef* USARTx, FunctionalState Newstate)
Behavior description	Enables or disables the USART IrDA mode.
Input parameter1	USARTx: Select the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	NewState: new state of the IrDA mode. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the USART1 IrDA Mode */
USART_IrDACmd(USART1, ENABLE);
```

## 20.2.24 USART\_GetFlagStatus function

[Table 650](#) describes the USART\_GetFlagStatus function.

**Table 650. USART\_GetFlagStatus function**

Function name	USART_GetFlagStatus
Function prototype	FlagStatus USART_GetFlagStatus(USART_TypeDef* USARTx, uint16 USART_FLAG)
Behavior description	Checks whether the specified USART flag is set or not.
Input parameter1	USARTx: Select the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	USART_FLAG: specifies the flag to check. Refer to <a href="#">USART_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of USART_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

### USART\_FLAG

The USART flags that can be checked are listed in the following table:

**Table 651. USART\_FLAG definition**

USART_FLAG	Description
USART_FLAG_CTS	CTS change flag (not available for UART4 and UART5)
USART_FLAG_LBD	LIN Break detection flag
USART_FLAG_TXE	Transmit data register empty flag
USART_FLAG_TC	Transmission complete flag
USART_FLAG_RXNE	Read data register Not empty flag
USART_FLAG_IDLE	Idle line detected
USART_FLAG_ORE	Overrun Error
USART_FLAG_NE	Noise Error
USART_FLAG_FE	Framing Error
USART_FLAG_PE	Parity Error

**Example:**

```
/* Check if the transmit data register is full or not */
FlagStatus Status;
Status = USART_GetFlagStatus(USART1, USART_FLAG_TXE);
```

**20.2.25 USART\_ClearFlag function**

[Table 652](#) describes the USART\_ClearFlag function.

**Table 652. USART\_ClearFlag function**

Function name	USART_ClearFlag
Function prototype	void USART_ClearFlag(USART_TypeDef* USARTx, u16 USART_FLAG)
Behavior description	Clears the USARTx pending flags.
Input parameter1	USARTx: Select the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	USART_FLAG: specifies the flag to clear. Refer to <a href="#">USART_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear Overrun error flag */
USART_ClearFlag(USART1, USART_FLAG_OR);
```



## 20.2.26 USART\_GetITStatus function

[Table 653](#) describes the USART\_GetITStatus function.

**Table 653. USART\_GetITStatus function**

Function name	USART_GetITStatus
Function prototype	ITStatus USART_GetITStatus(USART_TypeDef* USARTx, uint16 USART_IT)
Behavior description	Checks whether the specified USART interrupt has occurred or not.
Input parameter1	USARTx: Select the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	USART_IT: specifies the USART interrupt source to check. Refer to <a href="#">USART_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of USART_IT (SET or RESET).
Required preconditions	None
Called functions	None

### USART\_IT

USART\_IT is used to read the status of USART interrupt pending bits. Refer to [Table 654](#) for the values taken by this parameter.

**Table 654. USART\_IT definition**

USART_IT	Description
USART_IT_PE	Parity Error interrupt
USART_IT_TXE	Transmit interrupt
USART_IT_TC	Transmission Complete interrupt
USART_IT_RXNE	Receive interrupt
USART_IT_IDLE	IDLE line interrupt
USART_IT_LBD	LIN break detection interrupt
USART_IT_CTS	CTS change interrupt (not available for UART4 and UART5)
USART_IT_ORE	Overrun Error interrupt
USART_IT_NE	Noise Error interrupt
USART_IT_FE	Frame Error interrupt

#### Example:

```
/* Get the USART1 Overrun Error interrupt status */
ITStatus ErrorITStatus;
ErrorITStatus = USART_GetITStatus(USART1, USART_IT_ORE);
```

## 20.2.27 USART\_ClearITPendingBit function

[Table 655](#) describes the USART\_ClearITPendingBit function.

**Table 655. USART\_ClearITPendingBit function**

Function name	USART_ClearITPending Bit
Function prototype	<code>void USART_ClearITPendingBit (USART_TypeDef* USARTx, u16 USART_IT)</code>
Behavior description	Clears the USARTx interrupt pending bits.
Input parameter1	USARTx: Select the USART or UART peripheral. This parameter can assume one of the following values: USART1, USART2, USART3, UART4 or UART5.
Input parameter2	USART_IT <sup>(1)</sup> : specifies the interrupt pending bit to clear. Refer to <a href="#">USART_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

1. For the IDLE, ORE, NE, FE and PE pending bits, the application has to read the USART\_DR register after calling this function. The TXE pending bit cannot be cleared by this function, it is cleared only by writing to the USART\_DR register.

**Example:**

```
/* Clear the Overrun Error interrupt pending bit */  
USART_ClearITPendingBit(USART1, USART_IT_ORE);
```

## 21 Window watchdog (WWDG)

The window watchdog (WWDG) is used to detect if a software fault has occurred. A software fault is usually generated by external interference or by unforeseen logical conditions which cause the application program to abandon its normal sequence.

[Section 21.1: WWDG registers](#) describes the data structures used in the WWDG Firmware Library. [Section 21.2: Firmware library functions](#) presents the Firmware Library functions.

### 21.1 WWDG registers

The WWDG register structure, *WWDG\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32 CR;
    vu32 CFR;
    vu32 SR;
} WWDG_TypeDef;
```

[Table 656](#) gives the list of WWDG registers.

**Table 656. WWDG registers**

Register	Description
CR	Window Watchdog Control register
CFR	Window Watchdog Configuration Register
SR	Window Watchdog Status Register

The WWDG peripheral is declared in *stm32f10x\_map.h*, as following:

```
#define PERIPH_BASE          ((u32)0x40000000)
#define APB1PERIPH_BASE     PERIPH_BASE
#define APB2PERIPH_BASE     (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE      (PERIPH_BASE + 0x20000)

#define WWDG_BASE            (APB1PERIPH_BASE + 0x2C00)

#ifndef DEBUG
...
#define _WWDG
    #define WWDG                ((WWDG_TypeDef *) WWDG_BASE)
#endif /* _WWDG */
...
#else /* DEBUG */
...
#define _WWDG
    EXT WWDG_TypeDef            *WWDG;
#endif /* _WWDG */
...
```

```
#endif
```

When using the Debug mode, WWDG pointer is initialized in *stm32f10x\_lib.c*:

```
#ifdef _WWDG
    WWDG = (WWDG_TypeDef *) WWDG_BASE;
#endif /*_WWDG */
```

To access the window watchdog registers, `_WWDG` must be defined in *stm32f10x\_conf.h*, as follows:

```
#define _WWDG
```

## 21.2 Firmware library functions

[Table 657](#) gives the list of the various functions in the WWDG library.

**Table 657. WWDG firmware library functions**

Function name	Description
WWDG_DeInit	Resets the WWDG peripheral registers to their default reset values.
WWDG_SetPrescaler	Sets the WWDG Prescaler.
WWDG_SetWindowValue	Sets the WWDG window value.
WWDG_EnableIT	Enables the WWDG Early Wake-up interrupt (EWI).
WWDG_SetCounter	Sets the WWDG counter value.
WWDG_Enable	Enables WWDG and load the counter value.
WWDG_GetFlagStatus	Checks whether the Early Wake-up interrupt flag is set or not.
WWDG_ClearFlag	Clears Early Wake-up interrupt flag.

### 21.2.1 WWDG\_DeInit function

[Table 658](#) describes the WWDG\_DeInit function.

**Table 658. WWDG\_DeInit function**

Function name	WWDG_DeInit
Function prototype	<code>void WWDG_DeInit(void)</code>
Behavior description	Resets the WWDG peripheral registers to their default reset values.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	RCC_APB1PeriphResetCmd

**Example:**

```
/* Deinitialize the WWDG registers */
WWDG_DeInit();
```

## 21.2.2 WWDG\_SetPrescaler function

[Table 659](#) describes the WWDG\_SetPrescaler function.

**Table 659. WWDG\_SetPrescaler function**

Function name	WWDG_SetPrescaler
Function prototype	<code>void WWDG_SetPrescaler(u32 WWDG_Prescaler)</code>
Behavior description	Sets the WWDG Prescaler.
Input parameter	WWDG_Prescaler: specifies the WWDG Prescaler. Refer to <a href="#">WWDG_Prescaler</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### WWDG\_Prescaler

WWDG\_Prescaler selects the WWDG Prescaler. Refer to [Table 660](#) for the values taken by this parameter.

**Table 660. WWDG\_Prescaler values**

WWDG_Prescaler	Description
WWDG_Prescaler_1	WWDG counter clock = (PCLK1 / 4096) / 1
WWDG_Prescaler_2	WWDG counter clock = (PCLK1 / 4096) / 2
WWDG_Prescaler_4	WWDG counter clock = (PCLK1 / 4096) / 4
WWDG_Prescaler_8	WWDG counter clock = (PCLK1 / 4096) / 8

#### Example:

```
/* Set WWDG prescaler to 8 */
WWDG_SetPrescaler(WWDG_Prescaler_8);
```

### 21.2.3 WWDG\_SetWindowValue function

[Table 661](#) describes WWDG\_SetWindowValue function.

**Table 661. WWDG\_SetWindowValue function**

Function name	WWDG_SetWindowValue
Function prototype	void WWDG_SetWindowValue(u8 WindowValue)
Behavior description	Sets the WWDG window value.
Input parameter	WindowValue: specifies the window value to be compared to the downcounter. This parameter value must be lower than 0x80.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set WWDG window value to 0x50 */  
WWDG_SetWindowValue(0x50);
```

### 21.2.4 WWDG\_EnableIT function

[Table 662](#) describes WWDG\_EnableIT function.

**Table 662. WWDG\_EnableIT function**

Function name	WWDG_EnableIT
Function prototype	void WWDG_EnableIT(void)
Behavior description	Enables the WWDG Early Wake-up interrupt(EWI).
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable WWDG Early wakeup interrupt */  
WWDG_EnableIT();
```

## 21.2.5 WWDG\_SetCounter function

[Table 663](#) describes WWDG\_SetCounter function.

**Table 663. WWDG\_SetCounter function**

Function name	WWDG_SetCounter
Function prototype	void WWDG_SetCounter(u8 Counter)
Behavior description	Sets the WWDG counter value.
Input parameter	Counter: specifies the watchdog counter value. This parameter must be a number between 0x40 and 0x7F.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set WWDG counter value to 0x70 */
WWDG_SetCounter(0x70);
```

## 21.2.6 WWDG\_Enable function

[Table 664](#) describes WWDG\_Enable function.

**Table 664. WWDG\_Enable function**

Function name	WWDG_Enable
Function prototype	void WWDG_Enable(u8 Counter)
Behavior description	Enables WWDG and load the counter value <sup>(1)</sup>
Input parameter	Counter: specifies the watchdog counter value. This parameter must be a number between 0x40 and 0x7F.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

1. Once enabled the WWDG can not be disabled any more.

**Example:**

```
/* Enable WWDG and set counter value to 0x7F */
WWDG_Enable(0x7F);
```

### 21.2.7 WWDG\_GetFlagStatus function

[Table 665](#) describes WWDG\_GetFlagStatus function.

**Table 665. WWDG\_GetFlagStatus function**

Function name	WWDG_GetFlagStatus
Function prototype	FlagStatus WWDG_GetFlagStatus(void)
Behavior description	Checks whether the Early Wake-up interrupt flag is set or not.
Input parameter	None
Output parameter	None
Return parameter	The new state of the Early Wake-up interrupt flag (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Test if the counter has reached the value 0x40 */
FlagStatus Status;
Status = WWDG_GetFlagStatus();
if (Status == RESET)
{
    ...
}
else
{
    ...
}
```

### 21.2.8 WWDG\_ClearFlag function

[Table 666](#) describes WWDG\_ClearFlag function.

**Table 666. WWDG\_ClearFlag function**

Function name	WWDG_ClearFlag
Function prototype	void WWDG_ClearFlag(void)
Behavior description	Clears Early Wake-up interrupt flag.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear EWI flag */
WWDG_ClearFlag();
```



## 22 Digital/analog converter (DAC)

The digital/analog converter (DAC) module is a 12-bit, voltage output digital/analog converter.

[Section 22.1](#) describes the data structures used in the DAC firmware library. [Section 22.2](#) one presents the firmware library functions.

### 22.1 DAC register structure

The `DAC_TypeDef` DAC register structure is defined in the `stm32f10x_map.h` file as follows:

```
typedef struct
{
    vu32 CR;
    vu32 SWTRIGR;
    vu32 DHR12R1;
    vu32 DHR12L1;
    vu32 DHR8R1;
    vu32 DHR12R2;
    vu32 DHR12L2;
    vu32 DHR8R2;
    vu32 DHR12RD;
    vu32 DHR12LD;
    vu32 DHR8RD;
    vu32 DOR1;
    vu32 DOR2;
} DAC_TypeDef;
```

[Table 667](#) shows the DAC registers.

**Table 667. DAC registers**

Register	Description
CR	DAC Control Register
SWTRIGR	DAC Software Trigger Register
DHR12R1	DAC channel1 12-bit Right Aligned Data Holding Register
DHR12L1	DAC channel1 12-bit Left Aligned Data Holding Register
DHR8R1	DAC channel1 8-bit Right Aligned Data Holding Register
DHR12R2	DAC channel2 12-bit Right Aligned Data Holding Register
DHR12L2	DAC channel2 12-bit Left Aligned Data Holding Register
DHR8R2	DAC channel2 8-bit Right Aligned Data Holding Register
DHR12RD	Dual DAC 12-bit Right Aligned Data Holding Register
DHR12LD	Dual DAC 12-bit Left Aligned Data Holding Register
DHR8RD	Dual DAC 8-bit Right Aligned Data Holding Register
DOR1	DAC channel1 Data Output Register
DOR2	DAC channel2 Data Output Register

The DAC peripheral is declared in the same file:

```
...
#define PERIPH_BASE    0x40000000
#define APB1PERIPH_BASE    (PERIPH_BASE)
...
#define DAC_BASE      (APB1PERIPH_BASE + 0x7400)
...
#ifndef DEBUG
...
#define DAC ((DAC_TypeDef *) DAC_BASE)
...
#else
...
#ifdef _DAC
    EXT DAC_TypeDef    *DAC;
#endif /*_DAC */
...
#endif
```

When the debug mode is used, `_DAC` pointer is initialized in the `stm32f10x_lib.c` file:

```
...
#ifdef _DAC
    DAC = (DAC_TypeDef *) DAC_BASE;
#endif /*_DAC */
...
```

`_DAC` must be defined in the `stm32f10x_conf.h` file, to access the peripheral registers as follows:

```
...
#define _DAC
...
```

## 22.2 Firmware library functions

[Table 668](#) gives the list of the DAC library functions.

**Table 668. DAC firmware library functions**

Function name	Description
DAC_DeInit	De-initializes the DAC peripheral registers to their default reset values.
DAC_Init	Initializes the DAC peripheral according to the specified parameters in DAC_InitStruct.
DAC_StructInit	Fills each DAC_InitStruct member with its default value.
DAC_Cmd	Enables or disables the specified DAC channel.
DAC_DMACmd	Enables or disables the specified DAC channel DMA request.
DAC_SoftwareTriggerCmd	Enables or disables the selected DAC channel software trigger.
DAC_DualSoftwareTriggerCmd	Simultaneously enables or disables the two DAC channel software triggers.
DAC_WaveGenerationCmd	Enables or disables the selected DAC channel wave generation.
DAC_SetChannel1Data	Sets the specified data holding register value for DAC channel1.
DAC_SetChannel2Data	Sets the specified data holding register value for DAC channel2.
DAC_SetDualChannelData	Sets the specified data holding register value for dual channel DAC.
DAC_GetDataOutputValue	Returns the last data output value for the selected DAC channel.

### 22.2.1 DAC\_DeInit

[Table 669](#) describes the DAC\_DeInit function.

**Table 669. DAC\_DeInit function**

Function name	DAC_DeInit
Function prototype	<code>void DAC_DeInit(void)</code>
Behavior description	De-initializes the DAC peripheral registers to their default reset values.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called function	RCC_APB1PeriphClockCmd().

**Example:**

```
/* Deinitialize the DAC */
DAC_DeInit();
```

## 22.2.2 DAC\_Init

[Table 670](#) describes the DAC\_Init function.

**Table 670. DAC\_Init function**

Function name	DAC_Init
Function prototype	<code>void DAC_Init(u32 DAC_Channel, DAC_InitTypeDef* DAC_InitStruct)</code>
Behavior description	Initializes the DAC peripheral according to the specified parameters in DAC_InitStruct.
Input parameter1	DAC_Channel: specifies the selected DAC channel. Refer to <a href="#">DAC_Channel</a> for more details on the allowed values for this parameter.
Input parameter2	DAC_InitStruct: pointer to a DAC_InitTypeDef structure that contains the configuration information for the DAC peripheral. Refer to <a href="#">DAC_InitTypeDef</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## DAC\_Channel

Specifies the DAC channel to configure. Refer to [Table 671](#) for the values taken by this parameter.

**Table 671. DAC\_Channel definition**

DAC_Channel	Description
DAC_Channel_1	DAC Channel1 selected
DAC_Channel_2	DAC Channel2 selected

## DAC\_InitTypeDef

The DAC\_InitTypeDef structure is defined in the *stm32f10x\_dac.h* file:

```
typedef struct
{
  u32 DAC_Trigger;
      u32 DAC_WaveGeneration;
  u32 DAC_LFSRUnmask_TriangleAmplitude;
  u32 DAC_OutputBuffer;
} DAC_InitTypeDef;
```

## DAC\_Trigger

Specifies the external trigger for the selected DAC channel (see [Table 672](#)).

**Table 672. DAC\_Trigger definition**

DAC_Trigger	Description
DAC_Trigger_None	Conversion is automatic once the DAC1_DHRxxxx register has been loaded, and not by external trigger
DAC_Trigger_T6_TRGO	TIM6 TRGO selected as external conversion trigger for DAC channel
DAC_Trigger_T8_TRGO	TIM8 TRGO selected as external conversion trigger for DAC channel
DAC_Trigger_T7_TRGO	TIM7 TRGO selected as external conversion trigger for DAC channel
DAC_Trigger_T5_TRGO	TIM5 TRGO selected as external conversion trigger for DAC channel
DAC_Trigger_T2_TRGO	TIM2 TRGO selected as external conversion trigger for DAC channel
DAC_Trigger_T4_TRGO	TIM4 TRGO selected as external conversion trigger for DAC channel
DAC_Trigger_Ext_IT9	External interrupt 9 event selected as external conversion trigger for DAC channel
DAC_Trigger_Software	Conversion started by external software trigger for DAC channel

**DAC\_WaveGeneration**

Specifies whether DAC channel noise waves or triangle waves are generated, or whether no wave is generated. [Table 673](#) shows the values that can be assumed by this member.

**Table 673. DAC\_WaveGeneration definition**

DAC_WaveGeneration	Description
DAC_WaveGeneration_None	No wave is generated on DAC channel
DAC_WaveGeneration_Noise	Noise wave is generated on DAC channel
DAC_WaveGeneration_Triangle	Triangle wave is generated on DAC channel

**DAC\_LFSRUnmask\_TriangleAmplitude**

Specifies the LFSR mask for noise wave generation or the maximum amplitude triangle generation for the DAC channel. [Table 674](#) shows the values that can be assumed by this member.

**Table 674. DAC\_LFSRUnmask\_TriangleAmplitude definition**

DAC_LFSRUnmask_TriangleAmplitude	Description
DAC_LFSRUnmask_Bit0 / DAC_TriangleAmplitude_1	Unmask DAC channel LFSR bit0 for noise wave generation / Select max triangle amplitude of 1
DAC_LFSRUnmask_Bits1_0 / DAC_TriangleAmplitude_3	Unmask DAC channel LFSR bit[1:0] for noise wave generation / Select max triangle amplitude of 3
DAC_LFSRUnmask_Bits2_0 / DAC_TriangleAmplitude_7	Unmask DAC channel LFSR bit[2:0] for noise wave generation / Select max triangle amplitude of 7
DAC_LFSRUnmask_Bits3_0 / DAC_TriangleAmplitude_15	Unmask DAC channel LFSR bit[3:0] for noise wave generation / Select max triangle amplitude of 15
DAC_LFSRUnmask_Bits4_0 / DAC_TriangleAmplitude_31	Unmask DAC channel LFSR bit[4:0] for noise wave generation / Select max triangle amplitude of 31

**Table 674. DAC\_LFSRUnmask\_TriangleAmplitude definition (continued)**

DAC_LFSRUnmask_TriangleAmplitude	Description
DAC_LFSRUnmask_Bits5_0 / DAC_TriangleAmplitude_63	Unmask DAC channel LFSR bit[5:0] for noise wave generation / Select max triangle amplitude of 63
DAC_LFSRUnmask_Bits6_0 / DAC_TriangleAmplitude_127	Unmask DAC channel LFSR bit[6:0] for noise wave generation / Select max triangle amplitude of 127
DAC_LFSRUnmask_Bits7_0 / DAC_TriangleAmplitude_255	Unmask DAC channel LFSR bit[7:0] for noise wave generation / Select max triangle amplitude of 255
DAC_LFSRUnmask_Bits8_0 / DAC_TriangleAmplitude_511	Unmask DAC channel LFSR bit[8:0] for noise wave generation / Select max triangle amplitude of 511
DAC_LFSRUnmask_Bits9_0 / DAC_TriangleAmplitude_1023	Unmask DAC channel LFSR bit[9:0] for noise wave generation / Select max triangle amplitude of 1023
DAC_LFSRUnmask_Bits10_0 / DAC_TriangleAmplitude_2047	Unmask DAC channel LFSR bit[10:0] for noise wave generation / Select max triangle amplitude of 2047
DAC_LFSRUnmask_Bits11_0 / DAC_TriangleAmplitude_4095	Unmask DAC channel LFSR bit[11:0] for noise wave generation / Select max triangle amplitude of 4095

**DAC\_OutputBuffer**

Specifies whether the DAC channel output buffer is enabled or disabled. [Table 675](#) shows the values that can be assumed by this member.

**Table 675. DAC\_OutputBuffer definition**

DAC_OutputBuffer	Description
DAC_OutputBuffer_Enable	Output buffer is enabled for DAC channel
DAC_OutputBuffer_Disable	Output buffer is disabled for DAC channel

**Example:**

```
/* Initialize the DAC channel1 according to the DAC_InitStructure
members */
DAC_InitTypeDef DAC_InitStructure;

DAC_InitStructure.DAC_Trigger = DAC_Trigger_T6_TRGO;
DAC_InitStructure.DAC_WaveGeneration = DAC_WaveGeneration_Noise;
DAC_InitStructure.DAC_LFSRUnmask_TriangleAmplitude =
DAC_LFSRUnmask_Bits11_0;
DAC_InitStructure.DAC_OutputBuffer = DAC_OutputBuffer_Enable;
DAC_Init(DAC_Channel_1, &DAC_InitStructure);
```

### 22.2.3 DAC\_StructInit

[Table 676](#) describes the DAC\_StructInit function.

**Table 676. DAC\_StructInit function**

Function name	DAC_StructInit
Function prototype	void DAC_StructInit(DAC_InitTypeDef* DAC_InitStruct)
Behavior description	Fills each DAC_InitStruct member with its default value.
Input parameter	DAC_InitStruct: pointer to an DAC_InitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### DAC\_InitStruct

[Table 677](#) gives the values that can be assumed by the DAC\_InitStruct members.

**Table 677. DAC\_InitStruct definition**

DAC_InitStruct	Default values
DAC_Trigger	DAC_Trigger_None
DAC_WaveGeneration	DAC_WaveGeneration_None
DAC_LFSRUnmask_TriangleAmplitude	DAC_LFSRUnmask_Bit0
DAC_OutputBuffer	DAC_OutputBuffer_Enable

#### Example:

```
/* Initialize a DAC_InitTypeDef structure. */
DAC_InitTypeDef DAC_InitStructure;
DAC_StructInit(&DAC_InitStructure);
```

## 22.2.4 DAC\_Cmd

[Table 678](#) describes the DAC\_Cmd function.

**Table 678. DAC\_Cmd function**

Function name	DAC_Cmd
Function prototype	void DAC_Cmd(u32 DAC_Channel, FunctionalState NewState)
Behavior description	Enables or disables the specified DAC channel.
Input parameter1	DAC_Channel: specifies the selected DAC channel. Refer to <a href="#">DAC_Channel</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the selected DAC channel. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable DAC channel1 */
DAC_Cmd(DAC_Channel_1, ENABLE);
```

## 22.2.5 DAC\_DMAMCmd

[Table 679](#) describes the DAC\_DMAMCmd function.

**Table 679. DAC\_DMAMCmd function**

Function name	DAC_DMAMCmd
Function prototype	DAC_DMAMCmd(u32 DAC_Channel, FunctionalState NewState)
Behavior description	Enables or disables the specified DAC channel DMA request.
Input parameter1	DAC_Channel: specifies the selected DAC channel Refer to <a href="#">DAC_Channel</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the selected DAC channel DMA request. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called Functions	None

**Example:**

```
/* Enable DAC channel2 DMA request */
DAC_DMAMCmd(DAC_Channel_2, ENABLE);
```



## 22.2.6 DAC\_SoftwareTriggerCmd

[Table 680](#) describes the DAC\_SoftwareTriggerCmd function.

**Table 680. DAC\_SoftwareTriggerCmd function**

Function name	DAC_SoftwareTriggerCmd
Function prototype	void DAC_SoftwareTriggerCmd(u32 DAC_Channel, FunctionalState NewState)
Behavior description	Enables or disables the selected DAC channel software trigger.
Input parameter1	DAC_Channel: specifies the selected DAC channel. Refer to <a href="#">DAC_Channel</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the selected DAC channel software trigger. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable DAC channel1 software trigger */
DAC_SoftwareTriggerCmd(DAC_Channel_1, ENABLE);
```

## 22.2.7 DAC\_DualSoftwareTriggerCmd

[Table 676](#) describes the DAC\_DualSoftwareTriggerCmd function.

**Table 681. DAC\_DualSoftwareTriggerCmd function**

Function name	DAC_DualSoftwareTriggerCmd
Function prototype	void DAC_DualSoftwareTriggerCmd(FunctionalState NewState)
Behavior description	Enables or disables the selected DAC channel software trigger.
Input parameter1	NewState: new state of the dual DAC channel software trigger. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable both DAC channels software trigger */
DAC_DualSoftwareTriggerCmd(ENABLE);
```

## 22.2.8 DAC\_WaveGenerationCmd

[Table 676](#) describes the DAC\_WaveGenerationCmd function.

**Table 682. DAC\_WaveGenerationCmd function**

Function name	DAC_WaveGenerationCmd
Function prototype	void DAC_WaveGenerationCmd(u32 DAC_Channel, u32 DAC_Wave, FunctionalState NewState)
Behavior description	Enables or disables the selected DAC channel wave generation.
Input parameter1	DAC_Channel: specifies the selected DAC channel Refer to <a href="#">DAC_Channel</a> for more details on the allowed values for this parameter.
Input parameter2	DAC_Wave: specifies the wave type to enable or disable. Refer to <a href="#">DAC_Wave</a> for more details on the allowed values for this parameter.
Input parameter3	NewState: new state of the selected DAC channel wave generation. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### DAC\_Wave

[Table 683](#) gives the values to be selected to have the desired DAC wave type.

**Table 683. Dac\_Wave definition**

DAC_Wave	Description
DAC_Wave_Noise	Selects noise wave generation
DAC_Wave_Triangle	Selects triangle wave generation

#### Example:

```
/* Enable DAC channel1 noise wave generation */
DAC_Wave GenerationCmd(DAC_Channel_1, DAC_Wave_Noise, ENABLE);
```

## 22.2.9 DAC\_SetChannel1Data

[Table 676](#) describes the DAC\_SetChannel1Data function.

**Table 684. DAC\_SetChannel1Data function**

Function name	DAC_SetChannel1Data
Function prototype	void DAC_SetChannel1Data(u32 DAC_Align, u16 Data)
Behavior description	Set the specified data holding register value for DAC channel1.
Input parameter1	DAC_Align: Specifies the data alignment for DAC channel1. Refer to <a href="#">DAC_Align</a> for more details on the allowed values for this parameter.
Input parameter2	Data: the data to be loaded in the selected data holding register. The value must be: - 12bit right data alignment: Data<= 0x0FFF - 12bit left data alignment: Data<= 0xFFFF0 - 8bit right data alignment: Data<= 0x00FF
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### DAC\_Align

[Table 685](#) gives the values used to select the desired data holding register.

**Table 685. DAC\_Align definition**

DAC_Align	Description
DAC_Align_12b_R	12-bit right data alignment for the selected DAC channel
DAC_Align_12b_L	12-bit left data alignment for the selected DAC channel
DAC_Align_8b_R	8-bit right data alignment for the selected DAC channel

#### Example:

```
/* Set 0x500 value in the DAC channel1 12bit right alignment data
holding register */
DAC_SetChannel1Data(DAC_Align_12b_R, 0x500);
```

## 22.2.10 DAC\_SetChannel2Data

[Table 676](#) describes the DAC\_SetChannel2Data function.

**Table 686. DAC\_SetChannel2Data function**

Function name	DAC_SetChannel2Data
Function prototype	void DAC_SetChannel2Data(u32 DAC_Align, u16 Data)
Behavior description	Sets the specified data holding register value for DAC channel2.
Input parameter1	DAC_Align: specifies the data alignment for DAC channel2. Refer to <a href="#">DAC_Align</a> for more details on the allowed values for this parameter.
Input parameter2	Data: specifies the data to be loaded in the selected data holding register. The value must be: – 12-bit right data alignment: Data<= 0x0FFF – 12-bit left data alignment: Data<= 0xFFFF0 – 8-bit right data alignment: Data<= 0x00FF
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set 0x8880 value in the DAC channel2 12bit left alignment data
holding register */
DAC_SetChannel2Data(DAC_Align_12b_L, 0x8880);
```

## 22.2.11 DAC\_SetDualChannelData

[Table 676](#) describes the DAC\_SetDualChannelData function.

**Table 687. DAC\_SetDualChannelData function**

Function name	DAC_SetDualChannelData
Function prototype	void DAC_SetDualChannelData(u32 DAC_Align, u16 Data2, u16 Data1)
Behavior description	Sets the specified data holding register value for dual channel DAC.
Input parameter1	DAC_Align: specifies the data alignment for dual channel DAC. Refer to <a href="#">DAC_Align</a> for more details on the allowed values for this parameter.
Input parameter2	Data2: specifies the data for DAC channel2 to be loaded in the selected data holding register. The value must be: – 12-bit right data alignment: Data<= 0x0FFF – 12-bit left data alignment: Data<= 0xFFFF0 – 8-bit right data alignment: Data<= 0x00FF
Input parameter3	Data1: specifies the data for DAC channel1 to be loaded in the selected data holding register. The value must be: – 12-bit right data alignment: Data<= 0x0FFF – 12-bit left data alignment: Data<= 0xFFFF0 – 8-bit right data alignment: Data<= 0x00FF
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set 0xF1 value for DAC channel1 and 0x40 for DAC channel2, in the
dual channel DAC 8bit right alignement data holding register */
DAC_SetDualChannelData(DAC_Align_8b_R, 0x40, 0xF1);
```

## 22.2.12 DAC\_GetDataOutputValue

[Table 676](#) describes the DAC\_GetDataOutputValue function.

**Table 688. DAC\_GetDataOutputValue function**

Function name	DAC_GetDataOutputValue
Function prototype	u16 DAC_GetDataOutputValue(u32 DAC_Channel)
Behavior description	Returns the last data output value of the selected DAC channel.
Input parameter	DAC_Channel: specifies the selected DAC channel Refer to <a href="#">DAC_Channel</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The selected DAC channel data output value.
Required preconditions	None
Called functions	None

**Example:**

```
/* Returns the DAC channel1 data output value */  
u16 DataValue;  
DataValue = DAC_GetDataOutputValue(DAC_Channel_1);
```

## 23 Flexible static memory controller (FSMC)

The FSMC block is able to interface with

[Section 23.1](#) describes the data structures used in the FSMC firmware library. [Section 23.2](#) presents the firmware library functions.

### 23.1 FSMC register structure

The *FSMC\_TypeDef* FSMC register structure is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32  BPCR[8];
} FSMC_Bank1_TypeDef;

typedef struct
{
    vu32  BWTR[7];
} FSMC_Bank1E_TypeDef;

typedef struct
{
    vu32  PCR2;
    vu32  SR2;
    vu32  PMEM2;
    vu32  PATT2;
    u32   RESERVED0;
    vu32  ECCR2;
} FSMC_Bank2_TypeDef;

typedef struct
{
    vu32  PCR3;
    vu32  SR3;
    vu32  PMEM3;
    vu32  PATT3;
    u32   RESERVED0;
    vu32  ECCR3;
} FSMC_Bank3_TypeDef;

typedef struct
{
    vu32  PCR4;
    vu32  SR4;
    vu32  PMEM4;
    vu32  PATT4;
    vu32  PIO4;
} FSMC_Bank4_TypeDef;
```

Table 689 gives the list of FSMC registers.

**Table 689. FSMC registers**

Register	Description
FSMC_BCR1	SRAM/NOR-Flash chip-select control register1
FSMC_BTR1	SRAM/NOR-Flash chip-select timing register1
FSMC_BWTR1	SRAM/NOR-Flash chip-select timing register1
FSMC_BCR2	SRAM/NOR-Flash chip-select control register2
FSMC_BTR2	SRAM/NOR-Flash chip-select timing register2
FSMC_BWTR2	SRAM/NOR-Flash chip-select timing register2
FSMC_BCR3	SRAM/NOR-Flash chip-select control register3
FSMC_BTR3	SRAM/NOR-Flash chip-select timing register4
FSMC_BWTR3	SRAM/NOR-Flash chip-select timing register3
FSMC_BCR4	SRAM/NOR-Flash chip-select control register4
FSMC_BTR4	SRAM/NOR-Flash chip-select timing register3
FSMC_BWTR4	SRAM/NOR-Flash chip-select timing register4
FSMC_PCR2	PC Card/NAND Flash control register2
FSMC_SR2	FIFO status and interrupt register2
FSMC_PMEM2	Common memory space timing register2
FSMC_PATT2	Attribute memory space timing register2
FSMC_ECCR2	ECC result registers2
FSMC_PCR3	PC Card/NAND Flash control register3
FSMC_SR3	FIFO status and interrupt register3
FSMC_PMEM3	Common memory space timing register3
FSMC_PATT3	Attribute memory space timing register3
FSMC_ECCR3	ECC result registers3
FSMC_PCR4	PC Card/NAND Flash control register4
FSMC_PMEM4	Common memory space timing register4
FSMC_PATT4	Attribute memory space timing register3
FSMC_PIO4	I/O space timing register4

When the debug mode is used, the `_FSMC` pointer is initialized in the `stm32f10x_lib.c` file. `_FSMC` must be defined in the `stm32f10x_conf.h` file to access the peripheral registers. The FSMC peripheral is declared in the same file:

```
/* FSMC registers base address */
#define FSMC_R_BASE          ((u32)0xA0000000)
...
/* FSMC Bankx registers base address */
#define FSMC_Bank1_R_BASE    (FSMC_R_BASE + 0x0000)
#define FSMC_Bank1E_R_BASE   (FSMC_R_BASE + 0x0104)
#define FSMC_Bank2_R_BASE    (FSMC_R_BASE + 0x0060)
```



```

#define FSMC_Bank3_R_BASE      (FSMC_R_BASE + 0x0080)
#define FSMC_Bank4_R_BASE      (FSMC_R_BASE + 0x00A0)
...
#ifndef DEBUG
...
#define _FSMC
    #define FSMC_Bank1          ((FSMC_Bank1_TypeDef *)
FSMC_Bank1_R_BASE)
    #define FSMC_Bank1E        ((FSMC_Bank1E_TypeDef *)
FSMC_Bank1E_R_BASE)
    #define FSMC_Bank2          ((FSMC_Bank2_TypeDef *)
FSMC_Bank2_R_BASE)
    #define FSMC_Bank3          ((FSMC_Bank3_TypeDef *)
FSMC_Bank3_R_BASE)
    #define FSMC_Bank4          ((FSMC_Bank4_TypeDef *)
FSMC_Bank4_R_BASE)
#endif /*_FSMC */
...
#else /* DEBUG */
...
#define _FSMC
    EXT FSMC_Bank1_TypeDef      *FSMC_Bank1;
    EXT FSMC_Bank1E_TypeDef     *FSMC_Bank1E;
    EXT FSMC_Bank2_TypeDef      *FSMC_Bank2;
    EXT FSMC_Bank3_TypeDef      *FSMC_Bank3;
    EXT FSMC_Bank4_TypeDef      *FSMC_Bank4;
#endif /*_FSMC */
...
#endif /* DEBUG */
When debug mode is used, _FSMC pointer is initialized in
stm32f10x_lib.c file :
...
#define _FSMC
    FSMC_Bank1 = (FSMC_Bank1_TypeDef *)    FSMC_Bank1_R_BASE;
    FSMC_Bank1E = (FSMC_Bank1E_TypeDef *)  FSMC_Bank1E_R_BASE;
    FSMC_Bank2 = (FSMC_Bank2_TypeDef *)    FSMC_Bank2_R_BASE;
    FSMC_Bank3 = (FSMC_Bank3_TypeDef *)    FSMC_Bank3_R_BASE;
    FSMC_Bank4 = (FSMC_Bank4_TypeDef *)    FSMC_Bank4_R_BASE;
#endif /*_FSMC */
...
_FSMC must be defined, in stm32f10x_conf.h file, to access the
peripheral registers as follows:
...
#define _FSMC
...

```

## 23.2 Firmware library functions

[Table 690](#) gives the list of the FSMC library functions.

**Table 690. FSMC firmware library functions**

Function name	Description
FSMC_NORSRAMDeInit	Re-initializes the FSMC NOR bank registers to their default reset values.
FSMC_NANDDeInit	Re-initializes the FSMC NAND bank registers to their default reset values.
FSMC_PCCARDDeInit	Re-initializes the FSMC PCCARD bank registers to their default reset values.
FSMC_NORSRAMInit	Initializes the FSMC NOR memory bank according to the parameters specified in FSMC_NORInitStruct.
FSMC_NANDInit	Initializes the FSMC NOR memory bank according to the parameters specified in FSMC_NANDInitStruct.
FSMC_PCCARDInit	Initializes the FSMC PCCARD memory bank according to the parameters specified in FSMC_NORInitStruct.
FSMC_NORSRAMStructInit	Fills each FSMC_NORInitStruct member with its default value.
FSMC_NANDStructInit	Fills each FSMC_NORInitStruct member with its default value.
FSMC_PCCARDStructInit	Fills each FSMC_NORInitStruct member with its default value.
FSMC_NORSRAMCmd	Enables or disables the NOR/SRAM memory bank1.
FSMC_NANDCmd	Enables or disables the specified NAND memory bank(1 or 2).
FSMC_PCCARDCmd	Enables or disables the PCCARD memory bank3.
FSMC_NANDECCCmd	Enables or disables the NAND ECC feature.
FSMC_GetECC	Returns the error correction code register value.
FSMC_ITConfig	Enables or disables the specified interrupts.
FSMC_GetFlagStatus	Checks whether the specified FSMC flag is set or not.
FSMC_ClearFlag	Clears the FSMC's pending flags.
FSMC_GetITStatus	Checks whether the specified FSMC interrupt has occurred or not.
FSMC_ClearITPendingBit	Clears the FSMC's interrupt pending bits.

### 23.2.1 FSMC\_NORSRAMDeInit

[Table 691](#) describes the FSMC\_NORSRAMDeInit function.

**Table 691. FSMC\_NORSRAMDeInit function**

Function name	FSMC_NORSRAMDeInit
Function prototype	<code>void FSMC_NORSRAMDeInit(u32 FSMC_Bank)</code>
Behavior description	Re-initializes the FSMC NOR/SRAM bank registers to their default reset values.
Input parameter	FSMC_Bank: specifies the FSMC NOR/SRAM bank to be used. Refer to <a href="#">FSMC_Bank</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### FSMC\_Bank

Specifies the NOR/SRAM Banks that can be used. [Table 692](#) shows the values assumed by this parameter.

**Table 692. FSMC\_Bank definition**

FSMC_Bank	Description
FSMC_Bank1_NORSRAM1	FSMC Bank1 NOR/SRAM1
FSMC_Bank1_NORSRAM2	FSMC Bank1 NOR/SRAM2
FSMC_Bank1_NORSRAM3	FSMC Bank1 NOR/SRAM3
FSMC_Bank1_NORSRAM4	FSMC Bank1 NOR/SRAM4

#### Example:

```
/* Deinitialize the FSMC NOR/SRAM Memory Bank1 */
FSMC_NORSRAMDeInit(FSMC_Bank1_NORSRAM1);
```

### 23.2.2 FSMC\_NANDDeInit

[Table 693](#) describes the FSMC\_NANDDeInit function.

**Table 693. FSMC\_NANDDeInit function**

Function name	FSMC_NANDDeInit
Function prototype	<code>void FSMC_NANDDeInit(u32 FSMC_Bank)</code>
Behavior description	Re-initializes the FSMC NAND bank registers to their default reset values.
Input parameter	FSMC_Bank: specifies the NAND FSMC bank to be used. Refer to <a href="#">FSMC_Bank</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

#### FSMC\_Bank

Specifies the NAND banks that can be used. [Table 692](#) shows the values assumed by this parameter.

**Table 694. FSMC\_Bank definition**

FSMC_Bank	Description
FSMC_Bank2_NAND	FSMC Bank2 NAND
FSMC_Bank3_NAND	FSMC Bank3 NAND

**Example:**

```
/* Deinitialize the FSMC NAND Memory Bank3 */  
FSMC_NANDDeInit(FSMC_Bank3_NAND);
```

### 23.2.3 FSMC\_PCCARDDeInit

[Table 695](#) describes the FSMC\_PCCARDDeInit function.

**Table 695. FSMC\_PCCARDDeInit function**

Function name	FSMC_PCCARDDeInit
Function prototype	<code>void FSMC_PCCARDDeInit(void)</code>
Behavior description	Re-initializes the FSMC PCCARD bank registers to their default reset values.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Deinitialize the FSMC PCCARD Memory Bank */
FSMC_PCCARDDeInit();
```

### 23.2.4 FSMC\_NORSRAMInit

[Table 696](#) describes the FSMC\_NORSRAMInit function.

**Table 696. FSMC\_NORSRAMInit function**

Function name	FSMC_NORSRAMInit
Function prototype	<code>void FSMC_NORSRAMInit(FSMC_NORSRAMInitTypeDef* FSMC_NORSRAMInitStruct)</code>
Behavior description	Initializes the FSMC NOR/SRAM banks according to the specified parameters in FSMC_NORSRAMInitStruct.
Input parameter1	FSMC_NORSRAMInitStruct: pointer to an FSMC_NORSRAMInitTypeDef structure that contains the configuration information for the specified FSMC NOR/SRAM banks. Refer to <a href="#">FSMC_NORSRAMInitTypeDef</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The FSMC\_NORSRAMTimingInitTypeDef and FSMC\_NORSRAMInitTypeDef structures are defined in the *stm32f10x\_fsmc.h* file:

## FSMC\_NORSRAMTimingInitTypeDef

```
typedef struct
{
    u32  FSMC_AddSetupTime;
    u32  FSMC_AddHoldTime;
    u32  FSMC_DataSetupTime;
    u32  FSMC_BusTurnaroundDuration;
    u32  FSMC_CLKDivision;
    u32  FSMC_DataLatency;
    u32  FSMC_AccessMode;
}FSMC_NORSRAMTimingInitTypeDef;
```

### FSMC\_AddSetupTime

Defines the number of HCLK cycles to configure the duration of the address setup time. This parameter can be a value between 0 and 0xF. It is not used with synchronous NOR Flash memories.

### FSMC\_AddHoldTime

Defines the number of HCLK cycles to configure the duration of the address hold time. This parameter can be a value between 0 and 0xF. It is not used with synchronous NOR Flash memories.

### FSMC\_DataSetupTime

Defines the number of HCLK cycles to configure the duration of the data setup time. This parameter can be a value between 0 and 0xFF. It is used for SRAMs, ROMs and asynchronous multiplexed NOR Flash memories.

### FSMC\_BusTurnaroundDuration

Defines the number of HCLK cycles to configure the duration of the bus turnaround. This parameter can be a value between 0 and 0xF. It is only used for multiplexed NOR Flash memories.

### FSMC\_CLKDivision

Defines the number of HCLK cycles to configure the duration of the data setup time. This parameter can be a value between 0 and 0xF. This parameter is not used for asynchronous NOR Flash, SRAM or ROM accesses.

### FSMC\_DataLatency

Defines the number of memory clock cycles to issue to the memory before getting the first data. The value of this parameter depends on the memory type as shown below:

- It must be set to 0 in case of a CRAM
- It is don't care in asynchronous NOR, SRAM or ROM accesses
- It may assume a value between 0 and 0xF in NOR Flash memories with synchronous burst mode enable

**FSMC\_AccessMode**

Specifies the asynchronous access mode. [Table 697](#) gives the values assumed by this parameter.

**Table 697. FSMC\_AccessMode definition**

FSMC_AccessMode	Description
FSMC_AccessMode_A	Access mode A.
FSMC_AccessMode_B	Access mode B.
FSMC_AccessMode_C	Access mode C.
FSMC_AccessMode_D	Access mode D.

**FSMC\_NORSRAMInitTypeDef**

```
typedef struct
{
    u32  FSMC_Bank;
    u32  FSMC_DataAddressMux;
    u32  FSMC_MemoryType;
    u32  FSMC_MemoryDataWidth;
    u32  FSMC_BurstAccessMode;
    u32  FSMC_WaitSignalPolarity;
    u32  FSMC_WrapMode;
    u32  FSMC_WaitSignalActive;
    u32  FSMC_WriteOperation;
    u32  FSMC_WaitSignal;
    u32  FSMC_ExtendedMode;
    u32  FSMC_AsyncWait;
    u32  FSMC_WriteBurst;
    /* Timing Parameters for write and read access if the
    ExtendedMode is not used*/
    FSMC_NORSRAMTimingInitTypeDef*  FSMC_ReadWriteTimingStruct;
    /* Timing Parameters for write access if the ExtendedMode is
    used*/
    FSMC_NORSRAMTimingInitTypeDef*  FSMC_WriteTimingStruct;
}FSMC_NORSRAMInitTypeDef;
```

**FSMC\_Bank**

Specifies the memory bank that will be used. [Table 698](#) gives the values assumed by this parameter.

**Table 698. FSMC\_Bank definition**

FSMC_Bank	Description
FSMC_Bank1_NORSRAM1	BANK1 NOR SRAM1
FSMC_Bank1_NORSRAM2	BANK1 NOR SRAM2
FSMC_Bank1_NORSRAM3	BANK1 NOR SRAM3
FSMC_Bank1_NORSRAM4	BANK1 NOR SRAM4

**FSMC\_DataAddressMux**

Specifies whether the address and data values are multiplexed on the databus or not. [Table 699](#) gives the values assumed by this member.

**Table 699. FSMC\_DataAddressMux definition**

FSMC_DataAddressMux	Description
FSMC_DataAddressMux_Disable	Address/Data non multiplexed
FSMC_DataAddressMux_Enable	Address/Data multiplexed on databus

**FSMC\_MemoryType**

Specifies the type of external memory attached to the corresponding memory bank. [Table 700](#) gives the values assumed by this member.

**Table 700. FSMC\_MemoryType definition**

FSMC_MemoryType	Description
FSMC_MemoryType_SRAM	SRAM and ROM memory
FSMC_MemoryType_CRAM	Cellular RAM memory
FSMC_MemoryType_NOR	NOR and OneNAND™ memory
FSMC_MemoryType_COSMORAM	COSMO RAM memory

**FSMC\_MemoryDataWidth**

Specifies the external memory device width. [Table 700](#) gives the values assumed by this member.

**Table 701. FSMC\_MemoryDataWidth definition**

FSMC_MemoryDataWidth	Description
FSMC_MemoryDataWidth_8b	8-bit external memory device data width.
FSMC_MemoryDataWidth_16b	16-bit external memory device data width.

**FSMC\_BurstAccessMode**

Enables or disables the burst access mode for Flash memory, valid only with synchronous burst Flash memories. [Table 700](#) gives the values assumed by this member.

**Table 702. FSMC\_BurstAccessMode definition**

FSMC_BurstAccessMode	Description
FSMC_BurstAccessMode_Disable	Disables the burst access mode
FSMC_BurstAccessMode_Enable	Enables the burst access mode



**FSMC\_WaitSignalPolarity**

Specifies the wait signal polarity, valid only when accessing the Flash memory in burst mode. [Table 703](#) gives the values assumed by this member.

**Table 703. FSMC\_WaitSignalPolarity definition**

FSMC_WaitSignalPolarity	Description
FSMC_WaitSignalPolarity_Low	Wait signal active low.
FSMC_WaitSignalPolarity_High	Wait signal active high.

**FSMC\_WrapMode**

Enables or disables the Wrapped burst access mode for Flash memory, valid only when accessing Flash memories in burst mode. [Table 704](#) gives the values assumed by this member.

**Table 704. FSMC\_WrapMode definition**

FSMC_WrapMode	Description
FSMC_WrapMode_Disable	Direct wrapped burst is disabled
FSMC_WrapMode_Enable	Direct wrapped burst is enabled

**FSMC\_WaitTiming**

Specifies the wait signal polarity, valid only when accessing Flash memories in burst mode. [Table 700](#) gives the values assumed by this member.

**Table 705. FSMC\_WaitTiming definition**

FSMC_WaitTiming	Description
FSMC_WaitTiming_BeforeWaitState	WAITn signal is active one data cycle before the wait state.
FSMC_WaitTiming_DuringWaitState	WAITn signal is active during the wait state.

**FSMC\_WriteOperation**

Enables or disables the write operation to be accepted by the FSMC. [Table 700](#) gives the values assumed by this member.

**Table 706. FSMC\_WriteOperation definition**

FSMC_WriteOperation	Description
FSMC_WriteOperation_Disable	Write operations are disabled in the bank by the FSMC.
FSMC_WriteOperation_Enable	Write operations are enabled in the bank by the FSMC

**FSMC\_WaitSignal**

Enables or disables the wait-state insertion via WAITn signal, valid for Flash memory access in burst mode. [Table 707](#) gives the values assumed by this member.

**Table 707. FSMC\_WaitSignal definition**

FSMC_WaitSignal	Description
FSMC_WaitSignal_Disable	WAITn signal is disabled.
FSMC_WaitSignal_Enable	WAITn signal is enabled.

**FSMC\_ExtendedMode**

Enables or disables the extended mode. [Table 700](#) gives the values assumed by this member.

**Table 708. FSMC\_ExtendedMode definition**

FSMC_ExtendedMode	Description
FSMC_ExtendedMode_Disable	Extended mode is disabled
FSMC_ExtendedMode_Enable	Extended mode is enabled

**FSMC\_AsyncWait**

Enables or disables the wait signal in asynchronous protocol. [Table 700](#) gives the values assumed by this member.

**Table 709. FSMC\_AsyncWait definition**

FSMC_AsyncWait	Description
FSMC_AsyncWait_Disable	NWAIT signal is not taken into account when running an asynchronous protocol
FSMC_AsyncWait_Enable	NWAIT signal is taken into account when running an asynchronous protocol

**FSMC\_WriteBurst**

Enables or disables the write burst operation. [Table 700](#) gives the values assumed by this member.

**Table 710. FSMC\_WriteBurst definition**

FSMC_WriteBurst	Description
FSMC_WriteBurst_Disable	Write operations are always performed in asynchronous mode
FSMC_WriteBurst_Enable	Write operations are always performed in synchronous mode

**Example:**

```
/* Initialize the FSMC NOR memory according to the
FSMC_NORSRAMInitStructure members */
FSMC_NORSRAMInitTypeDef FSMC_NORSRAMInitStructure;
FSMC_NORSRAMTimingInitTypeDef* FSMC_NORSRAMTimingStructure;

FSMC_NORSRAMTimingStructure.FSMC_AddSetupTime = 0x2;
```

```
FSMC_NORSRAMTimingStructure.FSMC_AddHoldTime = 0x2;
FSMC_NORSRAMTimingStructure.FSMC_DataSetupTime = 0x2;
FSMC_NORSRAMTimingStructure.FSMC_BusTurnaroundDuration = 0x0;
FSMC_NORSRAMTimingStructure.FSMC_CLKDivision = 0x0;
FSMC_NORSRAMTimingStructure.FSMC_DataLatency = 0x0;
FSMC_NORSRAMTimingStructure.FSMC_AccessMode = FSMC_AccessMode_A;

FSMC_NORSRAMInitStructure.FSMC_Bank = FSMC_Bank1_NORSRAM1;
FSMC_NORSRAMInitStructure.FSMC_DataAddressMux =
FSMC_DataAddressMux_Disable;
FSMC_NORSRAMInitStructure.FSMC_MemoryType = FSMC_MemoryType_NOR;
FSMC_NORSRAMInitStructure.FSMC_MemoryDataWidth =
FSMC_MemoryDataWidth_16b;
FSMC_NORSRAMInitStructure.FSMC_BurstAccessMode =
FSMC_BurstAccessMode_Disable;
FSMC_NORSRAMInitStructure.FSMC_WaitSignalPolarity =
FSMC_WaitSignalPolarity_Low;
FSMC_NORSRAMInitStructure.FSMC_WrapMode = FSMC_WrapMode_Disable;
FSMC_NORSRAMInitStructure.FSMC_WaitTiming =
FSMC_WaitSignalActive_BeforeWaitState;
FSMC_NORSRAMInitStructure.FSMC_WriteOperation =
FSMC_WriteOperation_Enable;
FSMC_NORSRAMInitStructure.FSMC_WaitSignal =
FSMC_WaitSignal_Disable;
FSMC_NORSRAMInitStructure.FSMC_ExtendedMode =
FSMC_ExtendedMode_Disable ;
FSMC_NORSRAMInitStructure.FSMC_AsyncWait = FSMC_AsyncWait_Disable;
FSMC_NORSRAMInitStructure.FSMC_WriteBurst =
FSMC_WriteBurst_Disable;
FSMC_NORSRAMInitStructure.FSMC_ReadWriteTimingStructure =
&FSMC_NORSRAMTimingStructure;

FSMC_NORSRAMInit(&FSMC_NORSRAMInitStructure);
```

## 23.2.5 FSMC\_NANDInit

[Table 711](#) describes the FSMC\_NANDInit function.

**Table 711. FSMC\_NANDInit function**

Function name	FSMC_NANDInit
Function prototype	<code>void FSMC_NANDInit(FSMC_NAND_PCCARDInitTypeDef* FSMC_NANDInitStruct)</code>
Behavior description	Initializes the FSMC NAND banks according to the parameters specified in FSMC_NANDInitStruct.
Input parameter	FSMC_NANDInitStruct: pointer to an FSMC_NANDInitTypeDef structure that contains the configuration information for the specified FSMC NAND banks. Refer to <a href="#">FSMC_NANDInitTypeDef</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

The FSMC\_NAND\_PCCARDTimingInitTypeDef and FSMC\_NANDInitTypeDef are defined in the *stm32f10x\_fsmc.h* file:

### FSMC\_NAND\_PCCARDTimingInitTypeDef

```
typedef struct
{
    u32 FSMC_SetupTime;
    u32 FSMC_WaitSetupTime;
    u32 FSMC_HoldSetupTime;
    u32 FSMC_HiZSetupTime;
}FSMC_NAND_PCCARDTimingInitTypeDef;
```

#### FSMC\_SetupTime

Defines the number of HCLK cycles to setup address before the command assertion for NAND-Flash read or write access to common/Attribute or I/O memory space (depending on the memory space timing to be configured). This parameter can assume a value between 0 and 0xFF.

#### FSMC\_WaitSetupTime

Defines the minimum number of HCLK cycles to assert the command for NAND-Flash read or write access to common/Attribute or I/O memory space (depending on the memory space timing to be configured). This parameter can assume a value between 0 and 0xFF.

#### FSMC\_HoldSetupTime

Defines the number of HCLK clock cycles to hold address (and data for write access) after the command deassertion for NAND-Flash read or write access to common/Attribute or I/O memory space (depending on the memory space timing to be configured). This parameter can assume a value between 0 and 0xFF.

**FSMC\_HiZSetupTime**

Defines the number of HCLK clock cycles during which the databus is kept in HiZ after the start of a NAND-Flash write access to common/Attribute or I/O memory space (depending on the memory space timing to be configured). This parameter can assume a value between 0 and 0xFF.

**FSMC\_NANDInitTypeDef**

The FSMC\_NANDInitTypeDef structure is defined in the *stm32f10x\_fsmc.h* file:

```
/* FSMC NAND Init structure definition */
typedef struct
{
    u32 FSMC_Bank;
    u32 FSMC_Waitfeature;
    u32 FSMC_MemoryDataWidth;
    u32 FSMC_ECC;
    u32 FSMC_ECCPageSize;
    u32 FSMC_AddressLowMapping;
    u32 FSMC_TCLRSetupTime;
    u32 FSMC_TARSetupTime;
    /* FSMC Common Space Timing */
    FSMC_NAND_PCCARDTimingInitTypeDef*   FSMC_CommonSpaceTimingStruct;
    /* FSMC Attribute Space Timing */
    FSMC_NAND_PCCARDTimingInitTypeDef*   FSMC_AttributeSpaceTimingStruct;
}FSMC_NANDInitTypeDef;
```

**FSMC\_Bank**

Specifies the memory bank that will be used. [Table 712](#) gives the values assumed by this member.

**Table 712. FSMC\_Bank definition**

FSMC_Bank	Description
FSMC_Bank2_NAND	BANK2 NAND
FSMC_Bank3_NAND	BANK3 NAND

**FSMC\_Waitfeature**

Enables or disables the Wait feature for the NAND Memory Bank. [Table 713](#) gives the values assumed by this member.

**Table 713. FSMC\_Waitfeature definition**

FSMC_Waitfeature	Description
FSMC_Waitfeature_Disable	Disables the Wait feature for the NAND memory bank.
FSMC_Waitfeature_Enable	Enables the Wait feature for the NAND memory bank.

**FSMC\_MemoryDataWidth**

Specifies the external memory device width. [Table 712](#) gives the values assumed by this member.

**Table 714. FSMC\_MemoryDataWidth definition**

FSMC_MemoryDataWidth	Description
FSMC_MemoryDataWidth_8b	8-bit external memory device data width.
FSMC_MemoryDataWidth_16b	16-bit external memory device data width.

**FSMC\_ECC**

Enables or disables the ECC computation. [Table 712](#) gives the values assumed by this member.

**Table 715. FSMC\_ECC definition**

FSMC_ECC	Description
FSMC_ECC_Disable	Disables the ECC logic.
FSMC_ECC_Enable	Enables the ECC logic.

**FSMC\_ECCPageSize**

Defines the page size for the extended ECC. [Table 712](#) gives the values assumed by this member.

**Table 716. FSMC\_ECCPageSize definition**

FSMC_ECCPageSize	Description
FSMC_ECCPageSize_256Bytes	256 byte ECC page size
FSMC_ECCPageSize_512Bytes	512 byte ECC page size
FSMC_ECCPageSize_1024Bytes	1024 byte ECC page size
FSMC_ECCPageSize_2048Bytes	2048 byte ECC page size
FSMC_ECCPageSize_4096Bytes	4096 byte ECC page size
FSMC_ECCPageSize_8192Bytes	8192 byte ECC page size

**FSMC\_AddressLowMapping**

Defined which NAND-Flash controller address bits are delivered on A[24:16] signals. [Table 712](#) gives the values assumed by this member.

**Table 717. FSMC\_AddressLowMapping definition**

FSMC_AddressLowMapping	Description
FSMC_AddressLowMapping_Direct	Direct mapping: A[24:16] delivers the [24:16] AHB address lines
FSMC_AddressLowMapping_Indirect	Low-address bit mapping: A[24:16] delivers the [8:0] AHB address lines

**FSMC\_TCLRSetupTime**

Defines the number of HCLK cycles to configure the delay between CLE low and RE low. This parameter can assume a value between 0 and 0xFF.

**FSMC\_TARSetupTime**

Defines the number of HCLK cycles to configure the delay between ALE low and RE low. This parameter can assume a value between 0 and 0xFF.

**Example:**

```
/* Initialize the FSMC NAND memory Bank2 according to the
FSMC_NANDInitStructure members */
FSMC_NANDSRAMInitTypeDef FSMC_NANDSRAMInitStructure;
FSMC_NAND_PCCARDTimingInitTypeDef FSMC_CommonSpaceTimingStructure;
FSMC_NAND_PCCARDTimingInitTypeDef
FSMC_AttributeSpaceTimingStructure;
FSMC_CommonSpaceTimingStructure.FSMC_SetupTime = 0x4;
FSMC_CommonSpaceTimingStructure.FSMC_WaitSetupTime = 0x0;
FSMC_CommonSpaceTimingStructure.FSMC_HoldSetupTime = 0x7;
FSMC_CommonSpaceTimingStructure.FSMC_HiZSetupTime = 0x0;
FSMC_AttributeSpaceTimingStructure.FSMC_SetupTime = 0x4;
FSMC_AttributeSpaceTimingStructure.FSMC_WaitSetupTime = 0x0;
FSMC_AttributeSpaceTimingStructure.FSMC_HoldSetupTime = 0x7;
FSMC_AttributeSpaceTimingStructure.FSMC_HiZSetupTime = 0x0;

FSMC_NANDSRAMInitStructure.FSMC_Bank = FSMC_Bank2_NAND;
FSMC_NANDSRAMInitStructure.FSMC_Waitfeature =
FSMC_Waitfeature_Enable;
FSMC_NANDSRAMInitStructure.FSMC_MemoryDataWidth =
FSMC_MemoryDataWidth_8b;
FSMC_NANDSRAMInitStructure.FSMC_ECC = FSMC_ECC_Enable;
FSMC_NANDSRAMInitStructure.FSMC_ECCPageSize =
FSMC_ECCPageSize_512Bytes;
FSMC_NANDSRAMInitStructure.FSMC_AddressLowMapping =
FSMC_AddressLowMapping_Direct;
FSMC_NANDSRAMInitStructure.FSMC_TCLRSetupTime = 0x1;
FSMC_NANDSRAMInitStructure.FSMC_TARSetupTime = 0x1;

FSMC_NANDSRAMInitStructure.FSMC_CommonSpaceTimingStructure =
&FSMC_CommonSpaceTimingStructure;

FSMC_NANDSRAMInitStructure.FSMC_AttributeSpaceTimingStructure =
&FSMC_AttributeSpaceTimingStructure;

FSMC_NANDInit (&FSMC_NANDSRAMInitStructure);
```

## 23.2.6 FSMC\_PCCARDInit

[Table 691](#) describes the FSMC\_PCCARDInit function.

**Table 718. FSMC\_PCCARDInit function**

Function name	FSMC_PCCARDInit
Function prototype	<code>void FSMC_PCCARDInit(FSMC_NAND_PCCARDInitTypeDef* FSMC_PCCARDInitStruct)</code>
Behavior description	Initializes the FSMC PC-CARD bank according to the parameters specified in FSMC_PCCARDInitStruct.
Input parameter	FSMC_PCCARDInitStruct: pointer to an FSMC_PCCARDInitTypeDef structure that contains the configuration information for the FSMC PC-CARD bank. Refer to <a href="#">FSMC_PCCARDInitTypeDef</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

FSMC\_NAND\_PCCARDTimingInitTypeDef and FSMC\_PCCARDInitTypeDef are defined in the *stm32f10x\_fsmc.h* file:

### FSMC\_NAND\_PCCARDTimingInitTypeDef

```
typedef struct
{
    u32 FSMC_SetupTime;
    u32 FSMC_WaitSetupTime;
    u32 FSMC_HoldSetupTime;
    u32 FSMC_HiZSetupTime;
}FSMC_NAND_PCCARDTimingInitTypeDef;
```

#### FSMC\_SetupTime

Defines the number of HCLK cycles to setup the address before the command assertion for PCCARD read or write access to common/Attribute or I/O memory space (depending on the memory space timing to be configured). This parameter can assume a value between 0 and 0xFF.

#### FSMC\_WaitSetupTime

Defines the minimum number of HCLK cycles to assert the command for PCCARD read or write access to common/Attribute or I/O memory space (depending on the memory space timing to be configured). This parameter can assume a value between 0 and 0xFF.

#### FSMC\_HoldSetupTime

Defines the number of HCLK clock cycles to hold the address (and data for write access) after the command deassertion for PCCARD read or write access to common/Attribute or I/O memory space (depending on the memory space timing to be configured). This parameter can assume a value between 0 and 0xFF.



**FSMC\_HiZSetupTime**

Defines the number of HCLK clock cycles during which the databus is kept in HiZ after the start of a PCCARD write access to common/Attribute or I/O memory space (depending on the memory space timing to be configured). This parameter can assume a value between 0 and 0xFF.

**FSMC\_PCCARDInitTypeDef**

```
/* FSMC PCCARD Init structure definition */
typedef struct
{
    u32 FSMC_Waitfeature;
    u32 FSMC_AddressLowMapping;
    u32 FSMC_TCLRSetupTime;
    u32 FSMC_TARSetupTime;
    /* FSMC Common Space Timing */
    FSMC_NAND_PCCARDTimingInitTypeDef*   FSMC_CommonSpaceTimingStruct;
    /* FSMC Attribute Space Timing */
    FSMC_NAND_PCCARDTimingInitTypeDef*   FSMC_AttributeSpaceTimingStruct;
    /* FSMC IO Space Timing */
    FSMC_NAND_PCCARDTimingInitTypeDef*   FSMC_IOSpaceTimingStruct;
}FSMC_PCCARDInitTypeDef;
```

**FSMC\_Waitfeature**

Enables or disables the Wait feature for the NAND memory bank. [Table 719](#) gives the list of values assumed by this member.

**Table 719. FSMC\_Waitfeature definition**

FSMC_Waitfeature	Description
FSMC_Waitfeature_Disable	Disables the Wait feature for the NAND memory bank.
FSMC_Waitfeature_Enable	Enables the Wait feature for the NAND memory bank.

**FSMC\_AddressLowMapping**

Defined which NAND-Flash controller address bits are delivered on the A[24:16] signals. [Table 719](#) gives the list of values assumed by this member.

**Table 720. FSMC\_AddressLowMapping definition**

FSMC_AddressLowMapping	Description
FSMC_AddressLowMapping_Direct	Direct mapping: A[24:16] delivers the [24:16] AHB address lines
FSMC_AddressLowMapping_Indirect	Low address bit mapping: A[24:16] delivers the [8:0] AHB address lines

**FSMC\_TCLRSetupTime**

Defines the number of HCLK cycles to configure the delay between CLE low and RE low. This parameter can assume a value between 0 and 0xFF.

**FSMC\_TARSetupTime**

Defines the number of HCLK cycles to configure the delay between ALE low and RE low. This parameter can assume a value between 0 and 0xFF.

**Example:**

```
/* Initialize the FSMC PC-CARD memory Bank4 according to the
FSMC_PCCARDInitStructure members */
FSMC_PCCARDInitTypeDef  FSMC_PCCARDInitStructure;
FSMC_NAND_PCCARDTimingInitTypeDef  FSMC_CommonSpaceTimingStructure;
FSMC_NAND_PCCARDTimingInitTypeDef
FSMC_AttributeSpaceTimingStructure;
FSMC_NAND_PCCARDTimingInitTypeDef  FSMC_IOSpaceTimingStructure;

FSMC_CommonSpaceTimingStructure.FSMC_SetupTime = 0x4;
FSMC_CommonSpaceTimingStructure.FSMC_WaitSetupTime = 0x0;
FSMC_CommonSpaceTimingStructure.FSMC_HoldSetupTime = 0x7;
FSMC_CommonSpaceTimingStructure.FSMC_HiZSetupTime = 0x0;

FSMC_AttributeSpaceTimingStructure.FSMC_SetupTime = 0x4;
FSMC_AttributeSpaceTimingStructure.FSMC_WaitSetupTime = 0x0;
FSMC_AttributeSpaceTimingStructure.FSMC_HoldSetupTime = 0x7;
FSMC_AttributeSpaceTimingStructure.FSMC_HiZSetupTime = 0x0;

FSMC_IOSpaceTimingStructure.FSMC_SetupTime = 0x4;
FSMC_IOSpaceTimingStructure.FSMC_WaitSetupTime = 0x0;
FSMC_IOSpaceTimingStructure.FSMC_HoldSetupTime = 0x7;
FSMC_IOSpaceTimingStructure.FSMC_HiZSetupTime = 0x0;

FSMC_PCCARDInitStructure.FSMC_Waitfeature =
FSMC_Waitfeature_Enable;
FSMC_PCCARDInitStructure.FSMC_AddressLowMapping =
FSMC_AddressLowMapping_Direct;
FSMC_PCCARDInitStructure.FSMC_TCLRSetupTime = 0x1;
FSMC_PCCARDInitStructure.FSMC_TARSetupTime = 0x1;
FSMC_PCCARDInit(&FSMC_PCCARDInitStructure);
```

## 23.2.7 FSMC\_NORSRAMStructInit

[Table 691](#) describes the FSMC\_NORSRAMStructInit function.

**Table 721. FSMC\_NORSRAMStructInit function**

Function name	FSMC_NORSRAMStructInit
Function prototype	void FSMC_NORSRAMStructInit (FSMC_NORSRAMInitTypeDef* FSMC_NORSRAMInitStruct)
Behavior description	Fills each FSMC_NORSRAMInitStruct member with its default value.
Input parameter	FSMC_NORSRAMInitStruct: pointer to an FSMC_NORSRAMInitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

[Table 722](#) gives the default values of the FSMC\_NORSRAMInitStruct members.

**Table 722. FSMC\_NORSRAMInitStruct member definition**

Member	Default value
FSMC_Bank	FSMC_Bank1_NORSRAM1
FSMC_DataAddressMux	FSMC_DataAddressMux_Enable
FSMC_MemoryType	FSMC_MemoryType_SRAM
FSMC_MemoryDataWidth	FSMC_MemoryDataWidth_8b
FSMC_BurstAccessMode	FSMC_BurstAccessMode_Disable
FSMC_WaitSignalPolarity	FSMC_WaitSignalPolarity_Low
FSMC_WrapMode	FSMC_WrapMode_Disable
FSMC_WaitSignalActive	FSMC_WaitSignalActive_BeforeWaitState
FSMC_WriteOperation	FSMC_WriteOperation_Enable
FSMC_WaitSignal	FSMC_WaitSignal_Enable
FSMC_ExtendedMode	FSMC_ExtendedMode_Disable
FSMC_AsyncWait	FSMC_AsyncWait_Disable
FSMC_WriteBurst	FSMC_WriteBurst_Disable
FSMC_ReadWriteTimingStruct->FSMC_AddSetupTime	0xF
FSMC_ReadWriteTimingStruct->FSMC_AddHoldTime	0xF
FSMC_ReadWriteTimingStruct->FSMC_DataSetupTime	0xFF
FSMC_ReadWriteTimingStruct->FSMC_BusTurnaroundDuration	0xF
FSMC_ReadWriteTimingStruct->FSMC_CLKDivision	0xF
FSMC_ReadWriteTimingStruct->FSMC_DataLatency	0xFF
FSMC_ReadWriteTimingStruct->FSMC_AccessMode	FSMC_AccessMode_A

**Table 722. FSMC\_NORSRAMInitStruct member definition (continued)**

Member	Default value
FSMC_WriteTimingStruct->FSMC_AddSetupTime	0xF
FSMC_WriteTimingStruct->FSMC_AddHoldTime	0xF
FSMC_WriteTimingStruct->FSMC_DataSetupTime	0xFF
FSMC_WriteTimingStruct->FSMC_BusTurnaroundDuration	0xF
FSMC_WriteTimingStruct->FSMC_CLKDivision	0xF
FSMC_WriteTimingStruct->FSMC_DataLatency	0xFF
FSMC_WriteTimingStruct->FSMC_AccessMode	FSMC_AccessMode_A

**Example:**

```
/* Initialize a FSMC_NORSRAMInitTypeDef structure. */
FSMC_NORSRAMInitTypeDef FSMC_NORSRAMInitStructure;
FSMC_NORSRAMStructInit(&FSMC_NORSRAMInitStructure);
```

**23.2.8 FSMC\_NANDStructInit**

[Table 691](#) describes the FSMC\_NANDStructInit function.

**Table 723. FSMC\_NANDStructInit function**

Function name	FSMC_NANDStructInit
Function prototype	void FSMC_NANDStructInit(FSMC_NANDInitTypeDef* FSMC_NANDInitStruct)
Behavior description	Fills each FSMC_NANDInitStruct member with its default value.
Input parameter	FSMC_NANDInitStruct: pointer to an FSMC_NANDInitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

[Table 722](#) gives the default values of the FSMC\_NANDInitStruct members.

**Table 724. FSMC\_NANDInitStruct member definitions**

Member	Default value
FSMC_Bank	FSMC_Bank2_NAND
FSMC_Waitfeature	FSMC_Waitfeature_Disable
FSMC_MemoryDataWidth	FSMC_MemoryDataWidth_8b
FSMC_ECC	FSMC_ECC_Disable
FSMC_ECCPageSize	FSMC_ECCPageSize_256Bytes
FSMC_AddressLowMapping	FSMC_AddressLowMapping_Direct
FSMC_TCLRSetupTime	0x0
FSMC_TARSetupTime	0x0

**Table 724. FSMC\_NANDInitStruct member definitions (continued)**

Member	Default value
FSMC_CommonSpaceTimingStruct->FSMC_CommonSetupTime	0xFC
FSMC_CommonSpaceTimingStruct->FSMC_CommonWaitSetupTime	0xFC
FSMC_CommonSpaceTimingStruct->FSMC_CommonHoldSetupTime	0xFC
FSMC_CommonSpaceTimingStruct->FSMC_CommonHiZSetupTime	0xFC
FSMC_AttributeSpaceTimingStruct->FSMC_AttributeSetupTime	0xFC
FSMC_AttributeSpaceTimingStruct->FSMC_AttributeWaitSetupTime	0xFC
FSMC_AttributeSpaceTimingStruct->FSMC_AttributeHoldSetupTime	0xFC
FSMC_AttributeSpaceTimingStruct->FSMC_AttributeHiZSetupTime	0xFC

**Example:**

```

/* Initialize a FSMC_NANDInitStructTypeDef structure. */
FSMC_NANDInitStructTypeDef FSMC_NANDInitStruct;
FSMC_NAND_PCCARDTimingInitTypeDef FSMC_CommonSpaceTimingStructure;
FSMC_NAND_PCCARDTimingInitTypeDef
FSMC_AttributeSpaceTimingStructure;
FSMC_NANDStructInit (&FSMC_NANDInitStruct);

```

**23.2.9 FSMC\_PCCARDStructInit**

[Table 691](#) describes the FSMC\_PCCARDStructInit function.

**Table 725. FSMC\_PCCARDStructInit function**

Function name	FSMC_PCCARDStructInit
Function prototype	void FSMC_PCCARDStructInit(FSMC_NAND_PCCARDInitTypeDef* FSMC_PCCARDInitStruct)
Behavior description	Fills each FSMC_PCCARDInitStruct member with its default value.
Input parameter	FSMC_PCCARDInitStruct: pointer to an FSMC_NAND_PCCARDInitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

Table 722 gives the default values of the FSMC\_PCCARDInitStruct members.

**Table 726. FSMC\_PCCARDInitStruct member definition**

Member	Default value
FSMC_Waitfeature	FSMC_Waitfeature_Disable
FSMC_AddressLowMapping	FSMC_AddressLowMapping_Direct
FSMC_TCLRSetupTime	0x0
FSMC_TARSetupTime	0x0
FSMC_CommonSpaceTimingStruct->FSMC_CommonSetupTime	0xFC
FSMC_CommonSpaceTimingStruct->FSMC_CommonWaitSetupTime	0xFC
FSMC_CommonSpaceTimingStruct->FSMC_CommonHoldSetupTime	0xFC
FSMC_CommonSpaceTimingStruct->FSMC_CommonHiZSetupTime	0xFC
FSMC_AttributeSpaceTimingStruct->FSMC_AttributeSetupTime	0xFC
FSMC_AttributeSpaceTimingStruct->FSMC_AttributeWaitSetupTime	0xFC
FSMC_AttributeSpaceTimingStruct->FSMC_AttributeHoldSetupTime	0xFC
FSMC_AttributeSpaceTimingStruct->FSMC_AttributeHiZSetupTime	0xFC
FSMC_IOSpaceTimingStruct->FSMC_AttributeSetupTime	0xFC
FSMC_IOSpaceTimingStruct->FSMC_AttributeWaitSetupTime	0xFC
FSMC_IOSpaceTimingStruct->FSMC_AttributeHoldSetupTime	0xFC
FSMC_IOSpaceTimingStruct->FSMC_AttributeHiZSetupTime	0xFC

**Example:**

```
/* Initialize a FSMC_PCCARDInitTypeDef structure. */
FSMC_PCCARDInitTypeDef FSMC_PCCARDInitStructure;
FSMC_NAND_PCCARDTimingInitTypeDef FSMC_CommonSpaceTimingStructure;
FSMC_NAND_PCCARDTimingInitTypeDef FSMC_AttributeSpaceTimingStructure;
FSMC_NAND_PCCARDTimingInitTypeDef FSMC_IOSpaceTimingStructure;
FSMC_PCCARDStructInit(&FSMC_PCCARDInitStructure);
```

## 23.2.10 FSMC\_NORSRAMCmd

[Table 691](#) describes the FSMC\_NORSRAMCmd function.

**Table 727. FSMC\_NORSRAMCmd function**

Function name	FSMC_NORSRAMCmd
Function prototype	<code>void FSMC_NORSRAMCmd(u32 FSMC_Bank, FunctionalState NewState)</code>
Behavior description	Enables or disables the NOR/SRAM memory bankx.
Input parameter1	FSMC_Bank: specifies the FSMC bank to be used. Refer to <a href="#">FSMC_Bank</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the FSMC_Bank. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the FSMC Bank 2 for NOR/SRAM Memory use */
FSMC_NORSRAMCmd(FSMC_Bank1_NORSRAM2, ENABLE);
```

## 23.2.11 FSMC\_NANDCmd

[Table 691](#) describes the FSMC\_NANDCmd function.

**Table 728. FSMC\_NANDCmd function**

Function name	FSMC_NANDCmd
Function prototype	<code>void FSMC_NANDCmd(u32 FSMC_Bank, FunctionalState NewState)</code>
Behavior description	Enables or disables the NAND memory bank.
Input parameter1	FSMC_Bank: specifies the FSMC bank to be used. Refer to <a href="#">FSMC_Bank</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the FSMC_Bank. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the FSMC Bank 2 or NAND Memory */
FSMC_NANDCmd(FSMC_Bank2_NAND, ENABLE);
```

### 23.2.12 FSMC\_PCCARDCmd

[Table 691](#) describes the FSMC\_PCCARDCmd function.

**Table 729. FSMC\_PCCARDCmd function**

Function name	FSMC_PCCARDCmd
Function prototype	<code>void FSMC_PCCARDCmd(FunctionalState NewState)</code>
Behavior description	Enables or disables the PC-CARD memory bank.
Input parameter	NewState: new state of the PCCARD memory bank. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the FSMC Bank 3 for PC-CARD Memory */
FSMC_PCCARDCmd(ENABLE);
```

### 23.2.13 FSMC\_PCCARDCmd

[Table 691](#) describes the FSMC\_PCCARDCmd function.

**Table 730. FSMC\_PCCARDCmd function**

Function name	FSMC_PCCARDCmd
Function prototype	<code>void FSMC_PCCARDCmd(FunctionalState NewState)</code>
Behavior description	Enables or disables the PC-CARD memory bank.
Input parameter	NewState: new state of the PCCARD memory bank. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the FSMC Bank 3 for PC-CARD Memory */
FSMC_PCCARDCmd(ENABLE);
```



### 23.2.14 FSMC\_NANDECCCmd

[Table 691](#) describes the FSMC\_NANDECCCmd function.

**Table 731. FSMC\_NANDECCCmd function**

Function name	FSMC_NANDECCCmd
Function prototype	<code>void FSMC_NANDECCCmd(u32 FSMC_Bank, FunctionalState NewState)</code>
Behavior description	Enables or disables the FSMC NAND ECC feature.
Input parameter1	FSMC_Bank: specifies the FSMC bank to be used. Refer to <a href="#">FSMC_Bank</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the FSMC NAND ECC feature. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables FSMC NAND Bank2 ECC functionality */
FSMC_NANDECCCmd(FSMC_Bank2_NAND, ENABLE);
```

### 23.2.15 FSMC\_ITConfig

[Table 691](#) describes the FSMC\_ITConfig function.

**Table 732. FSMC\_ITConfig function**

Function name	FSMC_ITConfig
Function prototype	<code>void FSMC_ITConfig(u32 FSMC_Bank, u32 FSMC_IT, FunctionalState NewState)</code>
Behavior description	Enables or disables the specified FSMC interrupts.
Input parameter1	FSMC_Bank: specifies the FSMC bank to be used. This parameter can assume one of the following values: – FSMC_Bank2_NAND: FSMC Bank2 NAND – FSMC_Bank3_NAND: FSMC Bank3 NAND – FSMC_Bank4_PCCARD: FSMC Bank4 PC memory card
Input parameter2	FSMC_IT: specifies the FSMC interrupt sources to be enabled or disabled. Refer to <a href="#">FSMC_IT</a> for more details on the allowed values for this parameter.
Input parameter3	NewState: new state of the FSMC interrupt source. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**FSMC\_IT**

[Table 733](#) shows the values that can be combined to enable or disable FSMC interrupts.

**Table 733. FSMC\_IT definition**

FSMC_IT	Description
FSMC_IT_RisingEdge	Interrupt rising edge detection
FSMC_IT_Level	Interrupt level detection
FSMC_IT_FallingEdge	Interrupt falling edge detection

**Example:**

```
/* Enables the FSMC_Bank2 Rising edge detection Interrupt source */
FSMC_ITConfig(FSMC_Bank2, FSMC_IT_RisingEdge, ENABLE);
```

**23.2.16 FSMC\_GetFlagStatus**

[Table 691](#) describes the FSMC\_GetFlagStatus function.

**Table 734. FSMC\_GetFlagStatus function**

Function name	FSMC_GetFlagStatus
Function prototype	FlagStatus FSMC_GetFlagStatus(u32 FSMC_Bank, u32 FSMC_FLAG)
Behavior description	Checks whether the specified FSMC flag is set or not.
Input parameter1	FSMC_Bank: specifies the FSMC bank to be used. This parameter can assume one of the following values: – FSMC_Bank2_NAND: FSMC Bank2 NAND – FSMC_Bank3_NAND: FSMC Bank3 NAND – FSMC_Bank4_PCCARD: FSMC Bank4 PC memory card
Input parameter2	FSMC_FLAG: specifies the flag to check. Refer to <a href="#">ADC_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of FSMC_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

**FSMC\_FLAG**

[Table 735](#) gives the list of the flags that can be checked.

**Table 735. FSMC\_FLAG definition**

FSMC_FLAG	Description
FSMC_FLAG_RisingEdge	Rising Edge detection flag
FSMC_FLAG_Level	Level detection flag
FSMC_FLAG_FallingEdge	Falling Edge detection flag
FSMC_FLAG_FEMPT	FIFO empty flag

**Example:**

```

/* Check if the FSMC_Bank2 FIFO is empty or not */
if(FSMC_GetFlagStatus(FSMC_Bank2_NAND, FSMC_FLAG_FEMPT) == SET)
{
}

```

**23.2.17 FSMC\_ClearFlag**

[Table 691](#) describes the FSMC\_ClearFlag function.

**Table 736. FSMC\_ClearFlag function**

Function name	FSMC_ClearFlag
Function prototype	void FSMC_ClearFlag(u32 FSMC_Bank, u32 FSMC_FLAG)
Behavior description	Clears the FSMC's pending flags.
Input parameter1	FSMC_Bank: specifies the FSMC bank to be used. This parameter can assume one of the following values: – FSMC_Bank2_NAND: FSMC Bank2 NAND – FSMC_Bank3_NAND: FSMC Bank3 NAND – FSMC_Bank4_PCCARD: FSMC Bank4 PC memory card
Input parameter2	FSMC_FLAG: specifies the flag to check. Refer to <a href="#">ADC_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of FSMC_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```

/* Clear the FSMC_Bank2 FIFO flag */
FSMC_ClearFlag(FSMC_Bank2_NAND, FSMC_FLAG_FEMPT);

```

## 23.2.18 FSMC\_GetITStatus

[Table 691](#) describes the FSMC\_GetITStatus function.

**Table 737. FSMC\_GetITStatus function**

Function name	FSMC_GetITStatus
Function prototype	ITStatus FSMC_GetITStatus(u32 FSMC_Bank, u32 FSMC_IT)
Behavior description	Checks whether the specified FSMC interrupt has occurred or not.
Input parameter1	FSMC_Bank: specifies the FSMC bank to be used. This parameter can assume one of the following values: – FSMC_Bank2_NAND: FSMC Bank2 NAND – FSMC_Bank3_NAND: FSMC Bank3 NAND – FSMC_Bank4_PCCARD: FSMC Bank4 PC memory card
Input parameter2	FSMC_IT: specifies the FSMC interrupt source to check. Refer to <a href="#">FSMC_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of FSMC_IT (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the FSMC_Bank2 interrupt Rising edge detection */
FSMC_GetITStatus(FSMC_Bank2_NAND, FSMC_IT_RisingEdge);
```

## 23.2.19 FSMC\_ClearITPendingBit

[Table 691](#) describes the FSMC\_ClearITPendingBit function.

**Table 738. FSMC\_ClearITPendingBit function**

Function name	FSMC_ClearITPendingBit
Function prototype	void FSMC_ClearITPendingBit(u32 FSMC_Bank, u32 FSMC_IT)
Behavior description	Clears the FSMC's interrupt pending bits.
Input parameter1	FSMC_Bank: specifies the FSMC bank to be used. This parameter can assume one of the following values: – FSMC_Bank2_NAND: FSMC Bank2 NAND – FSMC_Bank3_NAND: FSMC Bank3 NAND – FSMC_Bank4_PCCARD: FSMC Bank4 PC memory card
Input parameter2	FSMC_IT: specifies the FSMC interrupt source to check. Refer to <a href="#">FSMC_IT</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of FSMC_IT (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Clear the FSMC_Bank2 interrupt Rising edge detection */
FSMC_ClearITPendingBit(FSMC_Bank2_NAND, FSMC_IT_RisingEdge);
```

## 24 SDIO interface (SDIO)

The SD/SDIO MMC card host interface (SDIO) provides an interface between the AHB peripheral bus and MultiMediaCards (MMCs), SD memory cards, SDIO cards and CE-ATA devices.

[Section 24.1](#) describes the data structures used in the SDIO firmware library. [Section 24.2](#) presents the firmware library functions.

### 24.1 SDIO register structure

The *SDIO\_TypeDef* SDIO register structure is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32 POWER;
    vu32 CLKCR;
    vu32 ARG;
    vu32 CMD;
    vuc32 RESPCMD;
    vuc32 RESP1;
    vuc32 RESP2;
    vuc32 RESP3;
    vuc32 RESP4;
    vu32 DTIMER;
    vu32 DLEN;
    vu32 DCTRL;
    vuc32 DCOUNT;
    vuc32 STA;
    vu32 ICR;
    vu32 MASK;
    u32 RESERVED0[2];
    vuc32 FIFOCNT;
    u32 RESERVED1[13];
    vu32 FIFO;
} SDIO_TypeDef;
```

[Table 739](#) gives the list of SDIO registers.

**Table 739. SDIO registers**

Register	Description
POWER	SDIO Power Control Register
CLKCR	SDIO Clock Control Register
ARG	SDIO Argument Register
CMD	SDIO Command Register
RESPCMD	SDIO Command Response Register
RESP1	SDIO response 1 register

**Table 739. SDIO registers (continued)**

Register	Description
RESP2	SDIO response 2 register
RESP3	SDIO response 3 register
RESP4	SDIO response 4 register
DTIMER	SDIO Data Timer Register
DLEN	SDIO Data Length Register
DCTRL	SDIO Data Control Register
DCOUNT	SDIO Data Counter Register
STA	SDIO Status Register
ICR	SDIO Interrupt Clear Register
MASK	SDIO Mask Register
FIFOCNT	SDIO FIFO Counter Register
FIFO	SDIO Data FIFO Register

The SDIO peripheral is declared in the same file:

```
...
#define PERIPH_BASE    0x40000000
#define APB3PERIPH_BASE    (PERIPH_BASE + 18000)
....
#define SDIO_BASE (APB3PERIPH_BASE)
....
#ifndef DEBUG
...
#define SDIO ((SDIO_TypeDef *) SDIO_BASE)
...
#else
...
#ifdef _SDIO
    EXT SDIO_TypeDef    *SDIO;
#endif /*_SDIO */
...
#endif
```

When debug mode is used, `_SDIO` pointer is initialized in `stm32f10x_lib.c` file :

```
...
#ifdef _SDIO
    SDIO = (SDIO_TypeDef *) SDIO_BASE;
#endif /*_SDIO */
...
```

`_SDIO` must be defined, in `stm32f10x_conf.h` file, to access the peripheral registers as follows:

```
...
#define _SDIO
...
```

## 24.2 Firmware library functions

[Table 740](#) gives the lists of the SDIO library functions.

**Table 740. SDIO firmware library functions**

Function name	Description
SDIO_DelInit	Resets the SDIO peripheral registers to their default reset values.
SDIO_Init	Initializes the SDIO peripheral according to the specified parameters in the SDIO_InitStruct.
SDIO_StructInit	Fills each SDIO_InitStruct member with its default value.
SDIO_ClockCmd	Enables or disables the SDIO Clock.
SDIO_SetPowerState	Sets the power status of the controller.
SDIO_GetPowerState	Gets the power status of the controller.
SDIO_ITConfig	Enables or disables SDIO interrupts.
SDIO_DMAMCmd	Enables or disables SDIO DMA request.
SDIO_SendCommand	Initializes the SDIO command according to the parameters specified in SDIO_CmdInitStruct ,and sends the command.
SDIO_CmdStructInit	Fills each SDIO_CmdInitStruct member with its default value.
SDIO_GetCommandResponse	Returns command index of last command for which a response was received.
SDIO_GetResponse	Returns the response received from the card for the last command.
SDIO_DataConfig	Initializes the SDIO data path according to the parameters specified in the SDIO_DataInitStruct.
SDIO_DataStructInit	Fills each SDIO_DataInitStruct member with its default value.
SDIO_GetDataCounter	Returns the number of remaining data bytes to be transferred.
SDIO_ReadData	Reads one data word from RX FIFO.
SDIO_WriteData	Writes one data word to TX FIFO.
SDIO_GetFIFOCount	Returns the number of words left to be written to or read from FIFO.
SDIO_StartSDIOReadWait	Starts the SD I/O Read Wait operation.
SDIO_StopSDIOReadWait	Stops the SD I/O Read Wait operation.
SDIO_SetSDIOReadWaitMode	Sets one of the two options of inserting read wait interval.
SDIO_SetSDIOOperation	Enables or disables the SD I/O mode operation.
SDIO_SendSDIOSuspendCmd	Enables or disables the SD I/O mode suspend command.
SDIO_CommandCompletionCmd	Enables or disables the command completion signal.
SDIO_CEATAITCmd	Enables or disables the CE-ATA interrupt.
SDIO_SendCEATACmd	Sends CE-ATA command (CMD61).
SDIO_GetFlagStatus	Checks whether the specified SDIO flag is set or not.
SDIO_ClearFlag	Clears the SDIO's pending flags.

**Table 740. SDIO firmware library functions (continued)**

Function name	Description
SDIO_GetITStatus	Checks whether the specified SDIO interrupt has occurred or not.
SDIO_ClearITPendingBit	Clears the SDIO's interrupt pending bits.

## 24.2.1 SDIO\_DeInit

[Table 741](#) describes the SDIO\_DeInit function.

**Table 741. SDIO\_DeInit function**

Function name	SDIO_DeInit
Function prototype	void SDIO_DeInit(void)
Behavior description	Resets the SDIO peripheral registers to their default reset values.
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### Example:

```
/* Deinitialize the SDIO */
SDIO_DeInit();
```

## 24.2.2 SDIO\_Init

[Table 742](#) describes the SDIO\_Init function.

**Table 742. SDIO\_Init function**

Function name	SDIO_Init
Function prototype	void SDIO_Init(SDIO_InitTypeDef* SDIO_InitStruct)
Behavior description	Initializes the SDIO peripheral according to the parameters specified in the SDIO_InitStruct.
Input parameter	SDIO_InitStruct: pointer to an SDIO_InitTypeDef structure that contains the configuration information for the SDIO peripheral. Refer to <a href="#">DAC_InitTypeDef</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None



## SDIO\_InitTypeDef

The SDIO\_InitTypeDef structure is defined in the *stm32f10x\_sdio.h* file:

```
typedef struct
{
    u8  SDIO_ClockDiv;
    u32 SDIO_ClockEdge;
    u32 SDIO_MCLKBypass;
    u32 SDIO_ClockPowerSave;
    u32 SDIO_BusWide;
    u32 SDIO_HardwareFlowControl;
} SDIO_InitTypeDef;
```

### SDIO\_ClockDiv

Specifies the clock frequency of the SDIO controller. Its value ranges be from 0x00 to 0xFF.

### SDIO\_ClockEdge

Specifies the clock transition on which the bit capture is made. [Table 743](#) shows the values this member can assume.

**Table 743. SDIO\_ClockEdge definition**

SDIO_ClockEdge	Description
SDIO_ClockEdge_Rising	SDIO clock generated on the rising edge of master clock MCLK
SDIO_ClockEdge_Falling	SDIO clock generated on the falling edge of master clock MCLK

### SDIO\_MCLKBypass

Specifies whether the SDIO Clock divider bypass is enabled or disabled. [Table 744](#) shows the values this member can assume.

**Table 744. SDIO\_MCLKBypass definition**

SDIO_MCLKBypass	Description
SDIO_MCLKBypass_Disable	SDIO Clock divider bypass is disabled
SDIO_MCLKBypass_Enable	SDIO Clock divider bypass is enabled

### SDIO\_ClockPowerSave

Specifies whether SDIO Clock output is enabled or disabled when the bus is idle. [Table 745](#) shows the values this member can assume.

**Table 745. SDIO\_ClockPowerSave definition**

SDIO_ClockPowerSave	Description
SDIO_ClockPowerSave_Disable	SDIO Clock output is disabled when the bus is idle
SDIO_ClockPowerSave_Enable	SDIO Clock output is enabled when the bus is idle

**SDIO\_BusWide**

Specifies the SDIO bus width. [Table 746](#) shows the values this member can assume.

**Table 746. SDIO\_BusWide definition**

SDIO_BusWide	Description
SDIO_BusWide_1b	1-bit wide bus mode
SDIO_BusWide_4b	4-bit wide bus mode
SDIO_BusWide_8b	8-bit wide bus mode

**SDIO\_HardwareFlowControl**

Specifies whether the SDIO hardware flow control is enabled or disabled. [Table 747](#) shows the values this member can assume.

**Table 747. SDIO\_HardwareFlowControl definition**

SDIO_HardwareFlowControl	Description
SDIO_HardwareFlowControl_Disable	SDIO hardware flow control is disabled
SDIO_HardwareFlowControl_Enable	SDIO hardware flow control is enabled

**Example:**

```
/* Configure the SDIO peripheral */
SDIO_InitTypeDef SDIO_InitStructure;

SDIO_InitStructure.SDIO_ClockDiv = 0xB2;
SDIO_InitStructure.SDIO_ClockEdge = SDIO_ClockEdge_Rising;
SDIO_InitStructure.SDIO_MCLKBypass = SDIO_MCLKBypass_Disable;
SDIO_InitStructure.SDIO_ClockPowerSave =
SDIO_ClockPowerSave_Enable;
SDIO_InitStructure.SDIO_BusWide = SDIO_BusWide_4b;
SDIO_InitStructure.SDIO_HardwareFlowControl =
SDIO_HardwareFlowControl_Enable;
SDIO_Init(&SDIO_InitStructure);
```

### 24.2.3 SDIO\_StructInit

[Table 741](#) describes the SDIO\_StructInit function.

**Table 748. SDIO\_StructInit function**

Function name	SDIO_StructInit
Function prototype	<code>void SDIO_StructInit(SDIO_InitTypeDef* SDIO_InitStruct)</code>
Behavior description	Fills each SDIO_InitStruct member with its default value.
Input parameter	SDIO_InitStruct: pointer to an SDIO_InitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

[Table 749](#) shows the values assumed by the SDIO\_InitStruct members.

**Table 749. SDIO\_InitStruct member definition**

Member	Default value
SDIO_ClockDiv	0x00
SDIO_ClockEdge	SDIO_ClockEdge_Rising
SDIO_MCLKBypass	SDIO_MCLKBypass_Disable
SDIO_ClockPowerSave	SDIO_ClockPowerSave_Disable
SDIO_BusWide	SDIO_BusWide_1b
SDIO_HardwareFlowControl	SDIO_HardwareFlowControl_Disable

**Example:**

```
/* Initialize a SDIO_InitTypeDef structure. */
SDIO_InitTypeDef SDIO_InitStructure;
SDIO_StructInit(&SDIO_InitStructure);
```

## 24.2.4 SDIO\_ClockCmd

[Table 750](#) describes the SDIO\_ClockCmd function.

**Table 750. SDIO\_ClockCmd function**

Function name	SDIO_ClockCmd
Function prototype	void SDIO_ClockCmd(FunctionalState NewState)
Behavior description	Enables or disables the SDIO Clock.
Input parameter	NewState: new state of the SDIO Clock. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable SDIO Clock*/
SDIO_ClockCmd(ENABLE);
```

## 24.2.5 SDIO\_SetPowerState

[Table 751](#) describes the SDIO\_SetPowerState function.

**Table 751. SDIO\_SetPowerState function**

Function name	SDIO_SetPowerState
Function prototype	void SDIO_SetPowerState(u32 SDIO_PowerState)
Behavior description	Sets the power status of the controller.
Input parameter	SDIO_PowerState: new power state. Refer to <a href="#">SDIO_PowerState</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### SDIO\_PowerState

Specifies Power state to set. [Table 752](#) shows the values assumed by this member.

**Table 752. SDIO\_PowerState definition**

SDIO_PowerState	Description
SDIO_PowerState_OFF	Power off: the clock to card is stopped.
SDIO_PowerState_ON	Power on: the card is clocked.

**Example:**

```
/* Set SDIO Power Status */
SDIO_SetPowerState(SDIO_PowerState_ON);
```

## 24.2.6 SDIO\_GetPowerState

[Table 753](#) describes the SDIO\_GetPowerState function.

**Table 753. SDIO\_GetPowerState function**

Function name	SDIO_GetPowerState
Function prototype	u32 SDIO_GetPowerState(void)
Behavior description	Gets the power status of the controller.
Input parameter	None
Output parameter	None
Return parameter	Power status of the controller.
Required preconditions	None
Called functions	None

**Example:**

```
/* Get SDIO Power Status */
u32 PowerState;
PowerState = SDIO_GetPowerState();
```

## 24.2.7 SDIO\_ITConfig

[Table 754](#) describes the SDIO\_ITConfig function.

**Table 754. SDIO\_ITConfig function**

Function name	SDIO_ITConfig
Function prototype	void SDIO_ITConfig(u32 SDIO_IT, FunctionalState NewState)
Behavior description	Enables or disables the SDIO interrupts.
Input parameter1	SDIO_IT: specifies the SDIO interrupt sources to be enabled or disabled. Refer to <a href="#">SDIO_IT</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the specified SDIO interrupts. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**SDIO\_IT**

*Table 755* shows the values that can be combined to enable or disable the SDIO interrupts.

**Table 755. SDIO\_IT definition**

SDIO_IT	Description
SDIO_IT_CCRCFAIL	Command response received (CRC check failed) interrupt mask
SDIO_IT_DCRCFAIL	Data block sent/received (CRC check failed) interrupt mask
SDIO_IT_CTIMEOUT	Command response timeout interrupt mask
SDIO_IT_DTIMEOUT	Data timeout interrupt mask
SDIO_IT_TXUNDERR	Transmit FIFO underrun error interrupt mask
SDIO_IT_RXOVERR	Received FIFO overrun error interrupt mask
SDIO_IT_CMDREND	Command response received (CRC check passed) interrupt mask
SDIO_IT_CMDSSENT	Command sent (no response required) interrupt mask
SDIO_IT_DATAEND	Data end (data counter SDIDCOUNT is zero) interrupt mask
SDIO_IT_STBITERR	Start bit not detected on all data signals in wide bus mode interrupt mask
SDIO_IT_DBCKEND	Data block sent/received (CRC check passed) interrupt mask
SDIO_IT_CMDACT	Command transfer in progress interrupt mask
SDIO_IT_TXACT	Data transmit in progress interrupt mask
SDIO_IT_RXACT	Data receive in progress interrupt mask
SDIO_IT_TXFIFOBW	Transmit FIFO burst writable interrupt mask
SDIO_IT_RXFIFOBW	Receive FIFO burst readable interrupt mask.
SDIO_IT_TXFIFOE	Transmit FIFO full interrupt mask
SDIO_IT_RXFIFOE	Receive FIFO full interrupt mask.
SDIO_IT_TXFIFOE	Transmit FIFO empty interrupt mask
SDIO_IT_RXFIFOE	Receive FIFO empty interrupt mask
SDIO_IT_TXDAVL	Data available in transmit FIFO interrupt mask
SDIO_IT_RXDAVL	Data available in receive FIFO interrupt mask
SDIO_IT_SDIOIT	SDIO interrupt received interrupt mask
SDIO_IT_CEATAEND	CE-ATA command completion signal received for CMD61

**Example:**

```
/* Enable Receive FIFO full interrupt */
SDIO_ITConfig(SDIO_IT_RXFIFOE, ENABLE);
```

## 24.2.8 SDIO\_DMAMCmd

[Table 756](#) describes the SDIO\_DMAMCmd function.

**Table 756. SDIO\_DMAMCmd function**

Function name	SDIO_DMAMCmd
Function prototype	<code>void SDIO_DMAMCmd(FunctionalState NewState)</code>
Behavior description	Enables or disables the SDIO DMA request.
Input parameter	NewState: new state of the selected SDIO DMA request. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called Functions	None

**Example:**

```
/* Enable SDIO DMA request */
SDIO_DMAMCmd(ENABLE);
```

## 24.2.9 SDIO\_SendCommand

[Table 757](#) describes the SDIO\_SendCommand function.

**Table 757. SDIO\_SendCommand function**

Function name	SDIO_SendCommand
Function prototype	<code>void SDIO_SendCommand(SDIO_CmdInitTypeDef *SDIO_CmdInitStruct)</code>
Behavior description	Initializes the SDIO command according to the parameters specified in SDIO_CmdInitStruct, and sends the command.
Input parameter	SDIO_CmdInitStruct: pointer to an SDIO_CmdInitTypeDef structure that contains the configuration information for the SDIO command. Refer to <a href="#">SDIO_CmdInitTypeDef</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

## SDIO\_CmdInitTypeDef

The SDIO\_CmdInitTypeDef structure is defined in the *stm32f10x\_sdio.h* file:

```
typedef struct
{
    u32 SDIO_Argument;
    u32 SDIO_CmdIndex;
    u32 SDIO_Response;
    u32 SDIO_Wait;
    u32 SDIO_CPSM;
} SDIO_CmdInitTypeDef;
```

### SDIO\_Argument

Specifies the SDIO command argument which is sent to a card as part of a command message. If a command contains an argument, it must be loaded into this register before writing the command to the command register.

### SDIO\_CmdIndex

Specifies the SDIO command index. It must be lower than 0x40.

### SDIO\_Response

Specifies the SDIO response type. [Table 758](#) gives the values assumed by this parameter.

**Table 758. SDIO\_Response definition**

SDIO_Response	Description
SDIO_Response_No	No Response is expected
SDIO_Response_Short	Short Response is expected
SDIO_Response_Long	Long Response is expected

### SDIO\_Wait

Specifies whether SDIO wait-for-interrupt request is enabled or disabled. [Table 759](#) gives the values assumed by this parameter.

**Table 759. SDIO\_Wait definition**

SDIO_Wait	Description
SDIO_Wait_NO	No wait is requested
SDIO_Wait_IT	SDIO wait for interrupt request is enabled
SDIO_Wait_Pend	SDIO Wait End of transfer is enabled

### SDIO\_CPSM

Specifies whether SDIO Command path state machine (CPSM) is enabled or disabled. [Table 760](#) gives the values assumed by this parameter



**Table 760. SDIO\_CPSM definition**

SDIO_CPSM	Description
SDIO_CPSM_Enable	SDIO command path state machine (CPSM) is enabled
SDIO_CPSM_Disable	SDIO command path state machine (CPSM) is disabled

**Example:**

```

/* Configure the SDIO Command */
SDIO_CmdInitTypeDef SDIO_CmdInitStructure;
SDIO_CmdInitStructure.SDIO_Argument = 0x0;
SDIO_CmdInitStructure.SDIO_CmdIndex = 0x0;
SDIO_CmdInitStructure.SDIO_Response = SDIO_Response_Short;
SDIO_CmdInitStructure.SDIO_Wait = SDIO_Wait_IT;
SDIO_CmdInitStructure.SDIO_CPSM = SDIO_CPSM_Enable;
SDIO_SendCommand(&SDIO_CmdInitStructure);

```

**24.2.10 SDIO\_CmdStructInit**

[Table 761](#) describes the SDIO\_CmdStructInit function.

**Table 761. SDIO\_CmdStructInit function**

Function name	SDIO_CmdStructInit
Function prototype	void SDIO_CmdStructInit(SDIO_CmdInitTypeDef* SDIO_CmdInitStruct)
Behavior description	Fills each SDIO_CmdInitStruct member with its default value.
Input parameter	SDIO_CmdInitStruct: pointer to an SDIO_CmdInitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

[Table 762](#) gives the default values of the SDIO\_CmdInitStruct members.

**Table 762. SDIO\_CmdInitStruct member definition**

Member	Default value
SDIO_Argument	0x00
SDIO_CmdIndex	0x00
SDIO_RespType	SDIO_RespType_No
SDIO_Wait	SDIO_Wait_No
SDIO_CPSM	SDIO_CPSM_Disable

**Example:**

```

/* Initialize a SDIO_CmdInitTypeDef structure */
SDIO_CmdInitTypeDef SDIO_CmdInitStructure;
SDIO_CmdStructInit(&SDIO_CmdInitStructure);

```

## 24.2.11 SDIO\_GetCommandResponse

[Table 763](#) describes the SDIO\_GetCommandResponse function.

**Table 763. SDIO\_GetCommandResponse function**

Function name	SDIO_GetCommandResponse
Function prototype	u8 SDIO_GetCommandResponse(void)
Behavior description	Returns command index of last command for which a response was received.
Input parameter	None
Output parameter	None
Return parameter	Returns the command index of the last command response received.
Required preconditions	None
Called Functions	None

**Example:**

```
/* Get the Command Response */
u8 CmdResp = 0;
CmdResp = SDIO_GetCommandResponse();
```

## 24.2.12 SDIO\_GetResponse

[Table 764](#) describes the SDIO\_GetResponse function.

**Table 764. SDIO\_GetResponse function**

Function name	SDIO_GetResponse
Function prototype	u32 SDIO_GetResponse(u32 SDIO_RESP)
Behavior description	Returns the response received from the card for the last command.
Input parameter	SDIO_RESP: specifies the SDIO response register. Refer to <a href="#">SDIO_RESP</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The corresponding response register value.
Required preconditions	None
Called Functions	None

**SDIO\_RESP**

Specifies the Response register to be read. [Table 765](#) gives the values assumed by this member.

**Table 765. SDIO\_RESP definition**

SDIO_RESP	Description
SDIO_RESP1	SDIO Response register 1
SDIO_RESP2	SDIO Response register 2
SDIO_RESP3	SDIO Response register 3
SDIO_RESP4	SDIO Response register 4

**Example:**

```
/* Get the Data Response received */
u32 Response = 0;
Response = SDIO_GetResponse(SDIO_RESP1);
```

**24.2.13 SDIO\_DataConfig**

[Table 766](#) describes the SDIO\_DataConfig function.

**Table 766. SDIO\_DataConfig function**

Function name	SDIO_DataConfig
Function prototype	void SDIO_DataConfig(SDIO_DataInitTypeDef* SDIO_DataInitStruct)
Behavior description	Initializes the SDIO data path according to the parameters specified in SDIO_DataInitStruct.
Input parameter	SDIO_DataInitStruct: pointer to an SDIO_DataInitTypeDef structure that contains the configuration information for the SDIO command. Refer to <a href="#">SDIO_DataInitTypeDef</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**SDIO\_DataInitTypeDef**

The SDIO\_DataInitTypeDef structure is defined in the *stm32f10x\_sdio.h* file:

```
typedef struct
{
    u32 SDIO_DataTimeOut;
    u32 SDIO_DataLength;
    u32 SDIO_DataBlockSize;
    u32 SDIO_TransferDir;
    u32 SDIO_TransferMode;
    u32 SDIO_DPSM;
} SDIO_DataInitTypeDef;
```

**SDIO\_DataTimeOut**

Specifies the data timeout period in card bus clock periods.

**SDIO\_DataLength**

Specifies the number of data bytes to be transferred.

**SDIO\_DataBlockSize**

Specifies the data block size for block transfer. [Table 767](#) gives the values assumed by this member.

**Table 767. SDIO\_DataBlockSize definition**

SDIO_DataBlockSize	Description
SDIO_DataBlockSize_1b	Data Block length = $2^0$ = 1 bytes
SDIO_DataBlockSize_2b	Data Block length = $2^1$ = 2 bytes
SDIO_DataBlockSize_4b	Data Block length = $2^2$ = 4 bytes
SDIO_DataBlockSize_8b	Data Block length = $2^3$ = 8 bytes
SDIO_DataBlockSize_16b	Data Block length = $2^4$ = 16 bytes
SDIO_DataBlockSize_32b	Data Block length = $2^5$ = 32 bytes
SDIO_DataBlockSize_64b	Data Block length = $2^6$ = 64 bytes
SDIO_DataBlockSize_128b	Data Block length = $2^7$ = 128 bytes
SDIO_DataBlockSize_256b	Data Block length = $2^8$ = 256 bytes
SDIO_DataBlockSize_512b	Data Block length = $2^9$ = 512 bytes
SDIO_DataBlockSize_1024b	Data Block length = $2^{10}$ = 1024 bytes
SDIO_DataBlockSize_2048b	Data Block length = $2^{11}$ = 2048 bytes
SDIO_DataBlockSize_4096b	Data Block length = $2^{12}$ = 4096 bytes
SDIO_DataBlockSize_8192b	Data Block length = $2^{13}$ = 8192 bytes
SDIO_DataBlockSize_16384b	Data Block length = $2^{14}$ = 16384 bytes

**SDIO\_TransferDir**

Specifies the data transfer direction, whether the transfer is a read or write. [Table 768](#) gives the values assumed by this member.

**Table 768. SDIO\_TransferDir definition**

SDIO_TransferDir	Description
SDIO_TransferDir_ToCard	From controller to card
SDIO_TransferDir_ToSDIO	From card to controller

**SDIO\_TransferMode**

Specifies whether data transfer is in stream or block mode. [Table 769](#) gives the values assumed by this member.

**Table 769. SDIO\_TransferMode definition**

SDIO_TransferMode	Description
SDIO_TransferMode_Stream	Stream data transfer
SDIO_TransferMode_Block	Block data transfer

**SDIO\_DPSM**

Specifies whether SDIO Data path state machine (DPSM) is enabled or disabled. [Table 769](#) gives the values assumed by this member.

**Table 770. SDIO\_DPSM definition**

SDIO_DPSM	Description
SDIO_DPSM_Enable	SDIO Data path state machine (DPSM) is enabled
SDIO_DPSM_Disable	SDIO Data path state machine (DPSM) is disabled

**Example:**

```
/* Configure the SDIO Data Path State Machine */
SDIO_DataInitTypeDef SDIO_DataInitStructure;
SDIO_DataInitStructure.SDIO_DataTimeOut = 0xFFFFFFFF;
SDIO_DataInitStructure.SDIO_DataLength = 0x100;
SDIO_DataInitStructure.SDIO_DataBlockSize = SDIO_DataBlockSize_16b;
SDIO_DataInitStructure.SDIO_TransferDir = SDIO_TransferDir_ToCard;
SDIO_DataInitStructure.SDIO_TransferMode = SDIO_TansferMode_Block;
SDIO_DataInitStructure.SDIO_DPSM = SDIO_DPSM_Enable;
SDIO_DataConfig(&SDIO_DataInitStructure);
```

**24.2.14 SDIO\_DataStructInit**

[Table 771](#) describes the SDIO\_DataStructInit function.

**Table 771. SDIO\_DataStructInit function**

Function name	SDIO_DataStructInit
Function prototype	void SDIO_DataStructInit (SDIO_DataInitTypeDef* SDIO_DataInitStruct)
Behavior description	Fills each SDIO_DataInitStruct member with its default value.
Input parameter	SDIO_DataInitStruct: pointer to an SDIO_DataInitTypeDef structure which will be initialized.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

[Table 772](#) gives the default values of the SDIO\_DataInitStruct members.

**Table 772. SDIO\_DataInitStruct member definition**

Member	Default value
SDIO_DataTimeOut	0xFFFFFFFF
SDIO_DataLength	0x00
SDIO_DataBlockSize	SDIO_DataBlockSize_1b
SDIO_TransferDir	SDIO_TransferDir_ToCard
SDIO_TransferMode	SDIO_TransferMode_Block
SDIO_DPSM	SDIO_DPSM_Disable

**Example:**

```
/* Initialize a SDIO_DataInitTypeDef structure */
SDIO_DataInitTypeDef SDIO_DataInitStructure;
SDIO_DataStructInit(&SDIO_DataInitStructure);
```

**24.2.15 SDIO\_GetDataCounter**

[Table 773](#) describes the SDIO\_GetDataCounter function.

**Table 773. SDIO\_GetDataCounter function**

Function name	SDIO_GetDataCounter
Function prototype	u32 SDIO_GetDataCounter(void)
Behavior description	Returns number of remaining data bytes to be transferred.
Input parameter	None
Output parameter	None
Return parameter	Number of remaining data bytes to be transferred
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the Data Counter */
u32 DataCounter = 0;
DataCounter = SDIO_GetDataCounter();
```

## 24.2.16 SDIO\_ReadData

[Table 774](#) describes the SDIO\_ReadData function.

**Table 774. SDIO\_ReadData function**

Function name	SDIO_ReadData
Function prototype	u32 SDIO_ReadData(void)
Behavior description	Read one data word from Rx FIFO.
Input parameter	None
Output parameter	None
Return parameter	Data received
Required preconditions	None
Called functions	None

**Example:**

```
/* Read Data */
u32 Data = 0;
Data = SDIO_ReadData();
```

## 24.2.17 SDIO\_WriteData

[Table 775](#) describes the SDIO\_WriteData function.

**Table 775. SDIO\_WriteData function**

Function name	SDIO_WriteData
Function prototype	void SDIO_WriteData(u32 Data)
Behavior description	Write one data word to Tx FIFO.
Input parameter	Data: 32-bit data word to write.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Write Data */
SDIO_WriteData(0xFFFF);
```

## 24.2.18 SDIO\_GetFIFOCOUNT

[Table 776](#) describes the SDIO\_GetFIFOCOUNT function.

**Table 776. SDIO\_GetFIFOCOUNT function**

Function name	SDIO_GetFIFOCOUNT
Function prototype	u32 SDIO_GetFIFOCOUNT(void)
Behavior description	Returns the number of words left to be written to or read from FIFO.
Input parameter	None
Output parameter	None
Return parameter	Remaining number of words.
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the FIFO Data Counter */
u32 FIFODataCounter = 0;
FIFODataCounter = SDIO_GetFIFOCOUNT();
```

## 24.2.19 SDIO\_StartSDIOReadWait

[Table 777](#) describes the SDIO\_StartSDIOReadWait function.

**Table 777. SDIO\_StartSDIOReadWait function**

Function name	SDIO_StartSDIOReadWait
Function prototype	void SDIO_StartSDIOReadWait(FunctionalState NewState)
Behavior description	Starts the SD I/O Read Wait operation.
Input parameter	NewState: new state of the Start SDIO Read Wait operation. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Start the Read Wait Operation in SDIO mode */
SDIO_StartSDIOReadWait(ENABLE);
```



## 24.2.20 SDIO\_StopSDIOReadWait

[Table 778](#) describes the SDIO\_StopSDIOReadWait function.

**Table 778. SDIO\_StopSDIOReadWait function**

Function name	SDIO_StopSDIOReadWait
Function prototype	<code>void SDIO_StopSDIOReadWait(FunctionalState NewState)</code>
Behavior description	Stops the SD I/O Read Wait operation.
Input parameter	NewState: new state of the Stop SDIO Read Wait operation. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Stop the Read Wait Operation in SDIO mode */
SDIO_StopSDIOReadWait(ENABLE);
```

## 24.2.21 SDIO\_SetSDIOReadWaitMode

[Table 779](#) describes the SDIO\_SetSDIOReadWaitMode function.

**Table 779. SDIO\_SetSDIOReadWaitMode function**

Function name	SDIO_SetSDIOReadWaitMode
Function prototype	<code>void SDIO_SetSDIOReadWaitMode(u32 SDIO_ReadWaitMode)</code>
Behavior description	Sets one of the two options of inserting read wait interval.
Input parameter	SDIOReadWaitMode: SD I/O Read Wait operation mode. This parameter can be: – SDIO_ReadWaitMode_CLK: Read Wait control by stopping SDIOCLK – SDIO_ReadWaitMode_DATA2: Read Wait control using SDIO_DATA2
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Set the Read Wait Mode to SDIO CLK */
SDIO_SetSDIOReadWaitMode(SDIO_ReadWaitMode_CLK);
```

## 24.2.22 SDIO\_SetSDIOOperation

*Table 780* describes the SDIO\_SetSDIOOperation function.

**Table 780. SDIO\_SetSDIOOperation function**

Function name	SDIO_SetSDIOOperation
Function prototype	void SDIO_SetSDIOOperation(FunctionalState NewState)
Behavior description	Enables or disables the SD I/O mode operation.
Input parameter	NewState: new state of SDIO specific operation. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enable the SDIO Operation */
SDIO_SetSDIOOperation(ENABLE);
```

## 24.2.23 SDIO\_SendSDIOSuspendCmd

*Table 781* describes the SDIO\_SendSDIOSuspendCmd function.

**Table 781. SDIO\_SendSDIOSuspendCmd function**

Function name	SDIO_SendSDIOSuspendCmd
Function prototype	void SDIO_SendSDIOSuspendCmd(FunctionalState NewState)
Behavior description	Enables or disables the SD I/O Mode suspend command sending.
Input parameter	NewState: new state of the SD I/O Mode suspend command. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Send the SDIO Suspend Command */
SDIO_SendSDIOSuspendCmd(ENABLE);
```

## 24.2.24 SDIO\_CommandCompletionCmd

*Table 782* describes the SDIO\_CommandCompletionCmd function.

**Table 782. SDIO\_CommandCompletionCmd function**

Function name	SDIO_CommandCompletionCmd
Function prototype	<code>void SDIO_CommandCompletionCmd(FunctionalState NewState)</code>
Behavior description	Enables or disables the command completion signal.
Input parameter	NewState: new state of command completion signal. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the Command Completion signal */
SDIO_CommandCompletionCmd(ENABLE);
```

## 24.2.25 SDIO\_CEATAITCmd

*Table 783* describes the SDIO\_CEATAITCmd function.

**Table 783. SDIO\_CEATAITCmd function**

Function name	SDIO_CEATAITCmd
Function prototype	<code>void SDIO_CEATAITCmd(FunctionalState NewState)</code>
Behavior description	Enables or disables the CE-ATA interrupt.
Input parameter	NewState: new state of CE-ATA interrupt. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Enables the CEATA interrupt */
SDIO_CEATAITCmd(ENABLE);
```

## 24.2.26 SDIO\_SendCEATACmd

[Table 784](#) describes the SDIO\_SendCEATACmd function.

**Table 784. SDIO\_SendCEATACmd function**

Function name	SDIO_SendCEATACmd
Function prototype	<code>void SDIO_SendCEATACmd(FunctionalState NewState)</code>
Behavior description	Sends CE-ATA command (CMD61).
Input parameter	NewState: new state of CE-ATA command. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Sends the CEATA command (CMD61) */
SDIO_SendCEATACmd(ENABLE);
```

## 24.2.27 SDIO\_GetFlagStatus

[Table 785](#) describes the SDIO\_GetFlagStatus function.

**Table 785. SDIO\_GetFlagStatus function**

Function name	SDIO_GetFlagStatus
Function prototype	<code>FlagStatus SDIO_GetFlagStatus(u32 SDIO_FLAG)</code>
Behavior description	Checks whether the specified SDIO flag is set or not.
Input parameter	SDIO_FLAG: specifies the flag to check. Refer to <a href="#">ADC_FLAG</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of SDIO_FLAG (SET or RESET).
Required preconditions	None
Called functions	None

**SDIO\_FLAG**

*Table 786* gives the list of the SDIO flags that can be checked.

**Table 786. SDIO\_FLAG definition**

SDIO_FLAG	Description
SDIO_FLAG_CCRCFAIL	Command response received (CRC check failed) flag
SDIO_FLAG_DCRCFAIL	Data block sent/received (CRC check failed) flag
SDIO_FLAG_CTIMEOUT	Command response timeout flag
SDIO_FLAG_DTIMEOUT	Data timeout flag
SDIO_FLAG_TXUNDERR	Transmit FIFO underrun error flag
SDIO_FLAG_RXOVERR	Received FIFO overrun error flag
SDIO_FLAG_CMDREND	Command response received (CRC check passed)flag
SDIO_FLAG_CMDSSENT	Command sent (no response required) flag
SDIO_FLAG_DATAEND	Data end (data counter, SDIDCOUNT, is zero) flag
SDIO_FLAG_STBITERR	Start bit not detected on all data signals in wide bus mode flag
SDIO_FLAG_DBCKEND	Data block sent/received (CRC check passed)flag
SDIO_FLAG_CMDACT	Command transfer in progress flag
SDIO_FLAG_TXACT	Data transmit in progress flag
SDIO_FLAG_RXACT	Data receive in progress flag
SDIO_FLAG_TXFIFOBW	Transmit FIFO burst writable flag
SDIO_FLAG_RXFIFOBW	Receive FIFO burst readable flag
SDIO_FLAG_TXFIFOE	Transmit FIFO full flag
SDIO_FLAG_RXFIFOE	Receive FIFO full flag
SDIO_FLAG_TXFIFOE	Transmit FIFO empty flag
SDIO_FLAG_RXFIFOE	Receive FIFO empty flag
SDIO_FLAG_TXDAVL	Data available in transmit FIFO flag
SDIO_FLAG_RXDAVL	Data available in receive FIFO flag
SDIO_FLAG_SDIOIT	SDIO interrupt received flag
SDIO_FLAG_CEATAEND	CE-ATA command completion signal received for CMD61 flag

**Example:**

```
/* Get the SDIO Data available in transmit FIFO flag status */
FlagStatus Status = RESET;
Status = SDIO_GetFlagStatus(SDIO_FLAG_TXDAVL);
```

## 24.2.28 SDIO\_ClearFlag

[Table 787](#) describes the SDIO\_ClearFlag function.

**Table 787. SDIO\_ClearFlag function**

Function name	SDIO_ClearFlag
Function prototype	<code>void SDIO_ClearFlag(u32 SDIO_FLAG)</code>
Behavior description	Clears the SDIOx's pending flags.
Input parameter	SDIO_FLAG: specifies the flag to clear. Refer to <a href="#">SDIO_FLAG on page 510</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

### SDIO\_FLAG

[Table 788](#) gives the list of the SDIO flags that can be checked.

**Table 788. SDIO\_FLAG definition**

SDIO_FLAG	Description
SDIO_FLAG_CCRCFAIL	Command response received (CRC check failed) flag
SDIO_FLAG_DCRCFAIL	Data block sent/received (CRC check failed) flag
SDIO_FLAG_CTIMEOUT	Command response timeout flag
SDIO_FLAG_DTIMEOUT	Data timeout flag
SDIO_FLAG_TXUNDERR	Transmit FIFO underrun error flag
SDIO_FLAG_RXOVERR	Received FIFO overrun error flag
SDIO_FLAG_CMDREND	Command response received (CRC check passed) flag
SDIO_FLAG_CMDSSENT	Command sent (no response required) flag
SDIO_FLAG_DATAEND	Data end (data counter, SDIDCOUNT, is zero) flag
SDIO_FLAG_STBITERR	Start bit not detected on all data signals in wide bus mode flag
SDIO_FLAG_DBCKEND	Data block sent/received (CRC check passed) flag
SDIO_FLAG_SDIOIT	SDIO interrupt received flag
SDIO_FLAG_CEATAEND	CE-ATA command completion signal received for CMD61 flag

#### Example:

```
/* Clear the SDIO Received FIFO overrun error flag */
SDIO_ClearFlag(SDIO_FLAG_RXOVERR);
```

## 24.2.29 SDIO\_GetITStatus

[Table 789](#) describes the SDIO\_GetITStatus function.

**Table 789. SDIO\_GetITStatus function**

Function name	SDIO_GetITStatus
Function prototype	ITStatus SDIO_GetITStatus(u32 SDIO_IT)
Behavior description	Checks whether the specified SDIO interrupt has occurred or not.
Input parameter	SDIO_IT: specifies the SDIO interrupt source to check. Refer to <a href="#">SDIO_IT on page 494</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	The new state of SDIO_IT (SET or RESET).
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the SDIO Data available in transmit FIFO IT status */
ITStatus Status = RESET;
Status = SDIO_GetITStatus(SDIO_IT_TXDAVL);
```

## 24.2.30 SDIO\_ClearITPendingBit

[Table 790](#) describes the SDIO\_ClearITPendingBit function.

**Table 790. SDIO\_ClearITPendingBit function**

Function name	SDIO_ClearITPending Bit
Function prototype	void SDIO_ClearITPendingBit(u32 SDIO_IT)
Behavior description	Clears the SDIO's interrupt pending bits.
Input parameter	SDIO_IT: specifies the interrupt pending bit to clear. Refer to <a href="#">SDIO_IT on page 512</a> for more details on the allowed values for this parameter.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**SDIO\_IT**

To enable or disable SDIO interrupts, use a combination of one or more of the values given in [Table 791](#).

**Table 791. SDIO\_IT definitions**

SDIO_IT	Description
SDIO_IT_CCRCFAIL	Command response received (CRC check failed) interrupt mask
SDIO_IT_DCRCFAIL	Data block sent/received (CRC check failed) interrupt mask
SDIO_IT_CTIMEOUT	Command response timeout interrupt mask
SDIO_IT_DTIMEOUT	Data timeout interrupt mask
SDIO_IT_TXUNDERR	Transmit FIFO underrun error interrupt mask
SDIO_IT_RXOVERR	Received FIFO overrun error interrupt mask
SDIO_IT_CMDREND	Command response received (CRC check passed) interrupt mask
SDIO_IT_CMDSSENT	Command sent (no response required) interrupt mask
SDIO_IT_DATAEND	Data end (data counter SDIDCOUNT is zero) interrupt mask
SDIO_IT_STBITERR	Start bit not detected on all data signals in wide bus mode interrupt mask
SDIO_IT_DBCKEND	Data block sent/received (CRC check passed) interrupt mask
SDIO_IT_SDIOIT	SDIO interrupt received interrupt mask
SDIO_IT_CEATAEND	CE-ATA command completion signal received for CMD61 interrupt mask

**Example:**

```
/* Clear the SDIO Data block sent/received (CRC check
passed) interrupt pending bit*/
SDIO_ClearITPendingBit(SDIO_IT_DBCKEND);
```



## 25 Debug MCU

The DBGMCU can be used for a variety of purposes, including getting the device identifier, peripheral and low-power mode behavior when the MCU is in Debug mode.

[Section 25.1: DBGMCU register structure](#) describes the data structures used in the DBGMCU firmware library. [Section 25.2: Firmware library functions](#) presents the firmware library functions.

### 25.1 DBGMCU register structure

The DBGMCU register structure, *DBGMCU\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32 IDCODE;
    vu32 CR;
}DBGMCU_TypeDef;
```

[Table 792](#) gives the list of DBGMCU registers.

**Table 792. DBGMCU registers**

Register	Description
IDCODE	MCU device ID code register
CR	Control register

The DBGMCU peripheral is declared in the same file:

```
#define DBGMCU_BASE                ((u32) 0xE0042000)
#ifndef DEBUG
...
#endif
#ifdef _DBGMCU
    #define DBGMCU                ((DBGMCU_TypeDef *) DBGMCU_BASE)
#endif /* _DBGMCU */
...
#else /* DEBUG */
...
#endif
#ifdef _DBGMCU
    EXT DBGMCU_TypeDef            *DBGMCU;
#endif /* _DBGMCU */
...
#endif
```

When using the Debug mode, the DBGMCU pointer is initialized in the *stm32f10x\_lib.c* file:

```
#ifdef _DBGMCU
    DBGMCU = (DBGMCU_TypeDef *) DBGMCU_BASE;
#endif /* _DBGMCU */
```

To access the Debug MCU registers, *\_DBGMCU* must be defined in *stm32f10x\_conf.h* as follows:

```
#define _DBGMCU
```

## 25.2 Firmware library functions

[Table 793](#) gives the list of the various functions in the DBGMCU library.

**Table 793. DBGMCU firmware library functions**

Function name	Description
DBGMCU_GetREVID	Returns the device revision identifier.
DBGMCU_GetDEVID	Returns the device identifier.
DBGMCU_Config	Configures the specified peripheral and low-power mode behavior when the MCU is in Debug mode.

### 25.2.1 DBGMCU\_GetREVID function

[Table 794](#) describes the DBGMCU\_GetREVID function.

**Table 794. DBGMCU\_GetREVID function**

Function name	DBGMCU_GetREVID
Function prototype	u32 DBGMCU_GetREVID(void)
Behavior description	Returns the device revision identifier.
Input parameter	None
Output parameter	None
Return parameter	Device revision identifier
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the device revision identifier */  
u32 RevID = 0;  
RevID = DBGMCU_GetREVID();
```

## 25.2.2 DBGMCU\_GetDEVID function

[Table 795](#) describes the DBGMCU\_GetDEVID function.

**Table 795. DBGMCU\_GetDEVID function**

Function name	DBGMCU_GetDEVID
Function prototype	u32 DBGMCU_GetDEVID(void)
Behavior description	Returns the device identifier.
Input parameter	None
Output parameter	None
Return parameter	Device identifier
Required preconditions	None
Called functions	None

### Example:

```
/* Get the device identifier */
u32 DevID = 0;
DevID = DBGMCU_GetDEVID();
```

## 25.2.3 DBGMCU\_Config function

[Table 796](#) describes the DBGMCU\_Config function.

**Table 796. DBGMCU\_Config function**

Function name	DBGMCU_Config
Function prototype	void DBGMCU_Config(u32 DBGMCU_Periph, FunctionalState NewState)
Behavior description	Configures the specified peripheral and low-power mode behavior when the MCU is in Debug mode.
Input parameter1	DBGMCU_Periph: specifies the peripheral and low power mode. Refer to <a href="#">DBGMCU_Periph</a> for more details on the allowed values for this parameter.
Input parameter2	NewState: new state of the specified peripheral in Debug mode. This parameter can be: ENABLE or DISABLE.
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**DBGMCU\_Periph**

This parameter selects the peripheral to configure (see [Table 797](#)).

**Table 797. DBGMCU\_Periph definition**

DBGMCU_Periph	Description
DBGMCU_SLEEP	Keep debugger connection during Sleep mode
DBGMCU_STOP	Keep debugger connection during Stop mode
DBGMCU_STANDBY	Keep debugger connection during Standby mode
DBGMCU_IWDG_STOP	Debug IWDG stopped when Core is halted
DBGMCU_WWDG_STOP	Debug WWDG stopped when Core is halted
DBGMCU_TIM1_STOP	TIM1 counter stopped when Core is halted
DBGMCU_TIM2_STOP	TIM2 counter stopped when Core is halted
DBGMCU_TIM3_STOP	TIM3 counter stopped when Core is halted
DBGMCU_TIM4_STOP	TIM4 counter stopped when Core is halted
DBGMCU_CAN_STOP	Debug CAN stopped when Core is halted
DBGMCU_I2C1_SMBUS_TIMEOUT	I2C1 SMBUS timeout mode stopped when Core is halted
DBGMCU_I2C2_SMBUS_TIMEOUT	I2C2 SMBUS timeout mode stopped when Core is halted
DBGMCU_TIM5_STOP	TIM5 counter stopped when Core is halted
DBGMCU_TIM6_STOP	TIM6 counter stopped when Core is halted
DBGMCU_TIM7_STOP	TIM7 counter stopped when Core is halted
DBGMCU_TIM8_STOP	TIM8 counter stopped when Core is halted

**Example:**

```
/* Set PLL clock output to 72MHz using HSE (8MHz) as entry clock */  
RCC_PLLConfig(RCC_PLLSource_HSE_Div1, RCC_PLLMul_9);
```

## 26 CRC calculation unit

The CRC (cyclic redundancy check) calculation unit is used to get a CRC code from a 32-bit data word and a fixed generator polynomial.

[Section 26.1: CRC register structure](#) describes the data structures used in the CRC Firmware Library. [Section 26.2: Firmware library functions](#) presents the Firmware Library functions.

### 26.1 CRC register structure

The CRC register structure, *CRC\_TypeDef*, is defined in the *stm32f10x\_map.h* file as follows:

```
typedef struct
{
    vu32 DR;
    vu8  IDR;
    u8    RESERVED0;
    u16   RESERVED1;
    vu32 CR;
} CRC_TypeDef;
```

[Table 798](#) gives the list of CRC registers.

**Table 798. CRC registers**

Register	Description
DR	Data register
IDR	Independent Data register
CR	Control register

The CRC peripheral is declared in the same file:

```
#define PERIPH_BASE      ((u32)0x40000000)
#define APB1PERIPH_BASE PERIPH_BASE
#define APB2PERIPH_BASE (PERIPH_BASE + 0x10000)
#define AHBPERIPH_BASE  (PERIPH_BASE + 0x20000)
#define CRC_BASE         (AHBPERIPH_BASE + 0x3000)

#ifndef DEBUG
...
#endif
#define _CRC
#define CRC                ((CRC_TypeDef *) CRC_BASE)
#endif /* _CRC */
...
#else /* DEBUG */
...
#endif
#define _CRC
EXT CRC_TypeDef            *CRC;
#endif /* _CRC */
...
```

```
#endif
```

When using the Debug mode, CRC pointer is initialized in *stm32f10x\_lib.c* file:

```
#ifndef _CRC
    CRC = (CRC_TypeDef *) CRC_BASE;
#endif /*_CRC */
```

To access the CRC calculation unit registers, `_CRC` must be defined in *stm32f10x\_conf.h* as follows:

```
#define _CRC
```

## 26.2 Firmware library functions

[Table 799](#) gives the list of the various functions of the CRC library.

**Table 799. CRC firmware library functions**

Function name	Description
CRC_ResetDR	Resets the CRC Data register (DR).
CRC_CalcCRC	Computes the 32-bit CRC of a given data word (32-bit).
CRC_CalcBlockCRC	Computes the 32-bit CRC of a given data word buffer (32-bit).
CRC_GetCRC	Returns the current CRC value
CRC_SetIDRegister	Stores a 8-bit data in the independent data (ID) register.
CRC_GetIDRegister	Returns the 8-bit data stored in the independent data (ID) register

### 26.2.1 CRC\_ResetDR function

[Table 800](#) describes the CRC\_ResetDR function.

**Table 800. CRC\_ResetDR function**

Function name	CRC_ResetDR
Function prototype	void CRC_ResetDR(void)
Behavior description	Resets the CRC Data register (DR).
Input parameter	None
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Deinitialize the CRC Data register (DR) */
CRC_ResetDR();
```

## 26.2.2 CRC\_CalcCRC function

[Table 801](#) describes the CRC\_CalcCRC function.

**Table 801. CRC\_CalcCRC function**

Function name	CRC_CalcCRC
Function prototype	u32 CRC_CalcCRC(u32 Data)
Behavior description	Computes the 32-bit CRC of a given data word (32-bit).
Input parameter	Data: data word (32-bit) to compute its CRC
Output parameter	None
Return parameter	32-bit CRC
Required preconditions	None
Called functions	None

**Example:**

```
/* Compute the CRC of 0x32F103 data */
u32 DataCRC = 0;
DataCRC = CRC_CalcCRC(0x32F103);
```

## 26.3 CRC\_CalcBlockCRC function

[Table 802](#) describes the CRC\_CalcBlockCRC function.

**Table 802. CRC\_CalcBlockCRC function**

Function name	CRC_CalcBlockCRC
Function prototype	u32 CRC_CalcBlockCRC(u32 pBuffer[], u32 BufferLength)
Behavior description	Computes the 32-bit CRC of a given data word buffer (32-bit).
Input parameter1	pBuffer: pointer to the buffer containing the data to be computed
Input parameter2	BufferLength: length of the buffer to be computed
Output parameter	None
Return parameter	32-bit CRC
Required preconditions	None
Called functions	None

**Example:**

```
u32 DATA_t[2] = {0x32F103, 0x32F101};
u32 DATACRC = 0;

/* Compute the CRC of DATA_t buffer */
DATACRC = CRC_CalcBlockCRC(DATA_t, 2);
```

### 26.3.1 CRC\_GetCRC function

*Table 803* describes the CRC\_GetCRC function.

**Table 803. CRC\_GetCRC function**

Function name	CRC_GetCRC
Function prototype	u32 CRC_GetCRC(void)
Behavior description	Returns the current CRC value.
Input parameter	None
Output parameter	None
Return parameter	32-bit CRC
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the current CRC value */  
u32 DataCRC = 0;  
DataCRC = CRC_GetCRC();
```

### 26.3.2 CRC\_SetIDRegister function

*Table 804* describes the CRC\_SetIDRegister function.

**Table 804. CRC\_SetIDRegister function**

Function name	CRC_SetIDRegister
Function prototype	void CRC_SetIDRegister(u8 IDValue)
Behavior description	Stores 8-bit data into the independent data (ID) register.
Input parameter	IDValue: 8-bit value to be stored into the ID register
Output parameter	None
Return parameter	None
Required preconditions	None
Called functions	None

**Example:**

```
/* Store 0xF1 value into the Independent Data(ID) register */  
CRC_SetIDRegister(0xF1);
```



### 26.3.3 CRC\_GetIDRegister function

*Table 805* describes the CRC\_GetIDRegister function.

**Table 805. CRC\_GetIDRegister function**

Function name	CRC_GetIDRegister
Function prototype	u8 CRC_GetIDRegister(void)
Behavior description	Returns the 8-bit data stored in the Independent Data(ID) register
Input parameter	None
Output parameter	None
Return parameter	8-bit value of the ID register
Required preconditions	None
Called functions	None

**Example:**

```
/* Get the current ID register value */  
u8 IDValue = 0;  
IDValue = CRC_GetIDRegister();
```

## 27 Revision history

Table 806. Revision history

Date	Revision	Changes
28-May-2007	1	Initial release.
05-Oct-2007	2	<p><a href="#">Section 1.3.1: Variables on page 38</a> updated.</p> <p>In <a href="#">Peripheral declaration on page 40</a>, <code>#define DEBUG</code> replaced by <code>#define DEBUG 1</code>.</p> <p><code>assert</code> replaced by <code>assert_param</code> and <code>#undef assert</code> removed from document.</p> <p><a href="#">Figure 1: Firmware library folder structure</a> updated.</p> <p>RIDE added in <a href="#">Section 2.1.3: Project folder on page 43</a>.</p> <p>Targeted bit position modified in <a href="#">Section 2.4.1: Mapping formula on page 47</a>. BKP_RTCOutputConfig modified in <a href="#">Table 54: BKP library functions</a>.</p> <p>In <a href="#">Section 5.2: Firmware library functions on page 86</a>, BKP_RTCCalibrationClockOutputCmd() function replaced by BKP_RTCOutputConfig().</p> <p><a href="#">Table 75: CAN_SJW values</a> modified.</p> <p>Required preconditions updated in <a href="#">Table 162: FLASH_ReadOutProtection function</a> and note added in <a href="#">Section 9.2.13: FLASH_ReadOutProtection function</a>.</p> <p>RTC_GetPrescaler function removed (see <a href="#">Section 16.2: Firmware library functions</a>).</p> <p>Descriptions changed in <a href="#">Table 416: SPI_CPOL definition</a>.</p> <p><a href="#">Section 19.2.2: TIM_TimeBaseInit function</a> modified.</p> <p>TIM_InitTypeDef replaced by TIM_OCInitTypeDef and example updated in <a href="#">Section 19.2.3: TIM_OC1Init function</a>.</p> <p><a href="#">Table 489: TIM_ICSelection definition</a> and <a href="#">Table 525: TIM_ExtTRGPrescaler values</a> modified.</p> <p><a href="#">Section 19.2.51: TIM_OC1NPolarityConfig function</a>, <a href="#">Section 19.2.53: TIM_OC2NPolarityConfig function</a> and <a href="#">Section 19.2.55: TIM_OC3NPolarityConfig function</a> modified.</p> <p>Note added in <a href="#">USART_Parity on page 414</a>.</p> <p><a href="#">Section 5.2.5: BKP_RTCOutputConfig function</a> modified.</p> <p>Examples modified in <a href="#">Section 16.2.10: RTC_WaitForSynchro function</a> and <a href="#">Section 19.2.53: TIM_OC2NPolarityConfig function</a>.</p>

Table 806. Revision history

Date	Revision	Changes
22-May-2008	3	<p>User manual updated to support high-density STM32F10xxx devices.</p> <p><a href="#">Section 4: Analog/digital converter (ADC) on page 52</a>: 3 ADCs available.</p> <p><a href="#">Section 5: Backup registers (BKP) on page 83</a>: 42 registers available.</p> <p>Value range modified in <a href="#">ExtId on page 106</a> and <a href="#">ExtId on page 110</a>.</p> <p><a href="#">Table 87: IDE values on page 106</a> and <a href="#">Table 94: IDE values on page 110</a> modified.</p> <p><a href="#">Section 7: DMA controller (DMA) on page 117</a>: 12 channels available.</p> <p><a href="#">Section 9: Flash memory (FLASH) on page 145</a>: <a href="#">FLASH_Pages</a> updated.</p> <p><a href="#">Section 10: General purpose I/O (GPIO) on page 166</a>: GPIO ports F and G added, <a href="#">GPIO_PortSource</a> added, <a href="#">Table 203: GPIO_Remap values</a> updated.</p> <p><a href="#">Section 13: Nested vectored interrupt controller (NVIC) on page 219</a>: <a href="#">Table 267: NVIC registers</a> updated, <a href="#">NVIC_BASEPRICONFIG</a> modified in <a href="#">Table 268: NVIC firmware library functions</a>, <a href="#">Table 274: NVIC_IRQChannels</a> updated, Input parameter2 modified in <a href="#">Table 291: NVIC_SetVectorTable</a> function, <a href="#">NVIC_TypeDef</a> modified in <a href="#">Section 13.1: NVIC register structure on page 219</a>.</p> <p><a href="#">Section 15: Reset and clock control (RCC) on page 259</a>: Notes modified in <a href="#">Table 340: RCC_DeInit</a> function on page 262, <a href="#">Table 373: RCC_AHBPeriph</a> values updated, <a href="#">Table 375: RCC_APB2Periph</a> values updated, <a href="#">Table 377: RCC_APB1Periph</a> values updated.</p> <p><a href="#">Section 17: Serial peripheral interface (SPI) on page 301</a>: 3 SPIs available, <math>I^2S</math> feature added, <a href="#">Table 410: SPI firmware library functions</a> updated.</p> <p><a href="#">Section 17: Serial peripheral interface (SPI) on page 301</a> updated with <math>I^2S</math> functions.</p> <p><a href="#">Section 19: Advanced-control timer, general-purpose timer and basic timer (TIM) on page 332</a> updated (Advanced-control timer section and General-purpose timer section merged).</p> <p>Added sections:</p> <ul style="list-style-type: none"> <li>– <a href="#">Digital/analog converter (DAC) on page 441</a></li> <li>– <a href="#">Flexible static memory controller (FSMC) on page 455</a></li> <li>– <a href="#">SDIO interface (SDIO) on page 485</a></li> <li>– <a href="#">Debug MCU on page 513</a></li> <li>– <a href="#">CRC calculation unit on page 517</a></li> </ul>
13-Jun-2008	4	<a href="#">Figure 1: Firmware library folder structure</a> modified.

**Please Read Carefully:**

Information in this document is provided solely in connection with ST products. STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, modifications or improvements, to this document, and the products and services described herein at any time, without notice.

All ST products are sold pursuant to ST's terms and conditions of sale.

Purchasers are solely responsible for the choice, selection and use of the ST products and services described herein, and ST assumes no liability whatsoever relating to the choice, selection or use of the ST products and services described herein.

No license, express or implied, by estoppel or otherwise, to any intellectual property rights is granted under this document. If any part of this document refers to any third party products or services it shall not be deemed a license grant by ST for the use of such third party products or services, or any intellectual property contained therein or considered as a warranty covering the use in any manner whatsoever of such third party products or services or any intellectual property contained therein.

**UNLESS OTHERWISE SET FORTH IN ST'S TERMS AND CONDITIONS OF SALE ST DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY WITH RESPECT TO THE USE AND/OR SALE OF ST PRODUCTS INCLUDING WITHOUT LIMITATION IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE (AND THEIR EQUIVALENTS UNDER THE LAWS OF ANY JURISDICTION), OR INFRINGEMENT OF ANY PATENT, COPYRIGHT OR OTHER INTELLECTUAL PROPERTY RIGHT.**

**UNLESS EXPRESSLY APPROVED IN WRITING BY AN AUTHORIZED ST REPRESENTATIVE, ST PRODUCTS ARE NOT RECOMMENDED, AUTHORIZED OR WARRANTED FOR USE IN MILITARY, AIR CRAFT, SPACE, LIFE SAVING, OR LIFE SUSTAINING APPLICATIONS, NOR IN PRODUCTS OR SYSTEMS WHERE FAILURE OR MALFUNCTION MAY RESULT IN PERSONAL INJURY, DEATH, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE. ST PRODUCTS WHICH ARE NOT SPECIFIED AS "AUTOMOTIVE GRADE" MAY ONLY BE USED IN AUTOMOTIVE APPLICATIONS AT USER'S OWN RISK.**

Resale of ST products with provisions different from the statements and/or technical features set forth in this document shall immediately void any warranty granted by ST for the ST product or service described herein and shall not create or extend in any manner whatsoever, any liability of ST.

ST and the ST logo are trademarks or registered trademarks of ST in various countries.

Information in this document supersedes and replaces all information previously supplied.

The ST logo is a registered trademark of STMicroelectronics. All other names are the property of their respective owners.

© 2008 STMicroelectronics - All rights reserved

STMicroelectronics group of companies

Australia - Belgium - Brazil - Canada - China - Czech Republic - Finland - France - Germany - Hong Kong - India - Israel - Italy - Japan - Malaysia - Malta - Morocco - Singapore - Spain - Sweden - Switzerland - United Kingdom - United States of America

[www.st.com](http://www.st.com)